

取扱説明書 Instruction Manual

# クランプオンAC/DCハイテスタ CLAMP ON AC/DC HITESTER



Mar. 2019 Revised edition 19 3285A980-19 19-03H

3285



JA/FN

# 目 次

はじめに	1
点検	2
安全について	
ご使用にあたっての注意	6

第1章	重 製品	品概要	11
1.1	製品	の概要	11
1.2		の特長	
1.3	各部	の名称と機能	13
1.4	+-!	動作の流れ	
	1.4.1		
	1.4.2	電圧測定モード	
	1.4.3		
1.5	各モ	ードの説明	22
第2章		官方法	
2.1		準備	
2.2	電流	の測定	24
	2.2.1	直流電流(DC A)の測定	24
	2.2.2	交流電流(AC A)の測定	25
	2.2.3	交流+直流電流(AC+DC A)の測定・	26
	2.2.4	ピークホールド測定	
	2.2.5	出力機能	
2.3	電圧	の測定	32
	2.3.1	直流電圧 ( DC V ) の測定	32
	2.3.2	交流電圧 ( AC V ) の測定	33
	2.3.3	交流+直流電圧(AC+DC V)の測定 -	34
	2.3.4	ピークホールド測定	35

目次2

2.4 周波数測定36
2.4.1 電流モードでの周波数測定36
2.4.2 電圧モードでの周波数測定37
2.4.3 出力機能38
2.5 オートゼロ調整/ゼロキャンセル補正機能 39
2.5.1 オートゼロ調整機能39
2.5.2 ゼロキャンセル補正機能40
2.6 データホールド機能 HOLD40
2.7 表示更新の変更 40
2.7.1 SLOW モード41
2.7.2 FAST モード41
2.8 レコード機能 REC41
2.9 オートパワーオフ機能 APS44
2.10 電池消耗警告 🛛 🖪 44
2.11 ブザー音 44
第3章 仕様45
3.1 測定仕様 45
3.1.1 電流測定仕様45
3.1.2 電圧測定仕様48
3.2 一般仕様50
第4章 電池の交換方法53
第5章 AC アダプタ(別売)の使用 55
·····
第6章 ハンドストラップの付け方 57
第7章 故障とお考えになる前に 59
第8章 アフターサービス65

# はじめに

このたびは、HIOKI<sup>\*</sup>3285 クランプオン AC/DC ハイテスタ<sub>\*</sub> をご選定いただき、誠にありがとうございます。この製品を 十分にご活用いただき、末長くご使用いただくためにも、取 扱説明書は、ていねいに扱い、いつも手元に置いてご使用く ださい。

### お願い

本書の内容は、万全を期して作成しましたが、万一ご不明な 点や誤り、記載漏れなど、お気づきの点がありましたら、お 買上店(代理店)か最寄りの営業所にご連絡ください。

# 点検

本器がお手元に届きましたら、輸送中において異常または破 損がないか点検してからご使用ください。特に付属品および、 パネル面のスイッチ、キー、端子類に注意してください。万 一、破損あるいは仕様どおり動作しない場合は、お買上店(代 理店)か最寄りの営業所にご連絡ください。

#### 本体と付属品の確認

・本体

3285 クランプオン AC/DC ハイテスタ

# ・付属品

以下の標準付属品が添付されておりますので確認してくだ さい。

9345	携帯用ケース	1
L9207-10	テストリード(赤、黒)	1
ハンドストラップ		1
電池	6F22 (006P)	1
取扱説明書		1

オプション

L9094	出力コード
9445-02	AC アダプタ

# 安全について

この取扱説明書には本器を安全に操作し、安全な状態に保つ ために要する情報や注意事項が記載されています。本器をご 使用する前に下記の安全に関する事項をよくお読みください。

取扱説明書の注意事項には重要度に応じて以下の表記がされ ています。

⚠ 危険	操作や取り扱いを誤ると、使用者が死亡または重 傷につながる危険性が極めて高いことを意味しま す。
⚠ 警告	操作や取り扱いを誤ると、使用者が死亡または重 傷につながる可能性があることを意味します。
⚠ 注意	操作や取り扱いを誤ると、使用者が傷害を負う場 合、または機器を損傷する可能性があることを意 味します。

# 安全記号

Â	<ul> <li>・操作者は、機器上に表示されている▲マークの 所について、取扱説明書の▲マークの該当箇所 を参照し、機器の操作をしてください。</li> <li>・操作者は、この取扱説明書の中の▲マークのあ るところは必ず説明を読み注意する必要がある ことを示します。</li> </ul>
$\sim$	交流(AC)を示します。
	直流(DC)を示します。
2	直流(DC)と交流(AC)の両用を示します。
A	この端子には、危険な電圧がかかることを 示します。
	二重絶縁で保護されている機器を示します。
4	活線状態の電路に着脱できることを示します。

## f.s.(最大表示値、目盛長)

最大表示値または、目盛長を表します。一般的には、現在使 用中のレンジを表します。

### rdg. (読み値、表示値、指示値)

現在測定中の値、測定器が現在指示している値を表します。

dgt. (分解能)

ディジタル測定器における最小表示単位、つまり最小桁の"1" を表します。

# 測定カテゴリについて

本器は CATⅢに適合しています。

測定器を安全に使用するため、IEC61010では測定カテゴリ として、使用する場所により安全レベルの基準を CAT II ~ CATIVで分類しています。概要は下記のようになります。

- CAT II: コンセントに接続する電源コード付き機器(可搬形 工具・家庭用電気製品など)の一次側電路 コンセント差込口を直接測定する場合は CAT II で
  - す。
- CATIII:直接分電盤から電気を取り込む機器(固定設備)の 一次側および分電盤からコンセントまでの電路
- CATIV:建造物への引込み電路、引込み口から電力量メータ および一次側電流保護装置(分電盤)までの電路

カテゴリの数値の小さいクラスの測定器で、数値の大きいク ラスに該当する場所を測定すると重大な事故につながる恐れ がありますので、絶対に避けてください。

カテゴリのない測定器で、CAT II ~ CAT IVの測定カテゴリ を測定すると重大な事故につながる恐れがありますので、絶 対に避けてください。



6 A

# ご使用にあたっての注意

本器を安全にご使用いただくために、また機能を十二分にご 活用いただくために、下記の注意事項をお守りください。

 AC600 Vms を超える電路では使用しないでく ださい。600 Vを超えると感電事故や短絡事故 になります。
 クランプは、必ずプレーカの2次側に接続してく ださい。プレーカの2次側は、万一短絡があって も、プレーカにて保護します。1次側は、電流容 量が大きく、万一短絡事故が発生した場合、損傷 が大きくなるので、測定しないでください。
 AC アダプタは、指定の 9445-02 AC アダプタを 必ず使用してください。

	・本器をぬらしたり、ぬれた手で測定しないでく
	ださい。感電事故の原因になります。
	・活線で測定するので、感電事故を防ぐため、労働
	安全衛生規則に定められているように、電気用
	ゴム手袋、電気用ゴム長靴、安全帽等の絶縁保護
	具を着用してください。
⚠ 警告	・電流測定時には、テストリードを本体に接続し
	ないでください。
	・600 Vrms(1000 Vmax)を超える電圧を入力し
	ないでください。
	・感電事故を避けるため、クランプ部分を被測定
	物より外してから、ケースを開け、電池を交換し
	てください。また、交換後は、必ずバックケース
	をしてから、ネジ留め後使用してください。

	7
	$\bigwedge$
⚠警告	<ul> <li>・電池交換するときは極性+・に注意し、逆挿入しないでください。性能劣化や液漏れの原因になります。</li> <li>・使用済の電池をショート、分解または火中への投入はしないでください。破裂する恐れがあり危険です。</li> <li>・使用済の電池は地域で定められた規則に従って処分してください。</li> <li>・感電事故を防止するため、電源ラインの電圧を測定するときに使用するテストリードは、以下を満たすものをお使いください。</li> <li>・安全規格IEC61010またはEN61010に適合しているもの</li> <li>・測定カテゴリIIIまたはIV</li> <li>・定格電圧が測定する電圧よりも高いもの本器の付属のテストリードは、安全規格EN61010に適合しています。</li> <li>テストリードに表示した測定カテゴリと定格電圧に従って使用してください。</li> <li>・腐食性ガスや爆発性ガスが発生する場所では使用しないでください。本器の破損もしくは、爆発事故を誘発する可能性があります。</li> </ul>

•	ジョ	ーの先	端部に	異物な	どを挟	んだり、	物を	差
	し込	んだり	しないで	でくだ	さい。	センサ特	寺性の	悪
	化、	開閉動	作不具合	の原題	因にな	ります。		

- ・本器の損傷を避けるため、運搬および取り扱いの際は振動、衝撃を避けてください。特に、落下などによる衝撃に注意してください。また、ジョーに不要な力を加えたり、測定箇所に無理にこじ入れたりしないでください。
- ・使用前には、保存や輸送による故障がないか、点 検と動作確認をしてから使用してください。故 障を確認した場合は、お買上店(代理店)か最寄 りの営業所にご連絡ください。
- ・本器の損傷を避けるため、最大入力範囲を超える電流を入力しないでください。最大入力範囲は、測定電流の周波数によって異なります。(第)

▲ 注意

- 3章 仕様 図4参照 連続して高い周波数を入 力すると、ジョーが発熱しますので注意してく ださい。
- ・電池が消耗した状態(表示部の 🖪 点灯)で、使 用しないでください。必ず新しい電池と交換し てください。
- ・本器の調整や修理は、危険を良く知った技能者の責任で行ってください。
- ・内部メモリ保護のため、AC アダプタの抜差し は、電源を切った状態で行ってください。
- ・この機器は室内用に設計されています。安全性 を損なわないで0 ~40 の温度まで使用でき ます。
- ・直射日光や高温、多湿、結露するような環境下での保存や使用はしないでください。変形、絶縁劣 化を起こし、仕様を満足しなくなります。

・テストリードの先端金属ピンには、取り外し可 能なキャップが装着されています。 短絡事故を防ぐため、測定カテゴリ CAT で測
定するときは、必ずキャップをつけて使用して ください。CAT で測定するときに、ピンが被測 定部に届かない場合はキャップを外して使用し てください。 測定カテゴリについては、取扱説明書の「測定カ テゴリについて」(5ページ)を参照してください。 ・キャップを装着して測定する場合、キャップを 損傷しないように注意してください。測定中に 不用意にキャップが外れた場合などは、感電事 故を防ぐため取り扱いには十分注意してくださ い。 ・感電事故を防ぐため、ケーブル内部から白また は赤色部分(絶縁層)が露出していないか確認し ててください。ケーブル内部の色が露出してい る場合は、使用しないでください。

注記

- トランスや大電流路など強磁界の発生している近く、また無 線機など強電界の発生している近くでは、正確な測定ができ ない場合があります。
- 本器の汚れをとるときは、柔らかい布に水か中性洗剤を少量 含ませて、軽く拭いてください。ベンジン、アルコール、ア セトン、エーテル、ケトン、シンナー、ガソリン系を含む洗 剤は絶対に使用しないでください。変形、変色することがあ ります。
- 長い間使用しないときは、電池の液漏れによる腐食を防ぐために電池を抜いて保管してください。
- クランプオン AC/DC ハイテスタの電流検出部にはホール素 子を使用しています。ホール素子には経時的なドリフト、あ るいは周囲温度によるドリフトがありますので、連続測定時 には注意が必要です。
- ・ホール素子個々にバラツキがあり、経時や温度による変化量 を規定できません。連続測定時や温度変化の大きい使用環境 化においては、あらかじめ無入力でゼロ点の変化を掴んでお くことをお勧めします。なお、ゼロ点の変化は直流分です。
   ACモードにおいては影響ありません。
- ・ホール素子固有のオフセットのため、電源投入直後に表示が 0にならない場合がありますが故障ではありません。このカ ウント残りは0~数+A程度の個体差があります。
- ・DC モードまたは AC/DC モードでお使いいただく場合は、電 源投入ごとに必ず DADJ/RESET キーを押してオートゼロ調 整を行ってください。

ゼロ調整後に表示値が0となっていれば、電源投入直後のカ ウント残りの影響はなく測定いただけます。

# 第1章 製品概要

# 1.1 製品の概要

<sup>\*3285</sup>クランプオンAC/DCハイテスタ<sub>\*</sub>は、活線状態で直流、 交流、および、交流+直流電流を測定することができます。 ワンチップマイコンの採用により多機能化がはかれ、特にわ ずらわしいゼロ調整をワンタッチで行えます。 出力端子を持ち、またAC電源対応をしていますので、記録計 などの測定器に接続しての測定も可能です。

### 1.2 本器の特長

#### マイコン搭載による多機能化

マイコン搭載により機能も充実、小型、多機能で使い易くな りました。

# 真の実効値表示

真の実効値変換回路により、ひずみ波形の電流も正確に測定 できます。

#### AC+DC測定可能

交流に直流が重畳した波形や全波整流、半波整流などの測定 が可能です。

# ピーク測定可能

電流・電圧ともにピーク(波高値)ホールド測定ができます。 また、ピークの変動も見ることができます。

#### REC機能

測定値の最大値、最小値などを表示することができます。

#### 出力端子付

出力端子に記録計やオシロスコープを接続することにより、 簡単に電流記録および周波数記録が取れます。

電流(記録出力:REC,波形出力:MON)

周波数(記録出力:REC)

# 二電源方式

電池と AC 電源どちらでも使用できます。





製造番号ラベルは背面にあります。 製造番号は9桁の数字で構成されています。このうち、左から 2桁が製造年、次の2桁が製造月を表しています。 管理上必要です。はがさないでください。

# POWER +-

- ・電源の ON/OFF に使用します。
- オートパワーオフを使用しない場合はHOLDキーを押しながらPOWERキーを押します。

## 7+-

・電流測定およびモードの切り換えを行います。

# $\rightarrow$ DCA $\rightarrow$ ACA $\rightarrow$ AC+DCA -

# RANGE +-

- ・電流,電圧,周波数測定時にオートレンジ/マニュアルレンジを切り換えます。
- ・マニュアルレンジ時のレンジを切り換えます。
- ・キーを押した時に、バーグラフにレンジを示すカーソルが表示されます。
- 電流レンジは 200 A/2000 A、電圧レンジは 30 V/300 V/600
   V、周波数レンジは 10 Hz/100 Hz/1000 Hz です。

# HOLD +-

- ・表示更新の停止と解除を行います。
- ・電源投入時にHOLDキーを押しながらPOWERキーを押す と、オートパワーオフを解除します。

# OUTPUT +-

- ・電流測定時あるいは電流モードでの周波数測定時に、電圧の 出力ができます。
- ・オートパワーオフが解除されます。
- ・電流モードのとき、電池残量の確認ができます。

# SLOW/PEAK/Hz +-

- ・ **SLOW** は表示の更新を遅くします。(1回/3秒)
- ・FAST は表示の更新を速くします。(4回/秒) FAST 表示はなく、単位記号が点滅します。
- PEAK は波形のピーク(波高値)の測定を行います。(ピークホールド)
- ・Hz は電流モード、電圧モードでの周波数測定を行います。 (AC, AC+DC モードにて)

⊽+-

・電圧測定およびモードの切り換えを行います。

$$\rightarrow$$
 DCV  $\rightarrow$  ACV  $\rightarrow$  AC+DCV  $-$ 

# MAX/MIN +-

Г

- レコード (REC) 機能として、最大値 (MAX),最小値 (MIN), 最大値と最小値の平均値 (AVE)の表示ができます。
- MAX は REC 機能をスタートさせてからの測定最大値を表示 します。
- MINはREC機能をスタートさせてからの測定最小値を表示します。
- AVE は REC 機能をスタートさせてからの最大値と最小値の 平均値を表示します。
- ・オートパワーオフが解除されます。

# 0ADJ/RESET キー

- ・DC A, AC+DC A, DC V 時にオートゼロを行います。
- ・ピーク測定時にデータのリセットを行います。
- ・レコード(REC)機能動作時にデータのリセットを行います。
- ACA, AC+DCA, ACV, AC+DCV モード時、無入力で表示が 0にならない場合、[HOLD] キーを押した後に、0ADJ/RESET キーを押すとゼロキャンセル補正が行えます。

#### ジョー

電流測定をする際は、⑪レバーを握りジョーの先端を開き、 被測定導体が中央部になるようにしてジョーをしっかりと閉 じます。

**レバー** ジョーの開閉を行う際に握ります。

表示部(LCD)



Hz V

周波数	X
雷圧	

17
----

PEAK	ピーク値(波高値)
RMS	真の実効値
Α	電流
hour	1時間/1セグメント(バーグラフ)
min	1 分間/1 セグメント(バーグラフ)
•	入力オーバー(バーグラフ)

13出力端子

電流測定時あるいは電流モードでの周波数測定時に出力を取る場合、L9094 出力コード(別売オプション)を接続する端子です。

⑭AC アダプタ接続端子

電池を使用しない場合あるいは長時間測定を行う時に、 9445-02 ACアダプタ(別売オプション)を接続する端子です。

⑤電圧測定端子(V, COM 端子) 電圧測定の時に、L9207-10 テストリード(赤・黒、付属品) を接続する端子です。

16スライドツマミ

電圧測定端子を使用する時は上部へスライドさせ、出力端子 あるいは AC アダプタ接続端子を使用する時は下部へスライ ドさせます。カチッと音がするまでスライドしてください。

⑪バックケース

電池交換をする時に、ネジ2個を外します。

18ハンドストラップ

本体を落とさないようにしっかりと握る場合に取り付けます。



## バリア(障壁)

被測定導体を接触する際、テストリードの金属部側に触れる ことがないように、安全な接近限界を示しています。

キャップ

先ピンにキャップを装着して短絡事故を防止します。

⚠ 注意	<ul> <li>・測定カテゴリCAT で測定するときは、必ずキャップをつけて使用してください。CAT で測定するときに、ピンが被測定部に届かない場合はキャップを外して使用してください。</li> <li>・キャップを装着して測定する場合、キャップを 損傷しないように注意してください。測定中に 不用意にキャップが外れた場合などは、感電事故を防ぐため取り扱いには十分注意してください。</li> <li>・金属ピンの先端は尖っていますので、けがに注意してください。</li> </ul>
------	---

キャップの脱着方法

**キャップを取り外す** キャップの根元を軽くつまんで、引き 抜いてください。 取り外したキャップは、無くさないよ うに保管してください

キャップを装着する キャップの穴にテストリードの金属 ピンを通して、奥まで確実に押し込ん でください。

# 18



FAST, NORMAL の表示は表示部にありません。



FAST, NORMALの表示は表示部にありません。



21

+-

# 1.5 各モードの説明

電流,電圧には DC:直流 (━━)、AC:交流 (~)、AC+DC:交流+ 直流 (━━)のモードがあります。下記に示す波形に合ったモ ードを選択してください。

モード	入力波形	表示	OUTPUT (電流のみ)		
- F		衣小	REC	MON	
DC (===)	0	○平均値表示 (極性表示あり)		0	
	₀╋	×測定不可	無効	₀₩₩	
	$M_{\circ}$	×測定不可		$M_{\circ}$	
AC ( <b>X</b> )	0	×測定不可 (0 表示)	0 V	0 V	
	₀╋	○実効値表示	<u>م</u>	₀╇┯┯	
	$M_{\circ}$	×測定不可	, 	∘₩₩	
AC+DC ( <b>RC</b> )	0	○実効値表示 (極性表示なし)	0	0	
	₀╋	○実効値表示		₀₩₩	
	$M_{\circ}$	○実効値表示	0	$M_{\circ}$	

# 第2章 測定方法

#### 2.1 測定準備

- 1. バックケースを外し、電池を入れてください。(第4章 電 池の交換方法 参照)

ブザーが3回鳴ります

3. 直流電流の測定状態になります。

#### 電池電圧低下検出機能

■が点灯後、電池の電圧が低下した場合は、強制的に電源を OFFにします。この時、<sup>\*</sup>bAtt、<sup>\*</sup>Lo、の表示がされます。 この表示が出て電源がOFFになった場合は、新しい電池と交換してください。

#### 2.2 電流の測定

#### 注記

- トランスや大電流電路など強磁界の発生している近く、また 無線機など強電界の発生している近くでは、正確な測定がで きない場合があります。
- ・導体は必ず1本だけセンサ中央部にクランプしてください。
   単相(2本),3相(3本)を同時にクランプした場合は測定できません。



- ・無入力時に、外部磁界の影響で表示が大きく出る場合があり ますが、測定時の影響量は2A以下です。
- 2.2.1 直流電流 (DCA)の測定
  - 1. 〒キーを押して、… を表示させます。
  - 被測定電流に合わせてオートレンジ/マニュアルレンジを 切り換えてください。

3. 測定前に必ずオートゼロ調整を行ってください。被測定導体をクランプせずに、ジョーが完全に閉じた状態で、 OADJ/RESETキーを押してオートゼロ調整を行います。 (2.5.1 オートゼロ調整機能参照) オートゼロ調整が終わると ADJ マークが点灯します。(オ ートレンジの場合は2つのレンジについてオートゼロ調整 を行います。) ゼロ調整後に表示値が0となっていれば、電源投入直後の カウント残りの影響はなく測定いただけます。

- ジョーの先端を開き、クランプ部に表示してある電流方向 表示マークと被測定導体の電流方向を一致させて、被測定 導体がほぼ中央部になるようにクランプしてください。
- 第2章 測定方法



#### 注記

- ・DCA モードでは、交流分を含まない直流電流のみ正確な測定 が行えます。(1.5 各モードの説明 参照)
- ・ 200 A レンジでは、最大 250 A まで表示しますが確度保証範囲は 10 A~200 A までです。
- ・各レンジとも、レンジの1%(確度保証外)以下では内部補正 演算により、大きな誤差となる可能性があります。
- ・電源投入時に値がゼロにならない場合がありますが、不具合ではありません。測定前に必ずオートゼロ調整を実行してください。
- 2.2.2 交流電流(ACA)の測定
  - 1. 〒キーを押して、~を表示させます。
  - 必要に応じてオートレンジ/マニュアルレンジを切り換えてください。
  - 3. ジョーの先端を開き、被測定導体がほぼ中央部になるよう にクランプしてください。

注記

- 入力がなくなった直後や無入力でのモード切換えにより、しばらく表示が0にならない場合がありますが(約10秒程度)、内部回路の都合によるもので、異常ではありません。0にならないうちに測定しても、測定値に影響はありません。
- ・測定環境温度により、無入力でも表示が0にならない場合が ありますので、ゼロキャンセル補正を行ってください。(2.5.2 ゼロキャンセル補正機能参照)

- ・測定の応答速度は、フルスケール(f.s.)入力時に、立上り(0%→90%)は約 250 ms、立下り(100%→10%)は約 500 ms です。(2.2.5 の図 1, 2 参照)
- ・ACAモードでは、直流,全波整流,半波整流波形,および直流+ 交流波形の測定は行えません。(1.5 各モードの説明 参照)
- 200 A レンジでは、最大 250 A まで表示しますが、確度保証
   範囲は 10 A~200 A までです。
- ・各レンジとも、レンジの1%(確度保証外)以下では内部補正 演算により、大きな誤差となる可能性があります。
- 2.2.3 交流+直流電流(AC+DCA)の測定
  - 1. アキーを押して、元を表示させます。
  - 必要に応じてオートレンジ/マニュアルレンジを切り換え てください。
  - 測定前に必ずオートゼロ調整を行ってください。被測定導体をクランプせずに、ジョーが完全に閉じた状態で、 OADJ/RESET キーを押してオートゼロ調整を行います。
     (2.5.1 オートゼロ調整機能参照)

オートゼロ調整が終わるとADJマークが点灯します。(オ ートレンジの場合は2つのレンジについてオートゼロ調整 を行います。)

ゼロ調整後に表示値が0となっていれば、電源投入直後の カウント残りの影響はなく測定いただけます。

- 表示が0にならない場合は、HOLD キーを押した後、 OADJ/RESET キーを押してゼロキャンセル補正を行って ください。
- 5. ジョーの先端を開き、被測定導体がほぼ中央部になるよう にクランプしてください。

注記

- 入力がなくなった直後や無入力でのモード切換えにより、しばらく表示が0にならない場合がありますが(約10秒程度)、内部回路の都合によるもので、異常ではありません。0にならないうちに測定しても、測定値に影響はありません。
- ・測定環境温度により、無入力でも表示が0にならない場合が ありますので、ゼロキャンセル補正を行ってください。(2.5.2 ゼロキャンセル補正機能参照)

- ・DC 測定を行った場合、極性は表示されません。また、ジョー の向きを変えると値が変わる場合がありますが、いずれも確 度範囲内です。(被測定電路が直流成分のみの場合は、DCA モードで測定することをお勧めします。)
- ・測定の応答速度は、フルスケール(f.s.)入力時に、立上り (0%→90%)は約 250 ms、立下り(100%→10%)は約 500 msです。(2.2.5の図1,2参照)
- 200 A レンジでは、最大 250 A まで表示しますが、確度保証
   範囲は 10 A~200 A までです。
- ・各レンジとも、レンジの1%(確度保証外)以下では内部補正 演算により、大きな誤差となる可能性があります。
- ・オートゼロ調整後に周波数出力をした場合、電流測定は、オートゼロ調整が無効になります。周波数出力を解除(OFF) すると、オートゼロ調整が有効な電流測定を行います。
- ・電源投入時に値がゼロにならない場合がありますが、不具合ではありません。測定前に必ずオートゼロ調整を実行してください。
- 2.2.4 ピークホールド測定
  - 1. ★キーを押して、測定電路に応じて測定モードを選択しま す。
  - DCA, AC+DCA モードの場合は OADJ/RESET キーにより オートゼロ調整を行ってください。(2.5.1 オートゼロ調整 機能 参照)
  - 3. SLOW/PEAK/Hz]キーを押すと以下のように表示が切り 換りますのでPEAK に設定してください。

L→ SLOW →→ FAST→→ PEAK →→ Hz →→ NORMAL→ (単位記号点滅) (DC 除く)

- 必要に応じてオートレンジ/マニュアルレンジを切り換えてください。(ピーク電流値の予測が付かない場合は 2000 A レンジに固定してください。)
- 5. 測定前に DADJ/RESET キーを押してデータをリセットし てください。
- ジョーの先端を開き、被測定導体がほぼ中央部になるよう にクランプしてください。

#### 注記

- ・ピーク測定を行った場合、極性は表示されません。また、ジョーの向きを変えると値が変わる場合がありますが、いずれも確度範囲内です。
- 約1ms以上の幅を持つパルスからとらえることができます。
- クランプ後にも、必要に応じて OADJ/RESET キーを押してデ ータをリセットしてください。
- ・ピーク測定モードで、無入力時に OADJ/RESET キーを押して データをリセットしても表示が0にならない場合は、ジョー の帯磁が考えられますので、一度ピークモードから抜けて、 OADJ/RESET キーによりオートゼロ調整を行ってから、再度 設定してください。(OADJ/RESET キーを押しても、数カウ ント数字が残る場合もあります)
- ・ホールド値は大きな値が入らない限り変化しませんが、オートパワーオフでデータが消えてしまわないように注意してください。(2.9 オートパワーオフ機能 参照)
- ・オートパワーオフ時間を超える測定には、REC 機能を使用し てください。
- ・ピーク測定値は出力できません。ピーク測定モードで **OUTPUT**キーを押した場合は、現在の測定値を出力します。
- ・ピーク値の変動を見る場合は、「MAX/MIN」キーを押して、瞬時値(表示なし)にしてください。

2.2.5 出力機能

電流レンジのフルスケール「2000」カウントに対して AC/DC1Vの出力が得られます。

REC(記録出力)とMON(波形出力)が選択できます。

- (DCA モードでは MON のみ、1.5 各モードの説明 参照)
- 1. **RANGE** キーを押して電流レンジを固定してください。
- OUTPUT キーを押すと REC または MON マークが点灯 し、出力が有効になりオートパワーオフは自動的に無効に なります。(APS 消灯)

3. **OUTPUT** キーを押すと、出力を切り換えることができます。

- L→ REC(記録出力)→ MON(波形出力)→ 消灯 ― (オートパワーオフ無効) (オートパワーオフ無効) (オートパワーオフ有効)
- 本器の測定レンジと記録計などの測定器のレンジの双方から設定レンジを決めてください。換算表を示します。

測定器レンジ /DIV	10 mV	20 mV	50 mV	0.1 V	0.2 V	0.5 V	1 V
2000Aレンジ*	20 A	40 A	100 A	200 A	400 A	1000A	2000A
200 Aレンシ*	2 A	4 A	10 A	20 A	40 A	100 A	200 A

数値は記録計など測定器の 1DIV 当たりの電流値

▲ 警告 出力端子を短絡したり、電圧を加えると故障の原 因になりますので注意してください。

注記

- ・出力機能を使うときは、必ず OUTPUT キーを押して REC または MON マークが点灯していることを確認してください。 REC、MON が消灯している状態でも出力していますが、 オートパワーオフが有効になっていますので、約10分後に電源が OFF になってしまいます。また、DCA モードで MON マ ークが消灯している場合は、マイナスの電流値でもプラス側 に出力されますので特にご注意ください。
- ・オートレンジ (AUTO) のまま OUTPUT キーを押した場合 は、押したときの電流レンジに固定されます。(AUTO 消灯)
- ・DCA モードでオートゼロ調整を行わないと、出力値に誤差が 生じます。
- ・ゼロキャンセル補正機能は、出力には無効ですので、測定環
   境温度で無入力時に、電圧を出力してしまうことがあります。
- ・
   REC 出力はアナログ出力です。f.s.入力時の出力応答時間は立上がり(0%→90%約250ms)と立下がり(100%→10%約500ms)で違いがあります。(図2,3参照)また、測定値がレンジに対して小さいほど応答時間が長くなります。
- ・電流測定出力を取りながら表示更新の変更, ピーク測定, 周 波数測定, レコード機能, データホールド機能の使用も可能 です。(モードの変更, レンジの変更, 電圧測定モードへの変 更, オートゼロ調整機能は出力が変動してしまいます。)

- 記録計との接続は、L9094 出力コード(別売)を使用してく ださい。
- 記録計の入力インピーダンスは1MΩ以上のものを使用してく ださい。インピーダンスが低いと表示値にも影響を与えます。
- ・周波数測定記録を取りながら☆キーを押した場合には、出力 は周波数記録になっています。電流出力を取る場合は、
   ○UTPUT キーを押して一旦解除してから再設定する必要が あります。
- ・長時間の記録には、9445-02 AC アダプタ (別売)を使用して ください。
- AC アダプタを使用した場合、商用電源におおきなノイズが 含まれていると、数カウントの表示が出たり、出力にノイズ が乗る場合があります。このときは、記録計の接地端子ある いは記録計側のL端子をアースに接続してください。

GAIN [dB]









#### 2.3 電圧の測定

- 2.3.1 直流電圧(DCV)の測定
  - 1. マキーを押して、…を表示させます。
  - 2. スライドツマミを使用してスライドカバーを開いてから、 赤色テストリードを電圧測定端子の V に、黒色テストリー ドを電圧測定端子の COM に差し込んでください。
  - 必要に応じてオートレンジ/マニュアルレンジを切り換え てください。
  - 表示が0になっていない場合は使用するレンジに切り替えて(マニュアルレンジ)、OADJ/RESET キーを押してオートゼロ調整を行います。ゼロ調整が終わるとADJマークが 点灯します。(2.5.1 オートゼロ調整機能参照)
  - 5. 測定カテゴリに応じてキャップを着脱してください。
  - 十分に気を付けて、テストリードをそれぞれ電路へ接触させてください。

#### 注記

- ・測定カテゴリCATⅢで測定するときは、必ずキャップをつけ て使用してください。CATⅡで測定するときに、ピンが被測 定部に届かない場合はキャップを外して使用してください。
- ・オートゼロ調整範囲は、レンジの4%までです。
- オートゼロ調整を行ったレンジから他のレンジに変更すると、 調整値がずれてしまい正確な測定ができません。変更後は必ずオートゼロ調整を行ってください。(オートレンジではオートゼロ調整を行わないでください。)
- "マークが点灯した場合は、黒色テストリード側の電位が 赤色テストリード側の電位より高くなっていることを示します。
- ・DCV モードでは、交流分を含まない直流電圧のみ正確な測定 が行えます。(1.5 各モードの説明 参照)
- ・各レンジで最大 125%まで表示しますが、確度保証は 10%~ 100%までです。
- ・各レンジとも、レンジの1%(確度保証外)以下では内部補正 演算により、大きな誤差となる可能性があります。
# 2.3.2 交流電圧(ACV)の測定

- 1. 〒キーを押して、~を表示させます。
- スライドツマミを使用してスライドカバーを開いてから、 赤色テストリードを電圧測定端子のVに、黒色テストリー ドを電圧測定端子のCOMに差し込んでください。
- 必要に応じてオートレンジ/マニュアルレンジを切り換え てください。
- 4. 測定カテゴリに応じてキャップを着脱してください。
- 十分に気を付けて、テストリードをそれぞれ電路へ接触させてください。

注記

- ・測定カテゴリCATⅢで測定するときは、必ずキャップをつけ て使用してください。CATⅡで測定するときに、ピンが被測 定部に届かない場合はキャップを外して使用してください。
- 入力がなくなった直後や無入力でのモード切換えにより、しばらく表示が0にならない場合がありますが(約10秒程度)、内部回路の都合によるもので、異常ではありません。0にならないうちに測定しても、測定値に影響はありません。
- ・測定環境温度により無入力で表示が0にならない場合は、
   [HOLD] キーを押した後に (DADJ/RESET) キーを押してゼロ キャンセル補正を行ってください。(2.5.2 ゼロキャンセル補 正機能 参照)
- ・測定の応答速度は、フルスケール(f.s.)入力時に、立上り (0%→90%)は約 250 ms、立下り(100%→10%)は約 500 msです。(2.2.5の図1,2参照)
- ・ACV モードでは直流, 全波整流, 半波整流波形, および直流+ 交流波形の測定は行えません。(1.5 各モードの説明 参照)
- ・各レンジで最大 125%まで表示しますが、確度保証は 10%~ 100%までです。
- ・各レンジとも、レンジの1%(確度保証外)以下では内部補正 演算により、大きな誤差となる可能性があります。

- 2.3.3 交流+直流電圧(AC+DC V)の測定
  - 1. ▼キーを押して、 定を表示させます。
  - スライドツマミを使用してスライドカバーを開いてから、 赤色テストリードを電圧測定端子のVに、黒色テストリー ドを電圧測定端子のCOMに差し込んでください。
  - 必要に応じてオートレンジ/マニュアルレンジを切り換えてください。
  - 表示が安定しても表示が0にならない場合は使用するレンジに切り替えて(マニュアルレンジ)、HOLD キーを押した後に 0ADJ/RESET キーを押してゼロキャンセル補正を行ってください。(2.5.2 ゼロキャンセル補正機能参照)
  - 5. 測定カテゴリに応じてキャップを着脱してください。
  - 十分に気を付けて、テストリードをそれぞれ電路へ接触させてください。

注記

- ・測定カテゴリCATⅢで測定するときは、必ずキャップをつけて使用してください。CATⅡで測定するときに、ピンが被測定部に届かない場合はキャップを外して使用してください。
- ・ゼロキャンセル補正を行ったレンジから他のレンジに変更すると、補正値がずれてしまい正確な測定ができません。(オートレンジではゼロキャンセル補正を行わないでください。)オートレンジで行ってしまった場合は、一度電源を切り再び電源を入れてから、再度ゼロキャンセル補正を行ってください。
- 入力がなくなった直後や無入力でのモード切換えにより、しばらく表示が0にならない場合がありますが(約10秒程度)、内部回路の都合によるもので、異常ではありません。0にならないうちに測定しても、測定値に影響はありません。
- DC 測定を行った場合、極性は表示されません。また、テストリードの接続を変えると値が変わる場合がありますが、いずれも確度範囲内です。(被測定電路が直流成分のみの場合は DCV モードで測定することをお勧めします。)
- ・測定の応答速度は、フルスケール(f.s.)入力時に、立上り(0%→90%)は約 250 ms、立下り(100%→10%)は約 500 ms です。(2.2.5 の図 1, 2 参照)
- ・各レンジで最大 125%まで表示しますが、確度保証は 10%~ 100%までです。
- ・各レンジとも、レンジの1% (確度保証外)以下では内部補正 演算により、大きな誤差となる可能性があります。

2.3.4 ピークホールド測定

- 1. ▼キーを押して、測定電路に応じて測定モードを選択しま す。
- スライドツマミを使用してスライドカバーを開いてから、 赤色テストリードを電圧測定端子のVに、黒色テストリー ドを電圧測定端子のCOMに差し込んでください。
- 3. **SLOW/PEAK/Hz** キーを押すと以下のように表示が切り 換わりますので **PEAK** に設定してください。

→ SLOW —→ FAST—→ PEAK —→ Hz →→ NORMAL – (単位記号点滅) (DC 除く)

- 必要に応じてオートレンジ/マニュアルレンジを切り換え てください。(ピーク電圧値の予測が付かない場合は 600 Vレンジに固定してください。)
- 5. 測定カテゴリに応じてキャップを着脱してください。
- 十分に気を付けて、テストリードをそれぞれ電路へ接触させてください。
- 7. 測定前に 0ADJ/RESET キーを押してデータをリセットし てください。

注記

- ・測定カテゴリCATⅢで測定するときは、必ずキャップをつけ て使用してください。CATⅡで測定するときに、ピンが被測 定部に届かない場合はキャップを外して使用してください。
- ・ピーク測定を行った場合、極性は表示されません。また、テストリードの接続を変えると値が変わる場合がありますが、いずれも確度範囲内です。
- 約 1ms 以上の幅を持つパルスからとらえることができます。
- ・ピーク値の変動を見る場合は MAX/MIN キーを押して、瞬時 値(表示なし)にしてください。
- ・ピーク測定モードではゼロ調整は無効です。

## 2.4 周波数測定

- 2.4.1 電流モードでの周波数測定
  - 1. **☆**キーを押して、被測定電路に合わせ AC あるいは AC+DC の位置にします。
  - 被測定電路の電流値がわかっている場合は電流のレンジを マニュアルレンジに固定してください。(電流値が不明の 場合、測定してからレンジを固定してください。)
  - SLOW/PEAK/Hz キーを押すと以下のように表示が切り 換わりますのでHz に設定してください。(単位記号のAが 点滅します。バーグラフには電流値が表示されます。)

# └→ SLOW ----→ FAST----→ PEAK ----→ Hz---→ RMS---(単位記号点滅)

- 必要に応じてオートレンジ/マニュアルレンジを切り換えてください。
- 5. ジョーの先端を開き、被測定導体がほぼ中央部になるよう にクランプしてください。

注記

- ・100 Hz、1000 Hz レンジでは、10 Hz 未満の入力では表示が
   ----になります。
- ・1 Hz 未満は表示が----になります。
- ・1 kHz 以上は O.L.表示となります。
- 入力値がレンジ値に対して小さい場合は、表示が----や O.L.表示あるいは表示のふらつきなど、正確な測定ができない場合があります。
- 10 Hz レンジまたは 100 Hz レンジでは、最大 125%まで表示しますが、確度保証は 10%~100%までです。
- ・ MAX/MIN キーを押しても出力値に影響はありません。
- ・
   インバータのように特殊波形の電路の周波数に対しては、簡 易配慮がなされていますが、測定できない場合もあります。
   (キャリア周波数が数 kHz と低い場合など)
- ・全波整流の場合、内部回路で AC 結合していますので 2 倍の 周波数を表示します。
- ・周波数レンジあるいは入力周波数によっては、測定周波数表示が安定するまでに時間を要する場合があります。

- 2.4.2 電圧モードでの周波数測定
  - 1. 〒キーを押して、被測定電路に合わせ AC あるいは AC+DC の位置にします。
  - 被測定電路の電圧値がわかっている場合は、電圧のレンジ をマニュアルレンジに固定してください。(電圧値が不明 の場合、測定してからレンジを固定してください。)
  - スライドツマミを使用してスライドカバーを開いてから、 赤色テストリードを電圧測定端子のVに、黒色テストリー ドを電圧測定端子のCOMに差し込んでください。
  - SLOW/PEAK/Hz] キーを押すと以下のように表示が切り 換わりますのでHz に設定してください。(単位記号のVが 点滅します。バーグラフに電圧値が表示されます。)

# L→ SLOW →→ FAST→→ PEAK →→ Hz→→ NORMAL→ (単位記号点滅)

- 必要に応じてオートレンジ/マニュアルレンジを切り換えてください。
- 6. 測定カテゴリに応じてキャップを着脱してください。
- 十分に気を付けて、テストリードをそれぞれ電路へ接触させてください。

注記

- ・測定カテゴリCATⅢで測定するときは、必ずキャップをつけて使用してください。CATⅡで測定するときに、ピンが被測定部に届かない場合はキャップを外して使用してください。
- ・100 Hz、1000 Hz レンジでは、10 Hz 未満の入力では表示が
   ----になります。
- ・1 Hz 未満は表示が----になります。
- ・1 kHz 以上は O.L.表示となります。
- 入力値がレンジ値に対して小さい場合は表示が----やO.L.表示あるいは表示のふらつきなど、正確な測定ができない場合があります。
- 10 Hz レンジまたは 100 Hz レンジでは、最大 125%まで表示 しますが、確度保証は 10%~100%までです。
- インバータのように特殊波形の電路の周波数に対しては、簡易配慮がなされていますが、測定できない場合もあります。
   (キャリア周波数が数 kHz と低い場合など)

- ・全波整流の場合、内部回路で AC 結合していますので 2 倍の 周波数を表示します。
- ・周波数レンジあるいは入力周波数によっては、測定周波数表示が安定するまでに時間を要する場合があります。
- 2.4.3 出力機能

周波数測定出力は、電流測定モードでのみ可能です。 周波数レンジのフルスケール「1000」カウントに対して DC1Vの出力が得られます。出力は表示更新と同じ2回/秒に なります。(D/A 出力のため急激な周波数変動の場合は出力 波形は階段状になります。)

- 1. 電流モードでの周波数測定を参照して設定を行ってください。
- 2. **OUTPUT** キーを押すと **REC** マークが点灯し、出力が有 効になります。
- 3. オートパワーオフは自動的に無効になります。(APS 消灯)
- 本器の測定レンジと記録計などの測定器のレンジの双方から設定レンジを決めてください。

測定器レンジ /DIV	10 mV	20 mV	50 mV	0.1 V	0.2 V	0.5 V	1 V
1000 Hzレンジ	10 Hz	20 Hz	50 Hz	100 Hz	200 Hz	500 Hz	1000 Hz
100 Hzレンジ	1 Hz	2 Hz	5 Hz	10 Hz	20 Hz	50 Hz	100 Hz
10 Hzレンジ	0.1 Hz	0.2 Hz	0.5 Hz	1 Hz	2 Hz	5 Hz	10 Hz

注記

数値は記録計など測定器の 1DIV 当たりの周波数値

- ・出力機能を使うときは、必ず OUTPUT キーを押して REC マークが点灯していることを確認してください。REC が消 灯している状態での出力は、電流値の出力になっています。
- ・AC+DCA モードでは、オート<u>ゼロ調整は</u>無効です。
- ・オートレンジ(AUTO)のまま OUTPUT キーを押した場合は、 押したときの周波数レンジに固定されます。(AUTO 消灯)
- ・HOLD キーを押すと、出力値もホールドされます。
- ----表示の場合は0V、O.L.表示の場合は、1.36V程度出力します。
- ・記録計との接続は、19094 出力コード(別売)を使用してく ださい。
- 記録計の入力インピーダンスは1M
   以上のものを使用してください。

- ・長時間の記録には、9445-02 AC アダプタ(別売)を使用して ください。
- ・ACアダプタを使用した場合、商用電源におおきなノイズが 含まれていると、数カウントの表示が出たり、出力にノイズ が乗る場合があります。このときは、記録計の接地端子ある いは記録計側のL端子をアースに接続してください。
- ・電流測定記録を取りながら周波数測定モードに入った場合に
   は、出力は電流記録になっています。周波数出力を取る場合 は、「OUTPUT」キーを押して一日電流出力を解除してから再 設定してください。

#### 25 オートゼロ調整/ゼロキャンセル補正機能

# 251 オートゼロ調整機能

- DC A, AC+DC A, DC V モードで測定する際に、ジョーの帯 磁分や温度特性による内部回路のオフセット分を自動で調整 する機能です。直流の大電流を測定したり、強力な磁力を近 づけた場合、コアの帯磁があります。
  - 1. 無入力状態で表示が安定したのを確認してから OADJ/RESET キーを押してください。 ADJ マークが点灯します。

注記

- ・電流モードでの調整範囲は、±45 A までです。。
- 入力している状態や表示値が減少している過程で行うと正常な オートゼロ調整ができなくなり測定に影響が出ます。再度、無 入力であることを確認して表示が安定してから行ってください。
- ・AC+DC A モードでは表示が安定するのに時間がかかります。 (20 秒程度)
- ・AC+DCA モードで正常にオートゼロ調整が行われたにもか かわらず表示が0にならない場合はゼロキャンセル補正機能 を使用してください。
- ・オートゼロ調整中に、再度 0ADJ/RESET キーを押すと、オー トゼロ調整が無効になります。
- ・DC V モードではオートレンジでオートゼロ調整を行わない でください。必ず使用するレンジ (マニュアルレンジ) にし てから行ってください。

39

- 2.5.2 ゼロキャンセル補正機能
  - ACA, AC+DCA, ACV, AC+DCV モードで無入力にもかかわ らず表示が0にならない場合に使用できる機能です。
  - 1. **HOLD** キーを押してください。**HOLD** マークが表示され ます。
  - 2. **OADJ/RESET**キーを押してください。ADJマークが点滅します。 注記
    - オートレンジではゼロキャンセル補正は行わないでください。
       必ず使用するレンジ(マニュアルレンジ)にしてから行ってください。
    - 入力があったり表示値が減少している過程で行うと、測定値 が正常より低くなり、測定値に影響が出ます。
    - ・表示が 0 の時には HOLD キーを押した後の 0ADJ/RESET キーは効きません。
    - ・AC+DCAモードのとき、先にオートゼロ調整が終わっていない と「HOLD」キーを押した後の「DADU/RESET」キーは効きません。
    - ゼロキャンセル補正機能は、表示のみに機能するため、出力 値の補正は行っていません。

# 2.6 データホールド機能 **HOLD**

表示を止めて読み取りたいときに使用します。

 HOLD キーを押してください。HOLD マークが表示され ディジタル表示とバーグラフ表示を保持します。 データホールド機能はすべての測定で使用できます。 データホールド機能を解除するには、もう一度 HOLD キ ーを押してください。ホールド中に RANGE キーを押す と、バーグラフに現在のレンジを表示します。

# 2.7 表示更新の変更

起動時のディジタル表示更新は約2回/秒です。測定状況に応 じて、表示更新を変更することができます。 [SLOW/PEAK/Hz] キーを押すと以下のように表示が切り換 わります。

L→SLOW —→ FAST →→ PEAK →→ Hz →→ NORMAL → (単位記号点滅) (DC 除く)

- 2.7.1 SLOW モード 電流測定時,電圧測定時に表示値が変動して読みにくい場合、 表示更新を遅くして(約1回/3秒)読み取りやすくすることが できます。
- 2.7.2 FASTモード
  - ・電流測定時,電圧測定時にディジタル表示更新を約4回/秒に します。起動電流の測定など応用範囲が広がります。
  - ▲あるいは∨という単位記号が点滅します。
  - ・起動電流測定の際はレコード機能(REC)を使って最大値 (MAX)を保持すると読み取りに便利です。
- レコード機能 REC
   レコード機能を使うと、測定値の最大,最小,最大と最小の
   平均を保持します。
  - 1.測定表示値

電流または電圧を測定している時に MAX/MIN キーを押す とレコード機能が動作します。REC が点滅し、MAX/MIN キ ーが押された時点からの最大値 (MAX)・最小値 (MIN)・平 均値 (AVE)を本機の内部メモリに保持します。レコード機 能が動作している状態で、MAX/MIN キーを押すと、下記の ように表示が切り換わります。MAX, MIN, AVE の表示がな い場合は瞬時値を表示しています。

## →MAX MIN AVE 瞬時値→」 (表示なし)

表示を切り換えている間、データ (MAX, MIN, AVE) は保持 されますが、最大,最小のデータ更新があった場合、データ 値は変化します。

レコード機能動作中はオートパワーオフは解除されます。 (APS 消灯)

平均値(AVE)は、平均値=((最大値+最小値)/2)で計算 した値を表示します。

SLOW / PEAK / Hz キーにより、PEAK モードにした後に レコード機能を動作させて,瞬時値(表示なし)にするとピ ークの変動を見ることができます。

2.経過時間の表示

**MAX/MIN** キーを押してレコード機能を動作させると、バー グラフのセグメントが点滅して、経過時間が表示されます。 バーグラフの右隅に min が表示されているときは、バーグラ フの1セグメントが1分間を表します。

1 分経過するごとにバーグラフが左から1 セグメントずつ点 滅から点灯に変わります。バーグラフがすべて点灯したとき は経過時間が 30 分です。経過時間が 30 分以上になると、1 分経過するごとにバーグラフが左から1 セグメントずつ点滅 から消灯に変わります。

点滅セグメントの左側が点灯しているとき: 点灯しているセグメントの数が経過時間(0~29) 図は 20 分経過したことを表しています。

点滅セグメントの右側が点灯してるとき: 消灯してるセグメントの数(+30)が経過時間(30~59) 図は 50 分経過したことを表しています。

> 0 1 2 3 I....I...I...I...I...I.min

[MAX/MIN] キーを押してディジタル表示が平均値 (AVE) か ら瞬時値に切り換わるときに、バーグラフの右隅が hour にな ります。このときは、バーグラフの1 セグメントが1 時間を 表します。バーグラフの読み方は min と同じで、バーグラフ がすべて点灯したときは経過時間が 29 時間です。 図は1時間 40 分経過したことを表しています。

3.レコード機能の停止

HOLD キーを押すと、レコード機能が停止します。HOLD が 点灯し、REC が点滅から点灯に変わり、経過時間も停止しま す。レコード機能が停止している間は、導体からジョーをは ずしてもデータは更新されません。

**HOLD** キーをもう一度押すと、**HOLD** が消えレコード機能 が再開し、REC も点滅します。

- 4.レコード機能のリセット レコード機能動作中にデータをリセットする場合は、 DADJ/RESET キーを押してください。
- 5. レコード機能の解除 レコード機能を解除するには、電流測定中では **☆** キーを、電 圧測定中では **☆** キーを押してください。 レコード機能を解除すると、オートパワーオフ機能が有効に なります。(APS) 点灯)

注記

- ・測定時間が長くなる場合は、9445-02 AC アダプタ(別売)を 使用するか、電流モードで **OUTPUT** キーを押してバーグラ フにて電池残量を確認してから測定を開始することをお勧め します。
- オートレンジでレコード機能を開始したときは、MAX/MIN キーを押したときのレンジに固定されます。
- ・最小値データ、平均値データが必要な場合は測定中にレコード機能を開始するようにしてください。無入力時に開始すると最小値は常にゼロのままになってしまいます。また、レコード機能を終了する場合は、[HOLD]キーを押し最小値データ、平均値データを読み取ってから測定を終了してください。レコード機能を終了しないまま、被測定電路からクランプをはずしたりテストリードをはずすと最小値はゼロになってしまいます。
- ・電源をオフにするとデータは消えてしまいます。

- 2.9 オートパワーオフ機能 APS
  - APS が表示されているときは、オートパワーオフ機能が有効 です。
  - ・何もキーが押されないと約10分後に電源がオフになります。
  - ・オフする直前に APS が点滅しブザー音で警告します。(約 30 秒間)
  - ・ POWER キー以外のキーを押すと 10 分間延長できます。
    - オートパワーオフ機能を無効にする方法
    - HOLD キーを押しながら POWER キーを押して電源を入れる。
    - MAX/MIN キーを押して、レコード(REC)機能を使う。
       電流モードで OUTPUT キーを押す。

## 2.10 電池消耗警告 🖪

- ・電池が消耗しています。製品の確度保証ができませんので、 新しい電池に交換してください。
- ・電池残量のチェックは、電源投入直後および電流モードで
   〇UTPUT キーを押したときにバーグラフで確認することができます。ただし、残量は目安程度ですので出力を長時間取ったり REC 機能を使用する場合は十分に気を付けてください。
- ・電池には、しばらく使用しないと電圧値が多少上がる特性があります。前回警告マークが付いて終了していても、時間を置くと一時的には警告マークが点灯しなくなる場合もありますが早めに電池を交換するようにしてください。(第4章電池の交換参照)

2.11 ブザー音

ブザー音をオフするには、**RANGE** キーを押しながら **POWER** キーを押して電源を入れます。

# 第3章 仕様

## 3.1 測定仕様

確度保証温湿度範囲: 23 ±5 、80% rh 以下(結露しない こと) **四マ**ークが点灯していないこと

確度保証期間:1年間(ジョー開閉回数:1万回まで)

3.1.1 電流測定仕様

電流表示確度

直流電流 A(平均值表示)

レンジ(確度範囲)	分解能	DC
200A(±10.0~±200.0A)	0.1A	±1.3%rdg.±3dgt.
2000A(±100~±2000A)	1A	±1.3%rdg.±3dgt.

交流電流 Arms(真の実効値表示)

レンジ(確度範囲)	分解能	45 ~ 66Hz	10~45,66~1kHz
200A(10.0~200.0A)		± 1.3%rdg. ± 3dgt.	±2.0%rdg.±5dgt.
2000A (100 ~ 1800A) (1800 ~ 2000A)	1A	± 1.3%rdg. ± 3dgt.	±2.0%rdg.±5dgt.
(1800 ~ 2000A)	IA IA	± 2.3%rdg. ± 3dgt.	

交流+直流電流 Arms(真の実効値表示)

レン	ジ(確度範囲)	分解能	DC,45~66Hz	10~45,66~1kHz
200A(	10.0~200.0A)	0.1A	±1.3%rdg. ±13dgt.	±2.0%rdg. ±7dgt.
00004	(100 ~ 1800A) (1800 ~ 2000A)	1A	±1.3%rdg. ±13dgt.	±2.0%rdg. ±7dgt.
2000A	(1800 ~ 2000A)	IA	±2.3%rdg. ±13dgt.	

出力確度

直流電流 A(平均值表示)

レンジ(確度範囲)	MON	DC
$200A(\pm 10.0 \sim \pm 200.0A)$	1V/f.s.	±1.3%rdg.±5mV
2000A( ± 100 ~ ± 2000A)	1V/f.s.	±1.3%rdg.±5mV

交流電流 Arms(真の実効値表示)

### MON

レン	ジ(確度範囲)	MON	45 ~ 66Hz	10~45,66~1kHz
	10.0~200.0A)		±1.3%rdg.±5mV	±2.0%rdg.±5mV
20004	(100 ~ 1800A) (1800 ~ 2000A)	AC1V/f.s.	±1.3%rdg.±5mV	±2.0%rdg.±5mV
2000A	(1800 ~ 2000A)		±2.3%rdg.±5mV	

周波数帯域:0.5~15kHz(±3dB)

REC

レン	ジ(確度範囲)	REC	45 ~ 66Hz	10~45,66~1kHz
200A(	10.0~200.0A)		±1.3%rdg.±10mV	±2.0%rdg.±10mV
20004	(100 ~ 1800A) (1800 ~ 2000A)	DC1V/f.s.	±1.3%rdg.±10mV	±2.0%rdg.±10mV
2000A	(1800 ~ 2000A)		±2.3%rdg.±10mV	

出力応答 (f.s.入力時): 立上がり応答時間 (0% 90%) 250 ms 以下 立下がり応答時間(100% 10%)500 ms 以下

交流+直流電流 Arms(真の実効値表示)

MON

レン	ジ(確度範囲)	MON	DC,45~66Hz	10~45,66~1kHz
	10.0~200.0A)		±1.3%rdg.±5mV	±2.0%rdg.±5mV
20004	(100 ~ 1800A) (1800 ~ 2000A)	1V/f.s.	±1.3%rdg.±5mV	±2.0%rdg.±5mV
2000A	(1800 ~ 2000A)		±2.3%rdg.±5mV	

周波数帯域:DC~15kHz(±3dB)

REC

レン	ジ(確度範囲)	REC	DC,45~66Hz	10~45,66~1kHz
	10.0~200.0A)		±1.3%rdg.±10mV	±2.0%rdg.±10mV
00004	(100~2000A)	DC1V/f.s.	±1.3%rdg.±10mV	±2.0%rdg.±10mV
2000A	(1800 ~ 2000A)		±2.3%rdg.±10mV	

出力応答 (f.s.入力時): 立上がり応答時間(0% 90%)250 ms 以下 立下がり応答時間(100% 10%)500 ms 以下

第3章 什樣

ピーク測定確度(ピークホールド機能) 正弦波連続入力時

# 直流電流 Apeak(波高値表示)

レンジ(確度範囲)		分解能	DC
200A(10~500A)		1A	± 1.3%rdg. ± 7dgt.
2000A	(100~2300A)	1A	± 1.3%rdg. ± 7dgt.
2000A	(2300 ~ 2840A)	IA	±6.0%rdg.±7dgt.

交流電流 Apeak(波高值表示)

レン	ジ(確度範囲)	分解能	45 ~ 66Hz	10~45,66~1kHz
200	A(10~500A)	1A	± 1.3%rdg. ± 7dgt.	±2.0%rdg.±7dgt.
00004	(100 ~ 2300A)	1A	± 1.3%rdg. ± 7dgt.	±2.0%rdg.±7dgt.
2000A	(2300 ~ 2840A)	IA	± 6.0% rdg. ± 7dgt.	

交流+直流電流 Apeak(波高値表示)

レン	ジ(確度範囲)	分解能	DC,45~66Hz	10~45,66~1kHz
200	A(10~500A)	1A	±1.3%rdg.±7dgt.	±2.0%rdg. ±7dgt.
00004	(100 ~ 2300A) (2300 ~ 2840A)	1A	± 1.3%rdg. ± 7dgt.	±2.0%rdg. ±7dgt.
2000A	(2300 ~ 2840A)	IA	±6.0%rdg.±7dgt	

### 周波数測定 Hz

表示確度

レンジ(確度範囲)	分解能	
10Hz(1.00~10.00Hz)	0.01Hz	±0.3%rdg.±1dgt.
100Hz(10.0~100.0Hz)	0.1Hz	±0.3%rdg.±1dgt.
1000Hz(100~1000Hz)	1Hz	± 1.0%rdg. ± 1dgt.

出力確度

レンジ(確度範囲)	REC	
10Hz(1.00~10.00Hz)	DC1V/f.s.	±1.3%rdg.±3mV
100Hz(10.0~100.0Hz)		
1000Hz(100~1000Hz)	DC1V/f.s.	±2.0%rdg.±3mV

出力応答:1000Hz,100Hz レンジ 4 秒以下、10Hz レンジ 6 秒以下

#### 第3章 仕様

電流共通仕様				
最大許容電流	2000 /	Arms 連続、2	840 Amax.	
	周波数	によるディレ	ーティング特	生参照
	(図4)	)		
導体位置の影響	±0.7%	6以内(センサ	中心部を基準。	として
	いかな	る位置におい	ても)	
外部磁界の影響	AC400	) A/m の外部	磁界において	2 A 相
	当以下	-		
対地間最大定格電	王 最大 A	C600 Vrms		
2500				
2000				+ + + + +
≤ 1500 ₽				
(抑 1000 )				
¥ 500				
10	100	1 k	10 k	100 k
10	100	□x 周波数 [Hz]	10 %	100 %
図4	周波数によ	<b>にるディレー</b> ラ	ティング特性	

# 3.1.2 電圧測定仕様

電圧表示確度

直流電圧 V(平均値表示)

レンジ(確度範囲)	分解能	DC
30V(±3.00~±30.00V)	0.01V	±1.0%rdg.±3dgt.
300V(±30.0~±300.0V)	0.1V	±1.0%rdg.±3dgt.
$600V(\pm 60.0 \sim \pm 600V)$	1V	±1.0%rdg.±3dgt.

第3章 仕様

交流電圧 Vrms(真の実効値表示)

レンジ(確度範囲)	分解能	45 ~ 66Hz	10~45,66~1kHz
30V(3.00~30.00V)	0.01V	± 1.0%rdg. ± 3dgt.	±1.5%rdg.±5dgt.
300V(30.0~300.0V)	0.1V	± 1.0%rdg. ± 3dgt.	±1.5%rdg.±5dgt.
600V(60.0~600V)	1V	±1.0%rdg.±3dgt.	±1.5%rdg.±5dgt.

交流+直流電圧 Vrms(真の実効値表示)

レンジ(確度範囲)		DC,45~66Hz	10~45,66~1kHz
30V(3.00~30.00V)	0.01V	±1.0%rdg. ±13dgt.	±1.5%rdg. ±13dgt.
300V(30.0~300.0V)	0.1V	± 1.0%rdg. ± 7dgt.	±1.5%rdg.±7dgt.
600V(60.0~600V)	1V	± 1.0%rdg. ± 7dgt.	±1.5%rdg.±7dgt.

ピーク測定確度(ピークホールド機能)

正弦波連続入力時

直流電圧 Vpeak(波高値表示)

レンジ(確度範囲)	分解能	DC
30V(3.0~75.0V)	0.1V	± 1.0%rdg. ± 7dgt.
300V(30~750V)	1V	± 1.0%rdg. ± 7dgt.
600V(60~1000V)	1V	± 1.0%rdg. ± 7dgt.

交流電圧 Vpeak(波高値表示)

レンジ(確度範囲)	分解能	45 ~ 66Hz	10~45,66~1kHz
30V(3.0 ~ 75.0V)	0.1V	± 1.0%rdg. ± 7dgt.	±1.5%rdg.±7dgt.
300V(30~750V)	1V	± 1.0%rdg. ± 7dgt.	±1.5%rdg.±7dgt.
600V(60~1000V)	1V	± 1.0%rdg. ± 7dgt.	±1.5%rdg.±7dgt.

交流+直流電圧 Vpeak(波高値表示)

レンジ(確度範囲)	分解能	DC,45~66Hz	10~45,66~1kHz
30V(3.0~75.0V)	0.1V	± 1.0%rdg. ± 7dgt.	±1.5%rdg.±7dgt.
300V(30~750V)	1V	± 1.0%rdg. ± 7dgt.	±1.5%rdg.±7dgt.
600V(60~1000V)	1V	± 1.0%rdg. ± 7dgt.	±1.5%rdg.±7dgt.

# 周波数測定 Hz

表示確度

レンジ(確度範囲)	分解能	
10Hz(1.00~10.00Hz)	0.01Hz	±0.3%rdg.±1dgt.
100Hz(10.0~100.0Hz)	0.1Hz	±0.3%rdg.±1dgt.
1000Hz(100~1000Hz)	1Hz	± 1.0%rdg. ± 1dgt.

# 3.2 一般仕様

50

付属機能

オ - トゼロ調整機能	DC A, AC+DC A で <mark>0ADJ/RESET</mark> キーによりワンタッチ
ゼロキャンセル機能	AC および AC+DC モードで HOLD キ ーを押した後、 <mark>0ADJ/RESET</mark> キーにより ワンタッチ
レコード	電流、電圧、周波数の測定において最大値 (MAX)、最小値(MIN)、平均値(AVE) を表示可能
データホールド	表示を保持
オートパワーオフ	10.5 分±1 分、直前にブザー音にて警告、 延長、解除可能
ブザー音	ON/OFF

表示	液晶表示
ディジタル表示	最大 2500 カウント(電流) ただし 2000A レンジは 2000 カウント 最大 3750 カウント(電圧) ただし 600V レンジは 750 カウント 最大 1250 カウント(周波数) ただし 1000Hz レンジは 1000 カウント
バーグラフ表示	35 セグメント
オーバーレンジ表示	<b>0.L.</b> 表示 ▶バーグラフ表示
電池消耗警告	Ⅰ(点灯時、確度保証不可)
データホールド表示	HOLD
オートパワーオフ有 効表示	APS

単位	A, V, Hz			
ゼロサプレス	5 カウント			
表示更新レート	ディジタル表示			
	NORMAL 約2回/秒			
	SLOW 約1回/3秒			
	FAST 約4回/秒			
バーグラフ表示	約4回/秒			
表示応答時間	電流、電圧 1秒以下			
(レンジ固定	周波数 1000Hz, 100Hz レンジ1秒以			
0% 100%)	下、10Hz レンジ 2.5 秒以下			
レンジ切換え	オートレンジ/マニュアルレンジ (レンジ			
	固定)選択可能			
出力インピーダンス	300 Ω以下			
回路ダイナミック	2.5以下(2000Aレンジは 1.42以下、			
(クレストファクタ)	600V レンジは 1.7 以下)			
耐電圧	ケース-入力端子間、ケース-ジョー間			
	AC5400 Vrms/ 1 分間			
伝導性無線周波電磁	電流測定 -3 A 以下			
界の影響(3 V にて)				
使用場所	高度 2000 m まで			
	屋内			
適合規格 安全性	EN61010			
	測定カテゴリⅢ(予想される過渡過電圧			
	6000 V)汚染度 2			
	EN61326			
	EN61000-3-2			
EMC	EN61000-3-3			
防塵防水性	EN60529 IP40			
測定可能導体径	φ55 mm 以下			

# 第3章 仕様

温度特性	0~40℃において、0.1×確度仕様/℃		
保存温度範囲	-10~50℃(結露しないこと)		
電源	6F22 (006P) 9 V 1本		
	または 9445-02 AC アダプタ(別売)		
最大消費電力	110 mVA		
電池寿命	約 25 時間(連続、無負荷)		
外形寸法	約 62W×260H×39D mm		
質量	約 540 g		
付属品	L9207-10 テストリード(赤黒) 1		
	9345携帯用ケース 1		
	ハンドストラップ 1		
	電池 6F22(006P) 1		
	取扱説明書 1		
オプション	9445-02 AC アダプタ		
	L9094 出力コード		
製品保証期間	3 年間		

# 第4章 電池の交換方法

## ⚠ 注意 バックケースの留めネジは強く締めすぎないでく ださい。0.5N・m 程度が適切です。

### 注記

す。

- 積層型アルカリ乾電池も使用可能です。
- 積層型乾電池(9 V)は、メーカや種類により+と-それぞれの電極の形状やサイズが若干異なります。そのため、電池スナップへ装着する際に、緩かったりきつかったりする場合があります。
   その場合乾電池にスナップを取り付け、電池収納部分に収めると正常に動作します。
- 1. バックケースの留めネジ2本を、プラスドライバで外しま
- 2. バックケースを外します。
- 電池スナップのコードを引っ張らないように電池を外します。
- 電池スナップに、新しい電池を極性に注意して取り付け、 電池収納部に収めます。
- 5. バックケースを取り付けます。
- 6. バックケースをネジ留めします。

#### 53

#### 第4章 電池の交換方法



# 第5章

# AC アダプタ(別売)の使用

9445-02 AC アダプタ (別売)を AC アダプタ接続端子の奥ま で挿入します。

注記

- ・電池は入れてあっても外してあっても構いません。
- ・電池を入れてある場合、停電などによりAC電源が取れなく ても、電池によりバックアップされ引き続き測定が行えます。
- ・電池駆動から AC アダプタ駆動へ切り換わる場合(停電から の復帰など)下記について影響があります。
  - ①電流測定時の MON 出力波形→10msec 程度変動した後、元 に戻ります。

DC A 測定で長時間記録を取り、停電が考えられる場合は AC+DC Aモードで **REC** 出力を使用することをお勧めし ます。

- ②周波数測定時の REC 出力波形→10msec 程度変動した後、 元に戻ります。
- ③ピークホールド測定→大きく変動したままそのまま値をホ ールドしてしまいます。
  - いずれも電池の電圧が AC アダプタの電圧値(typ. 9 V) より低くなるほど、影響が大きくなります。
  - 短時間での停電復帰が考えられる場合は新品電池を入れて おくことをお勧めします。
- 新品電池を入れた場合に、ACアダプタによる電圧値よりも 電池の電圧値が高いときは電池が消耗します。電池の電圧の 方が低くなるとACアダプタに切り換わります。
- ・AC アダプタ使用時の電池残量表示(バーグラフ)は AC アダ プタの電圧値から算出して表示していますので、電池の残量 表示ではありません。

#### 第5章 AC アダプタ(別売)の使用

## 56

# 第5章 AC アダプタ(別売)の使用

# 第6章 ハンドストラップの付け方

ハンドストラップを付けると操作性が増します。



第6章 ハンドストラップの付け方

# 第6章 ハンドストラップの付け方

# 第7章 故障とお考えになる前に

次のような場合は、故障とお考えになりがちですが、他に原 因があることがあります。修理を依頼される前にもう一度お 確かめください。

症状	電池	電池スナップ	テストリード
電源が入らない	0	0	
■の点灯後、すぐ 電源がオフする	0		
<ul><li>・・ </li><li>・が点灯する </li></ul>	0		
使用中に電源が オフする*	0	0	
電圧測定ができ ない			0
処置: 直らないときは、 修理をご依頼く ださい。	新しい電池と 交換する	電池スナップ の端子部接触 チェック	テストリード の断線チェッ ク

注記

\*APS (オートパワーオフ) が有効になっているとき、何も キーが押されないと、約 10 分後に電源がオフになります。 (「2.9 オートパワーオフ機能」 参照)

電源投入後、表示が E.001~E.005 になる場合は修理が必要 です。

電源が入らない
・電池使用時には電池が消耗していないか確認してください。
(2.1 測定準備 参照)
・AC アダプタ使用時には AC アダプタ接続端子あるいはコン
セントの奥まで挿入されているか確認してください。
・電池では電源が入るのに AC アダプタでは入らない場合は
AC アダプタの不具合が考えられます。(AC アダプタは
9445-02 AC アダプタを使用してください)
表示が0にならない
・DC A, AC+DC A, DC V モードの場合は 2.5.1 オートゼロ調
整機能を使用してください。
・AC A, AC V, AC+DC V モードの場合は 2.5.2 ゼロキャンセ
ル補正機能を使用してください。
・AC+DC A モードでオートゼロ調整を行っても、表示が0に
ならない場合は、ゼロキャンセル補正を行ってください。

# 表示値が予測よりも小さい

#### 電流測定

- ・ジョーがしっかりと閉じているか確認してください。
- ・被測定電路の周波数が製品仕様の範囲から外れていないか 確認してください。(インバータのキャリア周波数が高いと 低めの表示になります)
- •2.5.1 オートゼロ調整機能および 2.5.2 ゼロキャンセル補正 機能の使用方法が間違っていないか確認してください。
- ・使用すべきモードが間違っていないか確認してください。 (1.5 各モードの説明 参照)
- ・ピーク値が製品仕様の回路ダイナミックを超えてしまっていないか確認してください。
   (ピーク値の変動は224あるいは234ピークホールド測定)
- (ビーク値の変動は2.2.4 あるいは2.3.4 ビークボールト測定 の注記を参照してください)
- ・クレストファクタ(=ピーク値/実効値)が製品仕様の中の回路ダイナミックを超えてしまっていないか確認してください。
- ・電池消耗警告マークが点灯していないか確認してください。 電圧測定
- ・テストリードがしっかりと接続されているか確認してください。
- ・被測定電路の周波数が製品仕様の範囲から外れていないか 確認してください。
- 2.5.1 オートゼロ調整機能および 2.5.2 ゼロキャンセル補正 機能の使用方法が間違っていないか確認してください。
- ・使用すべきモードが間違っていないか確認してください。 (1.5 各モードの説明 参照)
- ・ピーク値が製品仕様の回路ダイナミックを超えてしまっていないか確認してください。
   (ピーク値の変動は2.2.4 あるいは2.3.4 ピークホールド測定の注記を参照してください)
- ・クレストファクタ (=ピーク値/実効値) が製品仕様の回路ダ イナミックを超えてしまっていないか確認してください。
- ・電池消耗警告マークが点灯していないか確認してください。 周波数測定
- インバータなど特殊波形は測定できない場合もありますの で波形を確認してください。
- ・入力値がレンジに対して10%以上あるか確認してください。

## 表示値が予測よりも大きい

#### 電流測定

- ・レンジがあっているか確認してください。
- 予想している周波数成分以外が含まれていないか出力機能のMONで波形を確認してください。
- ピーク測定時に OADJ/RESET キーで表示をリセットしたか 確認してください。
- ・近くに大きな磁界や電界やノイズが発生していないか確認 してください。
- ・ピーク電流測定中に、電池駆動から AC アダプタ駆動に切り 換わった場合(停電から復帰の場合など)、表示値が大きくな る場合があります。(第5章 AC アダプタ(別売)の使用 参照)

## 電圧測定

- ・レンジがあっているか確認してください。
- ・ピーク測定時に OADJ/RESET キーで表示をリセットしたか 確認してください。
- ・近くに大きな磁界や電界やノイズが発生していないか確認 してください。

#### 周波数測定

- ・近くに大きな磁界や電界やノイズが発生していないか確認 してください。
- インバータなど特殊波形は測定できない場合もありますの
   で波形を確認してください。

# 出力値が予測よりも小さい 表示値と同様の確認をしてください。 ・L9094 出力コードが断線していないか確認してください。 ・出力の選択(REC.MON)が間違っていないか確認してく ださい。 ・先に選択されたモード(電流か周波数)の出力になっていな いか確認してください。 ・接続する測定器の入力インピーダンスが1MQ以上ある。 か、確認してください。 ・接続する測定器がAC結合になっていないかあるいはフィル タ機能が ON になっていないか確認してください。 出力値が予測よりも大きい 表示値と同様の確認をしてください。 ・出力の選択(REC.MON)が間違っていないか確認してく ださい。 ・先に選択されたモード(電流か周波数)の出力になっていな。 いか) ・電流測定時のMON 出力および周波数測定時の REC 出力中 に、電池駆動から AC アダプタ駆動に切り換わった場合(停 電から復帰の場合など)、出力値が大きく変動する場合があ ります。(第5章 ACアダプタ(別売)の使用 参照) 表示値がふらつく ・被測定電路が安定しているか確認してください。 ・電圧測定の場合はテストリードがしっかりと接続されてい るか、断線がないか確認してください。 ・周波数測定の場合、インバータなど特殊波形は測定できない 場合もありますので波形を確認してください。

# 第8章 アフターサービス

- ・補修部品の最低保有期間は、製造打ち切り後5年間です。
- アフターサービスについてご不明な点は、お買上店(代理店)か、最寄りの営業所にご連絡ください。
- ・輸送の際は、破損しないように梱包し、故障内容も書き添え てください。輸送中の破損については保証しかねます。

### 66

	保証書				ΗΙΟΚΙ			
	形名	製造番号		保証期間 購入日	年	月から3年間		
おそ	客様のご住所: <u>〒</u>							
お名前: お客様へのお願い ・保証書は再発行いたしませんので、大切に保管してください。 ・「形名・製造番号・購入日」および「ご住所・お名前」をご記入ください。 ※ご記入いただきました個人情報は修理サービスの提供および製品の紹介のみに使用します。								
本製品は弊社の規格に従った検査に合格したことを証明します。本製品が故障した場合は、お買い求め先にご連 絡ください。以下の保証内容に従い、本製品を修理または新品に交換します。ご連絡の際は、本書をご提示くだ さい。								
<ul> <li>保証内容</li> <li>1. 保証期間中は、本製品が正常に動作することを保証します。保証期間は購入日から3年間です。購入日が不明な場合は、本製品の製造年月(製造番号の左4桁)から3年間を保証期間します。</li> <li>2. 本製品にACアダブターが付属している場合、そのACアダブターの保証期間は購入日から1年間です。</li> <li>3. 測定値などの確度の保証期間は、製品仕様に別途規定しています。</li> <li>4. それぞれの保証期間内に本製品またはACアダブターが弦障した場合、その故障の責任が弊社にあると弊社が判断したときは、本製品またはACアダブターを依領で修理または新品と交換します。</li> <li>5. 以下の故源、損傷などは、無償修理または新品交換の保証の対象外とします。</li> <li>-1.消耗品、有寿命部品などの故障と損傷</li> </ul>								
<ul> <li>2. コネクター、ケーブルなどの故障と損傷</li> <li>3. お買い上げ後の輸送、落下、移設などによる故障と損傷</li> <li>4. 取扱説明書などで要求された保守・点検を怠ったことにより発生した故障と損傷</li> <li>5. 法令、取扱説明書などで要求された保守・点検を怠ったことにより発生した故障と損傷</li> <li>6. 火災、風水害、地震、落雷、電源の異常(電圧、周波数など)、戦争・暴動、放射能汚染、そのほかの不可抗力による故障と損傷(筐体の傷、変形、退色など)</li> <li>8. そのほかその責任が弊社にあるとみなされない故障と損傷</li> </ul>								
	6. 以下の場合は、本製品を保証の対象外とします。修理、校正などもお断りします。 <ol> <li>弊社以外の企業、機関、もしく(個人が本製品を修理した場合、または改造した場合</li> <li>特殊な用途(宇宙用、航空用、原子力用、医療用、車両制御用など)の機器に本製品を組み込んで使用することを、事前に弊社にご連絡いただかない場合</li> </ol>							
	<ol> <li>製品を使用したことにより発生した損失に対しては、その損失の責任が弊社にあると弊社が判断した場合、本 製品の購入金額までを補償します。ただし、以下の損失に対しては補償しません。</li> <li>・本製品を使用したことにより発生した被測定物の損害に起因する二次的な損害</li> <li>・2、本製品による測定の結果に起因する損害</li> </ol>							
8.	3.本製品と互いに接続した(ネットワーク経由の接続を含む)本製品以外の機器への損害 3.製造後一定期間を経過した製品、および部品の生産中止、不測の事態の発生などにより修理できない製品は、修理、校正などをお断りすることがあります。 サービス記録							
		サービス内容		皆 <b>電機</b> www.hioki				
						Contraction of the second s		

18-06 JA-3
## ΗΙΟΚΙ

# 3285 CLAMP ON AC/DC HITESTER

Instruction Manual

Mar. 2019 Revised edition 19 3285A980-19 19-03H

### Contents

Introduction	i
Shipping Check	ii
Safety-	iii
Attentions During Use	iv
Allentions During Use	IX
Chapter 1 Product Outline	1
1.1 Product Outline	1
1.2 Features	
1.3 Parts and Functions	
1.4 Flowchart of Key Operations	
1.4.1 Current Measurements Mode	10
1.4.2 Voltage Measurements Mode	11
1.4.3 Frequency Measurements Mode	
1.5 Modes	
Chapter 2 Measurement Procedure	. 15
2.1 Preparations	
2.2 Current Measurement	
2.2.1 Measuring DC Current (DC A) 2.2.2 Measuring AC Current (AC A)	
2.2.3 Measuring AC/DC Current (AC+DC A) 2.2.4 Peak Hold Measurement	
2.2.5 Output Function	
2.3 Voltage Measurement	
2.3 Voltage Measurement	- 25
2.3.1 Measuring AC Voltage (AC V)	
2.3.3 Measuring AC/DC Voltage (AC+DC V)	
2.3.4 Peak Hold Measurement	
	~ 20

2.4 Freque	ncy Measurement	.30
•	juency Measurement in Current Mode	
	uency Measurement in Voltage Mode	
	but Function for Frequency	
	ero-Adjustment/Zero-Cancel	
Correct	tion Function	· 34
2.5.1 Auto	-Zero-Adjustment Function	- 34
2.5.2 Zero	-Cancel Correction Function	- 35
2.6 Data H	old Function HOLD	35
2.7 Alterati	on of Counter Updates	· 36
2.7.1 SLO	W Mode	- 36
2.7.2 FAS	T Mode	- 36
2.8 Record	ling Function REC	· 36
	ower-Off Function APS	
	y Low Warning 🖪	
2.11 Beep	Tone	·41
	Specifications	
	rement Specifications	
	ent Measurement Specifications	
	age Measurement Specifications	
3.2 Genera	al Specifications	· 50
Chapter 4	Battery Replacement	53
Chapter 5	AC Adapter (Optional)	55
Chapter 6	Attaching the Hand Strap	57
Chapter 7	Troubleshooting	59
Chapter 8	Service	65

## Introduction

Thank you for purchasing the HIOKI "3285 CLAMP ON AC/DC HITESTER." To obtain maximum performance from the product, please read this manual first, and keep it handy for future reference.

#### Request

We have tried to bring this manual as close to perfection as we could achieve. If perchance you find any unclear portions, mistakes, omissions, or the like, we would be most obliged if you could please notify us of them via any HIOKI agent, or directly.

## Shipping Check

When the unit is delivered, check and make sure that it has not been damaged in transit. In particular, check the accessories, panel switches, keys, and terminals.

If the unit is damaged, or fails to operate according to the specifications, contact your dealer or HIOKI representative.

## Check the 3285 Unit and the Supplied Accessories

Main unit

3285 CLAMP ON AC/DC HITESTERSupplied accessories9345 CARRYING CASE1L9207-10 TEST LEAD (red and black)1Hand Strap16F22(006P)1Instruction manual1

#### Options

L9094 OUTPUT CORD 9445-02 AC ADAPTER

## Safety

#### 

This instrument is designed to comply with IEC 61010 Safety Standards, and has been thoroughly tested for safety prior to shipment. However, mishandling during use could result in injury or death, as well as damage to the instrument. Be certain that you understand the instructions and precautions in the manual before use. We disclaim any responsibility for accidents or injuries not resulting directly from instrument defects.

> This manual contains information and warnings essential for safe operation of the instrument and for maintaining it in safe operating condition. Before using it, be sure to carefully read the following safety precautions.

The following symbols in this manual indicate the relative importance of cautions and warnings.

A DANGER	Indicates that incorrect operation presents extreme danger of accident resulting in death or serious injury to the user.
	Indicates that incorrect operation presents a significant hazard that could result in serious injury or death to the user.
	Indicates that incorrect operation presents a possibility of injury to the user or damage to the instrument.
NOTE	Indicates advisory items related to performance or correct operation of the instrument.

## Safety Symbols

	The $\triangle$ symbol printed on the instrument indicates that the user should refer to a corresponding topic in the manual (marked with the $\triangle$ symbol) before using the relevant function.
	In the manual, the A symbol indicates particularly important information that the user should read before using the instrument.
$\sim$	Indicates AC (Alternating Current).
	Indicates DC (Direct Current).
~	Indicates both DC (Direct Current) and AC (Alternating Current).
	Indicates that dangerous voltage may be present at this terminal
	Indicates a device which is double- insulated.
4	Indicates that the instrument may be connected to or disconnected from a live circuit.

f.s. (maximum display or scale value, or length of scale) Signifies the maximum display (scale) value or the length of the scale (in cases where the scale consists of unequal increments or where the maximum value cannot be defined).

> In general, this is the range value (the value written on the range selector or equivalent) currently in use.

rdg. (displayed or indicated value)

Signifies the value actually being measured, i.e., the value that is currently indicated or displayed by the measuring instrument.

dgt. (resolution)

Signifies the smallest display unit on a digital measuring instrument, i.e., the value displayed when the last digit on the digital display is "1".

#### **Measurement categories**

This instrument complies with CAT III safety requirements.

To ensure safe operation of measurement instruments, IEC 61010 establishes safety standards for various electrical environments, categorized as CAT II to CAT IV, and called measurement categories. These are defined as follows.

- CAT II : Primary electrical circuits in equipment connected to an AC electrical outlet by a power cord (portable tools, household appliances, etc.) CAT II covers directly measuring electrical outlet receptacles.
- CAT III: Primary electrical circuits of heavy equipment (fixed installations) connected directly to the distribution panel, and feeders from the distribution panel to outlets.
- CAT IV: The circuit from the service drop to the service entrance, and to the power meter and primary overcurrent protection device (distribution panel).



Using a measurement instrument in an environment designated with a higher-numbered category than that for which the instrument is rated could result in a severe accident, and must be carefully avoided. Use of a measurement instrument that is not CATrated in CAT II to CAT IV measurement applications could result in a severe accident, and must be carefully avoided.



**Fixed Installation** 



## **Attentions During Use**

Follow these precautions to ensure safe operation and to obtain the full benefits of the various functions.



- To avoid electric shock, do not allow the product to get wet, and do not use it when your hands are wet.
- To avoid electric shock when measuring live lines, wear appropriate protective gear, such as insulated rubber gloves, boots and a safety helmet.
- During current measurement, to avoid an electric shock accident, do not connect the test leads to the product.



• Do not use the instrument where it may be exposed to corrosive or combustible gases. The instrument may be damaged or cause an explosion.

 Do not place foreign objects between the mating faces of the jaw or insert foreign objects into the gaps of the jaw. Doing so may worsen the performances of the sensor or interfere with clamping action. To avoid damage to the product, protect it from vibration or shock during transport and handling, and be especially careful to avoid dropping. Do not exert excessive pressure on the laws or attempt to wedge the sensor into a tight spot for measurement. · Before using the product the first time, verify that it operates normally to ensure that the no damage occurred during storage or shipping. If you find any damage, contact your dealer or HIOKI representative. · To avoid damage to the product, do not exceed the maximum input current rating, which depends on the frequency of the current being measured (see Fig.4 of Chapter 3) Be careful about the evolution of heat, when the input frequency is high. · Do not use the product if the battery is exhausted (when the **B** mark lights in the display area). Be sure to replace the exhausted battery with a new one. · When replacing the battery, make sure that the metal battery snap fitting is firmly connected. If the metal fitting is loose, adjust it and recheck the connection. If it isn't connected securely, the power may not be turned on, and a power may be turned off during the use. Adjustments and repairs should be made only by technically qualified personnel.

<ul> <li>For the inside memory protection, make sure the power is turned off before plugging in or unplugging the AC adapter.</li> </ul>
power is turned off before plugging in or unplugging
<ul> <li>the AC adapter.</li> <li>This product is designed for indoor use, and operates reliably from 0°C to 40°C.</li> <li>Do not store or use the product where it could be exposed to direct sunlight, high temperature or humidity, or condensation. Under such conditions, the product may be damaged and insulation may deteriorate so that it no longer meets specifications.</li> <li>Removable sleeves are attached to the metal pins at the ends of the test leads. To prevent a short circuit accident, be sure to use the test leads with the sleeves attached when performing measurements in the CAT III measurement category. In a CATII environment, if the tips of the test leads do not reach the measurement object, remove the rigid insulating sleeve before measuring. For details on measurement categories, see "Measurement categories "(page vi) in the instruction manual.</li> <li>When performing measurements with the sleeves attached, be careful to avoid damaging the sleeves. If the sleeves are inadvertently removed during measurement, be especially careful in handling the test leads to avoid electric shock.</li> <li>To prevent an electric shock accident, confirm that the white or red portion (insulation layer) inside the cable is not exposed. If a color inside the cable is exposed, do not use the cable.</li> </ul>



Accurate measurement may be impossible in locations subject to strong external magnetic fields, such as transformers and high-current conductors, or in locations subject to strong external electric fields, such as radio transmission equipment.

• Gently wipe dirt from the surface of the unit with a soft cloth moistened with a small amount of water or mild detergent.

Do not try to clean the unit using cleaners containing organic solvents such as benzine, alcohol, acetone, ether, ketones, thinners, or gasoline. They may cause discoloration or damage.

- When not in use for a long time, to prevent possible corrosion caused by battery leakage, remove the batteries before storage.
- •Hall elements are used in the current detection portion of the clamp on AC/DC HiTester. As there are two types of drifts in the Hall elements, drift depending on time and drift depending on the surrounding temperature, take note when conducting continuous measurements.
- The Hall elements lack uniformity, and it is impossible to determine the amount of variation which depends on time and the temperature. When conducting continuous measurement or in an environment where there are huge temperature variations, it is recommended that the variation at point 0 when nothing has been inputted should be first noted. The variation at point 0 is the direct current component.

This does not affect the AC mode.

• Due to the offset peculiar to elements from a hall effect, the display may sometimes not show 0 immediately after it is turned on, but this is not a malfunction. The count remaining has an instrumental difference of 0 to a few tens A.

## NOTE

• When using in DC or AC/DC mode, press the OADJ/RESET key each time the power is turned on to carry out auto zero adjustment. When 0 is displayed after zero adjustment, the measurement can be performed without the interference of the count remaining immediately after the power is turned on.

## Chapter 1 Product Outline

## 1.1 Product Outline

The 3285 CLAMP ON AC/DC HiTESTER makes it possible to measure DC, AC or AC+DC current in live power lines without tapping into or connecting the lines. Using a one-chip microprocessor, the tester provides many functions, including an automatic zero adjust function that changes a troublesome task into a one-touch operation. An AC adapter connection terminal and an output terminal are equipped so that you are able to measure by connecting to other instruments such as recorders.

## 1.2 Features

- A multi-function microcomputer The built-in microcomputer offers various functions in a compact form.
- Display of true rms values The true rms value conversion circuit allows accurate measurement of currents with distorted waveforms.

• Measurement for AC/DC

The unit permits measurement of AC superimposed on DC, as well as measurement of half- and fullwave rectification.

· Peak measurement

Allows measurement of peak hold values for either voltage or current. Transitional peak values can also be measured.

#### REC function

Displays the maximum and minimum measured values.

#### Output terminal

You can record current or frequency by connecting a recorder or an oscilloscope to the built-in output terminal.

Current (Record output: REC, Waveform output: MON)

Frequency (Record output: REC)

#### · Dual-power source

The unit operates on either a battery power or an AC power source.



The serial number label is affixed on the back side. The serial number consists of 9 digits. The first two (from the left) indicate the year of manufacture, and the next two indicate the month of manufacture.

Required for production control. Do not peel off the label.

POWER

- · Used to turn power on/off
- To disable the auto power-off function, hold **HOLD** and press **POWER**, when you turn power on.

🚡 key

· Switches current modes as follow.

 $\rightarrow$  DCA  $\rightarrow$  ACA  $\rightarrow$  AC+DCA --

#### RANGE

- Switches between auto and manual ranges in measurements of current, voltage, or frequency.
- Switches manual ranges.
- Displays a cursor on the bar graph to show the selected range.
- The current ranges are 200 A and 2000 A. The voltage ranges are 30 V, 300 V and 600 V. The frequency ranges are 10 Hz, 100 Hz and 1000 Hz.
- Used to suspend or inactivate the screen-updating function.
- To disable the auto power-off function when powering on, hold **HOLD** and press **POWER**.
- Allows voltage output during current measurement or frequency measurement in a current mode.
- The auto power-off function is inactivated.



• You can find how much the battery power remains on the bar graph, when you press **OUTPUT** in a current mode.

#### SLOW/PEAK/Hz

- **SLOW** slows down screen updating (once per three seconds).
- **FAST** speeds up screen updating (four times per second). There isn't an annunciator "**FAST**". Instead, the unit symbol blinks.
- PEAK measures peak values (Peak Hold).
- Hz measures frequency (in AC or AC+DC mode). ▼
- · Switches voltage modes as follows.

$$\rightarrow$$
 DC V  $\rightarrow$  AC V  $\rightarrow$  AC+DC V  $-$ 

#### MAX/MIN

- Displays the maximum value (**MAX**), the minimum value (**MIN**), or the average value (**AVE**) of the maximum and minimum values for the recording (**REC**) function.
- MAX displays the maximum measured value after the **REC** function is activated.
- MIN displays the minimum measured value after the **REC** function is activated.
- **AVE** displays the average value of the maximum and minimum measured values after the **REC** function is activated.
- The auto power-off function is disabled in the **REC** function.

#### 0ADJ/RESET

- Performs auto-zero-adjustment in DC A, AC+DC A and DC V modes.
- Resets data when measuring peak values. Reset all the data in a **REC** function.
- If zero is not indicated under no input in the AC A, AC+DC A, AC V or AC+DC V modes, press HOLD, then press OADJ/RESET to perform a zerocancel correction.

#### Jaws

• To measure current, open the top ends of the jaws by gripping the lever ①. Then position the conductor to be measured at the center of the jaws and firmly close the jaws.

Lever

• Used to open and close the jaws.



Α	Current
hour	1 hour/segment (bar graph)
min	1 minute/segment (bar graph)
	Input over (bar graph)

Output terminal

Connected to the optional N9094 OUTPUT CORD to provide output during a current measurement or a frequency measurement in a current mode.

#### AC adapter connection terminal

Connected to the optional 9445-02 AC"ADAPTER to perform measurements for no battery"qt"c"nqpi term measurement.

Voltage measurement terminal (V and COM terminals)

Connected to the L9207-10 TEST LEAD (red and black, supplied with the unit) to measure voltage.

#### Slide knob

Slide up to use the voltage measurement terminal or slide down to use the output terminal or AC adapter connection terminal. Move until a click is heard.

#### Rear cover

To replace the battery, remove the two screws.

#### Hand strap

Attach to get a better grip on the unit.

#### L9207-10 TEST LEAD



1 Protective barrier

Be careful to not touch the metal part of the test lead beyond the safety barrier when contacting a conductor for measurement.

2 Sleeve

Attach to the pins to prevent short circuit accidents.



- Be sure to use the test leads with the sleeves attached when performing measurements in the CAT III measurement category. In a CAT II environment, if the tips of the test leads do not reach the measurement object, remove the rigid insulating sleeve before measuring.
- When performing measurements with the sleeves attached, be careful to avoid damaging the sleeves. If the sleeves are inadvertently removed during measurement, be especially careful in handling the test leads to avoid electric shock.
- The tips of the metal pins are sharp, so take care not to injure yourself.

Removing and attaching the sleeves.

0		0
Removing th sleeves	е	Gently hold the bottom of the sleeves and pull the sleeves off.Safely store the removed sleeves so as not to lose them.
Attaching th sleeves	е	Insert the metal pins of the test leads into the holes of the sleeves, and firmly push them all the way in.

## 1.4 Flowchart of Key Operations

1.4.1 Current Measurements Modes



Chapter 1 Product Outline



\* Neither "FAST" or "NORMAL" annunciator is on the display.

Chapter 1 Product Outline



### 1.5 Modes

Mode	Input waveform	Display	(only for cu	PUT Irrent mode)
			REC	MON
DC (===)	0	○Average value displayed (with polarity)		。 □
	∘₩	×Not measurable	Disabled	°
	$M_{\circ}$	×Not measurable		.₩
	0	×Not measurable (zero displayed)	0 V	0 V
	₀╋	ORMS value	0	∘₩
	$M_{\circ}$	×Not measurable	0	°
AC+DC (RC)	0	ORMS value (without polarity)	0	0
	₀	ORMS value	0	°
	$M_{\circ}$	ORMS value	0	

Chapter 1 Product Outline

## Chapter 2 Measurement Procedure

## 2.1 Preparations

- 1. Remove the rear cover and insert a battery. (Refer to "Chapter 4 Battery Replacement".)
- 2. Press **POWER** to turn the unit on. Verify that all segments of the display light up briefly. Then the model name is shown, and the bar graph indicates the battery condition.

Ĭ	Fresh battery
°	Battery capacity 50%
l	Battery capacity 0 🖪 Beep tone sounds 3 time:

3. The DC current measurement mode is activated.

#### [Low battery voltage detection function]

After the **B** mark lights and battery voltage drops below a certain level, the power goes off automatically. When this occurs, **bAtt** and **Lo** are displayed.

When power goes off after display of these marks, replace the exhausted battery with a new one.

## 2.2 Current Measurement

- Accurate measurement may be impossible in locations subject to strong external magnetic fields, such as transformers and high-current conductors, or in locations subject to strong external electric fields,
  - such as radio transmission equipment.
    Make sure that only one conductor is clamped in the center of the jaws. If you clamp single-phase (2-wire) or three-phase (3-wire) lines together, it will be impossible to measure.



• The display may show a measured value bigger than the actual value due to a magnet:c field interference. The interference is less than 2 A during the measurement.

## 2.2.1 Measuring DC Current (DC A)

- Press X to display —.
- 2. Switch between the auto range and the manual range as necessary.
- 3. Please execute auto zero adjustment before measuring. Press **DADJ/RESET** to make an auto-zero-adjustment (without clamping the measured conductor inside the jaws) with the jaws firmly closed. (see 2.5.1: Auto-zeroadjustment function).

**ADJ** annunciator lights to indicate that auto-zeroadjustment is complete. (If you make an auto-zeroadjustment in the auto range, two current ranges will be adjusted in this mode.) When 0 is displayed after zero adjustment, the measurement can be performed without the interference of the count remaining immediately after the power is turned on.

4. Open the top ends of the jaws, orient the current direction indicator on the clamp in the current direction of the measured conductor, and clamp the conductor so that it passes through the center of the jaws.



(NOTE)

• The DC A mode permits only DC current measurements that does not include the AC component (see 1.5: Modes).

- The 200 A range will display up to 250 A, however, only the range from 10 A to 200 A can be displayed with guaranteed accuracy.
- At any range, gross errors may occur at 1% or below of the range, whose accuracy is not guaranteed, as a result of internal corrective calculations.
- •The value may sometimes not show 0 when the power is switched on, but this is not an instrument fault. Please execute auto zero adjustment before measuring.

#### 2.2.2 Measuring AC Current (AC A)

- 1. Press 🛐 to display ~.
- 2. Switch between the auto range and the manual range as necessary.
- 3. Open the top ends of the jaws and clamp the measured conductor so that it passes through the center of the jaws.

NOTE

• Just after suspension of input, or when modes are switched under no input, the counter would not become zero for about 10 seconds. This is normal and simply reflects the workings of the internal circuit. But you can measure with guaranteed accuracy before the counter becomes zero.

- Depending on ambient temperatures, the counter would not become zero under no input. If this happens, perform a zero-cancel correction (2.5.2: Zero-cancel correction function).
- During a f.s. input, the measurement response speed is about 250 ms during rise (0% to 90%) and about 500 ms (100% to 10%) during fall (2.2.5, Figs. 1 and 2).
- The AC A mode does not allow measurement of DC waveforms, full-wave rectification waveforms, half-wave rectification waveforms, or DC+AC waveforms (See 1.5: Modes).
- The 200 A range will display up to 250 A, however, only the range from 10 A to 200 A can be displayed with guaranteed accuracy.
- At any range, gross errors may occur at 1% or below of the range ,whose accuracy is not guaranteed, as a result of internal corrective calculations.

## 2.2.3 Measuring AC/DC Current (AC+DC A)

- 1. Press 🛐 to display 평.
- 2. Switch between the auto range and the manual range as necessary.
- 3. Please execute auto zero adjustment before measuring. Press **OADJ/RESET** to make an auto-zero-adjustment (without clamping the measured conductor inside the jaws) with the jaws firmly closed. (see 2.5.1: Auto-zeroadjustment function).

**ADJ** annunciator lights to indicate that auto-zeroadjustment is complete. (If you make an auto-zeroadjustment in the auto range, two current ranges will be adjusted in this mode.)
When 0 is displayed after zero adjustment, the measurement can be performed without the interference of the count remaining immediately after the power is turned on.

- Open the top ends of the jaws and clamp the measured conductor so that it passes through the center of the jaws.
- Just after suspension of input, or when modes are switched under no input, the counter would not become zero for about 10 seconds. This is normal and simply reflects the workings of the internal circuit. But you can measure with guaranteed accuracy before the counter becomes zero.
  - Depending on ambient temperatures, the counter would not become zero under no input. If this happens, preform a zero-cancel correction (2.5.2: Zero-cancel correction function).
  - The polarity of the input is not displayed, even if DC current is measured in this mode. If the jaws is reoriented, the measured values may change, but the values are within the guaranteed accuracy. (In case that you would like to measure a DC current which doesn't have AC components, you should make the measurement in DC A mode.)
  - During a f.s. input, the measurement response speed is about 250 ms during rise (0% to 90%) and about 500 ms (100% to 10%) during fall (2.2.5, Figs. 1 and 2).
  - The 200 A range will display up to 250 A, however, only the range from 10 A to 200 A can be displayed with guaranteed accuracy.
  - At any range, gross errors may occur at 1% or below of the range, whose accuracy is not guaranteed as a result of internal corrective calculations.
  - When displaying the current measured value during a frequency output, the auto-zero-adjustment is unavailable for the current measurement.
  - The value may sometimes not show 0 when the power is switched on, but this is not an instrument fault. Please execute auto zero adjustment before measuring.

### 2.2.4 Peak Hold Measurement

- 1. Press 🛣 and select a measurement mode for the measured circuit.
- In DC A and AC+DC A modes, make an auto-zeroadjustment by DADJ/RESET.
- 3. Set to **PEAK**. The measurement mode is switched by **SLOW/PEAK/Hz** as follows.
- → SLOW → FAST → PEAK → Hz → NORMAL (The unit (Except symbol blinks.) DC)
  - 4. Switch between the auto and the manual range as necessary. (If you are unable to estimate the peak current value, start at the 2000A range.)
  - 5. Before the measurement, press **DADJ/RESET** to reset the residual data.
  - 6. Open the top ends of the jaws and clamp the measured conductor so that it passes through the center of the jaws.
- (NOTE)
- The polarity of the input is not displayed during peak measurements. The measured values may change if the jaws is reoriented, but the values are within the guaranteed accuracy.
- You can capture from pulses with a width of about more than 1 ms.
- Even after clamping, press **OADJ/RESET** to reset the data as necessary.
- In case that the counter doesn't become zero under no input in peak measurement mode, even though you pressed **OADJ/RESET** to reset the peak data, the jaws may be magnetized. Quit the peak measurement mode, and perform the auto-zero adjustment by **OADJ/RESET**. Then make the settings again. (A few counts would remain, even if you push **OADJ/RESET**.)

21
<ul> <li>The hold value does not change, unless a larger value is measured, but be careful to avoid accidental loss of data resulting from the auto power-off function. (See 2.9: Auto power-off function.)</li> <li>Use the REC function to make measurements longer than the auto power OFF time.</li> <li>You cannot output peak values. When pressing OUTPUT during peak measurement, the present measured value is outputted.</li> <li>To check transitional peak value, press MAX/MIN to shift to the Instantaneous value (no annunciator).</li> </ul>
→ MAX →→ MIN →→ AVE →→ Instantaneous value → (no annunciator)
<ul> <li>2.2.5 Output Function <ul> <li>An output of AC/DC 1 V is produced for 2000-count on the full scale of each current range.</li> <li>Select either REC (record output) or MON (waveform output).</li> <li>(In DC A mode, only MON is available. See 1.5: Modes)</li> </ul> </li> <li>1. Press RANGE to set the current range.</li> <li>2. Press OUTPUT. REC or MON annunciator lights and activates the output function, automatically disabling the auto power-off function. (APS annunciator is turned off.)</li> <li>3. OUTPUT switches the output modes.</li> </ul>
<ul> <li>AEC (Record output) → MON (Waveform output) → Light turned off</li></ul>

conversi	conversion date for funges is provided below.						
Range /DIV	10 mV	20 mV	50 mV	0.1 V	0.2 V	0.5 V	1 V
2000Arange	20 A	40 A	100 A	200 A	400 A	1000A	2000A
200 A range	2 A	4 A	10 A	20 A	40 A	100 A	200 A

The figures are current values per DIV of a measuring instrument, such as a recorder.

#### Chapter 2 Measurement Procedure



# To avoid damage to the unit, do not short the output terminal and do not input voltage to the output terminal.

- NOTE Before using the output function, be sure to press OUTPUT, confirming that either **REC** or **MON** annunciator is on. Output is made even when both annunciators are off, but the power will be automatically off in approximately 10 minutes, since the auto power-off function is activated. In addition, when the **MON** mark is unlit in the DCA mode, even a minus current value will be inputted in the plus side so pay special attention to such cases.
  - If **OUTPUT** is pressed in an auto range (**AUTO**), the current range is set as the key is pressed. (**AUTO** annunciator is turned off.)
  - Errors may occur or output values unless an autozero-adjustment is done in DC A mode.
  - The zero-cancel function does not affect output. Thus, voltage would be generated because of an <u>ambient</u> temperature, even if there is no input.
  - **REC** outputs are analog outputs. The output response time during a f.s. input differs between rise (0% to 90%, about 250 ms) and fall (100% to 10%, about 500 ms). (Figs 2 and 3) As the measured value is small to the range response time becomes long.
  - Changes of counter updating rate, peak measurement, frequency measurement, recording, and data holding are possible when generating current measurement output. (But output will be changed during mode shift, range shift, shift to voltage measurement mode, or auto-zeroadjustment.)



- For recorders, use over 1 M $\Omega$  input impedance. Low impedances will affect indicated values.
- Even if you press **X** while recording frequency measurements, output is still for the frequency. To obtain a current output, press **OUTPUT** to disable the frequency output, then make new settings.
- For a long term measurement, use the optional 9445-02'CC ADAPTER
- When the AC adapter is used and there is a large amount of noise in the power line, the display may show several counts or noise may be present in the output. In such a case, connect the ground terminal of the level recorder or the L side of the input to ground.









### 2.3 Voltage Measurement

### 2.3.1 Measuring DC Voltage (DC V)

- 1. Press 🚺 to display -...
- 2. Slide the slide cover up using the slide knob. Next, insert the red test lead to V and the black test lead to COM of the voltage measurement terminal.
- 3. Switch between the auto range and the manual range as necessary.
- If the counter does not show zero, switch to the range you will use (manual range), and press to perform an auto-zero adjustment.

ADJ annunciator lights to indicate that auto-zeroadjustment is complete.

- 5. Attach or remove the rigid insulating sleeve as required by the measurement category.
- 6. Carefully contact the test leads to a circuit.
- (NOTE)
- Be sure to use the test leads with the sleeves attached when performing measurements in the CAT III measurement category. In a CAT II environment, if the tips of the test leads do not reach the measurement object, remove the rigid insulating sleeve before measuring.
  - You can perform the auto-zero-adjustment up to 4% of the range.
  - When you switch ranges after auto-zero adjustment, deviation of the adjustment value will prevent accurate measurement. Always perform the auto-zero adjustment after switching ranges. (Do not perform auto-zero adjustment when using the auto range.)
  - A lit annunciator indicates that potential is higher at the black test lead than at the red test lead.
  - The DC V mode permits only DC voltage measurements that does not include the AC component (see 1.5: Modes).

- NOTE Every range will display up to 125% of the range, however, only the range from 10% to 100% can be displayed with guaranteed accuracy.
  - At any range, gross errors may occur at 1% or below of the range, whose accuracy is not guaranteed, as a result of internal corrective calculations.

### 2.3.2 Measuring AC Voltage (AC V)

- 1. Press  $\mathbf{\tilde{x}}$  to display  $\sim$ .
- 2. Slide the slide cover up using the slide knob. Next, insert the red test lead to V and the black test lead to COM of the voltage measurement terminal.
- 3. Switch between the auto range and the manual range as necessary.
- 4. Attach or remove the rigid insulating sleeve as required by the measurement category.
- 5. Carefully contact the test leads to a circuit.
- Be sure to use the test leads with the sleeves NOTE attached when performing measurements in the CAT III measurement category. In a CAT II environment, if the tips of the test leads do not reach the measurement object, remove the rigid insulating sleeve before measuring.
  - · Just after suspension of input, or when modes are switched under no input, the counter would not become zero for about 10 seconds. This is normal and simply reflects the workings of the internal circuit. But you can measure with guaranteed accuracy before the counter becomes zero.
  - Depending on ambient temperatures, the counter would not become zero under no input, if this happens, press **HOLD** and then press **OADJ/RESET** to perform a zero-cancel correction. (2.5.2: Zerocancel correction function)
  - During a f.s. input, the measurement response speed is about 250 ms during rise (0% to 90%) and about 500 ms (100% to 10%) during fall (2.2.5, Figs. 1 and 2).

NOTE	<ul> <li>The AC V mode does not allow measurement of DC waveforms, full-wave rectification waveforms, half-wave rectification waveforms, or DC+AC waveforms (See 1.5: Modes).</li> <li>Every range will display up to 125% of the range, however, only the range from 10% to 100% can be displayed with guaranteed accuracy.</li> <li>At any range, gross errors may occur at 1% or below of the range, whose accuracy is not guaranteed, as a result of internal corrective calculations.</li> </ul>
2.3.3	<ul> <li>Measuring AC/DC Voltage (AC+DC V)</li> <li>1. Press x to display ₹.</li> <li>2. Slide the slide cover up using the slide knob. Next, insert the red test lead to V and the black test lead to COM of the voltage measurement terminal.</li> </ul>

- 3. Switch between the auto range and the manual range as necessary.
- If the counter does not show zero even after display stabilizes, switch to the range you will use (a manual range), press **HOLD** and then press **OADJ/RESET** to perform a zero-cancel correction. (2.5.2: Zero-cancel correction function)
- 5. Attach or remove the rigid insulating sleeve as required by the measurement category.
- 6. Carefully contact the test leads to a circuit.
- (NOTE)

• Be sure to use the test leads with the sleeves attached when performing measurements in the CAT III measurement category. In a CAT II environment, if the tips of the test leads do not reach the measurement object, remove the rigid insulating sleeve before measuring.

27

NOTE) • When you switch ranges after zero-cancel correction, deviation of the correction value will prevent accurate measurement. (Do not perform a zero-cancel correction when using the auto range.) If you accidentally perform zero-cancel correction while using the auto range, repeat zero-cancel correction after turning the power off once and then on again.

- Just after suspension of input, or when modes are switched under no input, the counter would not become zero for about 10 seconds. This is normal and simply reflects the workings of the internal circuit. But you can measure with guaranteed accuracy before the counter becomes zero.
- The polarity of the input is not displayed, even if DC voltage is measured in this mode. If the connections of test leads are moved, the measured values may change, but the values are within the guaranteed accuracy. (In case that you would like to measure DC voltage which doesn't have AC components, you should make the measurement in DC V mode.)
- During a f.s. input, the measurement response speed is about 250 ms during rise (0% to 90%) and about 500 ms (100% to 10%) during fall (2.2.5. Figs. 1 and 2).
- Every range will display up to 125% of the range, however, only the range from 10% to 100% can be displayed with guaranteed accuracy.
- At any range, gross errors may occur at 1% or below of the range, whose accuracy is not guaranteed, as a result of internal corrective calculations.

### 2.3.4 Peak Hold Measurement

- 1. Press  $\mathbf{\overline{v}}$  and select a measurement mode for the measured circuit.
- 2. Slide the slide cover up using the slide knob. Next, insert the red test lead to V and the black test lead to COM of the voltage measurement terminal.

3. Set to **PEAK**. The measurement mode is switched by **SLOW/PEAK/Hz** as follows.

→ SLOW → FAST → PEAK → Hz → NORMAL-J (The unit (Except symbol blinks.) DC)

- 4. Switch between the auto and the manual range as necessary. (If you are unable to estimate the peak voltage value, start at the 600 V range.)
- 5. Attach or remove the rigid insulating sleeve as required by the measurement category.
- 6. Carefully contact the test leads to a circuit.
- 7. Before the measurement, press **OADJ/RESET** to reset the residual data.
- Be sure to use the test leads with the sleeves attached when performing measurements in the CAT III measurement category. In a CAT II environment, if the tips of the test leads do not reach the measurement object, remove the rigid insulating sleeve before measuring.
  - The polarity of the input is not displayed during peak measurements. If the connections of test leads are moved, the measured values may change, but the values are within the guaranteed accuracy.
  - You can capture from pulses with a width of about more than 1 ms.
  - To check transitional peak value, press **MAX/MIN** to shift to the Instantaneous value (no annunciator).
  - In peak measurement mode, zero-adjustment is disabled.

→MAX → MIN → AVE →Instantaneous value – (no annunciator)

### 2.4 Frequency Measurement

### 2.4.1 Frequency Measurement in Current Mode

- 1. Press 🛣 and select AC or AC+DC, depending on the circuit to be measured.
- 2. If the current range of the measured circuit is known, set the current range to the manual range.
- 3. **SLOW/PEAK/Hz** switches the annunciators as follows. Select Hz by pressing the key. (The unit symbol **A** blinks, and a current value is displayed on the bar graph.)

SLOW → FAST→ PEAK → Hz→ RMS-(The unit symbol blinks.)

- 4. Switch the auto range and the manual range as necessary.
- 5. Open the top ends of the jaws and clamp the measured conductor so that it passes through the center of the jaws.
- (NOTE)

At the 100 Hz and 1000 Hz ranges, ---- appears on

- the counter when the frequency is lower than 10 Hz.
  ---- appears on the counter, if the frequency is lower than 1 Hz.
- **O. L.** appears on the counter, if the frequency is higher than 1 kHz.
- If an input value is significantly lower than the range, an accurate measurement may not be achieved, resulting in ----, **O. L.** or display fluctuations.
- The 10 Hz range or 100 Hz range will display up to 125% of each range, however, only the range from 10% to 100% can be displayed with guaranteed accuracy.
- MAX/MIN does not affect output values.

NOTE	<ul> <li>The frequencies, whose waveforms are special such as inverters, would not be measurable, when the carrier frequencies are lower than several kHz.</li> <li>Full-wave rectification indicates twice the actual value, due to an AC coupling in the internal circuit.</li> <li>It would take time to stabilize the counter, depending on the frequency range or the input frequency.</li> </ul>
2.4.2	<ol> <li>Frequency Measurement in Voltage Mode</li> <li>Press value and select AC or AC+DC, depending on the circuit to be measured.</li> <li>If the voltage range of the measured circuit is known, set the voltage range to the manual range.</li> <li>Slide the slide cover up using the slide knob. Next, insert the red test lead to V and the black test lead to COM of the voltage measurement terminal.</li> </ol>

- SLOW/PEAK/Hz switches the annunciators as follows. Select Hz by pressing the key. (The unit symbol V blinks, and a voltage value is displayed on the bar graph.)
- ↓ SLOW → FAST → PEAK → Hz → NORMAL / (The unit symbol blinks.)
  - 5. Switch between the auto range and the manual range as necessary.
  - 6. Attach or remove the rigid insulating sleeve as required by the measurement category.
  - 7. Carefully contact the test leads to a circuit.



• Be sure to use the test leads with the sleeves attached when performing measurements in the CAT III measurement category. In a CAT II environment, if the tips of the test leads do not reach the measurement object, remove the rigid insulating sleeve before measuring.

31

32

### NOTE

- At the 100 Hz and 1000 Hz ranges, ---- appears on the counter when the frequency is lower than 10 Hz.
- ---- appears on the counter, if the frequency is lower than 1 Hz.
- **O. L.** appears on the counter, if the frequency is higher than 1 kHz.
- If an input value is significantly lower than the range, on accurate measurement may not be achieved, resulting in ----, **O. L.** or display fluctuations.
- The 10 Hz range or 100 Hz range will display up to 125% of each range, however, only the range from 10% to 100% can be displayed with guaranteed accuracy.
- The frequencies, whose waveforms are special such as inverters, would not be measurable, when the carrier frequencies are lower than several kHz.
- Full-wave rectification indicates twice the actual value, due to an AC coupling in the internal circuit.
- It would take time to stabilize the counter, depending on the frequency range or the input frequency.

### 2.4.3 Output Function for Frequency

Frequency measurement output is available only in current modes.

An output of DC 1 V is produced for 1000-count on the full scale of the frequency range. An output is produced twice per second, the same as display refreshing. (The output waveform will be in step form for a large frequency change, due to D/A outputs.)

- 1. To make settings, refer to the frequency measurement procedure in a current mode.
- 2. Press **OUTPUT** . **REC** annunciator lights and activates the output function.

#### Chapter 2 Measurement Procedure

- 3. The auto power-off function is automatically disabled. (APS annunciator is tuned off.)
- 4. Set a range based on the unit's measurement range and other instruments, such as recorders.

Range/DIV	10 mV	20 mV	50 mV	0.1 V	0.2 V	0.5 V	1 V
1000 Hz range	10 Hz	20 Hz	50 Hz	100 Hz	200 Hz	500 Hz	1000 Hz
100 Hz range	1 Hz	2 Hz	5 Hz	10 Hz	20 Hz	50 Hz	100 Hz
10 Hz range	0.1 Hz	0.2 Hz	0.5 Hz	1 Hz	2 Hz	5 Hz	10 Hz

The figures are frequency values per DIV of a measuring instrument, such as a recorder.

- (NOTE)
- Before using the output function, be sure to press OUTPUT, confirming that **[REC]** annunciator is on. When **[REC]** annunciator is off, the output is for current measured values.
- No auto-zero-adjustment is available in AC +DC A mode.
- If [OUTPUT] is pressed in the auto range (AUTO), the frequency range is set as the key is pressed. (AUTO annunciator is turned off.)
- If you press **HOLD**, the frequency output is also held.
- The display "----" corresponds to 0 V output and the display "**O.L.**" corresponds to 1.36 V output respectively.
- To connect a recorder, use the optional'N; 094 OUTPUT CORD.
- For recorders, use over  $1 M\Omega$  input impedance.
- Current measurements will continue to be recorded when you shift to the frequency measurement mode during current measurement recording. To obtain frequency measurements, press **OUTPUT** to disable the current measurement mode, then make the new settings.
- For a long term measurement, use the optional 9445-02 AC ADAPTER.
- When the AC adapter is used and there is a large amount of noise in the power line, the display may show several counts or noise may be present in the output. In such a case, connect the ground terminal of the level recorder or the L side of the input to ground.

### 2.5 Auto-Zero-Adjustment/ Zero-Cancel Correction Function

### 2.5.1 Auto-Zero-Adjustment Function

The auto-zero-adjustment function is used to adjust offsets in the internal circuit automatically that result from temperature characteristics or jaws magnetization. The jaws is magnetized during a large DC current measurement, or when a powerful magnet is placed close to the jaws.

1. Wait until the counter is stable under no input. Then, press **OADJ/RESET**. **ADJ** annunciator lights.



- You can perform the auto-zero-adjustment, if the counter displays within  $\pm 45$  A in a current mode.
- When there is an input or the counter decreases, the measurement accuracy will be spoiled by pressing 0ADJ/RESET as well as the accurate auto-zero-adjustment. If inaccurate auto-zero-adjustment is perform the correct procedure again.
- It would take approximately 20 seconds to stabilize the counter in AC+DC A mode.
- Use the zero-cancel correction function if the counter fails to revert to zero after correct auto-zero-adjustment in <u>AC+DC A</u> mode.
- If you press **DADJ/RESET** again during the autozero-adjustment in the internal circuit, the auto-zeroadjustment is canceled.
- •Do not perform auto-zero adjustment when using auto range in the DC V mode. Always switch to the range you will use (a manual range) before performing the adjustment.

### 2.5.2 Zero-Cancel Correction Function

Use the zero-cancel correction function when the counter fails to become zero under no input in AC A, AC+DC A, AC V, or AC+DC V mode.

- 1. Press **HOLD** to display **HOLD** annunciator.
- 2. Press **0ADJ/RESET** . **ADJ** annunciator blinks.
- Do not perform a zero-cancel correction when using the auto range. Always switch to the range you will use (a manual range) before performing the adjustment.
  - When there is an input or the counter decreases, the measured values will be evaluated lower by pressing **OAJD/RESET**.
  - If the counter is zero, the zero-cancel correction function does not work.
  - In AC+DC A mode, the zero-cancel correction function does not work, unless auto-zero-adjustment is complete.
  - The zero-cancel correction function works only on the counter. It will not calibrate output values.

### 2.6 Data Hold Function



This function freezes the counter at any desired point for easy reading.

1. Press **HOLD**. **HOLD** annunciator lights on the display and the digital display value and bar graph display are maintained.

The data hold function is available for all measurements.

To cancel the data hold function, press **HOLD** again. If you press **RANGE** during the data hold function, the bar graph display the present range.

### 2.7 Alteration of Counter Updates

The counter is updated twice per second when powering on. The counter update may be altered according to measurement conditions.

**SLOW/PEAK/Hz** changes an annunciator as follows:

→ SLOW → FAST → PEAK → Hz → NORMAL-(The unit (Except DC) annunciator blinks.)

### 2.7.1 SLOW Mode

If the counter fluctuates rapidly and is hard to read, you can select a slower update rate (once every 3 seconds) by pressing **SLOW/PEAK/Hz**.

### 2.7.2 FAST Mode

- For current measurements and voltage measurements, the counter is updated four times per second in FAST mode.
   You can measure abrupt changes such as starting currents.
- The unit symbol **A** or **V** blinks.
- To facilitate reading when measuring a starting current, use the record (**REC**) function to hold the maximum value (**MAX**).

### 2.8 Recording Function REC

Use the recording function to hold the maximum and minimum measured values and maximum/minimum averages.

 Measurement indicated value Pressing the MAX/MIN key during measurements of current or voltage activates the recording function. REC flashes and the product saves the maximum value (MAX), minimum value (MIN), and average value (AVE) in internal memory from the instant you press the **MAX/MIN** key. Pressing the **MAX/MIN** key with the recording function activated switches the display as shown below. If MAX, MIN, or AVE is not displayed, an instantaneous value is assumed.

### MAX MIN AVE Instantaneous value − (no annunciator)

Data (MAX, MIN, AVE) remains displayed while the display is switched. If maximum or minimum data is updated in the meantime, however, the data values will change.

With the recording function activated, the auto power-off function remains disabled. (APS off.) The average value (AVE) displayed is calculated by: Average Value = [(Maximum value + Minimum Value)/2].

If the recording function is activated and Instantaneous value (no annunciator) selected after you activate PEAK mode with the **SLOW/PEAK/Hz** key, you can see the fluctuation of the peak.

### 2. Display of Elapsed Time

When you press the **MAX/MIN** key to activate the recording function, the bar graph segments flash and the elapsed time appears.

When "**min**" is shown in the right-hand corner of the bar graph, each segment of the bar graph corresponds to one minute. Every time one minute elapses, one segment of the flashing bar graph goes on. When all segments on the bar graph go on, the elapsed time is 30 minutes.

When the elapsed time exceeds 30 minutes, one segment of the flashing bar graph goes off every

time one minute elapses.

When the segments left of a flashing segment remain on: the number of "on" segments represents the elapsed time  $(0 \sim 29)$ .

The illustration below shows when 20 minutes have elapsed:

### 0 1 2 3 1....1...1...1...1...1 min

When the segments right of a flashing segment remain on: the number of "off" segments (+30) represents the elapsed time  $(30 \sim 59)$ .

The illustration below shows when 50 minutes have elapsed:

### 0 1 2 3 1....1....1....1....1 min

When digital display switches the average value (AVE) to a instantaneous value when you press the **MAX/MIN** key, the right corner of the bar graph indicates hours. In this mode, each segment of the bar graph corresponds to one hour. The way to read the bar graph here is similar to reading it in minutes. When all bar graph segments remain on, the elapsed time is 29 hours.

The illustration below shows when one hour, 40 minutes have elapsed.  $1^{\circ}$ 

- 3. Deactivation of Recording Function Pressing the HOLD key deactivates the recording function. HOLD goes on, REC stops flashing and goes on, and the elapsed time stops incrementing. While the recording function is being deactivated, data is not updated, even if the jaws is disconnected from the conductor. Pressing the HOLD key again cancels HOLD display and activates the recording function again,
- with **REC** flashing again. 4. Resetting of Recording Function
- Push **OADJ/RESET** key, in the case that data is reset during the recording function action.
- 5. Cancellation of Recording Function To cancel the recording function, press the related function key (A or V) for the measurement in progress. Once the recording function is canceled, the auto power-off function becomes effective. (APS goes on.)
- For a long term measurement, use the optional 9445-02 AC ADAPTER, or check how much the battery power remains by pressing **OUTPUT**.
  - When starting the recording function (**REC**) in an auto range, the range is set as the range of when that pushed **MAX/MIN** key.

### (NOTE)

- When you need minimum value and average value data, make sure to activate the recording function during measurement. If the function is activated when there is no input, the minimum value will remain zero. Also, when deactivating the recording function, press the **HOLD** key to terminate measurement once the minimum value and average value data have been read. If you disconnect the clamp or test lead from the circuit under measurement without deactivating the recording function beforehand, the minimum value will be zero.
  - When the unit is turned off, accumulated data are lost.

### 2.9 Auto Power-Off Function



- When the **APS** annunciator is displayed, the auto power-off function is active.
- If no key is pressed for about 10 minutes, the unit turns itself off automatically.
- Immediately before turning off automatically, **APS** annunciator blinks and a beep tone is heard for about 30 seconds.
- By pressing any key except **POWER**, you will extend the powered state for another 10 minutes.

Procedure for disabling the auto power-off function.

- Press **POWER** with holding down **HOLD**, when you turn power on.
- Use the recording function (**REC**) by pressing  $\boxed{MAX/MIN}$ .
- Press **OUTPUT** in a current mode.

#### Chapter 2 Measurement Procedure

### 2.10 Battery Low Warning

- When this indication appears, the battery is depleted. During which time accuracy cannot be guaranteed. Replace the battery as soon as possible.
- To check remaining battery life, check the bar graph, when powering on or by pressing **OUTPUT**. The bar graph provides a rough approximation of remaining battery life. Be careful for the battery life especially before using an output function for a long term or when using the REC function.
- Batteries tend to increase in voltage somewhat when left unused for a long period. Even if the battery warning annunciator becomes temporarily off after the period, replace the battery as soon as possible. If the battery is not replaced at this point in time, the annunciator may not light up immediately on the next occasion. Replace a new battery before it ruins a measurement or causes some other inconvenience. (See Chapter 4: Battery replacement)

### 2.11 Beep Tone

To disable the beep tone, hold **RANGE** when turning the unit on by pressing **POWER**.

R

## Chapter 3 Specifications

### 3.1 Measurement Specifications

Temperature and humidity for guaranteed accuracy	23 $\pm$ 5 (73°F $\pm$ 9°F), 80% RH or less (no condensation), Battery warning indicator <b>B</b> is off.
Guaranteed accuracy period	1 year, or opening and closing of the jaws 10,000 times, whichever comes first

### 3.1.1 Current Measurement Specifications

#### Current display accuracy

#### DC current A (mean value)

Range (Accuracy Range)	Resolution	DC
200A(±10.0~±200.0A)	0.1A	±1.3%rdg.±3dgt.
2000A(±100~±2000A)	1A	±1.3%rdg.±3dgt.

#### AC current Arms (true rms)

Range (Accuracy Range)	Resolution	45 ~ 66Hz	10~45,66~1kHz
200A(10.0~200.0A)	0.1A	±1.3%rdg.±3dgt.	± 2.0%rdg. ± 5dgt.
2000A (100 ~ 1800A) (1800 ~ 2000A)	· 1A	±1.3%rdg.±3dgt.	± 2.0%rdg. ± 5dgt.
(1800 ~ 2000A)	IA	±2.3%rdg.±3dgt.	

#### AC+DC current Arms (true rms)

Range (Accuracy Range)	Resolution	DC,45~66Hz	10~45,66~1kHz
200A(10.0~200.0A)	0.1A	±1.3%rdg.±13dgt.	± 2.0%rdg. ± 7dgt.
2000A (100 ~ 1800A) (1800 ~ 2000A)	· 1A	±1.3%rdg.±13dgt.	± 2.0%rdg. ± 7dgt.
(1800 ~ 2000A)	IA	±2.3%rdg. ±13dgt.	

### Output accuracy

### DC current A (mean value)

Range (Accuracy Range)	MON	DC
$200A(\pm 10.0 \sim \pm 200.0A)$	1V/f.s.	±1.3%rdg.±5mV
2000A(±100~±2000A)	1V/f.s.	±1.3%rdg.±5mV

#### AC current Arms (true rms)

### MON

Range (Accuracy Range	e) MON	45 ~ 66Hz	10~45,66~1kHz
200A(10.0~200.0		±1.3%rdg.±5mV	±2.0%rdg.±5mV
2000A (100 ~ 1800A (1800 ~ 2000	) AC1V/f.s.	± 1.3%rdg. ± 5mV	±2.0%rdg.±5mV
(1800 ~ 2000)	A)	±2.3%rdg.±5mV	

#### frequency bandwidth: $0.5 \sim 15 \text{kHz} (\pm 3 \text{dB})$

### REC

Range (Accuracy Range)	REC	45 ~ 66Hz	10~45,66~1kHz
200A(10.0~200.0A)		±1.3%rdg.±10mV	±2.0%rdg.±10mV
2000A (100 ~ 1800A) (1800 ~ 2000A)	DC1V/f.s.	±1.3%rdg.±10mV	±2.0%rdg. ±10mV
(1800 ~ 2000A)		±2.3%rdg.±10mV	

Output response (during a f.s. input):

Rise response time (0% to 90%) 250 ms or less Fall response time (100% to 10%) 500 ms or less

AC+DC current Arms (true rms)

### MON

Range (Accuracy Range)	MON	DC,45~66Hz	10~45,66~1kHz
200A(10.0~200.0A)		±1.3%rdg.±5mV	±2.0%rdg.±5mV
2000A (100 ~ 1800A) (1800 ~ 2000A)	1V/f.s.	±1.3%rdg.±5mV	±2.0%rdg.±5mV
(1800 ~ 2000A)		±2.3%rdg.±5mV	

frequency bandwidth:DC ~ 15kHz (±3dB)

REC

Range (Accuracy Range)	REC	DC,45~66Hz	10~45,66~1kHz
200A(10.0~200.0A)		±1.3%rdg.±10mV	±2.0%rdg.±10mV
2000A (100 ~ 2000A) (1800 ~ 2000A)	DC1V/f.s.	±1.3%rdg.±10mV	±2.0%rdg.±10mV
(1800 ~ 2000A)		±2.3%rdg.±10mV	

Output response (during a f.s. input):

Rise response time (0% to 90%) 250 ms or less Fall response time (100% to 10%) 500 ms or less

Peak measurement accuracy (Peak hold function) During continuous input of sine waves

DC current A peak (wave peak value)

(Accu	Range uracy Range)	Resolution	DC
200	A(10~500A)		±1.3%rdg.±7dgt.
00004	(100~2300A)	1A	±1.3%rdg.±7dgt.
2000A	(100 ~ 2300A) (2300 ~ 2840A)		±6.0%rdg.±7dgt.

AC current A peak (wave peak value)

(Acci	Range uracy Range)	Resolution	45 ~ 66Hz	10~45,66~1kHz
	A(10~500A)			± 2.0%rdg. ± 7dgt.
00004	(100~2300A)	1A	±1.3%rdg.±7dgt.	± 2.0%rdg. ± 7dgt.
2000A	(100 ~ 2300A) (2300 ~ 2840A)		±6.0%rdg.±7dgt.	

AC+DC current A peak (wave peak value)

(Acci	Range uracy Range)	Resolution	DC,45~66Hz	10~45,66~1kHz
200	A(10~500A)			± 2.0%rdg. ± 7dgt.
00004	(100 ~ 2300A) (2300 ~ 2840A)	1A	±1.3%rdg.±7dgt.	± 2.0%rdg. ± 7dgt.
2000A	(2300 ~ 2840A)		±6.0%rdg.±7dgt.	

### Frequency measurement Hz

### Display accuracy

Range (Accuracy Range)	Resolution	
10Hz(1.00~10.00Hz)		±0.3%rdg.±1dgt.
100Hz(10.0~100.0Hz)	0.1Hz	±0.3%rdg.±1dgt.
1000Hz(100~1000Hz)	1Hz	±1.0%rdg.±1dgt.

Output accuracy

Range (Accuracy Range)	REC	
10Hz(1.00~10.00Hz)	DC1V/f.s.	±1.3%rdg.±3mV
100Hz(10.0~100.0Hz)	DC1V/f.s.	±1.3%rdg.±3mV
1000Hz(100~1000Hz)	DC1V/f.s.	±2.0%rdg.±3mV

Output response: 4 seconds or less at 1000Hz and 100Hz ranges, 6 seconds or less at 10Hz range

Current Specifications	
Maximum permissible current	2000 A rms continuous, 2840 A max. See Fig.4.
Effect of conductor position	Within $\pm 0.7\%$ (in any direction from sensor center)
External magnetic field interference	AC 400 A/m (external magnetic fields) corresponds to 2 A or less (display)
Maximum rated voltage to earth	Max. 600 Vrms



Fig.4 Frequency-dependent deletion characteristics

### 3.1.2 Voltage Measurement Specifications

Voltage display accuracy

### DC voltage V (mean value)

Range (Accuracy Range)	Resolution	DC
$30V(\pm 3.00 \sim \pm 30.00V)$	0.01V	± 1.0%rdg. ± 3dgt
$300V(\pm 30.0 \sim \pm 300.0V)$	0.1V	±1.0%rdg.±3dgt.
$600V(\pm 60.0 \sim \pm 600V)$	1V	±1.0%rdg.±3dgt.

### AC voltage Vrms (true rms)

Range (Accuracy Range)	Resolution	45 ~ 66Hz	10~45,66~1kHz
30V(3.00~30.00V)	0.01V	±1.0%rdg.±3dgt.	± 1.5%rdg. ± 5dgt.
300V(30.0~300.0V)	0.1V	±1.0%rdg.±3dgt.	±1.5%rdg.±5dgt.
600V(60.0~600V)	1V	±1.0%rdg.±3dgt.	±1.5%rdg.±5dgt.

### AC+DC voltage Vrms (true rms)

Range (Accuracy Range)	Resolution	DC,45~66Hz	10~45,66~1kHz
30V(3.00~30.00V)	0.01V	±1.0%rdg. ±13dgt.	±1.5%rdg. ±13dgt.
300V(30.0~300.0V)	0.1V	±1.0%rdg.±7dgt.	±1.5%rdg.±7dgt.
600V(60.0~600V)	1V	±1.0%rdg.±7dgt.	±1.5%rdg.±7dgt.

Peak measurement accuracy (Peak hold function) During continuous input of sine waves

### DC voltage V peak (wave peak value)

Range (Accuracy Range)	Resolution	DC
30V(3.0~75.0V)	0.1V	±1.0%rdg. ±7dgt.
300V(30~750V)	1V	±1.0%rdg.±7dgt.
600V(60~1000V)	1V	±1.0%rdg.±7dgt.

#### AC voltage V peak (wave peak value)

Range (Accuracy Range)	Resolution	45 ~ 66Hz	10~45,66~1kHz
30V(3.0~75.0V)	0.1V	±1.0%rdg. ±7dgt.	±1.5%rdg.±7dgt.
300V(30~750V)	1V	±1.0%rdg. ±7dgt.	±1.5%rdg.±7dgt.
600V(60~1000V)	1V	±1.0%rdg.±7dgt.	±1.5%rdg.±7dgt.

#### Chapter 3 Specifications

### AC+DC voltage V peak (wave peak value)

Range (Accuracy Range)	Resolution	DC,45~66Hz	10~45,66~1kHz
30V(3.0~75.0V)	0.1V	±1.0%rdg.±7dgt.	± 1.5%rdg. ± 7dgt.
300V(30~750V)	1V	±1.0%rdg.±7dgt.	± 1.5%rdg. ± 7dgt.
600V(60~1000V)	1V	±1.0%rdg.±7dgt.	± 1.5%rdg. ± 7dgt.

Frequency measurement Hz

### Display accuracy

Range (Accuracy Range)	Resolution	
10Hz(1.00~10.00Hz)	0.01Hz	±0.3%rdg.±1dgt.
100Hz(10.0~100.0Hz)	0.1Hz	±0.3%rdg.±1dgt.
1000Hz(100~1000Hz)	1Hz	±1.0%rdg.±1dgt.

## 3.2 General Specifications

Accessory Functions:	
Auto-zero adjustment function	Pressing <b>OADJ/RESET</b> once in DC A or AC+DC A mode.
Zero cancel function	Pressing <b>OADJ/RESET</b> once with holding <b>HOLD</b> in AC or AC+DC mode.
Recording	Maximum (MAX), minimum (MIN), average (AVE) value display selectable for current, voltage and frequency measurements
Data hold	Data hold function
Auto power-off	Automatic shutdown after $10.5\pm1$ minutes. Beep tone warning before the shutdown. Extending and disabling possible.
Beep tone	ON/OFF

Display	LCD panel
Digital counter	2500 counts max. (current)
	but 2000 counts at 2002 A range
	3750 counts max. (voltage)
	but 750 counts at 600 V range
	1250 counts max. (frequency)
	but 1000 counts at 1000 Hz range
Bar graph display	35 segments
Over-range display	" <b>O.L</b> ." ► (bar graph)
Battery low warning	B goes on (during which time accuracy
	cannot be guaranteed).
Data hold annunciator	HOLD
Auto power-off	APS
annunciator	
Units	A, V, Hz
Zero suppression	5 counts
Display update rate	Digital counter
	NORMAL Approx. 2 times/second
	SLOW Approx. 1 time/3 seconds FAST Approx. 4 times/second
Par graph	approx. 4 times/second
Bar graph	11
Display response time (the range is fixed,	Current, Voltage: 1 s max.
0% to 100%)	Frequency: 1 s max. (1000 Hz, 100 Hz range)
	2.5  s max. (1000  Hz, 100  Hz range)
Range switching	Auto range, manual (fixed) range
Range switching	(selectable).
Output impedance	$300\Omega$ max.
Output impedance	
Circuit dynamic characteristics	2.5 max. (1.42 for 2000 A range, 1.7 for
(crest factor)	600 V range)
Dielectric strength	Between the case and input terminals,
Biolocato calongat	case and jaws AC 5400 Vrms/ 1 minute
Effect of conducted	Current measurement: -3 A or less
radio-frequency	Current incustrement. 5 11 of 1655
electromagnetic field	
(in 3 V)	
Location for use	Indoor, altitude up to 2000 m

Applicable standards	Safety: EN61010
	Pollution level 2, Measurement category III
	(expected transient overvoltage: 6000 V)
	EMC:
	ENG1326
	EN61000-3-2
	EN61000-3-2 EN61000-3-3
Dust resistance	EN60529 IP40
Maximum conductor diameter for	$\phi$ 55 mm max.
measurement	
Operating temperature	0 to 40°C (32 to 104°F),
and humidity range	
,	80%RH or less (no condensation)
Temperature characteristics	In 0 to 40 °C range: $0.1 \times accuracy$
	specifications/°C
Storage temperature	-10 to 50°C
range	(14 to 122°F, no condensation)
Power source	One 6F22 (006P) 9 V battery or
	9445-02 AC ADAPTER (option)
Maximum power	110 mVA
consumption	
Battery life	Approx. 25 hours (continuous, no load)
External dimensions	Approx. 62W×260H×39D mm
	Approx. 2.44"W×10.24"H×1.54"D
Mass	Approx. 540 g
	Approx. 19.0 oz.
Accessories	L9207-10 TEST LEAD (red and black) 1
	9345 CARRYING CASE 1
	Hand Strap 1
	6F22(006P) 1
	Instruction manual 1
Options	9445-02 AC ADAPTER
-	L9094 OUTPUT CORD
Product warranty	3 years
period	

### Chapter 4 Battery Replacement

A CAUTION

Do not fix the screws of the rear cover too tightly. The torque about 0.5N• m is recommended.

- •A 6LR61 battery improves the operation.
  - •Each of positive and negative terminals of nine-volt layered-type dry batteries differ slightly in shape and size according to manufactures and types. When attaching the battery onto the battery snap, you may notice them fastened each together tightly or loosely. Even then, the instrument will work if the battery with the battery snap attached is installed properly in the battery holder.

- 1. Remove the two fastening screws of the rear cover, using a Phillips screwdriver.
- 2. Remove the rear cover.
- 3. Remove the old battery without pulling the codes of the snap.
- 4. Attach the new battery onto the battery snaps, paying attention to the polarity, and then install the battery in the battery holder.
- 5. Fasten the rear cover.
- Screw in the fastening screws to fasten the rear cover.


## Chapter 5 AC Adapter (Optional)

Fully insert the optional 9445-02 AC ADAPTER into the AC adapter connection terminal.

## NOTE

- The adapter may be used either with or without a battery.
- Use of a battery enables continuous measurement if the AC power source temporarily becomes unavailable, due to a blackout or some other reason.
- When the power supply changes the battery to the AC adapter such as back from a blackout, the following would be shown,
  - 1. **MON** output waveform during current measurement:

After the output shifts for approximately 10 ms, the accurate output will be obtained.

It is recommended that **REC** output in AC+DC A mode should be used, when you would like to make a long term measurement on DC A and a blackout is likely to happen.

2. REC output waveform during frequency measurement:

After the output shifts for approximately 10 ms, the accurate output will be obtained.

3. Peak hold measurement: An inaccurate big value will be held.

- All of them will impact more largely as the battery voltage is lower relative to the AC adapter voltage (typ. 9 V). It is recommended that a new battery should be used, when the blackout seems to be short.
  - The battery will be preferred as the power source when the battery voltage is higher than the voltage that supplied by the AC adapter (typically the case with a brand-new battery). When battery voltage dips below the AC adapter, the source automatically switches over to the AC adapter.
  - The remaining battery charge (indicated by the bar graph), when used with the AC adapter, is based on the AC adapter voltage. It is not a display for battery life in this case.

## Chapter 6 Attaching the Hand Strap

Explains how to attach the hand strap, for easy handling of the unit in the field.



# Chapter 7 Troubleshooting

If the unit seems not to be working normally, check the following points first before requesting service.

Symptom	Battery	Battery clip	Test leads
Unit does not come on.	Yes	Yes	
indication appears and unit immediately turns off.	Yes		
indication appears.	Yes		
Unit turns off during use.*	Yes	Yes	
Voltage cannot be measured.			Yes
Remedy: If problem persists, request service.	Replace battery.	Check connection of battery to clip.	Check test leads for broken wire.



When APS (auto power-off) is effective, the unit is automatically shut down when no key is pressed for about 10 minutes. (See 2.9, "Auto Power-Off Function.")

Repair is required if E.001 to E.005 is indicated on the counter, when power is turned on.

If no power is supplied:

- If you're using a battery, check that it has sufficient remaining power. (See 2.1: Preparations )
- If you're using the AC adapter, check that it's fully inserted into the AC adapter terminal and socket.
- If no power is supplied by the AC adapter but the battery works, the adapter may be defective. (Make sure that you're using the 9445-02 AC ADAPTER.)

The counter doesn't become zero:

- If this occurs in DC A, AC+DC A or DC V modes, use the auto-zero adjustment function (2.5.1).
- If this occurs in AC A, AC V or AC+DC V mode, use the zero-cancel correction function (2.5.2).
- If this occures in AC + DC A mode after performing the suto-zero-adjustment, perform the zero cancel correction function (2.5.2).

The measured value is smaller than the estimated value.

## Current measurement:

- · Check that the jaws is firmly closed.
- Check that the frequency of the measured circuit is within the range provided in the specifications. (A smaller value will be displayed for a high inverter carrier frequency.)
- Check that the proper steps have been taken, according to procedure described in 2.5.1: Auto-zero adjustment function and 2.5.2: Zero-cancel correction function.
- Check that you're using the proper mode. (See 1.5: Modes.)
- Check that the peak value is below the circuit dynamic value provided in the specifications. (To check transitional peak values, see Notes in 2.2.4 and 2.3.4: Peak hold measurement.)
- Check that the crest factor (peak value / RMS value) is below the circuit dynamic value provided in the specifications.
- · Check that the battery warning annunciator is off.

## Voltage measurement:

- Check that the test leads are fully connected.
- Check that the frequency of the measured circuit is within the range provided in the specifications.
- Check that the proper steps have been taken, according to the procedure described in 2.5.1: Auto-zero adjustment function and 2.5.2: Zero-cancel correction function.
- Check that you're using the proper mode. (See 1.5: Modes.)
- Check that the peak value is below the circuit dynamic value provided in the specifications. (To check transitional peak value, see Notes in 2.2.4 and 2.3.4: Peak hold measurement.)

- Check that the crest factor (peak value / RMS value) is below the circuit dynamic value provided in the specifications.
- · Check that the battery warning annunciator is off.

### Frequency measurement:

- Check the waveform. Some special frequencies can't be measured, such as those of inverters.
- Check that the input value corresponds to 10% or more of the range.

The measured value is larger than the estimated value.

## Current measurement:

- Check that you're using the proper range.
- Examine the waveform using **MON** output function to confirm that no components but the estimated frequency are being used.
- Check that the counter has been reset with **OADJ/RESET** before peak measurement.
- Look for magnetic fields, electrical fields or possible noise sources near the unit.
- The measured value would be bigger than the actual value in case that the power supply changes the battery to the AC adapter such as back from a blackout. (See Chapter 5: AC Adapter (Optional) )

## Voltage measurement:

- Check that you're using the proper range.
- Check that the counter has been reset with **OADJ/RESET** before peak measurement.
- Look for magnetic fields, electrical fields or possible noise sources near the unit.

### Frequency measurement:

- Look for magnetic fields, electrical fields or possible noise sources near the unit.
- Check the waveform. Some special frequencies can't be measured, such as those of inverters.
  - The output value is smaller than the estimated value.
- Take the same precautionary steps as for the measured value on the counter.
- Make sure the L9094 OUTPUT CORD is fully connected.
- Make sure you've selected the proper output mode (**REC** or **MON**).
- Make sure the previously selected output mode (current or frequency) is not active.
- Check that the input impedance of the connected measuring instrument is at least 1 M $\Omega$ .
- Check that the mode of the connected measuring instrument is not an AC coupling, or that the filter function is disabled.

The output value is larger than the estimated value.

- Take the same precautionary steps as for the measured value on the counter.
- Check that you've selected the proper output mode (**REC** or **MON**).
- Check that the previously selected output mode (current or frequency) is not active.
- The output value would shift in case that that the power supply changes the battery to the AC adapter during MON output on current measurement on **REC** output on frequency measurement. (See Chapter 5: AC Adapter (Optional) )

64

The measured value fluctuates.

- · Check that the measured circuit is stable.
- During voltage measurements, check that the test leads are fully connected.
- Check the waveform. Some special frequencies can't be measured, such as those of inverters.

## Chapter 8 Service

65

- The minimum stocking period for replacement parts is five years after end of production.
- For information regarding service, please contact your dealer or the nearest HIOKI representative.
- If the unit is not functioning properly, check the battery. If a problem is found, contact your dealer or HIOKI representative. Pack the unit carefully so that it will not be damaged during transport, and write a detailed description of the problem. HIOKI cannot bear any responsibility for damage that occurs during shipment.

#### Warranty Certificate

Model	Serial number	Warranty period		
		Three (3) years from date of purchase ( / )		
a /				
Customer name:				
Customer address:				
Important Please relain this warranty certificate. Duplicates cannot be reissued. Complete the certificate with the model number, serial number, and date of purchase, along with your name and address. The personal information you provide on this form will only be used to provide repair service and information about Hicki products and services.				
This document certifies that the product has been inspected and verified to conform to Hioki's standards. Please contact the place of purchase in the event of a malfunction and provide this document, in which case Hioki will repair or replace the product subject to the warranty terms described below.				
<ul> <li>Warranty terms</li> <li>1. The product is guaranteed to operate properly during the warranty period (three [3] years from the date of purchase). If the date of purchase is unknown, the warranty period is defined as three (3) years from the date of purchase). If the date of purchase is unknown, the warranty period is defined as three (3) years from the date of purchase).</li> <li>2. If the product came with an AC adapter, the adapter is warranted for one (1) year from the date of purchase.</li> <li>3. The accuracy of measured values and other data generated by the product is guaranteed as described in the product specifications.</li> <li>4. In the event that the product or AC adapter maffunctions during its respective warranty period due to a defect of workmanship or materials, Hioki will repair or replace the product or AC adapter free of charge.</li> <li>5. The following maffunctions and issues are not covered by the warranty and as such are not subject to free repair or replacement:</li> <li>1. Maffunctions or damage of consumables, parts with a defined service life, etc.</li> <li>2. Maffunctions or damage caused by inappropriate handling that violates information found in the instruction manual or on precautionary labeling on the product itself</li> <li>5. Maffunctions or damage caused by a failure to perform maintenance or inspections as required by law or recommended in the instruction manual</li> <li>6. Maffunctions or damage caused by infine, storms or flooding, earthquakes, lightning, power anomalies (involving voltage, frequency, etc.), war or unrest, contamination with radiation, or other acts of God</li> <li>7. Demage that is limited to the product itself</li> </ul>				
fading of color, etc.) =8. Other matifunctions or damage for which Hioki is not responsible 6. The warranty wi∎ be considered invalidated in the fo∎owing circumstances, in which case Hioki will be unable to perform service such as repair or calibration: -1. If the product has been repaired or modified by a company, entity, or individual other than Hioki				
-2. If the product has been embedded in another piece of equipment for use in a special application (aerospace, nuclear power, medical use, vehicle control, etc.) without Hioki's having received prior notice 7. If you experience a loss caused by use of the product and Hioki determines that it is responsible for the underlying issue, Hioki will provide compensation in an amount not to exceed the purchase price, with the following exceptions: 1.1. Secondary damage arising from damage to a measured device or component that was caused by use of the product 2. Damage to a device other than the product that was sustained when connecting the device to the product (including via network connections)				
(Including Val Textor Conflictuols) 8 Hoki reserves the right to decline to perform repair, calibration, or other service for products for which a certain amoun of time has passed since their manufacture, products whose parts have been discontinued, and products that cannot b repaired due to unforeseen circumstances. HIOKI E.E. CORPORATION				

http://www.hioki.com

18-07 EN-3

# ΗΙΟΚΙ



Our regional contact information

# http://www.hioki.com

81 Koizumi Ueda, Nagano 386-1192 Japan

#### **HIOKI EUROPE GmbH**

Rudolf-Diesel-Strasse 5 65760 Eschborn, Germany hioki@hioki.eu

1808EN

Edited and published by HIOKI E.E. CORPORATION

Printed in Japan

- ·CE declarations of conformity can be downloaded from our website.
- ·Contents subject to change without notice.
- ·This document contains copyrighted content.
- It is prohibited to copy, reproduce, or modify the content of this document without permission.
- Company names, product names, etc. mentioned in this document are trademarks or registered trademarks of their respective companies.

# ΗΙΟΚΙ

## www.hioki.co.jp/

本社 〒386-1192 長野県上田市小泉 81

製品のお問い合わせ

## 0120-72-0560

9:00~12:00, 13:00~17:00 土・日・祝日を除く

TEL 0268-28-0560 FAX 0268-28-0569 info@hioki.co.jp

#### 修理・校正のお問い合わせ

ご依頼はお買上店(代理店)または最寄りの営業拠点まで お問い合わせはサービス窓口まで TEL 0268-28-1688 cs-info@hioki.co.jp



1801JA

編集·発行 日置電機株式会社

・CE 適合宣言は弊社 HP からダウンロードできます。

- ・本書の記載内容を予告なく変更することがあります。
- ・本書には著作権により保護される内容が含まれます。

・本書の内容を無断で転記・複製・改変することを禁止します。

・本書に記載されている会社名・商品名などは、各社の商標または登録商標です。

Printed in Japan