

BT4560

BT4560-50

HIOKI

Communication Command
Instruction Manual

BATTERY IMPEDANCE METER



The latest edition of the instruction manual



- ✓ This instruction manual explains the communication commands for Model BT4560, BT4560-50 Battery Impedance Meter.
- ✓ Before using BT4560 or BT4560-50, be sure to read the instruction manual of BT4560, BT4560-50.
- ✓ For details regarding the command settings, please refer to the instruction manual for Model BT4560, BT4560-50.
- ✓ Although all reasonable care has been taken in the production of this instruction manual, should you find any points which are unclear or in error, please contact your local distributor or HIOKI's website.(<https://www.hioki.com/contact>)


EN

Contents

1 Introduction	1
Message Format	1
Output Queue and Input Buffer	5
Status Byte Register	6
Event Registers	8
Initialization Items	11
Local Function	11
Command Execution Time	12
Errors During Communications	12
2 Message List	13
3 Message Reference	16
Message Reference Interpretation	16
Standard Commands	17
(1) System Data Command	17
*IDN?	
(2) Internal Operation Command	17
*RST	
*TST	
(3) Synchronization Commands	18
*OPC	
*WAI	
(4) Status and Event Control Commands	18
*CLS	
*ESE	
*ESR?	
*SRE	
*STB?	
*TRG	
Device-Specific Commands	21
(1) Instrument Model Name	21
:QPID	
(2) Event Status Register	21
:ESE0	
:ESR0?	
:ESE1	
:ESR1?	
(3) I/O	22
:IO:MODE?	
(4) Measurement Functions	23
:FUNCTion	
(5) Measurement Frequency	23
:FREQuency	
(6) Measurement range	24
:RANGe	
(7) Sampling Speed	24
:SAMPle:RATE	
(8) Sample Delay	25
:SAMPle:DELay:MODE	
:SAMPle:DELay:WAVE	
:SAMPle:DELay:VOLTage	
(9) Potential Slope Correction	26
:ADJust:SLOPe	
(10) Voltage Limit	26
:LIMiter	
:LIMiter:VOLTage	
(11) Measurement Signal Zero Cross Stop	26
:ZERO:CROSs	
(12) Averaging	27
:CALCulate:AVERage	

(13) Zero Adjustment	27
:ADJust?	
:ADJust:CLEar	
:ADJust:DATA:ALL?	
:ADJust:DATA:SPOT?	
:ADJust:STATe?	
(14) Self-Calibration	30
:CALibration	
:CALibration:AUTO	
(15) Comparator	30
:CALCulate:LIMit:STATe	
:CALCulate:LIMit:BEEPer	
:CALCulate:LIMit:ABS	
:CALCulate:LIMit:RESistance	
:CALCulate:LIMit:REACtance	
:CALCulate:LIMit:IMPedance	
:CALCulate:LIMit:PHASe	
:CALCulate:LIMit:VOLTage	
(16) Saving and Reading Measurement Conditions	34
:SAVE:/LOAD	
:SAVE:CLEar	
(17) System Reset	34
:SYSTem:RESet	
(18) Measured value output	34
:SYSTem:DATAout	
(19) Key Beeper	35
:SYSTem:BEEPer	
(20) Key-Lock	35
:SYSTem:KLOCK	
(21) Communications Settings	35
:SYSTem:LOCal	
(22) Header	35
:SYSTem:HEADer	
(23) Serial Number	36
:SYSTem:SERial	
(24) LCD Settings	36
:SYSTem:DISPlay:CONTrast	
:SYSTem:DISPlay:BACKlight	
(25) Triggering	37
:INITiate:CONTInuous	
:TRIGger:SOURce	
:INITiate	
(26) Reading Measured Values	40
:ABORt	
:MEASure:VALid	
:FETCh?	
:FETCh:TEMPerature?	
:READ?	
4 Data Exporting Methods	44
5 Sample Programs	46
Using Visual Basic 5.0 or 6.0	46
RS-232C/USB Communications (Using Microsoft Visual Basic Professional MSComm)	46
■ Simple Measurement	46
■ Measure by PC Key	47
■ External Trigger Measurement	48
■ Set Measurement Conditions	49
Using Visual Basic2013	50

Various messages are supported for controlling the instrument through the interfaces. Messages can be either program messages, sent from the controller such as PC to the instrument, or response messages, sent from the instrument to the controller.



Message Format

Program messages can be either Command Messages or Query Messages.

Instructions to control the instrument, such as to change settings or reset
Example: (instruction to set the measurement range)

Requests for responses relating to results of operation or measurement, or the state of instrument settings
Example: (request for the current measurement range)

See: "Headers (p.2)", "Separators (p.3)", "Data Formats (p.4)"

■ Response Messages

When a query message is received, its syntax is checked and a response message is generated. **:SYSTem:HEADer** command determines whether headers are prefixed to response messages.

Header ON **:RANGE 3.0000E-3**

Header OFF **3.0000E-3**

(The current measurement range is 3mΩ)

At power-on, Header OFF is selected.

If an error occurs when a query message is received, no response message is generated for that query.

Some query message has no header, such as **:FETCH?**.

■ Command Syntax

Command names are chosen to mnemonically represent their function, and can be abbreviated. The full command name is called the “long form”, and the abbreviated name is called the “short form”. The command references in this manual indicate the short form in upper-case letters, extended to the long form in lower case letters, although the commands are not case-sensitive in actual usage.

CALIBRATION? OK (long form)

CAL OK (short form)

CALIB Error

CA Error

Response messages generated by the instrument are in long form and in upper case letters.

■ Headers

Headers must always be prefixed to program messages.

(1) Command Program Headers

There are three types of commands: Simple, Compound and Standard.

- **Headers for Simple Commands**

This header type is a sequence of letters and digits

:ESE0

- **Headers for Compound Commands**

These headers consist of multiple simple command type headers separated by colons “:”

:SYSTem:RESet

- **Headers for Standard Commands**

This header type begins with an asterisk “*”, indicating that it is a standard command defined by IEEE 488.2.

***RST**

(2) Query Program Header

These commands are used to interrogate the instrument about the results of operations, measured values and the current states of instrument settings.

As shown by the following examples, a query is formed by appending a question mark “?” after a program header.

:FETCh?

:CALCulate:LIMit:BEEPer?

■ Message Terminators

This instrument recognizes the following message terminators (delimiters):

- CR
- CR+LF

Also the terminator for response messages is as follows:

- CR+LF

■ Separators

(1) Message Unit Separator

Multiple messages can be written in one line by separating them with semicolons “;”

:FREQUENCY 1000;*IDN?

- When messages are combined in this way and if one command contains an error, all subsequent messages up to the next terminator will be ignored.

(2) Header Separator

In a message consisting of both a header and data, the header is separated from the data by a space “ ” (ASCII code 20H).

:SYSTEM:HEADER OFF

(3) Data Separator

In a message containing multiple data items, commas “,” are required to separate the data items from one another.

:SAMPLe:RATE V MED

■ Data Formats

The instrument uses character data, decimal numeric data and character string data depending on the command.

(1) Character Data

Character data always begins with an alphabetic character, and subsequent characters may be either alphabetic or numeric. Character data is not case-sensitive, although response messages from the instrument are only upper case. When the command data portion contains **<1/0/ON/OFF>**, the operation will be similar to when 0 is OFF and 1 is ON.

:SYSTEM:HEADER **OFF**

(2) Decimal Numeric Data

Three formats are used for numeric data, identified as NR1, NR2 and NR3. Numeric values may be signed or unsigned. Unsigned numeric values are handled as positive values. Values exceeding the precision handled by the instrument are rounded to the nearest valid digit.

- NR1 Integer data (e.g.: +12, -23, 34)
- NR2 Fixed-point data (e.g.: +1.23, -23.45, 3.456)
- NR3 Floating-point exponential representation data (e.g.: +1.0E-2, -2.3E+4)

The term “NRf format” includes all three of the above numeric decimal formats.

The instrument accepts NRf format data. The format of response data is specified for each command, and the data is sent in that format.

:ESE0 **10**

:FETCH?

+1.06571E-03

■ Compound Command Header Omission

When several commands having a common header are combined to form a compound command (for example, **:CALCulate:LIMit:RESistance** and **:CALCulate:LIMit:VOLTage**), if they are written together in sequence, the common portion (here, **:CALCulate:LIMit:**) may be omitted after its initial occurrence. This common portion is called the “current path” (analogous to the path concept in computer file storage), and until it is cleared, the interpretation of subsequent commands presumes that they share the same common portion.

This usage of the current path is shown in the following example:

Full expression

:CALCulate:LIMit: RESistance 1.0E-2,5.0E-3 ;:CALCulate:LIMit: VOLTage 5.0,4.0

Compacted expression

:CALCulate:LIMit: RESistance 1.0E-2,5.0E-3; VOLTage 5.0,4.0



This portion becomes the current path, and can be omitted from the messages immediately following.

The current path is cleared when the power is turned on, when reset by key input, by a colon “:” at the start of a command, and when a message terminator is detected.

Standard command messages can be executed regardless of the current path. They have no effect upon the current path.

A colon “:” is not required at the start of the header of a Simple or Compound command. However, to avoid confusion with abbreviated forms and operating mistakes, we recommend always placing a colon at the start of a header.

Output Queue and Input Buffer

■ Output Queue

Response messages are stored in the output queue until read by the controller. The output queue is also cleared in the following circumstances:

- Power on


■ Input Buffer

The input buffer capacity of the instrument is 256 bytes.

If 256 bytes are allowed to accumulate in this buffer so that it becomes full, the interface will not accept data beyond 256 bytes.

Note: Ensure that no command ever exceeds 256 bytes.

Status Byte Register



Overview of Service Request Occurrence

The Status Byte Register contains information about the event registers and the output queue. Required items are selected from this information by masking with the Service Request Enable Register. When any bit selected by the mask is set, bit 6 (MSS; the Master Summary Status) of the Status Byte Register is also set.

■ **Status Byte Register (STB)**

When any Status Byte Register bit enabled by the Service Request Enable Register has switched from 0 to 1, the MSS bit becomes 1.

Although the MSS bit is only read by an ***STB?** query, it is not cleared until a clear event is initiated by the ***CLS** command.

Bit 7		Unused
Bit 6	MSS	This is the logical sum of the other bits of the Status Byte Register.
Bit 5	ESB	Standard Event Status (logical sum) bit This is logical sum of the Standard Event Status Register.
Bit 4	MAV	Unused
Bit 3		Unused
Bit 2		Unused
Bit 1	ESB1	Event Status (logical sum) bit 1 This is the logical sum of Event Status Register 1.
Bit 0	ESB0	Event Status (logical sum) bit 0 This is the logical sum of Event Status Register 0.

■ **Service Request Enable Register (SRER)**

This register masks the Status Byte Register. Setting a bit of this register to 1 enables the corresponding bit of the Status Byte Register to be used.

Event Registers

■ Standard Event Status Register (SESR)

The Standard Event Status Register is an 8-bit register. If any bit in the Standard Event Status Register is set to 1 (after masking by the Standard Event Status Enable Register), bit 5 (ESB) of the Status Byte Register is set to 1.

See: “Standard Event Status Register (SESR) and Standard Event Status Enable Register (SESER)” (p.9)

The Standard Event Status Register is cleared in the following situations:


- When a ***CLS** command is executed
- When an event register query (***ESR?**) is executed
- When the instrument is powered on

Bit 7	PON	Power-On Flag Set to 1 when the power is turned on, or upon recovery from an outage.
Bit 6	(Unused) URQ	User Request
Bit 5	CME	Command error (The command to the message terminator is ignored.) This bit is set to 1 when a received command contains a syntactic or semantic error: <ul style="list-style-type: none"> • Program header error • Incorrect number of data parameters • Invalid parameter format • Received a command not supported by the instrument
Bit 4	EXE	Execution Error This bit is set to 1 when a received command cannot be executed for some reason. <ul style="list-style-type: none"> • The specified data value is outside of the set range • The specified setting data cannot be set • Execution is prevented by some other operation being performed
Bit 3	(Unused) DDE	Device-Dependent Error This bit is set to 1 when a command cannot be executed due to some reason other than a command error, a query error or an execution error.
Bit 2	(Unused) QYE	Query Error (the output queue is cleared) This bit is set to 1 when a query error is detected by the output queue control. <ul style="list-style-type: none"> • When an attempt has been made to read an empty output queue (GP-IB only) • When the data overflows the output queue • When data in the output queue has been lost • When the next command is received while there is data in the output queue
Bit 1	(Unused) RQC	Request Control
Bit 0	OPC	Operation Complete This bit is set to 1 in response to an *OPC command. <ul style="list-style-type: none"> • It indicates the completion of operations of all messages up to the *OPC command

■ Standard Event Status Enable Register (SESER)

Setting any bit of the Standard Event Status Enable Register to 1 enables access to the corresponding bit of the Standard Event Status Register.

Standard Event Status Register (SESR) and Standard Event Status Enable Register (SESER)



■ Device-Specific Event Status Registers (ESR0 and ESR1)

This instrument provides two Event Status Registers for controlling events. Each event register is an 8-bit register.

When any bit in one of these Event Status Registers enabled by its corresponding Event Status Enable Register is set to 1, the following happens:

- For Event Status Register 0, bit 0 (ESB0) of the Status Byte Register (STB) is set to 1.
- For Event Status Register 1, bit 1 (ESB1) of the Status Byte Register (STB) is set to 1.

Event Status Registers 0 and 1 are cleared in the following situations:

- When a ***CLS** command is executed
- When an Event Status Register query (**:ESR0?** or **:ESR1?**) is executed
- When the instrument is powered on


Event Status Register 0 (ESR0)

Bit 7		Unused
Bit 6		Unused
Bit 5	ERR	Measurement Fault
Bit 4	V-Hi	V Measurement High Comparator Result
Bit 3	V-IN	V Measurement IN Comparator Result
Bit 2	V-Lo	V Measurement Low Comparator Result
Bit 1	INDEX	End of Reading
Bit 0	EOM	End of Measurement

Event Status Register 1 (ESR1)

Bit 7	FAIL	Total Judgment FAIL
Bit 6	PASS	Total Judgment PASS
Bit 5	X/θ-Hi	X/θ Measurement High Comparator Result
Bit 4	X/θ-IN	X/θ Measurement IN Comparator Result
Bit 3	X/θ-Lo	X/θ Measurement Low Comparator Result
Bit 2	R/Z-Hi	R/Z Measurement High Comparator Result
Bit 1	R/Z-IN	R/Z Measurement IN Comparator Result
Bit 0	R/Z-Lo	R/Z Measurement Low Comparator Result

Event Status Registers 0 (ESR0) and 1 (ESR1), and Event Status Enable Registers 0 (ESER0) and 1 (ESER1)



■ Register Reading and Writing

Register	Read	Write
Status Byte Register	*STB?	-
Service Request Enable Register	*SRE?	*SRE
Standard Event Status Register	*ESR?	-
Standard Event Status Enable Register	*ESE?	*ESE
Event Status Register 0	:ESR0?	-
Event Status Enable Register 0	:ESE0?	:ESE0
Event Status Register 1	:ESR1?	-
Event Status Enable Register 1	:ESE1?	:ESE1

Initialization Items

Item \ Initialization Method	At Power-on	*RST Command	:SYSTem:R ESET Command	*CLS Command	Factory Default
RS-232C setting (baud rate)	-	-	-	-	9600
Device-specific functions (range, etc.)	-	●*1	●	-	●
Output Queue	●	-	-	-	●
Input buffer	●	-	-	-	●
Status Byte Register	●	-	-	●	●
Event registers	●*2	-	-	●	●
Enable register	●	-	-	-	●
Current path	●	-	-	-	●
Headers on/off	OFF	-	-	-	OFF

*1. Except the zero adjustment value and the saved data.

*2. Except the PON bit (bit 7).

Local Function

The Remote state is entered during communication. [RMT] is displayed in the measurement display and operation keys are disabled.

EXT 10 mΩ Z:MED V:MED **RMT**

R 6.0000 mΩ
 X -0.5000 mΩ
 V 4.00000 v 1000 Hz 25.6 °C

■ Canceling the Remote state

- Pressing the [LOCAL] key on the front panel cancels the Remote state and enables key operations.

LOCAL

- Sending **:SYSTem:LOCa** command can also cancel the Remote state.

Command Execution Time

Command execution time indicates the time for analyzing and processing long form commands.

- Display delays may occur depending on the frequency of communication processes and process contents.
- All commands except ***TRG** and **:INIT** are processed sequentially.
- In communications with the controller, time must be added for data transmission. Transfer time depends on the controller.

The Transfer time, with start bit 1, data length 8, no parity, and stop bit 1, has a total of 10-bit. When the transfer speed (baud rate) setting is N bps, the general result will be as follows:

Transfer time T [1 character/sec] = Baud rate N [bps]/10 [bits]

If a measurement value is 11 characters, a 1 data transfer time will be 11/T.

(Example) For 9600 bps, $11/(9600/10)$ = Approx. 11 ms

Command	Execution time (except communication time) *1
:ADJust? ALL	15 s or less
:FETCh?	4 ms or less
:READ?	Measurement time + 4 ms or less
:LOAD	90 ms or less
:CALibration?	Calibration time + 6 ms or less
*RST	75 ms or less

*1 The values indicate an execution time when the instrument is not under a measurement.
The execution time may increase during a measurement.

Errors During Communications

An error occurs when messages are executed in the following cases:

- **Command Error**
When message syntax (spelling) is invalid
When the data format in a command or query is invalid
- **Execution Error**
When invalid character or numeric data is present

2 Message List

Message []: Omissible	Data Formats []: Omissible (): Response data	Description
Standard Commands		
*IDN?	(<Manufacturer name>, <Model name>, <Serial number>, <Software version>)	Queries the Instrument ID.
*RST		Initializes the Instrument.(Normal Reset)
*TST?	(0 to 1)	Initiates a self-test and queries the result.
*OPC		Sets an OPC after execution completion.
*OPC?	(1)	Queries execution completion.
*WAI		Wait for operations to finish.
*CLS		Clears the Status Byte Register and the related ques.
*ESE	0 to 255	Sets the Standard Event Status Enable Register.
*ESE?	(0 to 255)	Queries the Standard Event Status Enable Register.
*ESR?	(0 to 255)	Queries the Standard Event Status Register.
*SRE	0 to 255	Sets the Service Request Enable Register.
*SRE?	(0 to 255)	Queries the Service Request Enable Register.
*STB?	(0 to 255)	Queries the Status Byte Register.
*TRG		Executes one sampling.
Instrument Model Name		
:QPID	<Model name>	Queries the instrument model name.
Event Registers		
:ESE0	0 to 255	Sets the Event Status Enable Register 0.
:ESE0?	(0 to 255)	Queries the Event Status Enable Register 0.
:ESR0?	(0 to 255)	Queries the Event Status Register 0.
:ESE1	0 to 255	Sets the Event Status Enable Register 1.
:ESE1?	(0 to 255)	Queries the Event Status Enable Register 1.
:ESR1?	(0 to 255)	Queries the Event Status Register 1.
I/O		
:IO:MODE?	(NPN/PNP)	Queries the NPN/PNP switch status.
Measurement Functions		
:FUNction	RV/ZV/R/Z/V	Sets the measurement function.
:FUNction?	(RV/ZV/R/Z/V)	Queries the measurement function.
Measurement Frequency		
:FREquency	<Frequency>	Sets the measurement frequency.
:FREquency?	(<Frequency>)	Queries the measurement frequency.
Measurement Range		
:RANge	<Measurement range>	Sets the measurement range.
:RANge?	(<Measurement range>)	Queries the measurement range.
Sampling Speed		
:SAMple:RATE	<V/Z>, <FAST/MEDIUM/SLOW >	Sets the sampling speed.
:SAMple:RATE?	<V/Z> (<FAST/MEDIUM/SLOW >)	Queries the sampling speed.
Sample Delay		
:SAMple:DElay:MODE	WAVE/VOLTage	Sets the sample delay mode.
:SAMple:DElay:MODE?	(WAVE/VOLTAGE)	Queries the sample delay mode.
:SAMple:DElay:WAVE	<Wavenumber> = 0.0 to 9.0	Sets the sample delay with the frequency of the alternating current signal.
:SAMple:DElay:WAVE?	(<Wavenumber>)	Queries the sample delay frequency of the alternating current signal.
:SAMple:DElay:VOLTage	<Deviation of voltage fluctuation > =0.001 to 10.000	Sets the sample delay with the deviation of voltage fluctuation.
:SAMple:DElay:VOLTage?	(<Deviation of voltage fluctuation >)	Queries the sample delay deviation of voltage fluctuation.

Message []: Omissible	Data Formats []: Omissible (): Response data	Description
Voltage Limit		
:LIMiter	1/0/ON/OFF	Sets the voltage limit function.
:LIMiter?	(ON/OFF)	Queries the voltage limit function.
:LIMiter:VOLTage	<Voltage limit value> =0.01 to 5.00	Sets the voltage limit value.
:LIMiter:VOLTage?	(<Voltage limit value>)	Queries the voltage limit value.
Measurement Signal Zero Cross Stop		
:ZEOR:CROSSs	1/0/ON/OFF	Sets the measurement signal zero cross stop function.
:ZERO:CROSS?	(ON/OFF)	Queries the measurement signal zero cross stop function.
Averaging		
:CALCulate:AVERage	<Averaging count>	Sets the measurement averaging.
:CALCulate:AVERage?	(<Averaging count>)	Queries the measurement averaging.
Zero Adjustment		
:ADJust?	<SPOT/ALL> (0/1)	Executes zero adjustment and queries the result.
:ADJust:CLear		Clears zero adjustment.
:ADJust:DATA:ALL?	V/R/RV (<Adjusted value V>,<Adjusted value R at 10Hz>,<Adjusted value X at 10Hz>,<Adjusted value R at 100Hz>,<Adjusted value X at 100Hz>,<Adjusted value R at 330Hz>,<Adjusted value X at 330Hz>,<Adjusted value R at 660Hz>,<Adjusted value X at 660Hz>,<Adjusted value R at 1kHz>,<Adjusted value X at 1kHz>)	Queries the zero adjustment value (ALL).
:ADJust:DATA:SPOT?	V/R/RV (<Adjusted value V>,<Adjusted value R>,<Adjusted value X>)	Queries the zero adjustment value (SPOT).
:ADJust:STATe?	(ON/OFF)	Queries the state of zero adjustment execution.
Potential Slope Correction		
Adjust:SLOPe	1/0/ON/OFF	Sets the slope correction for AC signal response.
Adjust:SLOPe?	(ON/OFF)	Queries the slope correction for AC signal response.
Self-Calibration		
:CALibration		Executes self-calibration.
:CALibration:AUTO	1/0/ON/OFF	Sets the automatic self-calibration.
:CALibration:AUTO?	(ON/OFF)	Queries the automatic self-calibration.
Comparator		
:CALCulate:LIMit:STATe	1/0/ON/OFF	Sets the comparator.
:CALCulate:LIMit:STATe?	(ON/OFF)	Queries the comparator.
:CALCulate:LIMit:BEEPer	OFF/HL/IN/ALL	Sets the beep sound.
:CALCulate:LIMit:BEEPer?	(OFF/HL/IN/ALL)	Queries the beep sound.
:CALCulate:LIMit:ABS	1/0/ON/OFF	Sets the judgement of the voltage component comparator with the absolute value
:CALCulate:LIMit:ABS?	(ON/OFF)	Queries the judgement of the voltage component comparator with the absolute value
:CALCulate:LIMit:RESistance	<Upper limit>,<Lower limit>	Sets the upper/lower limits for the resistance component.
:CALCulate:LIMit:RESistance?	(<Upper limit>,<Lower limit>)	Queries the upper/lower limits for the resistance component.
:CALCulate:LIMit:REACtance	<Upper limit>,<Lower limit>	Sets the upper/lower limits for the reactance component.
:CALCulate:LIMit:REACtance?	(<Upper limit>,<Lower limit>)	Queries the upper/lower limits for the reactance component.
:CALCulate:LIMit:IMPedance	<Upper limit>,<Lower limit>	Sets the upper/lower limits for the impedance component.
:CALCulate:LIMit:IMPedance?	(<Upper limit>,<Lower limit>)	Queries the upper/lower limits for the impedance component.
:CALCulate:LIMit:PHASe	<Upper limit>,<Lower limit>	Sets the upper/lower limits for the phase component.

Message []: Omissible	Data Formats []: Omissible (): Response data	Description
:CALCulate:LIMit:PHASe?	(<Upper limit>,<Lower limit>)	Queries the upper/lower limits for the phase component.
:CALCulate:LIMit:VOLTage	<Upper limit>,<Lower limit>	Sets the upper/lower limits for the voltage component.
:CALCulate:LIMit:VOLTage?	(<Upper limit>,<Lower limit>)	Queries the upper/lower limits for the voltage component.

Saving and Reading Measurement Conditions

:SAVE	Save No.	Saves the measurement conditions.
:SAVE:CLEar	Save No.	Clears the saved measurement conditions.
:LOAD	Save No.	Reads the measurement conditions.

System Reset

:SYSTem:RESet		Initializes the instrument.(System Reset)
---------------	--	---

Output measured value after measurement completes

:SYSTem:DATAout	1/0/ON/OFF	Sets the measured value output.
:SYSTem:DATAout?	(ON/OFF)	Queries the measured value output.

Key-Lock

:SYSTem:KLOCK	1/0/ON/OFF	Sets the key-lock.
:SYSTem:KLOCK?	(ON/OFF)	Queries the key-lock.

Key Beeper

:SYSTem:BEEPer	1/0/ON/OFF	Sets the key beeper.
:SYSTem:BEEPer?	(ON/OFF)	Queries the key beeper.

Communications Settings

:SYSTem:LOCal		Cancels the communication (remote) state.
---------------	--	---

Header Presence

:SYSTem:HEADer	1/0/ON/OFF	Sets the header presence.
:SYSTem:HEADer?	(ON/OFF)	Queries the header presence.

Serial Number

:SYSTem:SERial?	Serial number	Queries the serial number.
-----------------	---------------	----------------------------

LCD Settings

:SYSTem:DISPlay:CONTrast	<Contrast> =1 to 100	Sets the contrast.
:SYSTem:DISPlay:CONTrast?	(<Contrast>)	Queries the contrast.
:SYSTem:DISPlay:BACKlight	<Brightness> =10 to 100	Sets the backlight brightness.
:SYSTem:DISPlay:BACKlight?	(<Brightness>)	Queries the backlight brightness.

Triggering

:TRIGger:SOURce	IMMEDIATE/EXTernal	Sets the trigger source.
:TRIGger:SOURce?	(IMMEDIATE/EXTernal)	Queries the trigger source.
:INITiate:CONTinuous	1/0/ON/OFF	Sets continuous measurement (permits/prohibits transition to the idle state).
:INITiate:CONTinuous?	(ON/OFF)	Queries the continuous measurement.
:INITiate		Transits to the trigger waiting state.

Reading Measured Values

:ABORT		Measurement is aborted (forcibly terminated).
:MEASure:Valid	<MR0> =1 to 7	Sets the response data to be returned from a measurement value reading query.
:MEASure:Valid?	(<MR0>)	Queries the response data for a measurement value reading query.
:FETCh?	(<Total judgment result>,<Measurement value>,<Judgment result>,<Measurement value>,<Judgment result>,...)	Queries the last measurement value.
:FETCh:TEMPerature?	(<Temperature measurement value>)	Queries the temperature measurement value.
:READ?	(<Total judgment result>,<Measurement value>,<Judgment result>,<Measurement value>,<Judgment result>,...)	Cancels the idle state and queries the measurement value after the measurement is completed.

3 Message Reference

Message Reference Interpretation

< >: Indicates the contents (character or numeric parameters) of the data portion of a message. Character parameters are returned as all capital letters.

Numeric Parameters:

- NRf Number format may be any of NR1, NR2 and NR3
- NR1 Integer data (e.g.: +12, -23, 34)
- NR2 Fixed-point data (e.g.: +1.23, -23.45, 3.456)
- NR3 Floating-point exponential representation data (e.g.: +1.0E-2, -2.3E+4)

Shows the command description.

Shows the message syntax.
Explains the command data or response message.
Describes the message.

Shows an example of an actual command application. (Normally described with HEADER OFF [except the HEADER command itself].)


Read/Write the Standard Event Status Enable Register (SESER)

Syntax Command ***ESE <0 to 255 (NR1)>**
Query ***ESE?**
Response **<0 to 255 (NR1)>**

Description Command The SESER mask is set to the numerical value 0 to 255. The initial value (at power-on) is 0.
Query The contents of the SESER, as set by the *ESE command, are returned as an NR1 value (0 to 255).

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
PON	URQ	CME	EXE	DDE	QYE	RQC	OPC

Example ***ESE 36**
(Sets bits 5 and 2 of SESER)



Standard Commands

(1) System Data Command

Query Instrument ID (Identification Code)

Syntax	Query	*IDN?
	Response	<Manufacturer name>,<Model name>,<Serial number>,<Software version>

Example *IDN?
HIOKI, BT4560, 123456, V1.00
The Instrument ID is HIOKI BT4560, serial number 123456, software version 1.00.

(2) Internal Operation Command

Initialize Instrument (Normal Reset)

Syntax	Command	*RST
---------------	---------	------

Description	Command	Resets the instrument to factory settings excluding the communication state, , zero adjustment value and saved data.(Normal Reset) The initial display is displayed after initialization.
--------------------	---------	--

Note The communication state is not initialized.
Use the **:SYSTem:RESet** command(p.34) to initialize the zero adjustment value and saved data.

Execute Self-Test and Query Result

Syntax	Query	*TST?
	Response	<0 to 1 (NR1)>
	<0> = No error	
	<1> = ROM error	

Description	Perform the instrument self-test and return the result as NR1 value 0 or 1. Returns zero when no error occurs.
--------------------	---

Example *TST?
1
A ROM error occurred.

(3) Synchronization Commands

Set OPC bit of SESR when Finished with All Pending Operations

Syntax	Command	*OPC
Description	Sets OPC bit 0 of the Standard Event Status Register (SESR) when all commands prior to *OPC have finished processing.	
Example	A;B;*OPC;C The OPC bit of SESR is set after A and B command processing has been completed.	

Respond with ASCII "1" when Finished with All Pending Operations

Syntax	Query	*OPC?
	Response	1
Description	Responds with ASCII "1" when all commands prior to *OPC have finished processing.	

Wait for Pending Commands to Finish

Syntax	Command	*WAI
Description	The instrument waits until all prior commands finish before executing any subsequent commands.	
Example	:TRIG:SOUR EXT :INIT:CONT ON *TRG;*WAI;FETC? Reads the measurement value after waiting for the measurement triggered by the *TRG command to finish.	
Note	The *WAI command is accepted, as it is a mandatory command under IEEE Standard 488.2-1987. However, since all the device-specific commands implemented in this instrument, except the *TRG and the :INITiate, are sequential, the *WAI command has no effect even if used.	

(4) Status and Event Control Commands

Clear Event Register, Status Byte Register (Except Output Queue)

Syntax	Command	*CLS
Description	Clears the event status registers. The Status Byte Register bits corresponding to the event status registers are also cleared. (SESR, ESR0, ESR1)	
Note	The output queue is unaffected.	

Set and Query Standard Event Status Enable Register (SESER)

Syntax Command ***ESE** <0 to 255(NR1)>
 Query ***ESE?**
 Response <0 to 255(NR1)>

Description Command The SESER mask is set to the numerical value 0 to 255. The initial value (at power-on) is 0.

 Query The contents of the SESER, as set by the ***ESE** command, are returned as an NR1 value (0 to 255).

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
PON	Unused	CME	EXE	Unused	Unused	Unused	OPC

Example ***ESE 32**
 Sets bit 5 of SESER.

Query and Clear Standard Event Status Register (SESR)

Syntax Query ***ESR?**
 Response <0 to 255 (NR1)>

Description Returns the contents of the SESR as an NR1 value from 0 to 255, then clears register contents.
 The response message has no header.

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
PON	Unused	CME	EXE	Unused	Unused	Unused	OPC

Example ***ESR?**
 32
 Bit 5 of the SESR has been set to 1.

Set and Query Service Request Enable Register (SRER)

Syntax	Command	*SRE <0 to 255 (NR1)>
	Query	*SRE?
	Response	<0 to 255 (NR1)>

Description	Command	The SRER mask is set to the numerical value 0 to 255. Although NRf numerical values are accepted, values to the right of the decimal are rounded to the nearest integer. Bit 6 and unused bits 2, 3 and 7 are ignored. The data is initialized to 0 at power-on.
	Query	The contents of the SRER, as set by the *SRE command, are returned as an NR1 value (0 to 255). Bit 6 and unused bits 2, 3 and 7 always return as zero.

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
Unused	0	ESB	Unused	Unused	Unused	ESE1	ESE0

Example	*SRE 33
	Set SRER bits 0 and 5 to 1.
	*SRE?
	33 SRER bits 0 and 5 have been set to 1.

Query Status Byte and MSS Bit

Syntax	Query	*STB?
	Response	<0 to 255 (NR1)>

Description	The contents of the STB are returned as an NR1 value (0 to 255).
	The response message has no header.

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
Unused	MSS	ESB	Unused	Unused	Unused	ESE1	ESE0

Example	*STB?
	1
	STB bit 0 has been set to 1.

Request a Sample

Syntax	Command	*TRG
Description	Performs one measurement when external triggering (trigger source <EXTERNAL>) is enabled.	
Example	<pre>:TRIG:SOUR EXT :INIT:CONT ON *TRG;*WAI;;FETC?</pre> <p>Reads the measurement value after waiting for the measurement triggered by *TRG command to finish.</p>	
Note	<ul style="list-style-type: none"> An execution error occurs when the trigger source is :TRIGger:SOURce IMMEDIATE. If the continuous measurement setting is :INITiate:CONTinuous OFF, measurement is not triggered by *TRG command. Instead, use :INITiate or :READ? and input the external trigger signal to perform the measurement. To interrupt the measurement in process while awaiting a response to the *TRG;*WAI;;FETC? (*WAI is replaceable with *OPC or *OPC?) or :READ? query, press the LOCAL key. The instrument may not clear [RMT] to return measured values after the LOCAL key is pressed. In such case, hold the LOCAL key until [RMT] disappears. 	

Device-Specific Commands

(1) Instrument Model Name

Query Instrument Model Name (Identification Code)

Syntax	Query	:QPID
	Response	<Model name>
Example	<pre>:QPID BT4560</pre> <p>The instrument model name is BT4560.</p>	

(2) Event Status Register

Set and Query Device-Specific Event Status Enable Register ESER0

Syntax

Command

:ESE0 <0 to 255 (NR1)>

Query

:ESE0?

Response

<0 to 255 (NR1)>

Description

Command

Sets the mask pattern in Event Status Enable Register 0 (ESER0) for the Event Status Register.

Query

Queries the mask pattern in Event Status Enable Register 0 (ESER0) for the Event Status Register.

128

64

32

16

8

4

2

1

bit 7

bit 6

bit 5

bit 4

bit 3

bit 2

bit 1

bit 0

Unused

Unused

ERR

V-Hi

V-IN

V-Lo

INDEX

EOM

Note Data initializes to zero at power-on.

Query Device-Specific Event Status Register ESR0

Syntax Query **:ESR0?**
 Response <0 to 255 (NR1)>

Note For the description of each ESR0 register, see the :ESE0 command table.
 Executing ESR0? clears the contents of ESR0.

Set and Query Device-Specific Event Status Enable Register ESE1

Syntax Command **:ESE1** <0 to 255 (NR1)>
 Query **:ESE1?**
 Response <0 to 255 (NR1)>

Description Command Sets the mask pattern in Event Status Enable Register 1 (ESER1) for the Event Status Register.

 Query Queries the mask pattern in Event Status Enable Register 1 (ESER1) for the Event Status Register.

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
FAIL	PASS	X/θ-Hi	X/θ-IN	X/θ-Lo	R/Z-Hi	R/Z-IN	R/Z-Lo

Note Data initializes to zero at power-on.

Query Device-Specific Event Status Register ESR1

Syntax Query **:ESR1?**
 Response <0 to 255 (NR1)>

Note For the description of each ESR1 register, see the :ESE1 command table.
 Executing ESR1? clears the contents of ESR1.

(3) I/O

Query NPN/PNP Switch Status

Syntax Query **:IO:MODE?**
 Response <NPN / PNP>

Example **:IO:MODE?**
 NPN

(4) Measurement Functions

Set and Query Measurement Functions

Syntax	Command	:FUNCtion <RV / ZV / R / Z / V>
	Query	:FUNCtion?
	Response	<RV / ZV / R / Z / V>

RV...(R,X,V,T) function (resistance, reactance, voltage, temperature)
 ZV...(Z,θ,V,T) function (impedance, phase angle, voltage, temperature)
 R....(R,X,T) function (resistance, reactance, temperature)
 Z....(Z,θ,T) function (impedance, phase angle, temperature)
 V....(V,T) function (voltage, temperature)

Example **:FUNC RV**
 Set the function to (R,X,V,T).
:FUNC?
RV
 The function has been set to (R,X,V,T).

(5) Measurement Frequency

Set and Query Measurement Frequency

Syntax	Command	:FREQuency <Frequency>
	Query	:FREQuency?
	Response	<Frequency>

Description BT4560:<Frequency(Hz)> = **0.10 to 1050 (NR3)**
 BT4560-50:<Frequency(Hz)> = **0.01 to 1050 (NR3)**

Example **:FREQ 1000**
 Set the measurement frequency to 1000 (Hz).
:FREQ?
1000
 The measurement frequency has been set to 1000 (Hz).

Note

- Even when the settings are changed during a measurement with the internal trigger and low-frequency settings, the setting change is not applied immediately due to the long measurement time.
 To apply the change immediately, it is necessary to abort the measurement to enter the instrument into the idle state.
 To enter the instrument into the idle state, follow the procedure below:
 1. Deactivate the continuous measurement. (command: :INITiate:CONTInuous OFF)
 2. Abort the measurement. (command: :ABORT)
 3. Require a measurement-interruption response. (query: *OPC?)

(6) Measurement range

Set and Query Measurement Range

Syntax	Command	:RANGe <Measurement range>
	Query	:RANGe?
	Response	<Measurement range (Ω)>

Description	Command	<Measurement range (Ω)> = 0.0~120.0E-03(NR3) <ul style="list-style-type: none"> • $0.0 \leq \text{<Measurement range (Ω)>} \leq 3.0\text{E-}03$ Measurement range is set to 3mΩ. • $3.0\text{E-}03 < \text{<Measurement range (Ω)>} \leq 10.0\text{E-}03$ Measurement range is set to 10mΩ. • $10.0\text{E-}03 < \text{<Measurement range (Ω)>} \leq 120.0\text{E-}03$ Measurement range is set to 100mΩ.
	Query	Returns the currently set measurement range as the following format. <Measurement range (Ω)> = 3.0000E-3/10.0000E-3/100.000E-3

Example	:RANG 100.00E-03
	Set the measurement range to 100mΩ.
	:RANG?
	100.000E-3 The measurement range has been set to 100mΩ.

(7) Sampling Speed

Set and Query Sampling Speed

Syntax	Command	:SAMPLE:RATE <V / Z>,<Measurement speed>
	Query	:SAMPLE:RATE? <V / Z>
	Response	<Measurement speed>

<V> = V measurement sampling
 <Z> = Z measurement sampling
 <Measurement speed> = FAST / MEDIUM / SLOW

Example	:SAMP:RATE V, MED
	Set the V measurement sampling speed to MEDIUM.
	:SAMP:RATE? V
	MEDIUM The V measurement sampling speed has been set to MEDIUM.

(8) Sample Delay

Set and Query Sample Delay Mode

Syntax	Command	:SAMPLE:DElay:MODE <WAVE / VOLTage>
	Query	:SAMPLE:DElay:MODE?
	Response	<WAVE / VOLTAGE>

<WAVE> = Sets the sample delay with the frequency of the alternating current signal.
 <VOLTage> = Sets the sample delay with the deviation of voltage fluctuation.

Example **:SAMP:DEL:MODE WAVE**
 Sets the mode to execute the sample delay with the frequency of the alternating current signal.
:SAMP:DEL:MODE?
WAVE
 The mode has been set to execute the sample delay with the frequency of the alternating current signal.

Set and Query Sample Delay with the frequency of the alternating current signal

Syntax	Command	:SAMPLE:DElay:WAVE <Wavenumber>
	Query	:SAMPLE:DElay:WAVE?
	Response	<Wavenumber>

<Wavenumber (wave)> = 0.0 to 9.0(NR2)

Example **:SAMP:DEL:WAVE 6.0**
 Sets the delay wavenumber to 6.0.
:SAMP:DEL:WAVE?
6.0
 The delay wavenumber has been set to 6.0.

Set and Query Sample Delay with the deviation of voltage fluctuation

Syntax	Command	:SAMPLE:DElay:VOLTage <Deviation of voltage fluctuation>
	Query	:SAMPLE:DElay:VOLTage?
	Response	<Deviation of voltage fluctuation>

<Deviation of voltage fluctuation (mV)> = 0.001 to 10.000 (NR2)

Example **:SAMP:DEL:VOLT 0.1**
 Sets the delay deviation of voltage fluctuation to 0.1mV.
:SAMP:DEL:VOLT?
0.100
 The delay deviation of voltage fluctuation has been set to 0.1mV.

(9) Potential Slope Correction**Set and Query Potential Slope Correction**

Syntax	Command	:ADJust:SLOPe <1 / 0 / ON / OFF>
	Query	:ADJust:SLOPe?
	Response	<ON / OFF>

Example :ADJ:SLOP ON
 :ADJ:SLOP?
 ON

(10) Voltage Limit**Set and Query Voltage Limit Function**

Syntax	Command	:LIMiter <1 / 0 / ON / OFF>
	Query	:LIMiter?
	Response	<ON / OFF>

Example :LIM ON
 :LIM?
 OFF

Set and Query Voltage Limit Function

Syntax	Command	:LIMiter:VOLTage <Voltage limit value>
	Query	:LIMiter:VOLTage?
	Response	<Voltage limit value>

<Voltage limit value (V)> = 0.01 to 5.00 (NR2)

Example :LIM:VOLT 5.00
 :LIM:VOLT?
 5.00

(11) Measurement Signal Zero Cross Stop**Set and Query Measurement Signal Zero Cross Stop Function**

Syntax	Command	:ZERO:CROSS <1 / 0 / ON / OFF>
	Query	:ZERO:CROSS?
	Response	<ON / OFF>

Example :ZERO:CROSS ON
 :LIM:VOLT?
 OFF

(12) Averaging**Set and Query Measurement Averaging**

Syntax	Command	:CALCulate:AVERage <Count>
	Query	:CALCulate:AVERage?
	Response	<Count>

<Count> = 1 to 99 (NR1)

Only the number of impedance measurement values specified in <Count> are averaged and output.

Example **:CALC:AVER 10**
 :CALC:AVER?
 10

(13) Zero Adjustment**Execute Zero Adjustment and Query Result**

Syntax	Query	:ADJust? <SPOT / ALL>
	Response	<0 / 1>

Description <SPOT>= Executes zero adjustment for the frequency and voltage measurement in the currently set range.
 <ALL> = Executes zero adjustment for the currently set all frequency and voltage measurement.
 <0> = Indicates zero adjustment succeeded.
 <1> = Indicates that zero adjustment has failed.

For information on zero adjustment, see the instrument instruction manual.

Example **ADJ? SPOT**
 0

Zero adjustment is executed in the SPOT setting and completed normally.

Clear Zero Adjustment

Syntax	Command	:ADJust:CLEar
---------------	---------	----------------------

Description Clears zero adjustment.

Example **ADJ:CLE**

Query Zero Adjustment Value (ALL)

Syntax	Query	:ADJust:DATA:ALL? <V / R / RV>
	Response	<Voltage adjusted value>, <Resistance adjusted value at 100Hz>, <Reactance adjusted value at 100Hz>, <Resistance adjusted value at 1kHz>, <Reactance adjusted value at 1kHz>
Description	Query	<p><V> = Queries the voltage adjusted value.</p> <p><R> = Queries the resistance/reactance adjusted value at 10Hz, 100Hz, 330Hz, 660Hz and 1kHz.</p> <p><RV> = Queries the voltage adjusted value, and the resistance/reactance adjusted value at 10Hz, 100Hz, 330Hz, 660Hz and 1kHz.</p>
	Response	<p>• Response for :ADJust:DATA:ALL? V <Voltage adjusted value></p> <p>• Response for :ADJust:DATA:ALL? R <Resistance adjusted value at 10Hz>, <Reactance adjusted value at 10Hz>, <Resistance adjusted value at 100Hz>, <Reactance adjusted value at 100Hz>, <Resistance adjusted value at 330Hz>, <Reactance adjusted value at 330Hz>, <Resistance adjusted value at 660Hz>, <Reactance adjusted value at 660Hz>, <Resistance adjusted value at 1kHz>, <Reactance adjusted value at 1kHz></p> <p>• Response for :ADJust:DATA:ALL? RV <Voltage adjusted value>, <Resistance adjusted value at 10Hz>, <Reactance adjusted value at 10Hz>, <Resistance adjusted value at 100Hz>, <Reactance adjusted value at 100Hz>, <Resistance adjusted value at 330Hz>, <Reactance adjusted value at 330Hz>, <Resistance adjusted value at 660Hz>, <Reactance adjusted value at 660Hz>, <Resistance adjusted value at 1kHz>, <Reactance adjusted value at 1kHz></p>

Example

ADJ:DATA:ALL? V

+1.10000E-03

The voltage adjusted value has been set to 1.1mV.

ADJ:DATA:ALL? R

+1.10000E-04,+5.00000E-06,+2.50000E-04,+2.0000E-05,+4.50000E-04,+4.0000E-05,+4.00000E-04,+5.0000E-05,+1.50000E-04,+1.00000E-05

The resistance/reactance adjusted value at 10Hz has been set to 0.11mΩ/0.005mΩ.

The resistance/reactance adjusted value at 100Hz has been set to 0.25mΩ/0.02mΩ.

The resistance/reactance adjusted value at 330Hz has been set to 0.45mΩ/0.04mΩ.

The resistance/reactance adjusted value at 660Hz has been set to 0.40mΩ/0.05mΩ.

The resistance/reactance adjusted value at 1kHz has been set to 0.15mΩ/0.01mΩ.

ADJ:DATA:ALL? RV

+1.10000E-03,+1.10000E-04,+5.00000E-06,+2.50000E-04,+2.0000E-05,+4.50000E-04,+4.0000E-05,+4.00000E-04,+5.0000E-05,+1.50000E-04,+1.00000E-05,+4.00000E-04,+5.0000E-05,+1.50000E-04,+1.00000E-05

The voltage adjusted value has been set to 1.1mV.

The resistance/reactance adjusted value at 10Hz has been set to 0.11mΩ/0.005mΩ.

The resistance/reactance adjusted value at 100Hz has been set to 0.25mΩ/0.02mΩ.

The resistance/reactance adjusted value at 330Hz has been set to 0.45mΩ/0.04mΩ.

The resistance/reactance adjusted value at 660Hz has been set to 0.40mΩ/0.05mΩ.

The resistance/reactance adjusted value at 1kHz has been set to 0.15mΩ/0.01mΩ.

Query Zero Adjustment Value (SPOT)

Syntax	Query	:ADJust:DATA:SPOT? <V / R / RV>
	Response	<Voltage adjusted value>, <Resistance adjusted value>, <Reactance adjusted value>
Description	Query	<V> = Queries the voltage adjusted value. <R> = Queries the resistance/reactance adjusted value at the currently set frequency. <RV> = Queries the voltage adjusted value, and the resistance/reactance adjusted value at the currently set frequency.
	Response	<ul style="list-style-type: none"> • Response for :ADJust:DATA:ALL? V <Voltage adjusted value> • Response for :ADJust:DATA:ALL? R <Resistance adjusted value>, <Reactance adjusted value> • Response for :ADJust:DATA:ALL? RV <Voltage adjusted value>, <Resistance adjusted value>, <Reactance adjusted value>
	Example	ADJ:DATA:SPOT? V +1.10000E-03 The voltage adjusted value has been set to 1.1mV. ADJ:DATA: SPOT? R +2.50000E-04,+2.0000E-04 The resistance/reactance adjusted value has been set to 0.25mΩ/0.20mΩ. ADJ:DATA: SPOT? RV +1.10000E-03,+2.50000E-04,+2.0000E-04 The voltage adjusted value has been set to 1.1mV. The resistance/reactance adjusted value has been set to 0.25mΩ/0.20mΩ.

Query Zero Adjustment State

Syntax	Query	:ADJust:STATe?
	Response	<ON / OFF>
Description	<ON>	= The state of zero adjustment execution has been set to effective.
	<OFF>	= The state of zero adjustment execution has been set to disabled.
Example		ADJ:STAT? OFF The state of zero adjustment execution has been set to disabled.

(14) Self-Calibration**Execute Self-Calibration**

Syntax	Command	:CALibration
---------------	---------	---------------------

Note	If this command is received while measuring, self-calibration executes after the measurement is finished.
-------------	---

Execute and Set Self-Calibration

Syntax	Command	:CALibration:AUTO <1 / 0 / ON / OFF>
	Query	:CALibration:AUTO?
	Response	<ON / OFF>
	<ON>	= AUTO Self-Calibration selected Self-calibration is set to be executed at the time of voltage measurement.
	<OFF>	= MANUAL Self-Calibration selected Self-calibration is set to be executed manually. Self-calibration is executed with the :CALibration command or external CAL signal.

Example	:CAL:AUTO OFF :CAL:AUTO? OFF
----------------	---

(15) Comparator**Execute and Query Comparator**

Syntax	Command	:CALCulate:LIMit:STATe <1 / 0 / ON / OFF >
	Query	:CALCulate:LIMit:STATe?
	Response	<ON / OFF >

Example	:CALC:LIM:STAT ON :CALC:LIM:STAT? ON
----------------	---

Set and Query Beeper

Syntax	Command	:CALCulate:LIMit:BEEPer <Condition>
	Query	:CALCulate:LIMit:BEEPer?
	Response	<Condition>
	<Condition>	= OFF / HL / IN / ALL
	OFF	No buzzer
	HL	Beeps when the value is outside of the upper or lower limit range.
	IN	Beeps when the value is within upper and lower limit range.
	ALL	Always beeps.

Example	:CALC:LIM:BEEP IN :CALC:LIM:BEEP? IN
----------------	---

Set and Query Judgement of Voltage Component Comparator with Absolute Value

Syntax	Command	:CALCulate:LIMit:ABS <1 / 0 / ON / OFF >
	Query	:CALCulate:LIMit:ABS?
	Response	<ON / OFF >
Example		:CALC:LIM:ABS ON
		Sets the judgement of the voltage component comparator to be performed with the absolute value.
		:CALC:LIM:ABS?
		ON
		The judgement of the voltage component comparator has been set to be performed with the absolute value.

Set and Query Resistance Component Comparator Upper/Lower Limit

Syntax	Command	:CALCulate:LIMit:RESistance <Upper limit>,<Lower limit>
	Query	:CALCulate:LIMit: RESistance?
	Response	<Upper limit (Ω)>,<Lower limit (Ω)>
	Command	<p><Upper limit (Ω)> = -3.00000E-03 to +1.20000E-01(NR3), or OFF <Lower limit (Ω)> = -3.00000E-03 to +1.20000E-01(NR3), or OFF If the upper limit is set to a value out of above range, the upper limit becomes OFF. If the lower limit is set to a value out of above range, the lower limit becomes OFF.</p>
	Query	<p><Upper limit (Ω)> = -3.00000E-03 to +1.20000E-01(NR3), or OFF <Lower limit (Ω)> = -3.00000E-03 to +1.20000E-01(NR3), or OFF</p>
	Example	<p>:CALC:LIM:RES 0.1, 0.05 The upper and lower limits (regardless of the range) are 100mΩ and 50mΩ, respectively. :CALC:LIM:RES 5.0,0.05 :CALC:LIM:RES? OFF,+5.00000E-02 The upper and lower limits (regardless of the range) are OFF and 50mΩ, respectively. :CALC:LIM:RES 0.1,OFF :CALC:LIM:RES? +1.00000E-01,OFF The upper and lower limits (regardless of the range) are 100mΩ, and OFF, respectively.</p>
	Note	If the upper limit is set to a value smaller than the lower limit, the upper limit becomes the same value as the lower.

Set and Query Reactance Component Comparator Upper/Lower Limit

Syntax	Command	:CALCulate:LIMit:REACtance <Upper limit>,<Lower limit>
	Query	:CALCulate:LIMit: REACtance?
	Response	<Upper limit (Ω)>,<Lower limit (Ω)>
	Command	<Upper limit (Ω)> = -1.20000E-01 to +1.20000E-01(NR3), or OFF <Lower limit (Ω)> = -1.20000E-01 to +1.20000E-01(NR3), or OFF If the upper limit is set to a value out of above range, the upper limit becomes OFF. If the lower limit is set to a value out of above range, the lower limit becomes OFF.
	Query	<Upper limit (Ω)> = -1.20000E-01 to +1.20000E-01(NR3), or OFF <Lower limit (Ω)> = -1.20000E-01 to +1.20000E-01(NR3), or OFF

Example **:CALC:LIM:REAC 0.1, 0.05**
 The upper and lower limits (regardless of the range) are 100mΩ and 50mΩ, respectively.
:CALC:LIM:REAC 5.0,0.05
:CALC:LIM:REAC?
OFF,+5.00000E-02
 The upper and lower limits (regardless of the range) are OFF and 50mΩ, respectively.
:CALC:LIM:REAC 0.1,OFF
:CALC:LIM:REAC?
+1.00000E-01,OFF
 The upper and lower limits (regardless of the range) are 100mΩ, and OFF, respectively.

Note If the upper limit is set to a value smaller than the lower limit, the upper limit becomes the same value as the lower.

Set and Query Impedance Component Comparator Upper/Lower limit

Syntax	Command	:CALCulate:LIMit:IMPedance <Upper limit>,<Lower limit>
	Query	:CALCulate:LIMit: IMPedance?
	Response	<Upper limit (Ω)>,<Lower limit (Ω)>
	Command	<Upper limit (Ω)> = 0 to +1.20000E-01(NR3), or OFF <Lower limit (Ω)> = 0 to +1.20000E-01(NR3), or OFF If the upper limit is set to a value out of above range, the upper limit becomes OFF. If the lower limit is set to a value out of above range, the lower limit becomes OFF.
	Query	<Upper limit (Ω)> = 0 to +1.20000E-01(NR3), or OFF <Lower limit (Ω)> = 0 to +1.20000E-01(NR3), or OFF

Example **:CALC:LIM:IMP 0.10, 0.05**
 The upper and lower limits (regardless of the range) are 100mΩ and 50mΩ, respectively.
:CALC:LIM:IMP 5.0,0.05
:CALC:LIM:IMP?
OFF,+5.00000E-02
 The upper and lower limits (regardless of the range) are OFF and 50mΩ, respectively.
:CALC:LIM:IMP 0.1,OFF
:CALC:LIM:IMP?
+1.00000E-01,OFF
 The upper and lower limits (regardless of the range) are 100mΩ, and OFF, respectively.

Note If the upper limit is set to a value smaller than the lower limit, the upper limit becomes the same value as the lower.

Set and Query Phase Component Comparator Upper/Lower limit

Syntax	Command	:CALCulate:LIMit:PHASe <Upper limit>,<Lower limit>
	Query	:CALCulate:LIMit: PHASe?
	Response	<Upper limit (°)>,<Lower limit (°)>
	Command	<Upper limit (°)> = -1.80000E+02 to +1.80000E+02(NR3), or OFF <Lower limit (°)> = -1.80000E+02 to +1.80000E+02(NR3), or OFF If the upper limit is set to a value out of above range, the upper limit becomes OFF. If the lower limit is set to a value out of above range, the lower limit becomes OFF.
	Query	<Upper limit (°)> = -1.80000E+02 to +1.80000E+02(NR3), or OFF <Lower limit (°)> = -1.80000E+02 to +1.80000E+02(NR3), or OFF

Example **:CALC:LIM:PHAS 90.0, -90.0**
 The upper and lower limits are 90.0° and -90.0°, respectively.
:CALC:LIM:PHAS 300,-90.0
:CALC:LIM:PHAS?
OFF,-9.00000E+01
 The upper and lower limits (regardless of the range) are OFF and -90.0°, respectively.
:CALC:LIM:PHAS 90.0,OFF
:CALC:LIM:PHAS?
+9.00000E+01,OFF
 The upper and lower limits (regardless of the range) are 90.0° and OFF, respectively.

Note If the upper limit is set to a value smaller than the lower limit, the upper limit becomes the same value as the lower.

Set and Query Voltage Component Comparator Upper/Lower limit

Syntax	Command	:CALCulate:LIMit:VOLTage <Upper limit>,<Lower limit>
	Query	:CALCulate:LIMit: VOLTage?
	Response	<Upper limit (V)>,<Lower limit (V)>
	Command	<Upper limit (V)> = -5.10000E+00 to +5.10000E+00(NR3), or OFF <Lower limit (V)> = -5.10000E+00 to +5.10000E+00(NR3), or OFF If the upper limit is set to a value out of above range, the upper limit becomes OFF. If the lower limit is set to a value out of above range, the lower limit becomes OFF.
	Query	<Upper limit (V)> = -5.10000E+00 to +5.10000E+00(NR3), or OFF <Lower limit (V)> = -5.10000E+00 to +5.10000E+00(NR3), or OFF

Example **:CALC:LIM:VOLT 5.0, 4.0**
 The upper and lower limits are 5.0V and 4.0V, respectively.
:CALC:LIM:VOLT 30,4.0
:CALC:LIM:VOLT?
OFF,+4.00000E+00
 The upper and lower limits are OFF and 4.0V, respectively.
:CALC:LIM:VOLT 5.0,OFF
:CALC:LIM:VOLT?
+5.00000E+00,OFF
 The upper and lower limits are 5.0V and OFF, respectively.

Note If the upper limit is set to a value smaller than the lower limit, the upper limit becomes the same value as the lower.

(16) Saving and Reading Measurement Conditions**Save and Read Measurement Conditions**

Syntax Command **:SAVE** <Save No.>
:LOAD <Save No.>
 <Save No.> = 1 to 126 (NR1)

Example **:SAVE 10**
:SAVE:CLE 10
:LOAD 5

Note If **:SAVE** is executed when measurement conditions for the <Save No.> have previously been saved, the saved measurement conditions will be overwritten.
 If **:LOAD** is executed specifying a <Save No.> that does not have previously saved measurement conditions, an execution error will occur.

Clear Measurement Conditions

Syntax Command **:SAVE:CLEAr** <Save No.>
 <Save No.> = 1 to 126 (NR1)

Example **:SAVE:CLE 10**

Note If **:SAVE:CLEAr** is executed specifying a <Save No.> that does not have previously saved measurement conditions, an execution error will occur.

(17) System Reset**Initialize Instrument (System Reset)**

Syntax Command **:SYSTem:RESet**

Description Initializes all data except communication settings.(System Reset)
 Panel save data and zero adjust value are also initialized.

Note Use the ***RST** command (p.17) to leave the zero adjustment value and the panel save data.

(18) Measured value output**Setting and querying whether to output measured values after measurement is complete**

Syntax Command **:SYSTem:DATAout** <1 / 0 / ON / OFF>
 Query **:SYSTem:DATAout?**
 Response **<ON / OFF>**

Description Command <ON> = Outputs the measured value to the selected interface after measurement is complete.
 <OFF> = Outputs the measured value only when there is a measured value load request (:FETCh? or :READ? query).
 Query Responds with the setting for outputting measured values after measurement is complete.

Examples **:SYST:DATA ON**
:SYST:DATA?
ON

(19) Key Beeper**Set and Query Key Beeper**

Syntax	Command	:SYSTem:BEEPer <1 / 0 / ON / OFF>
	Query	:SYSTem:BEEPer?
	Response	<ON / OFF>

Example :SYST:BEEP ON
 :SYST:BEEP?
 ON

(20) Key-Lock**Set and Query Key-Lock State**

Syntax	Command	:SYSTem:KLOCK <1 / 0 / ON / OFF>
	Query	:SYSTem:KLOCK?
	Response	<ON / OFF>

Example :SYST:KLOC ON
 :SYST:KLOCK?
 ON

(21) Communications Settings**Return to Local Control**

Syntax	Command	:SYSTem:LOCal
---------------	---------	----------------------

Description Disables communications remote control and re-enables local control. The panel keys are re-enabled.

Example :SYST:LOC

(22) Header**Set and Query Header Presence**

Syntax	Command	:SYSTem:HEADer <1 / 0 / ON / OFF>
	Query	:SYSTem:HEADer?
	Response	<ON / OFF>

Description Sets whether the header is to be included in response messages.
 The response to a message header setting query is returned as ON or OFF.

Example :SYST:HEAD ON
 :SYST:HEAD?
 :SYSTEM:HEADER ON

 :SYST:HEAD OFF
 :SYST:HEAD?
 :OFF

Note When turning the power on, this is initialized to OFF (no header).

(23) Serial Number**Query Serial Number**

Syntax	Query	:SYSTem:SERial?
	Response	<Serial number>

Example	:SYST:SER? 123456789
----------------	---------------------------------------

(24) LCD Settings**Set and Query Contrast**

Syntax	Command	:SYSTEM:DISPlay:CONTRast <Contrast>
	Query	:SYSTEM:DISPlay:CONTRast?
	Response	<Contrast>
		<Contrast> = <0 to 100>

Example	:DISP:CONT 50 Set the display contrast to 50%. :DISP:CONT? 50 The display contrast has been set to 50%.
----------------	--

Set and Query Backlight

Syntax	Command	:SYSTEM:DISPlay:BACKlight <Brightness>
	Query	:SYSTEM:DISPlay:BACKlight?
	Response	<Brightness>
		<Brightness> = <10 to 100>





Example	:SYST:DISP:BACK 50 Set the backlight brightness to 50%. :SYST:DISP:BACK? 50 The backlight brightness has been set to 50%.
----------------	--

(25) Triggering

Relationship between Trigger Source and Continuous Measurement Operation

Operation depends on the continuous measurement setting (:[INITIATE:CONTINUOUS](#)) (p.38) and the trigger source setting (:[TRIGGER:SOURCE](#)) (p.38) as follows.

See: "5 Data Exporting Methods" (p.44)

Measurement Flow		Continuous Measurement Command-Specific Settings	
		: INITIATE:CONTINUOUS ON	: INITIATE:CONTINUOUS OFF
Trigger Source	: TRIGGER:SOURCE IMM	<p>Free-Run state. Measurement continues automatically.</p> 	<p>Start measurement by :INITIATE (or :READ?) command.</p> 
	: TRIGGER:SOURCE EXT	<p>Triggered by TRIG signal or *TRG command. After measurement, enters the trigger wait state.</p> 	<p>Issue :INITIATE (or :READ?) command to wait for trigger. Triggered by TRIG signal. After measurement, enters the idle state.</p> 

The :[INITIATE:CONTINUOUS OFF](#) can only be set by Remote command.

If this has been set to OFF, when operation is returned to the Local state or power is turned off, the :[INITIATE:CONTINUOUS ON](#) state occurs when power is turned back on.

See: "Return to Local Control" (p.35, p.11)

or Exporting measured values: "Data Exporting Methods" (p.44)

Set and Query Continuous Measurement

Syntax	Command	:INITiate:CONTinuous <1/0/ON/OFF>
	Query	:INITiate:CONTinuous?
	Response	<ON/OFF> <ON> = Continuous Measurement Enabled <OFF> = Continuous Measurement Disabled
Description	<ul style="list-style-type: none"> Continuous Measurement Enabled: After measurement, enters the Trigger Wait State. When there is an internal trigger (trigger source <IMMEDIATE>), the next trigger is promptly generated and enters a free run state. Continuous Measurement Disabled: After measurement, enters the Idle State instead of the Trigger Wait State. Triggering is ignored in the Idle State. Executing :INITiate enables the Trigger Wait State. Continuous measurement is enabled upon exiting from the Remote State. 	
Example	:INIT:CONT OFF Set continuous measurement to disabled. :INIT:CONT? OFF Continuous measurement has been set to disabled.	

Set and Query Trigger Source

Syntax	Command	:TRIGger:SOURce <IMMediate / EXTernal>
	Query	:TRIGger:SOURce?
	Response	<IMMEDIATE / EXTERNAL> <IMMEDIATE> = Internal triggering <EXTERNAL> = External triggering
Example	:TRIG:SOUR IMM Set the trigger source to internal triggering. :TRIG:SOUR? IMMEDIATE The trigger source has been set to internal triggering.	
Note	<ul style="list-style-type: none"> When setting the trigger source <IMMEDIATE>, :LIMITer:VOLTage will be set to ON. Even when the settings are changed during a measurement with the internal trigger and low-frequency settings, the setting change is not applied immediately due to the long measurement time. To apply the change immediately, it is necessary to abort the measurement to enter the instrument into the idle state. To enter the instrument into the idle state, follow the procedure below: <ol style="list-style-type: none"> Deactivate the continuous measurement. (command: :INITiate:CONTinuous OFF) Abort the measurement. (command: :ABORt) Require a measurement-interruption response. (query: *OPC?) 	

Transit to Trigger Waiting State

Syntax Command **:INITiate**

Description Switches triggering from the Idle State to the Trigger Wait State.

Example Disable continuous measurement, and read one value for each trigger event.

Example **:TRIG:SOUR IMM**..... Set the trigger source to internal triggering.
:INIT..... Switch triggering to Trigger Waiting State.
 Trigger a single measurement immediately upon internal triggering.

Example **:TRIG:SOUR EXT**..... Set the trigger source to external triggering.
:INIT..... Switch triggering to Trigger Waiting State.
 Trigger a single measurement when an external triggering signal is received.

- Note**
- When this command is received, automatically switches to **:INITiate:CONTINUOUS OFF**.
 - When there is an internal trigger (trigger source <IMMEDIATE>), triggering promptly occurs and enters the idle state.
 - When there is an external trigger (trigger source <EXTERNAL>), the external trigger wait state is entered. When a trigger is received, a single measurement is performed and enters the idle state.

(26) Reading Measured Values

Measurement Value Formats

- Impedance (absolute value display: unit Ω)

Measured Value	Measurement Fault
$\pm \square . \square \square \square \square E-0\square$	See: Measurement Value Formats(Measurement Fault) (p.40)

- Phase angle (absolute value display: unit $^\circ$)

Measured Value	Measurement Fault
$\pm \square . \square \square \square \square E\pm 0\square$	See: Measurement Value Formats(Measurement Fault) (p. 40)

- Resistance / Reactance (absolute value display: unit Ω)

Measured Value	Measurement Fault
$\pm \square . \square \square \square \square E-0\square$	See: Measurement Value Formats(Measurement Fault) (p. 40)

- Voltage (absolute value display: unit V)

Measured Value	Measurement Fault
$\pm \square . \square \square \square \square E\pm 0\square$	See: Measurement Value Formats(Measurement Fault) (p. 40)

- Temperature (absolute value display: unit $^\circ\text{C}$)

Measured Value	Measurement Fault
$\pm \square . \square \square \square \square E\pm 0\square$	See: Measurement Value Formats(Measurement Fault) (p. 40)

Measurement Value Formats(Measurement Fault)

- Impedance / Phase angle / Resistance / Reactance / Voltage

Measurement Fault	Display	Measured Value
Out of Z range	OverRange	+ 1. 00000 E+08
Impedance measurement error by drift voltage	DRIFT VOLTAGE	+ 2. 00000 E+08
Contact error between SOURCE-L and SENSE-L	CONTACT ERROR L	+ 3. 00000 E+08
Contact error between SOURCE-H and SENSE-H	CONTACT ERROR H	+ 4. 00000 E+08
Return cable not connected	RETURN CABLE ERROR	+ 5. 00000 E+08
Out of limit voltage	OVER V LIMIT	+ 6. 00000 E+08
Out of V range	OVER VOLTAGE	+ 7. 00000 E+08
Constant current error between SOURCE-H and SOURCE-L	-----	+ 8. 00000 E+08
A/D converter communication error	A/D ERROR	+ 9. 00000 E+08
Internal battery error	VREF B ERROR	+ 1. 00000 E+09
No measurement after power on		+ 2. 00000 E+09

- 温度

Measurement Fault	Display	Measured Value
Over the upper limit of T range	+Over $^\circ\text{C}$	+ 1. 00000 E+08
Under the lower limit of T range	-Under $^\circ\text{C}$	+ 2. 00000 E+08
Temperature sensor not connected	--,- $^\circ\text{C}$	+ 3. 00000 E+08
No measurement after power on		+ 4. 00000 E+08

Time to receive measured values is different for the :FETCh?/:FETCh:TEMPerature? and :READ? commands.
 See: Data Exporting Methods (p.44), Triggering (p.37)

Abort Measurement

Syntax	Query :ABORt
Description	Measurement is abort (forced termination). :READ? cannot be abort.
Example	:TRIG:SOUR EXT :INIT:CONT ON *TRG :ABOR Aborts a measurement. :TRIG:SOUR EXT :INIT:CONT ON *TRG;*WAI :ABOR In this case, a measurement cannot be aborted because the instrument waits the measurement to finish.
Note	An abort cannot be executed as the instrument waits until all prior commands finish if the query is sent after a *WAI command. An abort cannot be executed as the instrument waits until all prior commands finish if the query is sent after a *OPC and *OPC? command.

Read Measurement Value and Set and Query Response Data

Syntax	Command :MEASure:VALid <MR0> Query :MEASure:VALid? Response <MR0> <MR0> = 0 to 7(NR1) MR: Measurement register (see below)
Description	Command Uses bits in <MR0> to specify the measurement parameters to be returned in response to a query from a FETCh?/:READ? command. 1 is displayed at power-on. Query Returns the measurement parameters specified using bits in <MR0> in response to a query from a FETCh?/:READ? command.

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
Unused	Unused	Unused	Unused	Unused	Total judgment result	Judgment result	Measured value

Measurement register 0 (MR0)

Example	:MEAS:VAL 7 Sets to return the Measured value, Judgment result and Total judgment result. :MEAS:VAL? 7 The Measured value, Judgment result and Total judgment result have been set to be returned.
----------------	---

Read Most Recent Measurement Value

Syntax	Query	:FETCh?
	Response	<Total judgment result>,<Measurement value>,<Judgment result> ,<Measurement value>,<Judgment result>, ... See: "Measurement Value Formats" (p.40)
Description	<p>Reads the most recent impedance and voltage measurement. No trigger occurs. See: Data Exporting Methods (p.44), Triggering (p.37) For (R,X,V,T) measurement, the response is as follows. <Total judgment result> = PASS/FAIL/OFF <Measurement value> = R measurement value <Judgment result> = R measurement comparator judgment result <HI/IN/LO/OFF> <Measurement value> = X measurement value <Judgment result> = X measurement comparator judgment result < HI/IN/LO/OFF > <Measurement value> = V measurement value <Judgment result> = V measurement comparator judgment result < HI/IN/LO/OFF ></p>	

Example	:MEAS:VAL 1.... Sets to return the Measured value. :FETC? +1.02500E-01,+1.02800E-01,+3.00000E+00
	:MEAS:VAL 3.... Sets to return the Measured value and Judgment result. :FETC? +1.02500E-01,IN,+1.02800E-01,IN,+3.00000E+00,IN
	:MEAS:VAL 7.... Sets to return the Measured value, Judgment result and Total judgment result. :FETC? PASS,+1.02500E-01,IN,+1.02800E-01,IN,+3.00000E+00

Note	<ul style="list-style-type: none"> To interrupt the measurement in process while awaiting a response to the *TRG;*WAI;:FETC? (*WAI is replaceable with *OPC or *OPC?) or :READ? query, press the LOCAL key. The instrument may not clear [RMT] to return measured values after the LOCAL key is pressed. In such case, hold the LOCAL key until [RMT] disappears.
-------------	--

Read Temperature Measurement Value

Syntax	Query	:FETCh:TEMPerature?
	Response	<Measurement value> See: "Measurement Value Formats" (p.40)

Description	Reads the last (most recent) temperature measurement value.
--------------------	---

Example	:FETC:TEMP? +2.51000E+01
----------------	------------------------------------

Measure (Await Triggers and Read Measurements)

Syntax	Query	:READ?
	Response	<Total judgment result>,<Measurement value>,<Judgment result> ,<Measurement value>,<Judgment result>, ... See: "Measured value Formats" (p.40)

Description Switches from the Idle State to the Trigger Wait State, then reads the next measured value.

Trigger Source	Operation
IMMediate	Reads the measured value.
EXTErnal	Triggers by the external TRIG signal input, and continuously reads the measured values.

For (R,X,V,T) measurement, the response is as follows.

<Total judgment result> = PASS/FAIL/OFF

<Measurement value> = R measurement value

<Judgment result> = R measurement comparator judgment result <HI/IN/LO/OFF>

<Measurement value> = X measurement value

<Judgment result> = X measurement comparator judgment result <HI/IN/LO/OFF>

<Measurement value> = V measurement value

<Judgment result> = V measurement comparator judgment result <HI/IN/LO/OFF>

Example **:TRIG:SOUR IMM** Set the trigger source to internal triggering.
:MEAS:VAL 1 Set to return the Measured value.
:READ? Trigger a single measurement immediately upon
+1.02500E-01,+1.02800E-01,+3.00000E+00 internal triggering.

Example **:TRIG:SOUR EXT** Set the trigger source to external triggering.
:MEAS:VAL 1 Set to return the Measured value.
:READ? Trigger a single measurement when an external
+1.02500E-01,+1.02800E-01,+3.00000E+00 triggering signal is received.

- Note**
- When this command is received, automatically switches to **:INITIATE:CONTINUOUS OFF**.
 - When there is an internal trigger (trigger source <IMMEDIATE>), triggering promptly occurs and enters the idle state.
 - When there is an external trigger (trigger source <EXTERNAL>), the external trigger wait state is entered. When a trigger is received, a single measurement is performed and enters the idle state.
 - After sending the :Read? query, the measurement cannot be interrupted by sending communications commands.
Pressing the key can interrupt the measurement, resulting in the instrument responding with measured values at the time.
 - The next command does not execute until measurement is finished.
 - To interrupt the measurement in process while awaiting a response to the *TRG;*WAI::FETC?(*WAI is replaceable with *OPC or *OPC?) or :READ? query, press the LOCAL key. The instrument may not clear [RMT] to return measured values after the LOCAL key is pressed. In such case, hold the LOCAL key until [RMT] disappears.

4 Data Exporting Methods

Basic Data Exporting Methods

Flexible data exporting is available depending on the application.

Export Free-Run Data

Default Setting	:INITiate:CONTInuous ON (continuous measurement enable)
	:TRIGger:SOURce IMMEDIATE (internal triggering)
Exporting	:FETCh? Imports the most recent measurement.


Export by Controller (PC, PLC) Triggering

Default Setting	:INITiate:CONTInuous OFF (continuous measurement disable)
	:TRIGger:SOURce IMMEDIATE (internal triggering)
Exporting	:READ? A trigger occurs, and a measurement is performed and the result is transferred.

Export by Applying TRIG Signal


Default Setting	:INITiate:CONTInuous OFF (continuous measurement disable)
	:TRIGger:SOURce EXT (external triggering)
Exporting	:READ? When triggered by TRIG signal, a measurement is performed and the result is transferred.

Using the :FETCh? Command during Continuous Measurement with Internal Triggering



This is the simplest method for exporting measured values. It is ideal when measurement (tact) time is not limited, and when external synchronization is not needed. After connecting to the measurement target, wait for twice the measurement time before exporting the measured value.

Using the :READ? Command while Continuous Measurement is Disabled



Use this method to measure (and export) synchronously with the controller (PC, PLC) or external trigger signal. Measurement time can be minimized.

5 Sample Programs

These programs can be created using Visual Basic 5.0, 6.0 or Visual Basic2013.
Visual Basic is a registered trademark of Microsoft Corporation.

Using Visual Basic 5.0 or 6.0

These sample programs are created with Microsoft Visual Basic 5.0 and 6.0.

The following are used for communication:

For RS-232C/USB communication: MSComm from Visual Basic Professional

During communications, the terminator setting is supposed to be as follows:

RS-232C/USB: CR+LF

RS-232C/USB Communications (Using Microsoft Visual Basic Professional MSComm)

■ Simple Measurement

Imports measured values 10 times, and saves measurements in a text file.

```
Private Sub MeasureSubRS()
    Dim recvstr As String           'Receiving character string
    Dim i As Integer

    MSComm1.CommPort = 1           'COM1 (Check a communication port)
    MSComm1.Settings = "9600,n,8,1" 'Set a communication port (not required with USB)
    MSComm1.PortOpen = True        'Open a port
    Open App.Path & "\data.csv" For Output As #1 'Open a text file for saving

    MSComm1.Output = ":FUNC RV" & vbCrLf 'Select (R,X,V,T) measurement function
    MSComm1.Output = ":MEAS:VAL 1" & vbCrLf 'Output only the measurement value
    MSComm1.Output = ":TRIG:SOUR IMM" & vbCrLf 'Select an internal triggering
    MSComm1.Output = ":INIT:CONT ON" & vbCrLf 'Continuous measurement ON
    For i = 1 To 10
        MSComm1.Output = ":FETCH?" & vbCrLf 'Send ":FETCH?" to import the most recent measurement
        recvstr = "" 'From here on, continue receiving until an LF code occurs
        While Right(recvstr, 1) <> Chr(10)
            recvstr = recvstr + MSComm1.Input
            DoEvents
        Wend
        recvstr = Left(recvstr, Len(recvstr) - 2) 'Delete the terminator (CR+LF)
        Print #1, Str(i) & "," & recvstr 'Write to the file
    Next

    Close #1
    MSComm1.PortOpen = False
End Sub
```

■ Measure by PC Key

Measures and imports by key input on the PC, and saves measurements in a text file.

```
Private Sub MeasureReadSubRS()
    Dim recvstr As String           'Receiving character string
    Dim i As Integer

    MSComm1.CommPort = 1           'COM1 (Check a communication port)
    MSComm1.Settings = "9600,n,8,1" 'Set a communication port (not required with USB)
    MSComm1.PortOpen = True        'Open a port
    Open App.Path & "\data.csv" For Output As #1 'Open a text file for saving

    MSComm1.Output = ":FUNC RV" & vbCrLf 'Select (R,X,V,T) measurement function
    MSComm1.Output = ":MEAS:VAL 1" & vbCrLf 'Output only the measurement value
    MSComm1.Output = ":TRIG:SOUR IMM" & vbCrLf 'Select internal triggering
    MSComm1.Output = ":INIT:CONT OFF" & vbCrLf 'Continuous measurement OFF
    For i = 1 To 10
        'Wait for PC key input
        'Create a key input check routine to set InputKey() = True when a key is pressed
        Do While 1
            If InputKey() = True Then Exit Do
            DoEvents
        Loop
        'After confirming key input, measure once, and read the measured value
        MSComm1.Output = ":READ?" & vbCrLf 'Send ":READ?" to measure and import the measurement
        recvstr = "" 'From here on, continue receiving until an LF code occurs
        While Right(recvstr, 1) <> Chr(10)
            recvstr = recvstr + MSComm1.Input
            DoEvents
        Wend
        recvstr = Left(recvstr, Len(recvstr) - 2) 'Delete the terminator (CR+LF)
        Print #1, Str(i) & ", " & recvstr 'Write to the file
    Next

    Close #1
    MSComm1.PortOpen = False
End Sub
```

■ External Trigger Measurement

Measures and imports based on external triggering (TRIG signal input), and saves measurements in a text file.

```
Private Sub MeasureTrigSubRS()
    Dim recvstr As String           'Receiving character string
    Dim i As Integer

    MSComm1.CommPort = 1           'COM1 (Check a communication port)
    MSComm1.Settings = "9600,n,8,1" 'Set a communication port (not required with USB)
    MSComm1.PortOpen = True        'Open a port
    Open App.Path & "%data.csv" For Output As #1 'Open a text file for saving

    MSComm1.Output = ":FUNC RV" & vbCrLf 'Select (R,X,V,T) measurement function
    MSComm1.Output = ":MEAS:VAL 1" & vbCrLf 'Output only the measurement value
    MSComm1.Output = ":TRIG:SOUR EXT" & vbCrLf 'Select external triggering
    MSComm1.Output = ":INIT:CONT OFF" & vbCrLf 'Continuous measurement OFF
    For i = 1 To 10
        MSComm1.Output = ":READ?" & vbCrLf 'Send ":READ?" to measure and import the measurement
        recvstr = "" 'From here on, continue receiving until an LF code occurs
        While Right(recvstr, 1) <> Chr(10)
            recvstr = recvstr + MSComm1.Input
            DoEvents
            'After confirming external trigger signal, measure once, and read the measurement value.
        Wend
        recvstr = Left(recvstr, Len(recvstr) - 2) 'Delete the terminator (CR+LF)
        Print #1, Str(i) & ", " & recvstr 'Write to the file
    Next

    Close #1
    MSComm1.PortOpen = False
End Sub
```

■ Set Measurement Conditions

Sets up the measurement setting state.

```
'Measurement Setting Configuration
'Configures instrument settings for measurement
'Function: [R, X, V, T]
'Measurement frequency: 1000Hz
'Range: 100mΩ
'Z sampling: FAST, V sampling: FAST
'Trigger: Internal triggering
'Comparator enabled, beep upon Hi or Lo
'Resistance: Upper limit 100mΩ, lower limit 50mΩ
'Reactance: Upper limit 100mΩ, lower limit 50mΩ
'Impedance: Upper limit 100mΩ, lower limit 50mΩ
'Voltage; Upper limit 5V, lower limit 2.5V

Private Sub SettingsSubRS()
    MSComm1.CommPort = 1                'COM1 (Check a communication port)
    MSComm1.Settings = "9600,n,8,1"     'Set a communication port (not required with USB)
    MSComm1.PortOpen = True             'Open a port

    MSComm1.Output = ":FUNC RV" & vbCrLf 'Select (R,X,V,T) function
    MSComm1.Output = ":FREQ 1000"       'Select 1000Hz measurement frequency
    MSComm1.Output = ":RANG 1E-1" & vbCrLf 'Select 100mΩ range
    MSComm1.Output = ":SAMP:RATE Z FAST" & vbCrLf 'Select FAST sampling
    MSComm1.Output = ":SAMP:RATE V FAST" & vbCrLf
    MSComm1.Output = ":TRIG:SOUR :IMM" & vbCrLf 'Select internal triggering
    MSComm1.Output = ":INIT:CONT ON" & vbCrLf 'Continuous measurement ON
    MSComm1.Output = ":CALC:LIM:STAT ON" & vbCrLf 'From here on, comparator setting
    MSComm1.Output = ":CALC:LIM:BEEP HL" & vbCrLf
    MSComm1.Output = ":CALC:LIM:RES 1E-1,0.5E-1" & vbCrLf
    MSComm1.Output = ":CALC:LIM:REAC 1E-1,0.5E-1" & vbCrLf
    MSComm1.Output = ":CALC:LIM:IMP 1E-1,0.5E-1" & vbCrLf
    MSComm1.Output = ":CALC:LIM:VOLT 5E+0,2.5E+0" & vbCrLf

    MSComm1.PortOpen = False
End Sub
```

Using Visual Basic2013


This section describes an example of how to use the Windows development language, Visual Basic2013 Express Edition, to operate the BT4560 unit from a PC via an RS232C/USB interface, incorporate measurement values, and save measurement values to a file.

Visual Basic2013 is referred to as VB2013 hereafter.


Note: The procedure may differ slightly from the one described here depending on the environment of the PC and VB2013. For a detailed explanation on how to use VB2013, refer to the instruction manual or the Help feature of VB2013.

1. Create a new project.

1. Startup VB2013.



2. Select [File] - [New Project].




3. Select [Windows Forms Application] from the templates.


4. Click [OK].

2. Place a button.


1. Click [Button] from [Common Controls] of [Toolbox].
2. Drag and drop the button onto the form layout screen.



3. Change [Text] to "Start Measurement" from the Properties window.




4. The [Start Measurement] is placed on the form.




3. Place a serial communication component.

1. Click [SerialPort] from [Components] of [Toolbox].
2. Drag and drop the [SerialPort] component onto the form layout screen.




3. Change [PortName] to the port name to use for communication from the Properties window.

Check the port to use for communication beforehand.




4. Describe the code.


1. Double-click the placed button to display the code editor.



2. Enter the sample program into the code editor.



3. Select [Save All] from the [File] menu.



Shown below is a sample program which uses VB2013 to initiate RS-232C/USB communications, set the instrument measurement conditions, read measurement results, and then save them to file.

The sample program will be written in the following manner.

Description of creation procedure	Description in sample program
Button created to begin measurement	Button1
Button created to close application	Button2

When the [Begin Measurement] button is pressed, the instrument performs 10 measurements and writes the measurement values to a "data.csv" file.

When the [Close] button is pressed, the program closes.

The following program is written entirely in [Form1] code.

```

Imports System
Imports System.IO
Imports System.IO.Ports

Public Class Form1

    'Perform process when Button1 is pressed
    Private Sub Button1_Click(sender As Object, e As EventArgs) Handles Button1.Click
        Dim recvstr As String
        Dim i As Integer

        Try
            Button1.Enabled = False           'Disable buttons during communication..... (a)
            Button2.Enabled = False
            SerialPort1.NewLine = vbCrLf      'Terminator setting ..... (b)
            SerialPort1.ReadTimeout = 2000     '2 seconds time out ..... (c)
            SerialPort1.Open()                 'Open a port
            SendSetting(SerialPort1)           'Instrument settings
            FileOpen(1, "data.csv", OpenMode.Output) 'Create text file to be saved ..... (d)
            For i = 1 To 10
                SerialPort1.WriteLine(":FETCH?") 'Get measurement results ..... (e)
                recvstr = SerialPort1.ReadLine() 'Read measurement results
                PrintLine(1, recvstr)           'Write to file
            Next i
            Catch ex As Exception
                MessageBox.Show(ex.Message, "Error", MessageBoxButtons.OK, MessageBoxIcon.Error)
            End Try
            FileClose(1)                       'Close file
            SerialPort1.Close()                 'Close port
            Button1.Enabled = True
            Button2.Enabled = True

        End Sub

        'Set measurement conditions
        Private Sub SendSetting(ByVal sp As SerialPort)
            Try
                sp.WriteLine(":FUNC RV")        '[R,X,V,T] function
                sp.WriteLine(":FREQ 1000")      'Set frequency to 1000Hz
                sp.WriteLine(":TRIG:SOUR IMM")   'Select internal triggering
                sp.WriteLine(":INIT:CONT ON")    'Continuous measurement ON
            Catch ex As Exception
                MessageBox.Show(ex.Message, "Error", MessageBoxButtons.OK, MessageBoxIcon.Error)
            End Try
        End Sub

        'Close program when Button2 is pressed
        Private Sub Button2_Click(sender As Object, e As EventArgs) Handles Button2.Click
            Me.Dispose()
        End Sub

    End Class

```

- (a) During communication the [Begin Measurement] and [Close] buttons cannot be pressed.
- (b) Sets CR + LF as the terminator indicating the end of the sending and receiving character string.
- (c) Sets the reading operation time to 2 seconds.
- (d) Opens the "data.csv" file. However, if a file with this name already exists, the previous "data.csv" will be deleted and a new file created.
- (e) Sends the command to the instrument to return the measurement result to the computer.

HIOKI

www.hioki.com/



**All regional
contact
information**

HIOKI E.E. CORPORATION

81 Koizumi, Ueda, Nagano 386-1192 Japan

2402 EN

Edited and published by HIOKI E.E. CORPORATION

Printed in Japan

- Contents subject to change without notice.
- This document contains copyrighted content.
- It is prohibited to copy, reproduce, or modify the content of this document without permission.
- Company names, product names, etc. mentioned in this document are trademarks or registered trademarks of their respective companies.

Europe only

• EU declaration of conformity can be downloaded from our website.

• Contact in Europe: HIOKI EUROPE GmbH

Helfmann-Park 2, 65760 Eschborn, Germany

hioki@hioki.eu