



HIOKI

3855

RS-232C パッケージ

RS-232C PACKAGE

取扱説明書

Instruction Manual

July 1999

Edition 1

日置電機株式会社 Printed in Taiwan

HIOKI

日置電機株式会社

本社 TEL0268-28-0555 FAX0268-28-0559
〒386-1192 上田市小泉 8-1

東北(営) TEL022-288-1931 FAX022-288-1934
〒984-0011 仙台市若林区六丁の目西町 8-1

東京(営) TEL048-267-7234 FAX048-261-5790
〒333-0847 川口市芝中田 2-2-3-2-4

特販課 TEL048-267-0017 FAX048-261-5790
〒333-0847 川口市芝中田 2-2-3-2-4

北関東(営) TEL048-266-8161 FAX048-269-3842
〒333-0847 川口市芝中田 2-2-3-2-4

長野(営) TEL0268-28-0561 FAX0268-28-0569
〒386-1192 上田市小泉 8-1

神奈川(営) TEL046-224-8211 FAX046-224-8992
〒243-0016 厚木市田村町 8-8

静岡(営) TEL054-254-4166 FAX054-254-3160
〒420-0054 静岡市南安衛 1-3-10

名古屋(営) TEL052-702-6907 FAX052-702-6943
〒465-0081 名古屋市中区高岡町 2-2

大阪(営) TEL06-6871-0088 FAX06-6871-0025
〒565-0095 豊中市上新田 2-1-3-7

広島(営) TEL082-879-2251 FAX082-879-2253
〒731-0122 広島市安佐南区中筋 3-2-8-1-3

福岡(営) TEL092-482-3271 FAX092-482-3275
〒812-0006 福岡市博多区上牟田 3-8-1-9

※お問い合わせは最寄りの営業所または本社販売企画課まで。
E-mail: info@hioki.co.jp URL: http://www.hioki.co.jp/
3855A980-00 99-07-00015H

HIOKI

保証書

形名	製造番号	保証期間
3855		購入日 年 月より1年間

この製品は、弊社の厳密なる検査を経てお届けしたものです。万が一使用中に故障が発生した場合は、お買い求め先に依頼してください。本書記載内容で無償修理をさせていただきます。依頼の際は、本書を提示してください。

お客様 住所 〒 TEL
ご芳名
* 保証書の再発行はいたしませんので、大切に保管してください。

保証規定

- 取扱説明書・本体注意ラベルなどの注意事項にしたがった正常な使用状態で保証期間内に故障した場合には、無償修理いたします。
- 保証期間内でも、次の場合には有償修理となります。
 - 1 本書の提示がない場合。
 - 2 取扱説明書に基づかない不適当な取扱い、または使用上の誤りによる故障および損傷。
 - 3 不当な修理や改造による故障および損傷。
 - 4 お買い上げ後の輸送や落とされた場合などによる故障および損傷。
 - 5 外観上の変化（筐体のキズ等）の場合。
 - 6 火災・公害・異常電圧および地震・雷・風水害その他天災地変など、外部に原因がある故障および損傷。
 - 7 消耗部品（乾電池等）が消耗し取換えを要する場合。
 - 8 その他弊社の責任とみなされない故障。
- 本保証書は日本国内のみ有効です。
(This warranty is valid only in Japan.)

サービス記録

年月日	サービス内容

日置電機株式会社

〒386-1192 上田市小泉 8-1

TEL 0268-28-0555

FAX 0268-28-0559



はじめに

このたびは、HIOKI "3855 RS-232C PACKAGE" をご購入いただき、誠にありがとうございます。この製品を十分にご活用いただき、末長くご使用いただくためにも、取扱説明書はていねいに扱い、いつも手元に置いてご使用ください。

RS-232C PACKAGE をご使用にあたっての注意

ご使用する前に下記の事項を確認くださいますようお願いいたします。

- ・"RS-232C PACKAGE" は日置電機の著作物です。
- ・7015 のデータを処理する目的以外で"RS-232C PACKAGE" を一部または全部を複製、複写、改変することは法律で禁じられております。
- ・"RS-232C PACKAGE" は改良のため予告なく変更、バージョンアップすることがあります。
- ・"RS-232C PACKAGE" を引用し書籍を刊行する場合、弊社による事前の承諾が必要です。また、「HIOKI」の商標の使用はできません。
- ・弊社はいかなる場合においても、お客様が"RS-232C PACKAGE" を使用した運用結果に関して、一切の責任を負うものではありません。

●フロッピーディスクについて

- ・落としたり、手で曲げたり、強い衝撃を与えないでください。
- ・直射日光の当たるところ、強い磁気の近く、暖房器具の近くなどに置かないでください。
- ・水にぬらさないでください。

●登録商標について

- ・Windows は米国マイクロソフト社の登録商標です。
 - ・i486 は米国インテル社の登録商標です。
 - ・その他の製品名は各社の商標または登録商標です。
- Copyright(C)1987-1995 Microsoft Corporation, All rights reserved
Copyright(C)HIOKI E.E Corporation 1999.

1. RS-232C PACKAGE の概要

"RS-232C PACKAGE" はパソコンを使って 7015 のデータ処理を行うソフトウェアです。

2. RS-232C PACKAGE の一般仕様

メディア: 3.5 インチ 2HD(1.44 Mbyte)フロッピーディスク 1 枚
対応測定器: HIOKI 7015 シグナルソース

動作環境

本体	i486 以上の CPU を搭載し、Windows 3.1, Windows 95, Windows 98 または Windows NT 4.0 が動作する DOS/V パーソナルコンピュータ
メモリ	8 Mbyte 以上
ディスプレイ	VGA 640×480
ハードディスク	空き容量 4 Mbyte 以上

3. RS-232C PACKAGE の機能仕様

最大取扱データ数	32700 データ
ファイル操作	ファイルオープン、ファイルセーブ
印刷	データ印刷
記録	テキスト形式、Record 形式
通信	RS-232C よりデータの取込み

4. 接続方法

7015 とパソコンを付属のケーブルで接続します。7015 への接続はコネクタの向きに注意してください。詳しくは、7015 本体の取扱説明書を参照してください。

5. 起動方法

- ①「2. 一般仕様」の動作環境を満たしていることを確認して、RS-232C PACKAGE のフロッピーディスクをフロッピーディスクドライブに装着します。
- ②RS-232C PACKAGE のフロッピーディスクが入っているフロッピーディスクドライブを選択します。
- ③フロッピーディスク内のすべてのファイルを、ハードディスクの適当なフォルダにコピーしてください。
- ④コピーしたファイルの中から、「Cmm.exe」を実行してください。
- ⑤操作方法がよくわからない場合は「Cmmjp.hlp」を参照してください。

Introduction

Thank you for purchasing this HIOKI 3855 RS-232C PACKAGE. In order to use this product effectively and to ensure that it enjoys a long operational life, read this Instruction Manual carefully and then retain it for future reference.

Notes on Using RS-232C PACKAGE

Before using the software, please read these notes carefully.

- HIOKI E.E. Corporation is the author of RS-232C PACKAGE. Except for the purposes of processing data from the 7015 copying, reproduction, or amendment in whole or in part of RS-232C PACKAGE is prohibited by law.
- For the purposes of product development, RS-232C PACKAGE is subject to upgrading without notice.
- To publish material referencing RS-232C PACKAGE, the prior consent of HIOKI is required. The trademark "HIOKI" may not be used.
- HIOKI cannot accept any responsibility whatever for the results of a customers operation of RS-232C PACKAGE.

Floppy disks

- Do not drop floppy disks, bend them by hand, or subject them to violent shocks.
- Do not leave floppy disks where they are open to direct sunlight, close to magnetic fields, or close to heating equipment.
- Do not allow floppy disks to get wet.

Registered trademarks

- Windows is a registered trademark of Microsoft Corporation.
 - i486 is a registered trademark of Intel Corporation.
 - Other trademarks are the property of their respective owners.
- Copyright (c) 1987-1995 Microsoft Corporation, all rights reserved
Copyright (c) HIOKI E.E. Corporation, 1999.

1. RS-232C PACKAGE Overview

RS-232C PACKAGE is software which runs on a personal computer and processes 7015 data and controls the 7015.

2. RS-232C PACKAGE General Specification

Software supply medium:

One 3.5-inch 2HD floppy disk (1.44 Mbyte)

Unit supported:

HIOKI 7015 SIGNAL SOURCE

Operating environment

Computer	Personal computer (DOS/V) with at least an i486 CPU, running Windows 3.1, Windows 95, Windows 98 or Windows NT 4.0
Memory	At least 8 Mbytes
Monitor	VGA 640×480
Hard disk	At least 4 Mbytes available space

3. RS-232C PACKAGE Functional Specification

Maximum readings accepted	32700
File operations	Open file and save file
Printing	Data printing
Recording	.txt (ASCII text file), .rdf (Record file)
Remote functions	Data capture through serial (RS-232C) interface

4. Connection to a Computer

Connect 7015 with the personal computer by the attached cable. Confirm the direction of connector when fixing the cable to the 7015 bottom case. See the 7015 instruction manual.

5. Starting the Software

- ① Check that the operating environment meets the conditions shown in Section 2, "RS-232C PACKAGE General Specification," and insert the RS-232C PACKAGE floppy disk into the floppy disk drive.
- ② Move to the floppy disk drive in which the RS-232C PACKAGE disk is inserted.
- ③ Copy all files on the floppy disk to a suitable folder on the hard disk.
- ④ Move to the folder in which the copied files exist.
- ⑤ Run "Cmm.exe".
- ⑥ See "Cmm.hlp" when the detailed explanation of the operation is required.

HIOKI

HIOKI E. E. CORPORATION

HEAD OFFICE

81 Koizumi, Ueda, Nagano 386-1192, Japan
TEL +81-268-28-0562 / FAX +81-268-28-0568
E-mail: os-com@hioki.co.jp

HIOKI USA CORPORATION

6 Corporate Drive, Cranbury, NJ 08512, USA
TEL +1-609-409-9109 / FAX +1-609-409-9108

URL <http://www.hioki.co.jp>

3855A980-00 99-07-00015H