

9491 積算・D/Aユニット

9491は、ボード一枚で構成されています。

3192への取付は、次の手順に従ってください。

危険

(1) 測定ラインと3192との結線をはずしてください。

(2) 3192の電源コードを、3192のAC電源インレットからはずしてください。

測定ラインが結線されたまま、また、3192の電源が投入されたままですと、感電などの危険が伴います。また、3192や9491の故障の原因にもなります。

(3) 3192の取扱説明書「11-4. 取付方法」に従って、取付けてください。

(4) 3192のバックパネルの止めネジを元どおりに止めてください。

注意

バックパネルや止めネジにがたつきやゆるみがありますと、振動・衝撃により9491の接触不良などの不具合が発生する原因になります。

使用方法などについては、3192の取扱説明書の第11章を参照してください。

計測の先進機能を社会に

HIOKI
日置電機株式会社

本社 TEL0268-28-0555 FAX0268-28-0559
〒386-11 上田市小泉8-1

札幌(営) TEL011-832-2838 FAX011-832-2841
〒003 札幌市白石区東札幌3条2丁目1番

仙台(営) TEL022-288-1931 FAX022-288-1934
〒983 仙台市若林区六丁の目西町8-1

長野(支) TEL0268-28-0561 FAX0268-28-0569
〒386-11 上田市小泉8-1

東京(営) TEL048-267-7234 FAX048-261-5790
〒333 川口市芝中田2-23-24

埼玉(営) TEL048-266-8161 FAX048-269-3842
〒333 川口市芝中田2-23-24

神奈川(営) TEL0462-24-8211 FAX0462-24-8992
〒243 厚木市田村町8-8

静岡(営) TEL054-254-4166 FAX054-254-3160
〒420 静岡市南安信1-3-10

名古屋(営) TEL052-937-8351 FAX052-935-0984
〒461 名古屋市東区葵1-26-14

大阪(営) TEL06-337-1671 FAX06-384-7454
〒564 吹田市江坂町1-12-28

広島(営) TEL082-242-1230 FAX082-242-1236
〒730 広島市中区大手町4-6-16

福岡(営) TEL092-482-3271 FAX092-482-3275
〒812 福岡市博多区博多駅東3-10-15

※お問い合わせは最寄の営業所または本社営業企画部まで。

9491A980 93-01-H 78390060

9 4 9 1 Integrator and D/A Unit

The 9491 is composed of a board.

Installation to the 3192 is the following procedure.

DANGER

- (1) Take off the connecting wire between the line to be measured and the 3192.
- (2) Take off the 3192 power cord from the AC power inlet of the 3192

If leave the measurement line connecting or the 3192 turning the power on, there is danger of electric shock, and also the 3192 or the 9491 may be damaged.

- (3) Install following section 11-4 "Installation" of the 3192 manual.
- (4) Tighten the fixing screws on the back panel of the 3192 as before.

CAUTION

If the back panel and the fixing screws are not stable or loose, any vibration or shock have an effect on contact of the 9491.

Refer to section 11 on how to use of the 3192 instruction manual.