ΗΙΟΚΙ

GUIDE BOOK

8855 MEMORY HICORDER

HIOKI E.E. CORPORATION

Introduction

1

Thank you for purchasing the HIOKI "8855 MEMORY HiCORDER." To obtain maximum performance from the product, please read this manual first, and keep it handy for future reference.

About This Manual

The manual "Measurement Guide for the 8855" contains the minimum information necessary for operation of the 8855 MEMORY HiCORDER. For a detailed explanation of operating methods, please refer to the 8855 Quick Start Manual and 8855 Instruction Manual. Be sure to read and understand the sections entitled "Safety Notes" and Chapter 2 "Installation and Preparation" in the 8855 Instruction Manuals before using the product.

Identification of Controls and Indicators	2
Operation Method of the Panel Key	3
Display Screen and Setting Screen	5
Operation flow	- 13
Simple measurement operations	14
Measurement of instantaneous power interruption	
in a commercial power line	- 15
Measurement of the sensor output	21
External Memory Devices	28
Storage of measurement data	- 30
Reading measurement data	32
Automatic saving of measurement data	34
Real-time printing of measurement data	- 35
Useful Information	- 36

Identification of Controls and Indicators



Right Side Panel

1	Power switch	Switches on or off the power supply.
2	AC connector	The supplied power cord must be plugged in here.
3	Function ground terminal (GND)	Connects to the earth.
4	External sampling terminal	Allows input of an external sampling clock. (in the Memory function)
5	Trigger terminals	Can be used to synchronize multiple products, using the EXT TRIG input and TRIG OUT output.
6	PC card slot	Inserts the PC card.
7	Logic probe connectors	Input connector for the logic input section, designed for the dedicate logic probes (CH A to D).
(8)	Eject button	Removes the PC card.
9	External output terminal	Various output signals can be selected, such as the BUSY, storage, or probe offset (1 kHz, 5 V Rectangle wave output)
10	NG evaluation output terminal	When NG results from the numerical evaluation and waveform evaluation, a signal is output from this terminal.
1	GO evaluation output terminal	When GO results from the numerical evaluation and waveform evaluation, a signal is output from this terminal.
(12)	Ground terminal (GND)	Uses with (1) to (1) (except (12)) terminals.
(13)	External stop terminals	Stop operation can be controlled.
14)	External start terminals	Start operation can be controlled.
(15)	Key lock	Locks the operation of keys.

- 1 LAN connector Can be connected to a network through a LAN.
- (B) FD slot Floppy disk is inserted.
- (9) MO slot MO disk is inserted. (when the 9646 is installed)
- Input unit slots
 These slots accept input units.
- (2) Fastening screw Secures the plug-in product.
- Analog input connector Unbalanced analog input. (on ANALOG UNIT)
- Blowing slot

Operation Method of the Panel Key



Front Panel

- ① F1 to F10 key Serve to select setting items.
- 2 **HELP** key Provides on-line help.
- (3) **CHAN** key Causes the display to show the Channel screen which serves for making input channel settings.
- (4) **DISP** key Causes the display to show measurement and analysis results.
- (5) **FILE key** Causes the display to show the File screen which serves for reading, storing, etc. the waveform data etc.
- 6 **TRIG** key Causes the display to show the Trigger screen. Setting the trigger functions.
- ⑦ **STATUS** key Causes the display to show the Status screen which serves for setting most measurement parameters.

⁽⁸⁾ **TIME/DIV** key Serves to set the speed for inputting and storing the input signal.

- (9) **SYSTEM** key Causes the display to show the System screen. Makes all the settings of common functions, such as the initial settings and various other settings.
- (1) **PRINT** key Serves to print out stored waveforms.
- (1) **COPY** key Serves to print out a hard copy of the current screen display.
- ⁽²⁾ **FEED** key Causes the printer paper to advance for as long as the key is pressed.
- ⁽¹³⁾ **CURSOR** key These keys serve to move the flashing cursor in the four directions.
- (A) SAVE key Saves the data on the specified media.
- (15) **AUTO** key Pressing this key activates automatic setting of time axis range and voltage range values of input waveform.
- ⁽¹⁶⁾ **VALUE** key Uses to select the numerical values setting.
- 1 WAVE key Uses to select the the waveform scrolling.
- B JOG Rotary control knob that serves to change values, move the A/B cursors, and scroll the waveform.
- (9) SHUTTLE Concentric ring that serves to change values, move the A/B cursors, and to scroll the waveform. The speed of movement is proportional to the rotation angle.
- **A.B CSR key** Uses to select the the A/B cursor moving.
- (2) **RANGE** knob Sets the measurement range for the channel.
- STOP key Stops measurement and analysis. Pressing this key twice stops measurement.
- START key Initiates the measurement and analysis. During measurement, the LED above the key is lit.
- **POSITION** knob Sets the zero position for the channel.
- Channel select Selects channel. keys
- Bisc key Exits the Input or Set up screen.

Display Screen and Setting Screen

Waveform display screen

The screen shown below appears immediately after the power switch is turned on. The waveform display screen can also be displayed by pressing the red DISP key. The following explains the displayed items and the items that can be set in the waveform display screen.



Other settings can be made by pressing the CH setting key (F9 function key) in the waveform display screen. Each time the F9 key is pressed, the CH setting screen changes as shown on the next page, and displays channel information or allows setting to be performed.

Function Time	5,µs/DIV	(50ns/S) Trig	AUTO 🗗 0%		°01-11-06	15:35:34	
MEMORY Shot	30DIV (150µs)	×1 (5.00µs)	┝᠊᠊᠋ᠻ᠆ᠫᢄᡃᠮ᠆᠆᠋ᠨ᠆᠆᠆		,	
				CH1 🔳 5n	DC DC	50% OFF	
				CH2 🔳 5n	V DC	50% - 0FF	
				СНЗ 🔳 5л	V DC	50%	— CH setting screen
				CH4 🔳 20n	V DC	50% . OFF	
				CH5 🔳 5n	y pc	50% .0FF	
				CH6 🔳 5m	Y DC	50% OFF	
				€H7 ■ 1n	V DC	50% OFF	
				CH8 ■ 500,	Y DC	- 50% OFF	
						150 -	
					CHSD CH2D CH.SET	MANUTRIG	



Channel screen

The channel screen can be displayed by pressing the CHAN key located on the left side of the unit. This screen is used to set units (analog input) and to enter logic input, display the settings for each channel, and to enter scaling settings, comments, and other detail settings.

LIST							
MENU				MEMOR	Y	/	Indicates the channel. Settings can be copied between channels.
DICHANNEL.	ANALOG	G LO	GIC	XY	OPTION	/ /	Indicates the unit type.
ONE CH		CH1	CH2	CH3	CH4		Used to select waveform display ON/OFF.
LIST	Amp	ANALOG	DC/RMS	TEMP	HI RESO		Used to select waveform graph ON/OFF.
SCAL ING	Wave	🔳		I OFF	I OFF	/	This item is enabled when the display shows multiple screens.
COMMENT	Graph	GR1	GR2	GR3	GR4		Used to select the measurement mode. (voltage, current,
TRIGGER	Mode	VOLTAGE	DC	VOLTAGE	VOLTAGE		temperature, etc.)
TRIGGER	Range	200mV	200mV	500,JV	1V		Used to select the vertical axis (voltage axis) range.
DSTATUS	Coupling	DC	DC	DC	DC		Used to select the input coupling setting. (AC, DC, GND)
						<u> </u>	Used to select the low path filter ON/OFF.
	Zoom	×1 75%	>L	×1	×1	\sim	Used to select vertical axis (voltage axis) zoom
	Position	/3/	23%	006	006	<	
		200mU	200mV	500.JJ	11		Used to set the zero position . This allows selection of the zero-
SET UP	Diso	200111	2001117	500,20	10	//	
FILE SAVE	DISP	1	ľ	511	10	\backslash	Used to select variable ON/OFF. The position and size of the
PRINTER	Limits	-3	-1	-5m	-10		displayed wavelorm can be changed.
INTERFACE	Meas	4	4	10m	20		Indicates the voltage value per DIV (grid).
INITIALIZE	Limits	-4	-4	-10m	-20		This setting can be entered when variable is ON.
SELF CHECK	Unit	V	V	V	v	\backslash	Indicates the upper- and lower-limit values of the display screen. This setting can be entered when Variable is ON.
Operation Gu	ide ^{Make}	function	mode set	tings. Pr	ess the f	'	Indicates the upper- and lower-limit values within the selected
MENU				ЯZ	Г		Indicates the measurement unit of the vertical axis
				ORDER			
-			_				
	Page cha	ange ke	v				

The above screen shows the analog-setting list page. Press the Page Switch key (F3 function key) to change the display to pages for logic input setting, X-Y setting, and details (options) setting. The following describes each of these pages.



l ict

MENU				MEMOR	Y			*01-07-1	1 12:44:
ECHANNEL	ANALOS		GIC	XY	OPTION				
ONE CH									
LIST		CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8
SCAL ING	Апр	ANALOG	ANALOG	H1 RESO	HI RESO	CURRENT	CURRENT	TEMP	TEMP
COMMENT	Probe	1:1	1:10	1:100	1:1000				
ETRIGGER	A.A.F								
TR IGGER	Response								
ISTATUS	RJC							INT	INT
STATUS	Burn Out							OFF	OFF
MEMORY DIV	Level								
MEASUREMENT	Pull Up								
	Hold								
EISYSTEM	Slope								
SET UP									
FILE SAVE									
PR INTER									
INTERFACE									
INITIAL IZE									
SELE CHECK									
	_								_
Operation Gui	de F2 k	screen a eys to sw	itch sett	inging eac	h channel ns. and u	setting use the FS	from a li I key to c	st. Use t hange bet	he F1 and ween the
MENU V									0 Ad.iu

Options page

Selection of the probe pressuredistribution ratio when the 9665, 9666, or 9322 is used Setting of the antialiasing filter (enabled when used with the 8953-10 unit) Setting of details (reference contact, burnout) for temperature measurement when used with the 8954 unit Setting of details (threshold, hold, level, etc.) when used with the 8955 unit

In addition to the list page shown on the previous page, the channel screen includes the three types of pages specified below. To change pages, press the menu key (F1 F2 function keys) or CHAN key.



ONE CH

These pages are used to enter settings for individual channels. Since the page displays a level monitor and numerical values, variable and scaling settings can be entered while the input level is monitored.

MENU				M	EMORY				·01-05-29	16:14:09
ECHANNEL										
ONE CH		Scaling	EU/V	Inp	at		Scale	1	Unit	
LIST			Offset							
SCAL ING	CH1	ENG	1.0000	P1	50.000m		• P1	50.000m	V	
COMMENT			0.0000	P2	-50.000m	-	• P2	-50.000m		
TRIGGER	CH2	SC1	1.0000E+00	P1	50.000E-03		• P1	50.000E-03	V I	
TR JGGER			0.0000E+00	P2	-50.000E-03		• P2	-50.000E-03		
ESTATUS	CH3	OFF	1.0000	P1	50.000m		P1	50.000m	V	
STATUS			0.0000	P2	-50.000m		• P2	-50.000m		
MEMORY DIV	CH4	OFF	1.0000	P1	50.000m		• P1	50.000m	V	
MEASUREMENT			0.0000	P2	-50.000m		• P2	-50.000m		
	CH5	OFF	1.0000	P1	50.000m		P1	50.000m	V	
ESYSTEM			0.0000	P2	-50.000m		• P2	-50.000m		
SET UP	CH6	OFF	1.0000	P1	50.000m		• P1	50.000m	V	
FILE SAVE			0.0000	P2	-50.000m	-	• P2	-50.000m		
PR INTER	CH7	OFF	1.0000	P1	50.000m		• P1	50.000m	V	
INTERFACE			0.0000	P2	-50.000m	-	• P2	-50.000m		
INITIALIZE	CH8	OFF	1.0000	P1	50.000m		• P1	50.000m	V	
SELF CHECK			0.0000	P2	-50.000m		• P2	-50.000m		
Departion Gui	da					-				
operación du	00				_					
VENU A	\sim	ſ		NO	ROI					

SCALING

This page is used to enter scaling settings. It allows the setting of scaling values for all channels. For details, refer to 5.3 "Scaling Function" in the Instruction Manual.

MENU	MEMORY	*01-05-29 16:18:13
ECHANNEL	ANALOG LOGIC	
ONE CH	[Title]	
LIST	Setting Comment	
COMMENT	Title COMMENT	
TRIGGER	[Each Channel]	
TRIGGER	Setting Comment	
STATUS	CH1 SETTING	
MEMORY DIV	CH2	
MEASUREMENT		
	CHS	
ESYSTEM	CH6	
ETLE SAVE	CH7	
PRINTER	CH8	
INTERFACE		
INITIALIZE		
SELF CHECK		
Operation G	iide	
MENU		

COMMENT

This page is used to enter comments. It allows the input of comments for all channels (logic). For details, refer to 5.4 "Comment Function" in the Instruction Manual.

Trigger screen

The trigger screen can be displayed by pressing the TRIG key located on the left side of the unit.

This screen is used to set the trigger for each channel.

To switch the page between analog and logic, press the Page Switch key (F3 function key).

Analog trigger setting



Logic trigger setting



9

Status screen

The status screen can be displayed by pressing the <u>STATUS</u> key located on the left side of the unit. This screen is used to enter basic waveform data-acquisition settings, memory allocation settings, and calculation settings.



In addition to the basic setting page shown above, the status screen includes the three pages specified below. To change pages, press the menu key ($\begin{bmatrix} F1 \\ F2 \end{bmatrix}$ function keys) or CHAN key. Regarding the setting method, refer to the Instruction Manual provided with the product.



MEMORY DIV (Chapter 6 "Memory

WAVE CULC (Chapter 7: 7.2 "Waveform Calculation" in the Instruction Manual)

MENU						PERUKT				, v	2 03	00 12,044
DCHANNEL)	(ave C	alc	ulation		ON 4	🚓 Me	eas Are	a			ALL WAVE
ONE CH		Ch		Equation								
LIST	Z1	CH7	=	CH1+CH2								
SCAL ING	Z2	CH8	=	LOG(CH1)								
COMMENT	Z3	NONE	?									
STD LCCCD	Z4	NDNE	?									
TRIGGER	Z5	NONE	?									
INTOULN	Z6	NONE	?									
ISTATUS	Z7	NONE	?									
STATUS	Z8	NONE	?									
MEMORY DIV												
MEASUREMENT		Scale	Lo	ver	Upper	Unit	Mo∨	Sli	ECC	NST.]		
WAVE CALC	Z1	AUTO					1	0	a	0.0000	i	0.0000
ISYSTEM	Z2	AUTO					1	9	b	0.0000	j	0.0000
SET UP	Z3	AUTO					1	0	С	0.0000	k	0.0000
FILE SAVE	Z4	AUTO					1	0	d	0.0000	1	0.0000
PRINTER	Z5	AUTO					1	8	е	0.0000	m	0.0000
INTERFACE	Z6	AUTO					1	0	f	0.0000	n	0.0000
INITIAL 170	Z7	AUTO					1	0	8	0.0000	0	0.0000
INTERACIZE	Z8	AUTO					1	8	h	0.0000	p	0.0000
SELF UHEUK												
Operation Gui	de	Calc as a curr	ula wə ent	tions are veform. P in memor	applied Tressing E	to acquire Kecute app	d data lies t	. and he cal	the cula	results are tions to th	⊧di: he w	splayed aveform
V A				<u>_</u>	<u>-</u>	01100	٦					

MEASUREMENT (Chapter 7: 7.1 "Numerical Calculation" in the Instruction Manual)

MENU				MEMORY						.02-1	d5-08 12:02:	49
CHANNEL .	Mea	surement		ON		Res	sult to	Print	ter	1	OFF	
ONE CH	Mea	is Area		ALL WAVE		Sav	∕e Media	L			OFF	
LIST	Sto	no Made		GOSNG								
SCAL ING	1.0		- 1		- 1							
COMMENT												
TELEP		Kind	Ch	Parameter		_		Сопр	Lower	r	Upper	
TRIGGER	No.1	AVERAGE	CH1					OFF				-
	No.2	RMS	CH1					ON		95.000	105.00	-
DSTATUS	No.3	PEAK-PEAK	CH1					OFF				-1
STATUS	No.4	MAXIMUM	CH1					OFF				-
MEMORY DIV	No.5	MINIMUM	CH1					OFF				_
MEASUREMENT	No.6	PERIOD	CH1	L: 0.00	60 I	1	OFF S:1	OFF				-
MAVE CALC	No.7	FREQUENCY	CH1	L: 10.0	00m	:	OFF S:1	OFF				_
ANVE ONLO	No.8	PULSE WIDTH	A_C CH1	L: 20.0	00m	: 1	OFF S:1	OFF				
DISYSTEM	No.9	OFF										_
SET UP	No10	OFF										
FILE SAVE	No11	OFF										
PRINTER	No12	OFF										
INTEDEACE	No13	OFF										
THTEN PGE	No14	OFF										
INITIALIZE	No15	OFF										
SELF CHECK	No16	OFF										
Operation Gui	ide	Apply calculati calculations to applied selecti	ons to a wavefor vely to	acquired wa m data cur data betwe	rent rent	ly /B	. Press in memo cursors	EXEC ry. C	UTE t alcul	o apply ations	can be	
	ίυ.	OFI	7	N e>	ec.	J						



System screen

The system screen can be displayed by pressing the SYSTEM key located on the left side of the unit.

To change pages, press the menu key (F1 F2 function keys).

The system screen is used to enter settings common to all functions; settings for printer, files, and communication; 8855 initial settings; and self-diagnosis settings.

The following briefly describes each of these setting pages.

OUT OUT	(
UNE UNE	Grid Type	STANDARD	Auto Variable Scale	ON
LIST	Comment	OFF		
SCAL ING	Time Value	TIME		
COMMENT	Start Backup	DEE	START Key Accentance	ONE PUSH
TD IGGER	Back Light Saver	OFF		0110 1 0011
ATIC	Display Color	COLOR 3		
STATUS	Beep Sound	BEEP1		
EMORY DIV	Language	ENGL ISH		
YSTEM ISET UP	START/EXT.IN1 STOP /EXT.IN2	START STOP	GO NG	MEASURE
DET UP	EXT TRIG	+	EXT OUT	CALIBRATION
PRINTER	EXT.SMPL	t	TRIG OUT	PULSE
NTERFACE	[SCS1 SETTING]			
1T14L17E	SCS1 Host ID(8855)	7	MD controled by PC	OFF

SET UP (Refer to 9.2 "Set Up Screen" in the Quick Start Manual.)

- Display settings (grid display, comment display, etc.)
- Start condition settings (start backup, etc.)
- External control terminal settings (GO. NG terminal, probe correction output setting)
- SCSI settings (ID setting, external MO setting, PC connection setting)



FILE SAVE (Refer to 9.3 "File Screen" in the Quick Start Manual.)

- Auto-save settings (destination, file save format, saving range, etc.)
- Storage of numerical processing results (destination, <u>saving method</u>)
- SAVE key setting (saving operation performed when the SAVE key is pressed)



PRINTER (Refer to 9.4 "Printer Screen" in the Quick Start Manual.)

- Printer settings (Grid, density, gauge, marker, size, etc.)
- Printing format settings
- Comment printing settings
- Printing destination setting (printer, LAN equipment)
- Real-time print settings (recorder function, R&M)

MENU		MEMORY	*02-05-08 16:28:17
CHANNEL.	LAN PC CAR	D PPP	
ONE CH			
LIST			
SCAL ING	Use DHLP	UFF LFTPJ	
CONMENT	Host Name	Lhioki J User Name	Lhioki J
TE TRIGGER	IP Address	0. 0. 0. 0 Pass Word	[**********
TR IGGER	Subnet Mask	255.255.255. 0 Access Control	READ ONLY
RESTATUS	Use Gateway	OFF	
STATUS	IP Address	0. 0. 0. 0	
MEMORY DIV	Gateway Name	[]	
MEASUREMENT	Use DNS	OFF	
WAVE CALC	IP Address	0. 0. 0. 0	
NECVETEM	Data Server	0. 0. 0. 0	
SET UP	Server Name	[]	
ETLE SAVE	Port Number	100×	
PR INTER	Delimiter	CR+LF	
INTERFACE	Header	OFF	
INITIALIZE	·		
SELF CHECK		RESET	
	-		
Operation Gui	de Make function m	ode settings. Press the function keys	to select.

INTERFACE (Refer to Chapter 11 "Communication Settings" in the Instruction Manual.)

- LAN settings
- FTP settings
- PC card settings (RS-232C, GP-IB, modem)
- PPP settings (transmission, reception, etc.)



INITIALIZE (Refer to 9.5 "Initialize Screen" in the Quick Start Manual.)

- Clock setting
- Waveform data initialization
- System reset
- Menu control (display/hide setting)

MENU		MEMORY	02-05-08 16:28:42
CHANNEL			
ONE CH	No.1	ROM/RAM CHECK	
SCALING	<u> </u>		
COMMENT	(No.2	DD INTED CHECK	
TRIGGER	Ciore		
TRIGGER	(No 3	DISDLAY CHECK	
STATUS	(mu.s	DISPEAT CHECK	
MEMORY DIV	(No.4	VEV CHECK	
MEASUREMENT	L. 10.14	NET UNLOK	
ESYSTEM	(No. 5	SVOTEM VEDE ION	
SET UP	C ^{NU.5}	STOTETT VERSION	
FILE SAVE			
INTERFACE			
INITIALIZE			
SELF CHECK			
Operation Guide Mak	e function mode setting	s. Press the function ke	ys to select.
MENU	N AZ	R R	1.

SELF CHECK (Refer to 9.6 "Self-check" in the Quick Start Manual.)

- ROM/RAM check
- Printer check
- Display check
- Key check
- System component list (option information, version information, etc.)

Measurement Method

Operation flow

Pre-measurement operations

1	What is the measurement target object? What is the voltage of the target object?	Check the maximum input voltage. Check the maximum ground input voltage.
2	Connect the power cord to the 8855 unit.	Confirm that the power-supply voltage is 100 VAC to 200 VAC. Confirm that the power-supply frequency is 50/60 Hz (sine wave).
3	Connect to the measurement target object.	Confirm that the power switch of the measurement target object is turned off.
4	Turn on the power switch. Turn on the power switch located on the right side of the unit.	

Setting up the main unit

5	Select a measurement function.	In each screen, move the flashing cursor to the top (upper left) item. There are four selectable items: memory, recorder, R&M, and FFT.
6	Set the time axis. Press the DISP or STATUS key.	Make settings in the display or status screen. Sampling frequency (s) = Time axis (s/DIV) / 100 (number of pieces of data per DIV)
7	Set the recording length. Press the DISP or STATUS key.	Make settings in the display or status screen. Measurement times (s) = Time axis (s/DIV) / recording length (DIV)
8	Set the input channel. Press the CHAN key.	Make settings in the channel screen. Voltage axis range, zero position, coupling, filter, etc.
9	Make trigger settings. Press the TRIG key.	Make settings in the trigger screen. Trigger mode, pre-trigger, trigger type, trigger level, etc.

Starting measurement

10	Begin mea <u>sureme</u> nt. Press the <u>START</u> key.	On the front panel of the main unit, press the green START key located at the lower right corner. The LED lights up, and measurement starts.
11	End meas <u>urement</u> . Press the <u>STOP</u> key. (Trigger mode: Continuous/Auto)	In the single-trigger mode, measurement ends when data of the set recording length is obtained. In the continuous or auto trigger mode, measurement ends when the <u>STOP</u> key is pressed. To abort measurement, press the <u>STOP</u> key twice.

Starting analysis

12	Begin analysis	Waveform zoom (Refer to Chapter 8 in the 8855 Quick Start Manual.) A-B cursors (Refer to Chapter 8 in the 8855 Quick Start Manual.)
12	Degin analysis.	8855 Instruction Manual.) Waveform search (Refer to Chapter 8 in the 8855 Instruction Manual.)

Simple measurement operations

The following describes the simple operating procedures with a waveform input into Channel 1 (CH1) of the 8855 HiCORDER.

(Example) Input of a sine wave of 1 kHz and \pm 1 V, and observation of the waveform

Function	Time	100µs/DI	V (:	us/S)	Trig	AUTO	⊡ • 0%]	'02-06-12 18:40:1
MEMORY	Shot	30DI	V (3.0	00ms)		×1 (100µs)]	
			-						
				1 1					
			·····						
-CH1- VOL	TAGE		filte	r:F4	draw:FS	RA	NGE	POSITION	1
(- 2 \	\sim	2 V))F F	ON	10	200mV (50%	

Procedure

- (1) Press the DISP key to display the waveform display screen.
- (2) Move the flashing cursor to the "Function" indication at the upper left corner of the screen, then press the F1 key and select "Memory."
- (3) Press the CH1 button key of the CH. SELECT key.
- (4) Turn the RANGE knob to set the voltage axis range to "200 mV/DIV."
- (5) Turn the POSITION knob to set the zero position to "50%."
 The above settings set the full scale (upper- and
 - lower-limit values) on the display to " ± 2 V."
- (6) Turn the TIME/DIV knob to set the time axis to "100 μs/DIV."
- (7) Move the flashing cursor to "Trig" in the screen, and press the F3 key to set to "AUTO."
 Regarding the trigger setting method, refer to the "Trigger screen" section of this manual or Chapter 7 "Trigger Functions" in the Quick Start Manual.

The settings for waveform observation have been entered in the above steps.

- (8) Start measurement. Press the START key located at the lower right corner of the front panel. The green LED located next to the START key remains lit while waveform data is being acquired.
- (9) To abort the measurement, press the <u>STOP</u> key located next to the <u>START</u> key. When the measurement is aborted, the green LED next to the <u>START</u> key turns off.

< Key point >

The voltage axis range, position, and time axis range can be changed during a starting operation. To make changes, use the RANGE, POSITION, and TIME/DIV knobs.



Measurement of instantaneous power interruption in a commercial power line

To prevent electric shock and equipment damage, make sure each unit's maximum input voltage and maximum rated ground voltage (described in Chapter 2 "Installation and Preparation" in the Instruction Manual provided with the product) are not exceeded.

1. Method

Use the 8950 ANALOG UNIT to measure instantaneous power interruption in a commercial 100-V power supply (50 Hz). The 8951 VOLTAGE/CURRENT UNIT and 3273 CLAMP ON PROBE are also used at the same time to measure the amount of current flowing to equipment.

2. Connection

- CH1: Connection of the 9198 to the 8950 ANALOG UNIT Connect the cord and measure the commercial power supply.
- CH2: Connection of the 9198 to the 8950 ANALOG UNIT Connect the cord and measure the internal voltage of equipment likely to be affected by instantaneous power interruption.
- CH3: Connect the 3273 CLAMP ON PROBE to the 8951 VOLTAGE/CURRENT UNIT, and measure the current flowing in the equipment during instantaneous power interruption.







3. Setup

Display	Setting item	I	Setting		
Status screen	Time axis (Time/D	Div)	20 ms/DIV		
	Recording length	(Shot)	30DIV		
	Display mode (Fo	rmat)	Dual		
Channel screen	Graph	CH1	GR1		
		CH2	GR2		
		CH3	GR2		
	Mode	CH1	Voltage		
		CH2	Voltage		
		CH3	3273		
	Range	CH1	20 V		
		CH2	2 V		
		CH3	1 A		
Trigger screen	Trigger mode		Single		
	Pre-trigger		20%		
	Kind	CH1	In		
	Parameter	CH1	Lower (limit): -100.00 V Upper (limit): 100.00 V Filt. (Filter): 1.5 DIV		

4. Details



Press the function key corresponding to the setting displayed in the screen.



Status screen

1. Setting the time axis and recording length

For the observation of waveforms before and after an instantaneous power outage, follow the setting procedure described below. Press the STATUS key to display the status

screen.

Move the flashing cursor to "Time/Div" or "Shot."

Since the frequency of the commercial power supply to be measured is 50 Hz (20 ms), use the functions to set the "Time/Div" to "20 ms/DIV," and the "Shot" to "30 DIV."





Press the function key corresponding to the setting displayed in the screen.

MENU		MEMORY	
DCHANNEL	[Basic Setting]		
LIST	& Time/Div	20ms/DIV	
SCALING	Sampling	(200µs/S)	
COMMENT	₿ Shot	30DIV	
THITP ICCEP	Recording Time	(600.0ms)	
TRIGGER	Format	DUAL	Set to DUAL
DISTATUS			
STATUS			
MEMORY DIV			
MEASUREMENT			
WAVE CALC	[Application]		
DISYSTEM	Roll Mode	OFF	
SET UP	Overlay	OFF	
FILE SAVE	Averaging	OFF	
PRINTER	Use Channel	CH1-4	

Status screen



Press the function key corresponding to the setting displayed in the screen.



Channel screen

2. Window display

(1) Separate the display of commercial power-supply waveforms from the display of other waveforms to prevent overlapping.

Using the cursor keys, move the flashing cursor to "Format." Then, press the function key to set the "Format" to "DUAL."

(2) Press the CHAN key to display the channel screen. Move the flashing cursor to "Graph," and set Graph CH1 to "GR1," and CH2 and CH3 to "GR2."

17



Press the function key corresponding to the setting



3. Channel setting

Using the cursor keys, move the flashing cursor to "Range" or "Mode."

Since CH1 receives a commercial 100-V power supply (approx. 141 Vp), press the function key to set the range (vertical axis) to **"20 V/DIV**." Since CH2 is used to observe the interval voltage (12 VDC) of the equipment, press the function key to set the range (vertical axis) to **"2 V/DIV**."

CH3 measures the amount of current. Press the function key to set the mode to "**3273**." Although the current flowing in the equipment is normally 1A, it can increase to 10 times that level at the time the power switch is turned on. Therefore, press the function key and set the range (vertical axis) to "**1** A/DIV."

< Key point >

When ranges are set in the channel screen, the displayed upper- and lower-limit values and the upper- and lower-limit values for measurement vary according to the entered ranges. Refer to these limit values when setting the ranges.

4. Trigger setting

The following describes the trigger condition setting method.

To activate the trigger at the time of instantaneous power outage, use "Window In trigger."

A commercial 100 V power supply has a sine waveform that ranges from -141 V to 141 V. In the following setting, the lower limit of the Window In trigger is set to "-100 V" and the upper limit to "100 V." and the trigger is activated when the waveform enters the shaded range (window) in the left diagram. This setting activates the trigger every time the waveform enters the window. Therefore, a time duration (trigger filter) is set so that the trigger is activated only when the waveform remains in the window for longer than the set time. The frequency of a commercial power supply is 50 Hz, meaning that one cycle is 20 ms. Instantaneous power outage is a condition in which the voltage drops for a period longer than 20 ms. Therefore, the trigger filter is used to set a period in units of DIV. Since the time axis is set to 20 ms/DIV, the trigger filter is set to be longer than 20 ms. In the example, the trigger filter is set to "1.5 DIV." With this setting, the trigger is activated when waveform remains in the window for 30 ms or longer.

- (1) Press the TRIG key to display the trigger screen.
- (2) Using the cursor keys, move the flashing cursor to CH1 "Kind," and press the function key to change the type to "In."
- (3) Move the flashing cursor to CH1 "Parameter," and set the lower (limit) to "-100.00 V," the upper (limit) to "100.00 V," and the filter (Filt.) to "1.5 DIV."
- (4) Move the flashing cursor to "Trigger mode," and set the trigger mode to "Single" (stops after instantaneous power outage occurs and a waveform is acquired).
- (5) Move the flashing cursor to "Pre-trigger," and set the pre-trigger to "20%" (for observation of waveforms prior to the trigger).

Set to "Single" and "20%."

MENU					1	MEMORY					*02-I	05-09 10:	51:54
CHANNEL	ANA	LOG	LOGIC										
ONE CH													
LIST	Trigge	r Mode			SIN	IGLE	1	Timer	Trigger			OFF	
SCAL ING	Pre-Tr	igger				20%	ł						1
COMMENT	Trig	ger Pric	rity			OFF	•						
TRIGGER	Trigge	r Source				OR							
TRIGGER	Extern	al Trig				OFF							
DSTATUS													
STATUS	K	ind	Paramet	ter									
MEMORY DIV	CH1	IN	Lower:-	-100.0	30 V	Upper	: 1	00.00	V	Filt	t.:	1.5DIV	
MEASUREMENT	CH2 T	RIG OFF											
WAVE CALC	CH3 T	RIG OFF											
DSYSTEM	CH4 T	RIG OFF											

Trigger screen

< Key point >

By combining the Window In trigger upper- and lower-limit values with the filter, it is possible to detect not only a trigger caused by an instantaneous power outage but also waveform chipping and voltage dips in repeated waveforms.

-Set to "In," "-100.00 V," "100.00 V," and "1.5 DIV."





Press the function key corresponding to the setting displayed in the screen.

5. Starting measurement



(1) Press the DISP key to display the display screen.

(2) Press the START key to begin measurement.

When an instantaneous power outage occurs, the trigger is activated and a waveform is acquired. Until then, the unit stands by. The following shows an actual waveform obtained based on the conditions listed below.

CH1: Commercial power supply CH2: Equipment internal 12 VDC power CH3: Equipment current

The equipment's internal 12 VDC power supply did not drop in voltage even when a power outage of approximately 50 ms occurred. The data also shows that a current with a CH3 waveform flowed inside the equipment during the instantaneous power outage (see the screen below).



Measurement of the sensor output

1. Method

Use the 8953-10 HIGH RESOLUTION UNIT to measure the output of the acceleration sensor. Observe the waveform of the effect caused by an impact applied to the subject board.

2. Connection

Connect the sensor output (output from the amp that magnifies the sensor output in this example) to the input terminal of the 8953-10 HIGH RESOLUTION UNIT (CH1). The external sensor amp used in the example has a full scale of ± 2 V. The external amp also produces an output of 0 V at 0 G, and ± 2 V at ± 5 G.







3. Setup

Display	Setting item	Setting			
Status screen	Time axis (Time/Div)	1 ms/DIV			
	Recording length (Shot)		1000DIV		
Channel screen	Range	CH1	200 mV		
	Scaling	CH1	In decimals (ENG)		
	Setting method (Scaling Kind)		Set with 2 points (POINT)		
	Input P1 - Scale P1		[2.000] - [5.000]		
	Input P2 - Scale P2	CH1	[-2.000] - [-5.000]		
	Unit	CH1	G		
Trigger screen	Trigger mode		Single		
	Pre-trigger		5%		
	Kind	CH1	Level		
	Parameter		Level: 200 mV Slope: _ 1		

4. Details



Press the function key corresponding to the setting displayed in the screen.



Status screen

1. Setting the time axis and recording length

For measurement of the output of the acceleration sensor, follow the setting procedure described below.

Press the STATUS key to display the status screen.

Move the flashing cursor to "Time/Div" or "Shot."

To capture a waveform for a period of one second at a 100 k sampling rate, use the function keys to set the "Time/Div" to "1 ms/DIV" and the "Shot" to "1000 DIV."



Press the function key corresponding to the setting displayed in the screen.



Channel screen

- 2. Channel setting
- (1) Press the CHAN key to display the channel screen.
- (2) Make sure CH1 is selected. Using the cursor keys, move the flashing cursor to "Range." If CH1 is not selected, press the F3 key to select CH1 before moving the cursor to "Range."
- (3) Press the function key to set the range to "200 mV" (200 mV/DIV x 20 DIV results in ± 2 V because the full scale of the external sensor amp is ± 2 V).
- (4) Convert voltage (V) to acceleration (G).
 Move the flashing cursor to "Scaling," and set the scaling to "ENG."
 Move the flashing cursor to "Scaling Kind," and set

the "Scaling Kind" to "**POINT**."

- (5) Move the flashing cursor to "Input P1 Scale P1," and set it to "[2.0000] - [5.0000]."
- (6) Move the flashing cursor to "Input P2 Scale P2," and set it to "[-2.0000] - [-5.0000]."
- (7) Move the flashing cursor to "Unit," and set the unit to "G."

Since the external amp produces a ± 2 V output at ± 5 G, the above settings allow the direct reading of measured values (level monitor value, cursor reading value).

< Key point >

For easier range and scaling settings, observe the level monitor, measurable range, and display upper-/lower-limit values shown on the left side of each channel screen. If the external amp has a calibration or maximum output function, it is recommended to confirm that the set ranges are correct by observing the level monitor and numerical values.





Press the function key corresponding to the setting displayed in the screen.

3. Trigger setting

The following describes the procedure for setting trigger conditions. When there is a change from 0 V (0 G), the trigger is activated and waveform acquisition starts.

- (1) Press the TRIG key to display the trigger screen.
- (2) Using the cursor keys, move the flashing cursor to CH1 "Kind," and press the function key to change the "Kind" to "LEVEL."
- (3) Move the flashing cursor to CH1 "Parameter," and set the level to "**200 mV**" and the slope to "____."
- (4) Move the flashing cursor to "Trigger Mode," and set the trigger mode to "SINGLE."
- (5) Move the flashing cursor to "Pre-Trigger," and set the pre-trigger to "5%."

	Se	t to "Single" and "	5%."	
MENU		MEMORY	02-05-09 10:51:54	
DCHANNEL ONE CH	MNALUG LUGIC			
LIST	Trigger Mode	SINGLE Timer Tri	gger OFF	
SCAL ING	Pre-Trigger	5%		
COMMENT	Trigger Priority	OFF		
TRIGGER	Trigger Source	OR		
TRIGGER	External Trig	OFF		
DSTATUS				
STATUS	Kind Parameter			
MEMORY DIV	CH1 LEVEL Level: 200.	00m V Slope: 🕇	Filt.: OFF	Set to level, 200 mV, and
MEASUREMENT	CH2 TRIG OFF			
WAVE CALC	CH3 TRIG OFF			
DSYSTEM	CH4 TRIG OFF			
				1

Trigger screen

5. Starting measurement



Display the display screen.

Start measurement.

Press the DISP key to display the display screen. Press the START key to begin measurement.

- When the START key is pressed, "Waiting for trigger" is displayed at the upper right corner of the screen.
- When "Waiting for trigger" is displayed, apply an impact to the subject board.
- The trigger is activated, and "Storing" is displayed at the upper right corner of the screen.
- The measurement is completed in approximately one second, and a waveform is displayed.





Press the F4 key for "Zoom ON" to display an enlarged image. The waveform in each graph can be magnified or compressed. The waveform can also be scrolled.





(3) A-B cursors

A-B cursors are used to read frequency and numerical values such as maximum values. When the A.B CSR key is pressed, the red LED lights up and the GUI for A-B cursor settings appears. Select the type of cursor, ON/OFF of A-B cursors, and movement for reading a numerical value.

< Key point >

The waveform display screen can be switched between 30 DIV and 20 DIV by pressing the DISP key.

The aforementioned allows easier reading, since values such as those read by the cursors do not overlap with a waveform or grid.

To exit from the A-B cursor setting mode, press the A.B CSR key again, or press the WAVE, VALUE, or ESC key.



External Memory Devices

The following memory devices and data recording methods can be used with the 8855. By selecting a device or method, data can be saved in the specified media. Data saved on any of these media in the 8855 recording format can be loaded into the 8855 for display and analysis.

- 1. Internal memory devices
 - FD drive (floppy disk)
 - MO drive (MO disc)
 - HD drive (hard disk)
- 2. Interfaces
 - PCMCIA interface (PC card)
 - SCSI interface (external MO drive)
 - LAN (10BASE-T) interface (PC)

The following describes commonly used methods of storing and loading data.

For details on drives, interfaces, and data saving/loading methods, refer to Chapter 10 "Storing and Recalling Measurement Data" in the 8855 Quick Start Manual. Regarding the LAN interface, refer to Chapter 11 "Communication Settings" in the 8855 Instruction Manual.



Selection of recording media

- (1) Press the FILE key. The file screen is displayed.
- (2) Press the media change F1 key.
- (3) Press the function key, and select a media for file saving and loading operations from among "FD,"
 "PC CARD," "MO/HDD," "MO (EXT)," or "RAM." In this example, "Internal MO/HDD" is selected.



Storage of measurement data



- (1) Display the file screen, and select a data recording media (refer to "Selection of recording media").
- (2) Press the SAVE F2 key.



Press the function key corresponding to the setting displayed in the screen.

(3) Select a file save format. Using the cursor keys, move the flashing cursor to "Save Type," and select a save setting using the function key.

Setting	Stores setting conditions
Wave binary	Stores waveform data in binary format (for 8855)
Wave text	Stores waveform data in text format (for Excel). Data stored in text format cannot be loaded into the 8855.

(4) Specify a saving range.

Move the flashing cursor to "Save Area," and specify the range of data to be saved. When A-B cursors are used, specify the range to be saved. Select either "ALL WAVE" or "A-B WAVE."



 $\begin{array}{c} & & & \\ &$

Press the function key corresponding to the setting displayed in the screen.



(5) Enter a name (file name) for the data to be saved. Move the flashing cursor to "Save Name." Press the <u>input</u> F1 key to display the character input screen. Enter a file name. Regarding the input method, refer to "5.3.3 Character Entry Procedure" in the 8855 Instruction

 (6) Specify the method of processing to be executed if the entered file name already exists.
 Mayo the flaghing current to "Same Name" and

Move the flashing cursor to "Same Name," and select a processing method.

Auto	Automatically adds a number after the entered file name
Overwrite	Deletes the old file and saves the new file
Error	Displays an error message and stops saving the data

- (7) When saving data in text form, set a data thinning rate.
 - Move the flashing cursor to "Save Thin," and select a thinning rate.
- (8) Set the channel to be saved.

Move the flashing cursor to the position of the channel to be saved. For an analog channel, make settings individually for each unit. For a logic channel, make all settings at once.

(9) Save data.

Press the exec. F9 key to save the data. To cancel the data saving command, press the cancel F10 key.

Reading measurement data





Press the function key corresponding to the setting displayed in the screen.



 (4) Setting of a basic loading operation (for loading of settings files only)

Move the flashing cursor to "Basic Load," and select a loading method.

None	Does not load settings other than channel settings. All main-unit settings other than channel settings are retained.
Load	Loads settings other than channel settings. Loads all setting data.

- (5) Setting of a destination channel Move the flashing cursor to the position of the channel for loading, and press the function key to enter the setting.
- (6) Load data.
 Press the exec. F9 key to load data.
 To cancel the data loading command, press the cancel F10 key.

Automatic saving of measurement data

After measurement, data can be automatically saved in a specified media. For details, see 9.3.1 "Setting the Auto Save Function" in the 8855 Quick Start Manual.



Press several times to select "FILE SAVE."

MENU		MEMORY		°02-07-08 15:05:38
(CHANNEL	[Auto Save Setting]		Save Channel	DISP CH
ONE CH	Save Media	FD	Saving the Data	NORMAL SAVE
LIST	Save Type	TEXT	Save Area	ALL WAVE
SCAL ING	Save Name	[AUTO]	Save Thin	OFF
COMMENT	Make Directory	NONE		
TRIGGER TRIGGER			L	
EISTATUS	[Measure Setting]			
STATUS	Save Media	OFF		
MEMORY DIV				
VAVE CALC	[SAVE Key Setting]			
WAYE CALL	Save Media	OFF		
DSYSTEM SET UD				
ETLE SAVE				
DD INTED				
INTEDEACE				
INITIAL LZE				
JELI CHECK				
Operation Guid	Waveforms can be a Select the destina OFE disables the A	automatically save ation media when us auto Save function	d to selected media a sing the Auto Save fur	fter acquisition. Action. Selecting
) OFF			



Press the function key corresponding to the setting displayed in the screen.

- (1) Press the SYSTEM key several times, and select "FILE SAVE" in the menu screen.
- (2) Using the cursor keys, move the flashing cursor to "Save Media," and use the function key to select a media for automatic saving of data.
- (3) Move the flashing cursor to "Save Type," and select a save setting for auto save.

Wave binary	Saves waveform data in binary format (for 8855)
Wave text	Stores waveform data in text format (for Excel). Data stored in text format cannot be loaded into the 8855.

(4) Enter a file name.

Move the flashing cursor to "Save Name." Press the input F1 key to display the character input screen. Enter a file name.

Regarding the input method, refer to "5.3.3 Character Entry Procedure" in the 8855 Instruction Manual. The entered file name is assigned to the saved data file. When files are saved continuously, file names are attached with sequential numbers. If a file name is not entered, the first file is named "AUTO," the second file is named "AUTO0001," and so on.

- (5) Move the flashing cursor to "Make Directory," and select whether to create a new directory for each start of waveform data-acquisition. When "EXIST" is selected, a directory is created at each waveform data-acquisition. The maximum number of files in a directory is 5,000.
- (6) Move the flashing cursor to "Save Channel," and select the channel to be saved.

DISP CH	Saves the data of channels whose waveform display is ON	
ALL CH	Saves the data of all channels	

(7) Move the flashing cursor to "Saving the Data," and select a saving method.

Normal save	Stops auto save when the record media becomes full.	
Delete save	When the recording media becomes full, old data is deleted for continued auto-save operation.	

(8) Specify a saving range. Move the flashing cursor to "Save Area," and specify a saving range. When A-B cursors are used, specify the range to be saved. Select either "ALL WAVE" or "Between A-B WAVE."

START	Starts measurement	 (9) When saving data in text form, set a data thinning rate. Move the flashing cursor to "Save Thin," and select a thinning rate. (10) Start measurement
STOP	Stops measurement	Press the START key to start measurement. After data of the set recording length is obtained, the data is automatically saved. To stop the measurement or auto-save operation, press the STOP key. To forcibly stop the operation, press the STOP key twice.

Real-time printing of measurement data (using the 8994 printer unit)

Real-time printing is possible only when "Recorder" is selected as the function Measurement data can be continuously printed in real time. A measured waveform is automatically printed at the same time it is displayed on the screen. For details, refer to 9.4 "Printer Screen" and 9.4.3 "Real Time Print" in the 8855 Quick Start Manual.





Start measurement

PRINT

Pauses and resumes printing

- (1) Press the SYSTEM key several times and select "PRINTER" in the menu screen.
- (2) Using the cursor keys, move the flashing cursor to "Realtime Print," and select a setting using the F4 and F5 keys.

	OFF	Does not print in real time
ON Prints		Prints in real time

(3) Start measurement.

Press the START key to start measurement. When measurement starts, the printer prints as soon as the screen begins displaying a waveform. By pressing the PRINT key during the measurement, printing can be paused and resumed.

Note

- For a long time-axis range of 200 ms/DIV or more, there will be a delay in printing. If the recording length is set to "Continuous," real-time printing is not possible.
- The printing density may vary depending on the timeaxis setting and ambient temperature.

Useful Information

1. About the function keys

(1) Memory function

Stores A/D-converted data in the memory for each sampling operation. Changing the time axis also alters the sampling frequency.

(2) Recorder function

The sampling frequency is fixed. Because changing the sampling frequency does not alter the time axis, measurement at a fast sampling speed is possible even with a slow time axis. (Envelope recording)

Real-time printing is possible (time axis: 500 ms/DIV and up).

- (3) Recorder & memory function (Chapter 3 in the Instruction Manual) Even when the recorder mode is used, abrupt signal waveforms can be captured in the memory mode.
- (4) FFT function (Chapter 4 in the Instruction Manual) Spectrum analysis and a transfer function can be obtained.
- (5) Power monitor function (requires installation of the optional software "9549 FUNCTION UP DISK")

An instantaneous waveform and trend graph can be observed.

2. About the time axis and sampling

- (1) When using the memory function The sampling frequency equals 1/100 of the time axis. In the case of a 100-ms/DIV time axis, the sampling frequency becomes 1 ms.
- (2) When using the recorder function With 1/100 of the time axis as one point, the minimum and maximum values (MIN and MAX data) at the fixed sampling frequency are displayed as one-point two-data. One point on the time axis of 10 ms/DIV equals 100 ms. When the sampling frequency is set to 1 ms, one point corresponds to 100 samples. Two pieces of data - the maximum and minimum values of these 100 samples -- are displayed as one point on the screen (envelope recording).

3. About the recording lengths

The number of pieces of data in a recording length of 1 DIV is 100.

The total number of pieces of data in the entire recording length is as follows: set recording length (number of DIV) x 100 pieces of data + 1.

(Example) Number of pieces of data in a set recording length of 500 DIV is as follows: 50 DIV x 100 data + 1 = 5001 pieces of data.

4. About the pre-trigger

The pre-trigger setting is set by entering the percentage of the pre-trigger recording length (number of pieces of data) in the total recording length (all data).

(Example) Setting of a pre-trigger of 5% for a recording length of 1000 DIV

The recording length (number of pieces of data) prior to the trigger is as follows: 1000 DIV x 5% = 50 DIV (5000 data).

5. About the voltage axis and resolution

• The resolution of the 8950, 8951, and 8952 with a voltage axis of 1 DIV is 100 (100 LSB). The full scale of the screen is 20 DIV, so the resolution is 2000 LSB (at a voltage axis magnification rate of 1).

(Example) With a voltage axis of 5 V/DIV, the minimum resolution is as follows: 5 V / 100 = 50 mV.

 The resolution of the 8953-10 with a voltage axis of 1 DIV is 1600 (1600 LSB). The full scale of the screen is 20 DIV, so the resolution is 32000 LSB (at a voltage axis magnification rate of 1).

(Example) With a voltage axis of 5 V/DIV, the minimum resolution is as follows: 5 V / 1600 = 3.125 mV.

For further details, refer to 6.3.8 "Setting the Zero Position" in the Quick Start Manual.

6. About the screen display and DIV

The 8855 is equipped with an SVGA (800 x 600) LCD. The waveform area uses 750 dots horizontally and 500 dots vertically. As there are 30 DIV horizontally and 20 DIV vertically, one grid (1 DIV) on the screen measures 25 dots horizontally and 25 dots vertically.

• 1 grid (1 DIV) on the screen: 25 dots horizontally x 25 dots vertically

• 1 grid (1 DIV) in data: 100 samples horizontally x 100 LSB vertically

The grid size (1 DIV) of data changes according to the magnification/compression of the time axis and voltage axis.

7. Data saving speed

The following shows the speeds of saving binary data (reference values) using different media and interfaces. Note that the data saving speed varies depending on the saving conditions, device manufacturer, device capacity, communication conditions, and others.

Storage media	Saving speed (reference value)
Floppy disk	15 kB/s
MO disc	150 kB/s
HD	160 kB/s
PC card	200 kB/s
PC via LAN	200 kB/s

8. Conducting probe compensation

When using Model 9665 10:1 Probe or Model 9666 100:1 Probe and conducting probe compensation, please configure according to the following settings:

- 1. Press the SYSTEM key to display the Set up screen (refer to "System screen").
- 2. Move the flashing cursor to the "EXT.OUT" item.
- 3. Use the function keys to select the Calibration.

Based on these settings, a 1 kHz 5 V rectangular waveform will be output from the external output terminal (EXT.OUT terminal) in order to compensate the probes.

HIOKI 8855 MEMORY HICORDER GUIDE BOOK

Publication date: July 2002 Edition 1
Edited and published by HIOKI E.E. CORPORATION Technical Support Section
All inquiries to Sales and Marketing International Department 81 Koizumi, Ueda, Nagano, 386-1192, Japan TEL: +81-268-28-0562 / FAX: +81-268-28-0568
E-mail: os-com@hioki.co.jp
URL http://www.hioki.co.jp/

Printed in Japan 8855A983-00

- All reasonable care has been taken in the production of this manual, but if you find any points which are unclear or in error, please contact your supplier or the Sales and Marketing International Department at HIOKI headquarters.
- In the interests of product development, the contents of this manual are subject to revision without prior notice.
- Unauthorized reproduction or copying of this manual is prohibited.



HIOKI E. E. CORPORATION

HEAD OFFICE

81 Koizumi, Ueda, Nagano 386-1192, Japan TEL +81-268-28-0562 / FAX +81-268-28-0568 E-mail: os-com@hioki.co.jp

HIOKI USA CORPORATION

6 Corporate Drive, Cranbury, NJ 08512, USA TEL +1-609-409-9109 / FAX +1-609-409-9108

8855A983-00 02-07H

Printed on recycled paper