

8949

UNIVERSAL UNIT

Instruction Manual

Sept. 2018 Revised edition 5
8949A980-05 18-09H

EN

HIOKI

www.hioki.com/

HIOKI E.E. CORPORATION

81 Koizumi, Ueda, Nagano 386-1192 Japan

Edited and published by HIOKI E.E. CORPORATION

2402 EN Printed in Japan

- Contents subject to change without notice.
- This document contains copyrighted content.
- It is prohibited to copy, reproduce, or modify the content of this document without permission.
- Company names, product names, etc. mentioned in this document are trademarks or registered trademarks of their respective companies.

Europe only

- EU declaration of conformity can be downloaded from our website.
- Contact in Europe: HIOKI EUROPE GmbH

Helfmann-Park 2, 65760 Eschborn, Germany

hioki@hioki.eu

Warranty

Warranty malfunctions occurring under conditions of normal use in conformity with the Instruction Manual and Product Precautionary Markings will be repaired free of charge. This warranty is valid for a period of three (3) years from the date of purchase. Please contact the distributor from which you purchased the product for further information on warranty provisions.

Introduction

Thank you for purchasing the HIOKI Model 8949 UNIVERSAL UNIT. To obtain maximum performance from the device, please read this manual first, and keep it handy for future reference.

Overview

The 8949 UNIVERSAL UNIT is an option product for Hioki 8423 MEMORY HiLOGGER devices. Be sure to use this input module only by installing it in a Memory HiLogger. For information on how to install and use the input module, refer to the documentation for the Memory HiLogger.

Inspection and Maintenance

Initial Inspection

When you receive the device, inspect it carefully to ensure that no damage occurred during shipping. If damage is evident, or if it fails to operate according to the specifications, contact your dealer or Hioki representative.

Preliminary Checks

Before using the device the first time, verify that it operates normally to ensure that no damage occurred during storage or shipping. If you find any damage, contact your dealer or Hioki representative.

Maintenance and Service

- To clean the device, wipe it gently with a soft cloth moistened with water or mild detergent. Never use solvents such as benzene, alcohol, acetone, ether, ketones, thinners or gasoline, as they can deform and discolor the case.
- If the device seems to be malfunctioning, contact your dealer or Hioki representative.
- Pack the device so that it will not sustain damage during shipping, and include a description of existing damage. We cannot accept responsibility for damage incurred during shipping.

Safety

This manual contains information and warnings essential for safe operation of the device and for maintaining it in safe operating condition. Before using it, be sure to carefully read the following safety precautions.

DANGER

This device is designed to comply with IEC 61010 Safety Standards, and has been thoroughly tested for safety prior to shipment. However, mishandling during use could result in injury or death, as well as damage to the device. Be certain that you understand the instructions and precautions in the manual before use. We disclaim any responsibility for accidents or injuries not resulting directly from device defects.

Safety Symbol

	In the manual, the symbol indicates particularly important information that the user should read before using the device. The symbol printed on the device indicates that the user should refer to a corresponding topic in the manual (marked with the symbol) before using the relevant function.
	Indicates a ground.
	Indicates DC (Direct Current).

The following symbols in this manual indicate the relative importance of cautions and warnings.

DANGER Indicates that incorrect operation presents an extreme hazard that could result in serious injury or death to the user.

WARNING Indicates that incorrect operation presents a significant hazard that could result in serious injury or death to the user.

CAUTION Indicates that incorrect operation presents a possibility of injury to the user or damage to the device.

NOTE Indicates advisory items related to performance or correct operation of the device.

Usage Notes

Follow these precautions to ensure safe operation and to obtain the full benefits of the various functions.

DANGER

- The maximum input voltage is 60 V DC. Attempting to measure voltage in excess of the maximum input could destroy the device and result in personal injury or death.
- The maximum rated voltage between input terminals and ground (voltage between 8949 input terminal and main unit frame, and between input terminals of other input modules) is 600 V AC or 600 V DC. Attempting to measure voltages exceeding this level could damage the device and result in personal injury.
- The maximum rated voltage between channels is 120 V DC. Do not apply voltage exceeding this level between channels. Doing so could destroy the instrument and result in personal injury or death.
- Avoid making always-on connections where there is a possibility of a surge that could exceed the above maximum voltage rating. Doing so could destroy the instrument and result in personal injury or death.

WARNING

- Do not allow the device to get wet, and do not take measurements with wet hands. This may cause an electric shock.
- Do not use the device where it may be exposed to corrosive or combustible gases. The device may be damaged or cause an explosion.

CAUTION

- Do not store or use the device where it could be exposed to direct sunlight, high temperature or humidity, or condensation. Under such conditions, the device may be damaged and insulation may deteriorate so that it no longer meets specifications.
- This device is not designed to be entirely water- or dust-proof. Do not use it in an especially dusty environment, nor where it might be splashed with liquid. This may cause damage.
- To avoid damage to the device, protect it from physical shock when transporting and handling. Be especially careful to avoid physical shock from dropping.

NOTE

This device may cause interference if used in residential areas. Such use must be avoided unless the user takes special measures to reduce electromagnetic emissions to prevent interference to the reception of radio and television broadcasts.

Replacement Procedure

WARNING

- To avoid electric shock accidents, turn off the Memory HiLogger and disconnect all cables before connecting and disconnecting modules.
- Always attach the connector cover supplied with the Memory HiLogger to the module nearest the edge.

NOTE

Up to eight input modules can be connected to the Model 8423 MEMORY HiLOGGER. Measurement is not possible when nine or more modules are connected.

Attach the 8949 module to the Memory HiLogger using the supplied connection plate and connection fittings at the top and bottom edges. For details, refer to the instruction manual for the Model 8423 MEMORY HiLOGGER.

Specifications

Accuracy applies to $23 \pm 5^\circ\text{C}$ ($73 \pm 9^\circ\text{F}$), 30 to 80%RH (When executing zero-position adjustment 30 minute after power on)

Input type	Unbalanced (Isolated between channels) (except resistance temperature detector and humidity sensor channels, which are not isolated)
Number of input channels	15 channels (Each channel can be set for voltage, thermocouple, resistance temperature detector or humidity sensor)
Input terminals	Push-type terminal block (four terminals per channel) Detachable terminal block, terminal cover included
Measurement Parameter	Voltage, thermocouple (K, E, J, T, N, W, R, S, B), Resistance temperature detector (Pt 100, JPt 100) (3- or 4-wire connection, 1 mA measurement current), Humidity (requires optional Model 9701 HUMIDITY SENSOR)
Resolution	16 bit
Maximum sampling rate	10 ms (5 s when also measuring humidity)
Reference junction compensation accuracy	$\pm 0.5^\circ\text{C}$ (K, E, J, T) (Reference Junction Compensation: internally improves accuracy of thermocouple measurements.), $\pm 1.0^\circ\text{C}$ (N, R, S, B, W)
Temperature characteristic	To the measurement accuracy add (measurement accuracy $\times 0.1$) per $^\circ\text{C}$
Reference junction compensation	(measuring with the thermocouple) Selectable internal or external
Digital filter	OFF/ 50 Hz/ 60 Hz (Digital filtering is automatically set to the appropriate recording interval when selecting 50 or 60 Hz.)
Input resistance	1 M Ω $\pm 5\%$ (Voltage measurement and temperature measurement with thermocouple when Burn out detection is OFF), 2 M Ω $\pm 5\%$ (Temperature measurement with resistance temperature detector), 850 k Ω $\pm 5\%$ (Temperature measurement with thermocouple when Burn out detection is ON.)
Normal mode rejection ratio	50 dB min. (50Hz input recording at 5 s intervals, with 50Hz digital filter enabled) (60Hz input recording at 5 s intervals, with 60Hz digital filter enabled)
Common mode rejection ratio	100 dB min. (at 50/60 Hz, digital filter OFF with signal source resistance), 140 dB min. (50Hz input from signal source resistance of 100 Ω or less recording at 5 s intervals, with 60Hz digital filter enabled), (60Hz input from signal source resistance of 100 Ω or less recording at 5 s intervals, with 60Hz digital filter enabled)
Maximum input Voltage	60 VDC
Maximum rated voltage between channels	120 VDC
Maximum rated voltage to earth	600 V rms or 600 VDC (between each input channel and main unit, and between each unit), Measurement category II (anticipated transient overvoltage 4000 V)
Dielectric strength	4.29 kVAC for 1 minute (between each input channel and main unit, and between each unit), 350 VAC for 1 minute (between each input channels)
Location for use	Altitude up to 2000 m (6562 feet), indoors, Pollution degree 2
Operating temperature and humidity	Temperature 0 to 40°C (32°F to 104°F) Humidity 30 to 80%RH (no condensation)
Storage temperature and humidity	Temperature -10 to 50°C (14°F to 122°F), Humidity 80%RH max (no condensation)
Accuracy guarantee for temperature and humidity	Temperature $23 \pm 5^\circ\text{C}$ ($73 \pm 9^\circ\text{F}$), Humidity 30 to 80%RH (no condensation)
Guaranteed accuracy period	1 year
Product warranty period	3 years

Dimensions

Approx. 38.5W x 133H x 141.2D mm (1.52" W x 5.24" H x 5.56" D) (excluding projections)

Mass

Approx. 530 g (18.7 oz.)

Effect of conducted radio-frequency electromagnetic field Within $\pm 2\%$ f.s. at 3 V

Effect of radiated radio-frequency electromagnetic field Within $\pm 2\%$ f.s. at 3 V/m

Accessory Flathead screwdriver (for terminal block)1, instruction manual, connection plate

Applying standards Safety EN 61010
EMC EN 61326 Class A

Measurement ranges/ Measurable range/ Resolution/ Measurement accuracy

Measurement Parameter: Voltage

Range	Measurable range	Max. resolution	Measurement accuracy
100 mV f.s.	-150 to 150 mV	5 μV	
1 V f.s.	-1.5 to 1.5 V	50 μV	
10 V f.s.	-15 to 15 V	500 μV	
20 V f.s.	-30 to 30 V	1 mV	
100 V f.s.	-60 to 60 V	5 mV	
*1-5 V f.s.	1 to 5 V	500 μV	$\pm 0.1\%$ f.s.

Measurement Parameter: Thermocouple (not including increased accuracy of reference junction compensation)

Type	Range	Measurable range	Maximum resolution	Measurement accuracy
K * ²	100°C f.s.	-100 to 100°C	0.01°C	
	500°C f.s.	-200 to 500°C	0.05°C	
	2000°C f.s.	-200 to 1350°C	0.1°C	
	100°C f.s.	-100 to 100°C	0.01°C	
E * ²	500°C f.s.	-200 to 500°C	0.05°C	
	2000°C f.s.	-200 to 1000°C	0.1°C	
	100°C f.s.	-100 to 100°C	0.01°C	
J * ²	500°C f.s.	-200 to 500°C	0.05°C	
	2000°C f.s.	-200 to 1200°C	0.1°C	
	100°C f.s.	-100 to 100°C	0.01°C	
N * ²	500°C f.s.	-200 to 500°C	0.05°C	
	2000°C f.s.	-200 to 1300°C	0.1°C	
	100°C f.s.	-100 to 100°C	0.01°C	
R * ²	100°C f.s.	0 to 100°C	0.01°C	
	500°C f.s.	0 to 500°C	0.05°C	
	2000°C f.s.	0 to 1700°C	0.1°C	$\pm 0.05\%$ f.s. $\pm 3.5^\circ\text{C}$ (0 to $<400^\circ\text{C}$)
S * ²	100°C f.s.	0 to 100°C	0.01°C	
	500°C f.s.	0 to 500°C	0.05°C	
B * ²	2000°C f.s.	0 to 1800°C	0.1°C	
	100°C f.s.	0 to 100°C	0.01°C	