

9593-02

RS-232C INTERFACE

For 3157 AC GROUNDING HiTESTER

EN



Contents

Introduction	i
Chapter 1 Before Use	1
1.1 Check of External Appearance and Accessories	1
1.2 Shipping Precautions	2
1.3 Notes on Use	3
1.4 Installing the RS-232C Interface	4
Chapter 2 Overview	5
2.1 Introduction to the RS-232C Interface	5
2.2 Features	6
2.3 Specifications	7
Chapter 3 Names of Parts	11
3.1 Controls and Connections	11
Chapter 4 Connection to the Printer	13
4.1 9442 PRINTER	13
4.2 Setting the 9442 PRINTER Communication Conditions	14
4.3 Connecting the Printer	15
Chapter 5 Connection to the 3155	17
Chapter 6 Operation	19
6.1 Setting the RS-232C Communication Conditions	19
6.2 Communication Methods by the RS-232C	20
6.3 Message Format	21
6.3.1 Program Message	21
6.3.2 Response Messages	21
6.4 Headers	22
6.5 Data Formats	23
6.6 Delimiters	24
6.7 Separators	24
6.8 Abbreviation of Compound Commands	25
6.9 Output Queue	26
6.10 Input Buffer	26
6.11 Event Registers	27

Chapter 7 Command Reference	29
7.1 Command Summary	29
7.2 Format of Command Explanations	32
7.3 Particular Commands	33
7.4 Commands Specific to the 3157	35
7.5 Response Format for Queries as Numerical Value	67
7.6 Initialization Items	68
Chapter 8 Sample Programs	69
8.1 Sample program Flowchart	69
8.2 Sample programs	74
Chapter 9 Troubleshooting	81

Introduction

Thank you for purchasing this HIOKI "9593-02 RS-232C INTERFACE."
To get the maximum performance from the unit, please read this manual first,
and keep this at hand.

This Instruction Manual provides information and warnings essential for
operating this equipment in a safe manner and for maintaining it in safe
operating condition. Before using this equipment, be sure to carefully read the
following safety notes.

The following symbols are used in this Instruction Manual to indicate the
relative importance of cautions and warnings.

	Indicates that incorrect operation presents significant danger of accident resulting in death or serious injury to the user.
	Indicates that incorrect operation presents possibility of injury to the user or damage to the equipment.
	Denotes items of advice related to performance of the equipment or to its correct operation.

* The "3157" in this Instruction Manual includes the "3157-01."

Chapter 1

Before Use


1.1 Check of External Appearance and Accessories

When the unit is delivered, check and make sure that it has not been damaged in transit. If the unit is damaged, or fails to operate according to the specifications, contact your dealer or HIOKI representative.

- (1) 9593-02 RS-232C INTERFACE
- (2) This instruction manual

1.2 Shipping Precautions

If reshipping the unit, preferably use the original packing.



If this is not available, use the following procedure.

- (1) Wrap the unit in plastic sheeting.
- (2) After wrapping cushioning material around the unit, pack it into a cardboard box, and then seal up the box with adhesive tape.

1.3 Notes on Use

- (1) If you change the communication conditions of the 3157 while using it, you should immediately turn the power off and on again. If you do not do so, the communication conditions will not be changed to the new ones.
- (2) Always be sure to secure the RS-232C cable to the 9593-02 unit by tightening up the fixing screws provided.
- (3) Program messages sent just after the power has been turned on are executed after the self test has terminated.
- (4) It is vital that the proper data format is used when inputting commands with data values to the 3157 unit.
- (5) For details of the various functions, refer to the instruction manual for the 3157 unit.

1.4 Installing the RS-232C Interface

○ WARNING


- To prevent electrical shock, before adding or replacing the RS-232C interface, check that the power for the unit is off and the power cord and connectors are disconnected. [The fixing screws must be firmly tightened or the input unit may not function up to specification, or may even fail.]
- To avoid the danger of electric shock, never operate the unit with an RS-232C interface removed. If you should wish to use the unit after removing an interface, fit a blank panel over the opening of the removed unit.

○ CAUTION

When inserting in the interface, hold the metal plate. Directly touching the board may cause static electricity and lead to damage of the instrument. (Using the wrist strap for preventing static electricity when inserting is recommended.)

The space for fitting the 9593-02 RS-232C INTERFACE in the rear panel of the 3157 is covered with a blank panel. Follow these three steps to install the 9593-02 interface:

- (1) Remove the fixing screws, and take off the blank panel.
- (2) Insert the 9593-02 RS-232C INTERFACE into the exposed slot in the rear of the unit in the figure below.
- (3) Push the 9593-02 firmly into place, and fix with the screws removed in step 1.



Chapter 2

Overview

2.1 Introduction to the RS-232C Interface

By connecting the 9593-02 RS-232C INTERFACE to the 3157 AC GROUNDING HiTESTER, it is possible to control all the functions of the main unit (except for powering on and off) via the RS-232C bus.

2.2 Features

- (1) All of the functions of the 3157 main unit, except for powering on and off, can be controlled via the RS-232C interface. However, the ":START" command works in a state in which the momentary OUT settings are disabled even though the momentary OUT settings have been set.
- (2) The beeper sound can be turned on and off.
- (3) The unit can be reset.
- (4) Test results can be printed on the optional 9442 PRINTER.
- (5) Connecting with the optional 3155 LEAK CURRENT HiTESTER enables testing and the test results can be saved and printed together with the 3155 leakage current test results.

2.3 Specifications


Transfer system	Start-stop synchronization
Baud rate	2400, 4800, 9600, 19200 bps
Data length	7 or 8 bits
Parity	Even, odd, or none
Stop bits	1 or 2 bits
Delimiter	CR+LF, CR
Handshake	hardware

Selected by DIP switch.

Electrical characteristic

Input voltage levels	+5 V ~ +15 V -15 V ~ -5 V	ON OFF
Output voltage levels (load impedance 3 k to 7 k)	+5 V ~ +9 V -9 V ~ -5 V	ON OFF

Connector



RS-232C interface connector pin assignments
(D-subminiature 25-pin female)

NOTE

The connector on the 9593-02 is for terminal (DTE).

Signal assignments and explanation



Connector (Dsub) pin number	Circuit		Description
	RS-232C	CCITT	
1	AA(FG)	101	Protective Ground
2	BA(TxD)	103	Transmitted Data
3	BB(RxD)	104	Received Data
4	CA(RTS)	105	Request to Send
5	CB(CTS)	106	Clear to Send
7	AB(GND)	102	Signal Ground
20	CD(DTR)	108/2	Data Terminal Ready
Other pins			Unused

Connecting method

When connecting to the controller (DTE), use a cross cable which meets the connector specifications of both sides of the 9593-02 and the controller.

Example

When connecting to the PC/AT




Handshake

Buffer flow control

(1) Controls when receiving

When the receiving buffer is more than 85% full, CA (RTS) is set to Space to indicate to the controller that the empty buffer capacity is low.

Processing of data in the buffer continues, and when the receiving buffer is less than 25% full, CA (RTS) is set to Mark to indicate to the controller that there is ample buffer capacity.



(2) Controls when transmitting


When CB (CTS) is found to be Space, transmission is suspended; it is found to be Mark transmission resumes.

Chapter 3

Names of Parts

3.1 Controls and Connections

(1) 3157 front panel



① Display of RS-232C status

Each lamp displays the state of control by the RS-232C.


RMT: Remote

② Remote state releasing keys

Press the **O ADJ** key while holding down the **SHIFT** key to release the remote state by the RS-232C and resume the local state. However, this key operation is disabled if the RS-232C controller has put the unit into the local lock out state. (Pressing **SHIFT** + **O ADJ** has no effect.)

When the unit enters the remote state because of a command message, it is forcibly returned to the READY state.

(2) 9593-02 RS-232C interface outer panel



① Communication condition setting switches

These are used to set the communication conditions of the 3157 unit on the RS-232C bus. For how to set these switches, refer to Section 5.1, "Setting the RS-232C Communication Conditions."

② RS-232C connector


Connect the RS-232C cable to this connector.

Chapter 4

Connection to the Printer

4.1 9442 PRINTER

Using with the optional 9593-02 RS-232C INTERFACE, 9442 PRINTER, and 9446 CONNECTING CABLE, the test values can be printed out.



NOTE

- The 9442 is shipped with the function settings for use with the HIOKI 3166 CLAMP ON POWER HiTESTER. Before using, always change the settings of the DIP switches.
- For details on the operations and handling of the printer, refer to the instruction manual supplied to the printer. For the printer, use the 1196 RECORDING PAPER or an equivalent.

4.2 Setting the 9442 PRINTER Communication Conditions

The 9442 is shipped with the function settings for use with the HIOKI 3166 CLAMP ON POWER HiTESTER. Before using, always change the settings of the DIP switches.

Change the settings of the DIP switches as follows. For more information on settings, refer to the instruction manual for the DPU-414 supplied to the 9442.

Setting the 9442 PRINTER

■: Use these settings.

(1) Software DIP SW1

Switch No.	Function	ON	OFF
1	Input method	Parallel	Serial
2	Printing speed	High	Low
3	Auto loading	ON	OFF
4	CR function	Carriage return and line feed	Carriage return
5	DIP SW setting command	Enable	Disable
6 to 8	Printing density	See the table below.	

Printing density (%)	Switch No.		
	6	7	8
100	OFF	ON	ON

(2) Software DIP SW2

It has been set to the DPU-414 default setting.

(3) Software DIP SW3

Switch No.	Function	ON	OFF
1	Data bit length	8 bits	7 bits
2	Parity permission	None	With parity
3	Parity condition	Odd	Even
4	Flow control	H/W BUSY	XON/XOFF
5 to 8	Baud rate	See the table below.	

Baud rate (bps)	Switch No.			
	5	6	7	8
19200	OFF	ON	ON	OFF

Setting the 9593-02 RS-232C INTERFACE

Set all the communication condition setting switches on the RS-232C panel to ON.

4.3 Connecting the Printer

○ WARNING

- To prevent electrical shock, before adding or replacing the RS-232C interface, check that the power for the unit is off and the power cord and connectors are disconnected. [The fixing screws must be firmly tightened or the input unit may not function up to specification, or may even fail.]
- To avoid the danger of electric shock, never operate the unit with an RS-232C interface removed. If you should wish to use the unit after removing an interface, fit a blank panel over the opening of the removed unit.


To connect the 9593-02 and printer, use the 9446 CONNECTING CABLE. Use the 9443* AC ADAPTER and the 1196 RECORDING PAPER. (All are options.)

*9443-01 (for Japan)

*9443-02 (for EU)

*9443-03 (for U.S.A.)

- (1) Make the settings for both the 9442 PRINTER and the 9593-02.
- (2) Power off both the 3157 and the 9442 PRINTER.
- (3) Install the 9593-02 in the 3157.
- (4) Use the 9446 CONNECTING CABLE to connect the 9593-02 and printer.



Example of printing

Example of set value printing

```

SETTING
CURRENT      : 25.0 A , 50 Hz
UPPER        : 0.100 ohm
LOWER        : 0.005 ohm
TIME         : 60.0 s
MAX DATA #  : 10

```

Example of test result printing

```

HIOKI 3157 AC GROUNDING HiTESTER
DATA #       : 1 / 10
JUDGEMENT   : PASS
RESISTANCE   : 0.030 ohm ( 0.75 V )
CURRENT      : 24.9 A , 50 Hz

```

```

DATA #       : 2 / 10
JUDGEMENT   : UPPER FAIL
              5.1 s / 60.0 s
RESISTANCE   : 0.129 ohm ( 3.23 V )
CURRENT      : 25.0 A , 50 Hz

```

Actual size

Set value printing

SETTING	Shows test parameter printing.
CURRENT	Set current value and output current frequency
UPPER	Maximum test value
LOWER	Minimum test value "---" is printed if the optional minimum test value setting function is set to "0: Not set."
TIMER	Testing Time "---" is printed if the optional endless timer function is set to "1: Set."
MAX DATA #	Maximum number of test data (Not printed for OFF)

Test result printing

HIOKI 3157 GROUNDING HiTESTER	Model name This is printed if the test data count function is not used or if the number of test data is 1.)
DATA #	Number of test data and maximum number of test data These are not printed if the test data count function is not used.
JUDGEMENT	Test result PASS, UPPER FAIL or LOWER FAIL is printed. The elapsed time and testing time are also printed for FAIL.
RESISTANCE	Measured resistance value and measured voltage value at the end of a test
CURRENT	Measured current value and frequency at the end of a test

Chapter 5


Connection to the 3155

Attaching optional 9593-02 RS-232C INTERFACE to 3157 enables testing when connected with 3155.

3155 sends command to 3157 to start testing and receives test results when the 3157 testing is complete. The test results can be saved and printed together with the 3155 leakage current test results.

For usage for the 3155, see 3155 (-01) Instruction Manual.


When connecting 3155 with 3157 (9593-02), use connection cable as specified below.



Specification: D-subminiature 25-pin male to D-subminiature 9-pin female connectors, with "crossed" data connections

Settings

- (1) Leave power OFF for both 3155 and 3157 while connecting each RS-232C connector with the RS-232C cable.
- (2) Turn the power ON for both 3155 and 3157.
- (3) Set up 3157 test settings. Measurement does not start unless the following conditions are met.
 1. Test settings
 - Unit of the maximum and minimum test values: Resistance
 - Test time: ON
 - Maximum test value: ON
 When the optional minimum test value setting function is ON.
 - Minimum test value: OFF
 2. Optional function setting
 - Endless timer function: Not set



Chapter 6

Operation

6.1 Setting the RS-232C Communication Conditions

- Use the communication condition setting switches on the RS-232C panel to set the communication conditions.
- On dispatch from the factory, this address is initially set to 00000000.

Bit	1	2	3	4	5	6	7	8
Description	Baud rate		Data length	Parity		Stop bit	Delimiter	Fixed to 0

Bits	Baud rate
1 2	
0 0	9600
0 1	4800
1 0	2400
1 1	19200

Bit 3	Data length
0	8 bits
1	7 bits

Bits	Parity
4 5	
0 0	None
0 1	None
1 0	Even
1 1	Odd

Bit 6	Stop bit
0	1 bit
1	2 bits

Bit 7	Delimiter
0	CR+LF
1	CR

0: OFF, 1: ON

NOTE

- If you change the communication conditions while the 3157 is being used, then you should immediately turn the power off and on again. If this is not done, the communication conditions will not be changed to the new ones.
- When using with the personal computer, set bit 8 to 0.
- When using with the optional 9442 PRINTER, set all bits to 1.
- When the 3157 soft start mode is enabled, its operation slows down at starting test. This may cause a communication error, depending on the preset baud rate.

6.2 Communication Methods by the RS-232C

In order to control the 3157 by the RS-232C, there are several kinds of messages.

Of these, program messages are those received by the 3157 from the computer, while response messages are those sent from the 3157 to the computer.



(1) Program messages

Program messages are command messages or query messages.

- Command messages are orders for controls of the 3157, such as for making unit settings or for reset or the like.

Example :TIMER_<data>

(Command message which enables and disables the test time)

- Query messages are orders for responses relating to results of operation, results of measurement, or the state of 3157 settings. A question mark "?" is suffixed at the end of the command.

Example :TIMER?

(Queries the current test time enablement)

(2) Response messages


It represents the response data for query messages from the 3157.

Example :TIMER_ON

(Test time is currently enabled.)

NOTE

A space is represented by "_" in the examples.



6.3 Message Format

The commands for the 3157 are as far as possible mnemonic. Furthermore, all commands have a long form, and an abbreviated short form.

6.3.1 Program Message

The program message is made up from header and data portions.

Example Command message to set test time to ON

```
:TIMER_ON
```

① ②

①: Header portion

②: Data portion (ASCII-format text or numeric values. Some messages have no data portions...query messages, etc.)

A command header can be abbreviated. The whole command form is referred to as the "long form" and the abbreviated form as the "short form."

In this manual, the short form is written in upper case letters, and then this is continued in lower case letters so as to constitute the long form. Either of these forms will be accepted during operation, but intermediate forms will not be accepted. Further, during operation both lower case letters and upper case letters will be accepted without distinction.

For "TIMER", either "TImEr" (the long form) or "TIM" (the short form) will be accepted. However, any one of "TIME", or "TI" is wrong and will generate an error.

6.3.2 Response Messages

It represents the response message for query messages from the 3157.

Response messages generated by the 3157 are in long form and in upper case letters.

Example :TIMER_ON
(Test time is currently enabled.)

NOTE

If an error occurs when the query message is received, the query does not produce response message.

6.4 Headers

(1) Program message headers

There are three types of header: simple headers, compound headers, and particular headers.

- Simple header

A header consisting of a single word beginning with a letter.

Examples :HEADer etc.

- Compound header

A header consisting of a sequence of words separated by colons.

Examples :CONFIgure:CURRent, MEASure:RESistance?, etc.

- Particular header

A header beginning with an asterisk (*) to indicate that it is a particular command.

Examples *RST etc.

(2) Response message

Headers in response messages can be enabled or disabled by using the "HEADer" command.

Example When test time is enabled:

:TIMER?

(Query message asking for the current enablement state of the test time)

Response message when headers are on.

:TIMER_ON

①

②

①: Header portion

②: Data portion

Response message when headers are off.

ON

Data portion only

6.5 Data Formats

The 3157 uses character string data and decimal numeric data, and the type used varies according to the command in question.

(1) Character data

Character string data must always begin with an alphabetic character, and the characters following can be either alphabetic characters or numerals. Although in character data either upper case letters or lower case letters are accepted, response messages output by the 3157 are always in upper case letters.

Example :STATE_ready

(2) Decimal data

The numeric data values are all represented in decimal, in three formats identified as NR1, NR2 and NR3, and each of these can appear as either a signed number or an unsigned number. Unsigned numbers are taken as positive. Further, if the accuracy of a numerical value exceeds the limit which the 3157 can deal, it is rounded off (5 and above is rounded up; 4 and below is rounded down).

NR1 format: Integer data

Examples +3000, -50000, 210

NR2 format: Fixed point numbers

Examples +2.56, -30.45, 300.28

NR3 format: Floating point numbers.

Examples +3E-2, -1.2E3

The term "NRf format" includes all these three formats. When the 3157 is receiving it accepts NRf format, but when it is sending response messages it utilizes whichever one of the formats NR1 to NR3 is indicated in the specified command.

Examples :CONFigure:CURRENT_25

:CONFigure:CURRENT_+25.012

:CONFigure:CURRENT_0.0025E4

6.6 Delimiters

The term "delimiter" is used to refer to the following possibility for separating data sequences.

The 3157 recognizes either a carriage return (CR) or a carriage return plus linefeed (CR+LF) as delimiters.

NOTE

The 3157 only begins to analyze a command after recognizing the delimiter.

6.7 Separators

(1) Message unit separator

A semicolon (;) is used as a message unit separator when it is desired to set out several messages on a single line.

Example :UNIT_OHM;;UPPER_ON;;CONFIGURE:RUPPER_0.100

NOTE

When messages are combined in this way, if a syntax error occurs, all subsequent messages up to the next terminator will be ignored.

(2) Header separator

In a message which has a header and data, a space (represented by "_" in the examples) is used as the header separator to separate the header from the data.

Example :ADjust_ON

(3) Data separator

If a message has several data items, commas (,) are required as data separators for separating these data items from one another.

Example :KEY_< first byte>, <second byte>

6.8 Abbreviation of Compound Commands

When several compound commands have a common head portion (for example, :CONFigure:CURRent and :CONFigure:RUPPer, etc.), then, when and only when writing them directly following on from one another, this common portion (:CONFigure in this example) can be omitted from each command except for the first one.

This common portion is called "the current path", by analogy with the general concept of the current directory in the directory structure of UNIX or MSDOS, and until it is cleared the analysis of following commands is performed by deeming them to be preceded by the current path which has been curtailed in the interests of brevity. This manner of using the current path is shown in the following example:

Normal expression

```
:CONFigure:CURRent_25.0;:CONFigure:RUPPer_0.100
```

Abbreviated expression

```
:CONFigure:CURRent_25.0;RUPPer_0.100
```

↑ This becomes the current path, and can be curtailed from the following commands.

The current path is cleared when the power is turned on, when a colon (:) appears at the start of a command, and when a delimiter is detected. Messages with particular headers can be executed without relation to the current path. Further, they have no effect upon the current path.

With the 3157, there are 4 possible current paths:

```
:CONFigure:
```

```
:MEASure:
```

```
:MEMory:
```

```
:SYSTEM:
```

6.9 Output Queue

Response messages accumulate in the output queue and are transmitted as data and cleared.

The output queue is also cleared when the power is turned off and turned on again.

The 3157 has an output queue of 300 bytes capacity. If the response messages overflow this limit of 300 bytes, a query error is generated, and the output queue is cleared.

6.10 Input Buffer

The 3157 has an input buffer of 300 bytes capacity. When more than 300 bytes of data are transmitted, when the buffer is full any subsequent bytes received will be ignored.

(When the controller handshake setting is not the same as the 9593-02.)

6.11 Event Registers

The 3157 includes two 8-bit event registers. It is possible to determine the status of the unit by reading these registers.

The event register is cleared in the following situations:

- When a "*CLS" command is executed.
- When an event register query is executed. (*ESR?, :ESR0?)
- When the unit is powered on.

(1) Standard event status register (SESR) bit assignments

Bit 7 PON	Power on flag. When the power is turned on, or on recovery from a power cut, this bit is set to 1.
Bit 6	Unused.
Bit 5 CME	Command error. When a command which has been received contains a syntactic or semantic error, this bit is set to 1. <ul style="list-style-type: none"> • The command is not supported by the 3157. • There is a mistake in a program header. • The number of data parameters is wrong. • The format of the parameters is wrong.
Bit 4 EXE	Execution error. When for some reason a command which has been received cannot be executed, this bit is set to 1. <ul style="list-style-type: none"> • The designated data value is outside the set range. • The designated data value is not acceptable.
Bit 3 DDE	Device dependent error. When a command cannot be executed due to some cause other than a command error, a query error, or an execution error, this bit is set to 1. <ul style="list-style-type: none"> • Execution is impossible due to an abnormality inside the 3157.
Bit 2 QYE	Query error. This bit is set to 1 when a query error is detected by the output queue control. <ul style="list-style-type: none"> • When the data overflows the output queue. • When data in the output queue has been lost.
Bit 1	Unused.
Bit 0	Unused.

(2) Event status register 0 (ESR0) bit assignments

Bit 7	Unused
Bit 6	Unused
Bit 5	Unused
Bit 4	Unused
Bit 3 EOM	Test completed
Bit 2 LFAIL	Below lower limit of comparator
Bit 1 UFAIL	Above upper limit of comparator
Bit 0 PASS	Within limits of comparator

Chapter 7

Command Reference

7.1 Command Summary

Particular commands

Command	Explanation	Ref page
*CLS	Clears event register.	31
*ESR?	Queries standard event status register (SESR).	31
*IDN?	Queries device ID.	31
*RST	Device initialization.	32
*TST?	Queries the result of the self-test.	32

Commands specific to the 3157

Command	Explanation	Ref page
:ADJust	Enables and disables the zero adjustment function.	33
:ADJust?	Queries the zero adjustment function enablement.	33
:CONFigure?	Queries the test settings.	34
:CONFigure:CURRent	Sets the output current value.	34
:CONFigure:CURRent?	Queries the output current value.	35
:CONFigure:DATA	Sets the number of test data.	35
:CONFigure:DATA?	Queries the number of test data.	35
:CONFigure:RLOWer	Sets the minimum test value (resistance).	36
:CONFigure:RLOWer?	Queries the minimum test value (resistance).	36
:CONFigure:RUPPer	Sets the maximum test value (resistance).	37
:CONFigure:RUPPer?	Queries the maximum test value (resistance).	37
:CONFigure:TIMer	Sets the test time.	38
:CONFigure:TIMer?	Queries the test time.	38
:CONFigure:VLOWer	Sets the minimum test value (voltage).	39
:CONFigure:VLOWer?	Queries the minimum test value (voltage).	39
:CONFigure:VUPPer	Sets the maximum test value (voltage).	40
:CONFigure:VUPPer?	Queries the maximum test value (voltage).	40
:ESR0?	Queries event status register 0.	40
:HEADer	Enables and disables headers for the response messages.	41
:HEADer?	Queries whether or not headers on response messages are enabled.	41
:KEY	Sets key entry.	42
:LOWer	Enables and disables the minimum test value.	42
:LOWer?	Queries the minimum test value enablement.	43
:MEASure:CURRent?	Queries the measured current value.	43
:MEASure:RESistance?	Queries the measured resistance value.	44
:MEASure:TIMer?	Queries the test time elapsed.	44
:MEASure:VOLTage?	Queries the measured voltage value.	45
:MEASure:RESult:VOLTage?	Queries the measured value and result (voltage).	45
:MEASure:RESult:RESistance?	Queries the measured value and result (resistance).	46
:MEMory:CLEar	Clears Setting memory.	46
:MEMory:FILE?	Queries the contents of Setting memory.	47
:MEMory:LOAD	Loads Setting memory.	47
:MEMory:SAVE	Saves in Setting memory.	48
:STARt	Starts a test.	48
:STATe?	Queries the state.	48
:STOP	Performs forcible ending of a test and releases the hold state.	49
:SYSTem:ERRor?	Queries RS-232C communication condition errors.	49

Command	Explanation	Ref page
:SYSTem:OPTion:BUZZer	Sets the buzzer.	50
:SYSTem:OPTion:BUZZer?	Queries the buzzer.	50
:SYSTem:OPTion:CCHange	Sets the current changeability in the TEST state.	51
:SYSTem:OPTion:CCHange?	Queries the current changeability in the TEST state.	51
:SYSTem:OPTion:CDATa	Sets the maximum number of test data in the test data count function.	52
:SYSTem:OPTion:CDATa?	Queries the maximum number of test data in the test data count function.	52
:SYSTem:OPTion:COUNt	Sets the test data count function.	53
:SYSTem:OPTion:COUNt?	Queries the test data count function.	53
:SYSTem:OPTion:ENDLess	Sets the endless timer function.	54
:SYSTem:OPTion:ENDLess?	Queries the endless timer function.	54
:SYSTem:OPTion:FREQUency	Sets the output current frequency.	55
:SYSTem:OPTion:FREQUency?	Queries the output current frequency.	55
:SYSTem:OPTion:HOLD	Sets the hold function.	56
:SYSTem:OPTion:HOLD?	Queries the hold function.	56
:SYSTem:OPTion:LOWer	Sets the minimum test value.	57
:SYSTem:OPTion:LOWer?	Queries the minimum test value.	57
:SYSTem:OPTion:MOMentary	Sets the momentary OUT function.	58
:SYSTem:OPTion:MOMentary?	Queries the momentary OUT function.	58
:SYSTem:OPTion:PFHold	Sets the PASS/FAIL hold function.	59
:SYSTem:OPTion:PFHold?	Queries the PASS/FAIL hold function.	59
:SYSTem:OPTion:PRINter	Sets the printer output function.	60
:SYSTem:OPTion:PRINter?	Queries the printer output function.	60
:SYSTem:OPTion:TMODE	Sets the test mode.	61
:SYSTem:OPTion:TMODE?	Queries the test mode.	61
:TIMer	Enables and disables the test time.	62
:TIMer?	Queries the test time enablement.	62
:UNIT	Sets the unit of the maximum and minimum test values.	63
:UNIT?	Queries the unit of the maximum and minimum test values.	63
:UPPer	Enables and disables the maximum test value.	64
:UPPer?	Queries the maximum test value enablement.	64

7.2 Format of Command Explanations

Syntax	Specifies the syntax for the command (a space is represented by "_" in this syntax).
<data>	For a command that has parameters, specifies their format.
Function	Specifies the function of the command.
Note	Specifies precautions to be taken when using the command.
Example	These are simple examples of the use of the command. Note that all transmission messages are expressed in a "short form."
Error	Specifies what types of error may occur. Any spelling error in a message results in a command error.

NOTE

For details of each function, refer to the instruction manual for the 3157 unit.

7.3 Particular Commands

*CLS

Clears the status byte register and the event registers.

Syntax *CLS

Function · Clears all the event registers (SESR, ESR0) associated with the bits of the status byte register. Accordingly, also clears the status byte register.
 · This has no effect upon the output queue.

Error If the data parameters are set after this command, a command error occurs.

*ESR?

Queries the contents of the standard event status register (SESR).

Syntax *ESR?

Function · Returns the contents of the standard event status register (SESR) as a numerical value in NR1 format between 0 and 255, and then clears standard event status register.
 · No header is affixed to the response message.

Example Response 32
 Bit 5 of SESR has been set to 1.

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
PON	URQ	CME	EXE	DDE	QYE	RQC	OPC

Standard event status register (SESR)

Error If the response message is longer than 300 bytes, a query error is generated.

*IDN?

Queries manufacturer's name, model name, and software version.

Syntax *IDN?

Function · The response consists of the name of the manufacturer of the unit, the model name, and the software version.
 · No header is affixed to the response message.
 First field Manufacturer's name
 Second field Model name
 Third field Serial number (Not used - always zero)
 Fourth field Software version

Example Response HIOKI,3157,0,V01.01

Error If the response message is longer than 300 bytes, a query error is generated.

***RST**

Performs device initial setting.

Syntax *RST

Function Resets the 3157. The items which are reset are listed below.

Voltage or resistance indicator (unit)	Resistance
Test time enablement	ON
Maximum test value enablement	ON
Minimum test value enablement	OFF
Output current value	25.0 A
Maximum test value (resistance)	0.100
Minimum test value (resistance)	0.000
Maximum test value (voltage)	2.50 V
Minimum test value (voltage)	0.00 V
Test time	60.0 s

Error If the data parameters are set after this command, a command error occurs.

***TST?**

Requests execution of, and queries the result of, the self test.

Syntax *TST?

Function

- Performs the self test of the 3157, and returns the result thereof as a numerical value in NR1 format between 0 and 3.
- No header is affixed to the response message.
 - Bit 0: A ROM error occurred.
 - Bit 1: A RAM error occurred.
 - Bits 2 to 7: Unused

Example Response 3
A ROM error (bit 0) and a RAM error (bit 1) have occurred.

Error If the response message is longer than 300 bytes, a query error occurs. The execution of this command in a state other than the READY state causes an execution error.

7.4 Commands Specific to the 3157

:ADJust

Enables and disables the zero adjustment function.

Syntax :ADJust_<data>

<data> ON/OFF (character data)

Function · Turns the zero adjustment function on and off.

Example Transmission :ADJust ON
The zero adjustment function is turned on.

Error If <data> is other than character data and numerical value described above, a command error occurs.
The execution of this command in a state other than the READY state causes an execution error.

:ADJust?

Queries the zero adjustment function enablement.

Syntax :ADJust?

Function Returns the current enablement state of the zero adjustment function as character data.

<data> ON/OFF (character data)

Example Response
If headers are on :ADJUST ON
If headers are off ON

Error If the response message is longer than 300 bytes, a query error is generated.

:CONFigure?

Queries the test settings.

- Syntax** :CONFigure?
- Function** Returns as data the test settings as <output current value>, <maximum test value>, <minimum test value>, <test time> in order.
 If the unit of the maximum and minimum test values is set to "OHM" (resistance), the maximum and minimum test values are expressed as resistance values.
 If the unit of the maximum and minimum test values is set to "VOLT" (voltage), the maximum and minimum test values are expressed as voltage values.
- <data>** Output current value: Numerical value in NR2 format
 Maximum test value, minimum test value, test time: OFF, --- (character data), or numerical value in NR2 format
 When the minimum test value is not set, returns "---."
 When the minimum test value is set and set to OFF, returns "OFF."
 When the endless timer function is set, returns "---."
 When the endless timer function is not set, and the test time is set to OFF, returns "OFF."
- Example** Response
 If headers are on :CONFIGURE 25.0,0.100,0.000,60.0
 If headers are off 25.0,0.100,0.000,60.0
- Error** If the response message is longer than 300 bytes, a query error is generated.
-

:CONFigure:CURRent

Sets the output current value.

- Syntax** :CONFigure:CURRent_<data>
- <data>** Numerical data in NR2 format between 3.0 and 31.0
- Function** Sets the output current value.
 The numerical value can be in NRf format, but rounding is performed for figures beyond the last valid decimal place.
- Example** Transmission :CONFigure:CURRent 25.0
 The output current value is set to 25.0 A.
- Error** If <data> is other than numerical value described above, an execution error occurs.
 The execution of this command in a state other than the READY state causes an execution error.
 However, when the current value can be changed in the TEST state, this command is executed even in the TEST state.

:CONFigure:CURRent?

Queries the output current value.

Syntax :CONFigure:CURRent?

Function Returns the output current value setting as a numerical value in NR2 format.

<data> Numerical data in NR2 format between 3.0 and 31.0

Note If the output current value is reset in the TEST state (test in progress), the reset value is returned. On completion of the test, however, the value that was set before the test is returned.

Example Response
 If headers are on :CONFIGURE:CURRENT 25.0
 If headers are off 25.0

Error If the response message is longer than 300 bytes, a query error is generated.

:CONFigure:DATA

Sets the number of test data.

Syntax :CONFigure:DATA_<data>

<data> Numerical data in NR1 format between 1 and 99

Function Sets the number of test data.
 The numerical value can be in NRf format, but any digits after the decimal point will be rounded.

Example Transmission :CONFigure:DATA 10
 The number of test data is set to 10.

Error If <data> is other than numerical value described above, an execution error occurs.
 The execution of this command in a state other than the READY state causes an execution error.
 If a number exceeding the maximum number of test data in the test data count function is set, an execution error occurs.

:CONFigure:DATA?

Queries the number of test data.

Syntax :CONFigure:DATA?

Function Returns the setting for the number of test data as a numerical value in NR1 format.

<data> Numerical data in NR1 format between 1 and 99

Example Response
 If headers are on :CONFIGURE:DATA 10
 If headers are off 10

Error If the response message is longer than 300 bytes, a query error is generated.

:CONFigure:RLOWer

Sets the minimum test value (resistance).

Syntax :CONFigure:RLOWer_<data>

<data> Numerical data in NR2 format between 0.000 and 2.000

Function Sets the minimum test value (resistance).
The numerical value can be in NRf format, but rounding is performed for figures beyond the last valid decimal place.

Note The minimum test value (resistance) can be used as the basis for the test only when the maximum and minimum test values are set to be expressed in "OHM" (resistance) and when the minimum test value setting is not disabled, and when "ON" is selected in the ON/OFF setting for the minimum test value.

Example Transmission :CONFigure:RLOWer 0.000
The minimum test value (resistance) is set to 0.000 .

Error If <data> is other than numerical value described above, an execution error occurs.
The execution of this command in a state other than the READY state causes an execution error.

:CONFigure:RLOWer?

Queries the minimum test value (resistance).

Syntax :CONFigure:RLOWer?

Function Returns the minimum test value (resistance) setting as a numerical value in NR2 format.

<data> Numerical data in NR2 format between 0.000 and 2.000

Example Response
If headers are on :CONFigure:RLOWer 0.000
If headers are off 0.000

Error If the response message is longer than 300 bytes, a query error is generated.

:CONFigure:RUPPer

Sets the maximum test value (resistance).

Syntax :CONFigure:RUPPer_<data>

<data> Numerical data in NR2 format between 0.000 and 2.000

Function Sets the maximum test value (resistance).
The numerical value can be in NRf format, but rounding is performed for figures beyond the last valid decimal place.

Note The maximum test value (resistance) can be used as the basis for the test only when the maximum and minimum test values are set to be expressed in "OHM" (resistance) and when "ON" is selected in the ON/OFF setting for the maximum test value.

Example Transmission :CONFigure:RUPPer 0.100
The maximum test value (resistance) is set to 0.100 .

Error If <data> is other than numerical value described above, an execution error occurs.
The execution of this command in a state other than the READY state causes an execution error.

:CONFigure:RUPPer?

Queries the maximum test value (resistance).

Syntax :CONFigure:RUPPer?

Function Returns the maximum test value (resistance) setting as a numerical value in NR2 format.

<data> Numerical data in NR2 format between 0.000 and 2.000

Example Response
If headers are on :CONFigure:RUPPER 0.200
If headers are off 0.200

Error If the response message is longer than 300 bytes, a query error is generated.

:CONFigure:TIMer

Sets the test time.

Syntax :CONFigure:TIMer_<data>

<data> Numerical data in NR1 or NR2 format between 0.5 and 999

Function Sets the test time.

The numerical value can be in NRf format, but rounding is performed for figures beyond the last valid decimal place.

Note The test time can be used as the basis for the test only when the endless timer function setting is disabled and when "ON" is selected in the ON/OFF setting for the test time.

Example Transmission :CONFigure:TIMer 60.0
The test time is set to 60.0 s.

Error If <data> is other than numerical value described above, an execution error occurs.
The execution of this command in a state other than the READY state causes an execution error.

:CONFigure:TIMer?

Queries the test time.

Syntax :CONFigure:TIMer?

Function Returns the test time setting as a numerical value in NR1 or NR2 format.

<data> Numerical data in NR1 or NR2 format between 0.5 and 999

Example Response
If headers are on :CONFIGURE:TIMER 60.0
If headers are off 60.0

Error If the response message is longer than 300 bytes, a query error is generated.

:CONFigure:VLOWer

Sets the minimum test value (voltage).

Syntax :CONFigure:VLOWer_<data>

<data> Numerical data in NR2 format between 0.00 and 6.00

Function Sets the minimum test value (voltage).
The numerical value can be in NRf format, but rounding is performed for figures beyond the last valid decimal place.

Note The minimum test value (voltage) can be used as the basis for the test only when the maximum and minimum test values are set to be expressed in "VOLT" (voltage) and when the minimum test value setting is not disabled, and when "ON" is selected in the ON/OFF setting for the minimum test value.

Example Transmission :CONFigure:VLOWer 0.00
The minimum test value (voltage) is set to 0.00 V.

Error If <data> is other than numerical value described above, an execution error occurs.
The execution of this command in a state other than the READY state causes an execution error.

:CONFigure:VLOWer?

Queries the minimum test value (voltage).

Syntax :CONFigure:VLOWer?

Function Returns the minimum test value (voltage) setting as a numerical value in NR2 format.

<data> Numerical data in NR2 format between 0.00 and 6.00

Example Response
If headers are on :CONFIGURE:VLOWER 0.00
If headers are off 0.00

Error If the response message is longer than 300 bytes, a query error is generated.

:CONFigure:VUPPer

Sets the maximum test value (voltage).

- Syntax** :CONFigure:VUPPer_<data>
- <data>** Numerical data in NR2 format between 0.00 and 6.00
- Function** Sets the maximum test value (voltage).
The numerical value can be in NRf format, but rounding is performed for figures beyond the last valid decimal place.
- Note** The maximum test value (voltage) can be used as the basis for the test only when the maximum and minimum test values are set to be expressed in "VOLT" (voltage) and when "ON" is selected in the ON/OFF setting for the maximum test value.
- Example** Transmission :CONFigure:VUPPer 2.50
The maximum test value (voltage) is set to 2.50 V.
- Error** If <data> is other than numerical value described above, an execution error occurs.
The execution of this command in a state other than the READY state causes an execution error.

:CONFigure:VUPPer?

Queries the maximum test value (voltage).

- Syntax** :CONFigure:VUPPer?
- Function** Returns the maximum test value (voltage) setting as a numerical value in NR2 format.
- <data>** Numerical data in NR2 format between 0.00 and 6.00
- Example** Response
If headers are on :CONFigure:VUPPER 2.50
If headers are off 2.50
- Error** If the response message is longer than 300 bytes, a query error is generated.

:ESR0?

Queries event status register 0.

- Syntax** ESR0?
- Function** Returns the value of event status register 0 (ESR0) as a numerical value in NR1 format between 0 and 255, and then clears event status register 0. No header is prefixed to the response message.
- | | | | | | | | |
|--------|--------|--------|--------|-------|-------|-------|-------|
| 128 | 64 | 32 | 16 | 8 | 4 | 2 | 1 |
| bit 7 | bit 6 | bit 5 | bit 4 | bit 3 | bit 2 | bit 1 | bit 0 |
| Unused | Unused | Unused | Unused | EOM | LFAIL | UFAIL | PASS |
- Event status register 0 (ESR0)

- Example** Response 4
Bit 2 of ESR0 has been set to 1.
- Error** If the response message is longer than 300 bytes, a query error is generated.

:HEADer

Enables and disables headers for the response messages.

Syntax :HEADer_<data>

<data> ON/OFF (character data)

Function Sets whether or not the 3157 will prefix headers to its response messages. When powering on, <data> is initially set to OFF.

Example Transmission :HEADer ON
Headers are prefixed to response messages.

Error If <data> is other than character data described above, an execution error occurs.

:HEADer?

Queries whether or not headers on response messages are enabled.

Syntax :HEADer?

Function Returns whether or not headers on response messages are enabled as character data.

<data> ON/OFF (character data)

Example Response
If headers are on :HEADer ON
If headers are off OFF

Error If the response message is longer than 300 bytes, a query error is generated.

:KEY

Sets key entry.

Syntax :KEY_<data 1>, <data 2>**<data 1>** Numerical data in NR1 format between 0 and 1**<data 2>** Numerical data in NR1 format of 1, 2, 4, 8, 16, 32, 64 to 66, 68, 72, 80, 96, 128**Function** Sets the key registers 0 and 1 (KEY0 and KEY1).

<data 1>

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0

Unused	STOP						
--------	--------	--------	--------	--------	--------	--------	------

Key register 0 (KEY0)

<data 2>

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0

START	SHIFT	0 ADJ	ON/OFF	DOWN	UP	RIGHT	LEFT
-------	-------	-------	--------	------	----	-------	------

Key register 1 (KEY1)

Note Whether key entry is possible or not depends on the state of the unit. For more information, see the instruction manual for the 3157.**Example** Transmission :KEY 0,2
The right arrow key entry is set.**Error** If <data 1> and <data 2> are other than numerical values described above, an execution error occurs.

:LOWer

Enables and disables the minimum test value.

Syntax :LOWer_<data>**<data>** ON/OFF (character data)**Function** Enables and disables the minimum test value.**Note** When the minimum test value setting is disabled, the ON/OFF setting for the minimum test value is not reflected in the test.**Example** Transmission :LOWer ON
The minimum test value is set to ON.**Error** If <data> is other than character data and numerical value described above, a command error occurs.
The execution of this command in a state other than the following states causes an execution error:

- READY state
- Optional function setting screen

:LOWer?

Queries the minimum test value enablement.

Syntax	:LOWer?
Function	Returns the current enablement state of the minimum test value as character data.
<data>	ON/OFF (character data)
Example	Response If headers are on :LOWER ON If headers are off ON
Error	If the response message is longer than 300 bytes, a query error is generated.

:MEASure:CURRent?

Queries the measured current value.

Syntax	:MEASure:CURRent?
Function	Returns the measured current value as a numerical value in NR2 format.
<data>	Numerical data in NR2 format between 0.0 and 35.0
Note	The measured current value is returned in the TEST state (test in progress), and the result of the previous test is returned in the other states. In the stand-by state (as indicated by a blinking TEST lamp), the following values are returned. In the soft start mode: Measured value In the continuous test mode: Result of the previous test
Example	Response If headers are on :MEASURE:CURRENT 25.0 If headers are off 25.0
Error	If the response message is longer than 300 bytes, a query error is generated.

:MEASure:RESistance?

Queries the measured resistance value.

- Syntax** :MEASure:RESistance?
- Function** Returns the measured resistance value as a numerical value in NR2 format.
- <data>** O.F. (character data)
Numerical data in NR2 format between 0.000 and 2.000
- Note** The measured current value is returned in the TEST state (test in progress), and the result of the previous test is returned in the other states.
In the stand-by state (as indicated by a blinking **TEST** lamp), the following values are returned.
In the soft start mode: Measured value
In the continuous test mode: Result of the previous test
In the case of an overflow for the measured resistance, "O.F." is returned.
- Example** Response
If headers are on :MEASURE:RESISTANCE 0.200
If headers are off 0.200
- Error** If the response message is longer than 300 bytes, a query error is generated.
-

:MEASure:TIMer?

Queries the test time elapsed.

- Syntax** :MEASure:TIMer?
- Function** Returns the test time elapsed as a numerical value in NR2 format.
- <data>** --- (character data)
Numerical data in NR2 format between 0.0 and 999.0
- Note** The measured current value is returned in the TEST state (test in progress), and the result of the previous test is returned in the other states.
The test time elapsed is returned regardless of the ON/OFF setting for the test time. Thus, the value displayed on the GP-IB interface may differ from that displayed on the main body.
The test time elapsed is returned regardless of the ON/OFF setting for the test time. However, when the endless timer function is set, "---" is returned.
In the stand-by state (as indicated by a blinking **TEST** lamp), the following values are returned.
In the soft start mode: Measured value
In the continuous test mode: Result of the previous test
- Example** Response
If headers are on :MEASURE:TIMER 10.0
If headers are off 10.0
- Error** If the response message is longer than 300 bytes, a query error is generated.

:MEASure:VOLTage?

Queries the measured voltage value.

Syntax :MEASure:VOLTage?

Function Returns the measured voltage value as a numerical value in NR2 format.

<data> Numerical data in NR2 format between 0.00 and 6.00

Note The measured current value is returned in the TEST state (test in progress), and the result of the previous test is returned in the other states.

In the stand-by state (as indicated by a blinking **TEST** lamp), the following values are returned.

In the soft start mode: Measured value

In the continuous test mode: Result of the previous test

Example Response

If headers are on :MEASURE:VOLTAGE 2.50

If headers are off 2.50

Error If the response message is longer than 300 bytes, a query error is generated.

:MEASure:RESult:VOLTage?

Queries the measured value and result (voltage).

Syntax :MEASure:RESult:VOLTage?

Function Returns as data the measured value and result as <measured current value>, <measured voltage value>, <test time elapsed>, <screening result> in order. If the unit of the maximum and minimum test values is set to "OHM" (resistance), the measured voltage value and screening result are OFF.

<data> Measured current and voltage values: Numerical value in NR2 format
 Test time elapsed: --- (character data) or numerical value in NR2 format
 Screening results: PASS, UFAIL (UPPER FAIL), LFAIL (LOWER FAIL), ULFAIL (FAIL due to the protection function), OFF (other than PASS and FAIL) (character data)

Note The previous measured value and result are returned until the next test is completed.

If the measured resistance value is required, query using the ":MEASure:RESistance?" command until the next test starts.

The test time elapsed is returned regardless of the ON/OFF setting for the test time. However, when the endless timer function is set, "---" is returned.

Example Response

If headers are on :MEASURE:RESULT:VOLTAGE 25.0,2.50,60.0,PASS

If headers are off 25.0,2.50,60.0,PASS

Error If the response message is longer than 300 bytes, a query error is generated.

:MEASure:RESult:RESistance?

Queries the measured value and result (resistance).

- Syntax** :MEASure:RESult:RESistance?
- Function** Returns as data the measured value and result as <measured current value>, <measured resistance value>, <test time elapsed>, <screening result> in order. If the unit of the maximum and minimum test values is set to "VOLT" (voltage), the measured resistance value and screening result are OFF.
- <data>** Measured current value: Numerical value in NR2 format
 Measured resistance value: O.F. (character data) or numerical value in NR2 format
 Test time elapsed: --- (character data) or numerical value in NR2 format
 Screening results: PASS, UFAIL (UPPER FAIL), LFAIL (LOWER FAIL), ULFAIL (FAIL due to the protection function), OFF (other than PASS and FAIL) (character data)
- Note** The previous measured value and result are returned until the next test is completed.
 If the measured voltage value is required, query using the ":MEASure:VOLTage?" command until the next test starts.
 In the case of an overflow for the measured resistance, "O.F." is returned.
 The test time elapsed is returned regardless of the ON/OFF setting for the test time. However, when the endless timer function is set, "---" is returned.
- Example** Response
 If headers are on :MEASURE:RESULT:RESISTANCE 25.0,0.100,60.0,PASS
 If headers are off 25.0,0.100,60.0,PASS
- Error** If the response message is longer than 300 bytes, a query error is generated.
-

:MEMory:CLEar

Clears Setting memory.

- Syntax** :MEMory:CLEar_<data>
- <data>** Numerical data in NR1 format between 1 and 20
- Function** Clears Setting memory numbered <data>. The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
- Note** The specified Setting memory is initialized. For the items which are initialized, see the "*RST" command.
- Example** Transmission :MEMory:CLEar 10
 Setting memory numbered 10 is cleared.
- Error** If <data> is other than numerical value described above, an execution error occurs.
 The execution of this command in a state other than the READY state causes an execution error.

:MEMory:FILE?

Queries the contents of Setting memory.

- Syntax** :MEMory:FILE?_<data 1>
- <data 1>** Numerical data in NR1 format between 1 and 20
- Function** Returns as data (<data2>) the contents of Setting memory numbered <data 1> as <output current value>, <maximum test value>, <minimum test value>, <test time> in order.
 If the unit of the maximum and minimum test values is set to "OHM" (resistance), the maximum and minimum test values are expressed as resistance values.
 If the unit of the maximum and minimum test values is set to "VOLT" (voltage), the maximum and minimum test values are expressed as voltage values.
- <data 2>** Output current value: Numerical value in NR2 format
 Maximum test value, minimum test value, test time: OFF, --- (character data), or numerical value in NR2 format
 When the minimum test value is not set, returns "---."
 When the minimum test value is set and set to OFF, returns "OFF."
 When the endless timer function is set, returns "---."
 When the endless timer function is not set, and the test time is set to OFF, returns "OFF."
- Example** Transmission :MEMory:FILE? 1
 Response
 If headers are on :MEMORY:FILE 25.0,0.100,0.000,60.0
 If headers are off 25.0,0.100,0.000,60.0
- Error** If the response message is longer than 300 bytes, a query error is generated.
 The execution of this command in a state other than the READY state causes an execution error.

:MEMory:LOAD

Loads Setting memory.

- Syntax** :MEMory:LOAD_<data>
- <data>** Numerical data in NR1 format between 1 and 20
- Function** Loads Setting memory numbered <data>.
 The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
- Example** Transmission :MEMory:LOAD 10
 Setting memory numbered 10 is loaded.
- Error** If <data> is other than numerical value described above, an execution error occurs.
 The execution of this command in a state other than the READY state causes an execution error.

:MEMory:SAVE

Saves in Setting memory.

- Syntax** :MEMory:SAVE_<data>
- <data>** Numerical data in NR1 format between 1 and 20
- Function** Saves the current settings in Setting memory numbered <data>. The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
- Example** Transmission :MEMory:SAVE 10
The current settings are saved in Setting memory numbered 10.
- Error** If <data> is other than numerical value described above, an execution error occurs.
The execution of this command in a state other than the READY state causes an execution error.
-

:START

Starts a test.

- Syntax** :START
- Function** Starts a test in the READY state (except the optional function setting screen).
- Note** The ":START" command works in a state in which the momentary OUT settings are disabled even though the momentary OUT settings have been set.
- Example** Transmission :START
- Error** The execution of this command in a state other than the READY state causes an execution error.
If the data parameters are set after this command, a command error occurs.
-

:STATE?

Queries the state.

- Syntax** :STATE?
- Function** Returns the state as data.
- <data>** Screening results: PASS, UFAIL, LFAIL, ULFAIL, READY, TEST, OFF (character data)
PASS: PASS state
UFAIL: FAIL state (UPPER FAIL)
LFAIL: FAIL state (LOWER FAIL)
ULFAIL: FAIL state (FAIL due to the protection function)
OFF: Hold state (in a state other than the PASS and FAIL states), save screen, load screen, optional function setting screen
- Example** Response
If headers are on :STATE PASS
If headers are off PASS
- Error** If the response message is longer than 300 bytes, a query error is generated.

:STOP

Performs forcible ending of a test and releases the hold state.

Syntax :STOP

Function In the TEST state (test in progress), performs forcible ending of a test. When retaining the test result, returns to the READY state. In the save screen, returns to the READY state without saving. In the load screen, returns to the READY state without loading.

Example Transmission :STOP

Error If the data parameters are set after this command, a command error occurs.

:SYSTem:ERRor?

Queries RS-232C communication condition errors.

Syntax :ERRor?

Function Returns the value of RS-232C communication condition errors as a numerical value in NR1 format from 0 to 7, and then clears RS-232C communication condition errors. No header is prefixed to the response message.

<data> Numerical data in NR1 format between 0 and 7

Example Response 4
An overrun error has occurred.

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
Unused	Unused	Unused	Unused	Unused	Overrun error	Framing error	Parity error

RS-232C communication condition errors register

Error If the response message is longer than 300 bytes, a query error is generated.

:SYSTem:OPTion:BUZZer

Sets the buzzer.

- Syntax** :SYSTem:OPTion:BUZZer_<data>
- <data>** Numerical data in NR1 format between 0 and 3
- Function** Sets the buzzer.
1: ON at screening, ON at error
2: OFF at screening, OFF at error
3: OFF at screening, ON at error
4: ON at screening, OFF at error
The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
- Example** Transmission :SYSTem:OPTion:BUZZer 3
The buzzer is set to ON at screening, OFF at error.
- Error** If <data> is other than numerical value described above, an execution error occurs.
The execution of this command in a state other than the following states causes an execution error:
- READY state
 - Optional function setting screen

:SYSTem:OPTion:BUZZer?

Queries the buzzer.

- Syntax** :SYSTem:OPTion:BUZZer?
- Function** Returns the buzzer setting as a numerical value in NR1 format.
- <data>** Numerical data in NR1 format between 0 and 3
- Example** Response
If headers are on :SYSTEM:OPTION:BUZZER 3
If headers are off 3
- Error** If the response message is longer than 300 bytes, a query error is generated.

:SYSTem:OPTion:CCHange

Sets the current changeability in the TEST state.

Syntax :SYSTem:OPTion:CCHange_<data>

<data> Numerical data in NR1 format between 0 and 1

Function Sets the current changeability in the TEST state.

0: Not changeable

1: Changeable

The numerical value can be in NRf format, but any digits after the decimal point will be rounded.

Example Transmission :SYSTem:OPTion:CCHange 1

The current changeability in the TEST state is set to "Changeable."

Error If <data> is other than numerical value described above, an execution error occurs.

The execution of this command in a state other than the following states causes an execution error:

- READY state
- Optional function setting screen

:SYSTem:OPTion:CCHange?

Queries the current changeability in the TEST state.

Syntax :SYSTem:OPTion:CCHange?

Function Returns the setting for the current changeability in the TEST state as a numerical value in NR1 format.

<data> Numerical data in NR1 format between 0 and 1

Example Response

If headers are on :SYSTEM:OPTION:CCHANGE 1

If headers are off 1

Error If the response message is longer than 300 bytes, a query error is generated.

:SYSTem:OPTion:CDATa

Sets the maximum number of test data in the test data count function.

- Syntax** :SYSTem:OPTion:CDATa_<data>
- <data>** Numerical data in NR1 format between 1 and 99
- Function** Sets the maximum number of test data in the test data count function. The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
- Note** When the test data count function is not set, the setting for the maximum number of test data is not reflected in the test.
- Example** Transmission :SYSTem:OPTion:CDATa 10
The maximum number of test data is set to 10.
- Error** If <data> is other than numerical value described above, an execution error occurs.
If a smaller value than that set for the number of test data is set, an execution error occurs.
The execution of this command in a state other than the following states causes an execution error:
- READY state
 - Optional function setting screen

:SYSTem:OPTion:CDATa?

Queries the maximum number of test data in the test data count function.

- Syntax** :SYSTem:OPTion:CDATa?
- Function** Returns the setting for the maximum number of test data in the test data count function as a numerical value in NR1 format.
- <data>** Numerical data in NR1 format between 1 and 99
- Example** Response
If headers are on :SYSTEM:OPTION:CDATA 10
If headers are off 10
- Error** If the response message is longer than 300 bytes, a query error is generated.

:SYSTem:OPTion:COUNT

Sets the test data count function.

- Syntax** :SYSTem:OPTion:COUNT_<data>
- <data>** Numerical data in NR1 format between 0 and 1
- Function** Sets the test data count function.
 0: Not set
 1: Set
 The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
- Note** When the test data count function is not set, the setting for the maximum number of test data is not reflected in the test.
- Example** Transmission :SYSTem:OPTion:COUNT 1
 The test data count function is set.
- Error** If <data> is other than numerical value described above, an execution error occurs.
 The execution of this command in a state other than the following states causes an execution error:
- READY state
 - Optional function setting screen

:SYSTem:OPTion:COUNT?

Queries the test data count function.

- Syntax** :SYSTem:OPTion:COUNT?
- Function** Returns the test data count function setting as a numerical value in NR1 format.
- <data>** Numerical data in NR1 format between 0 and 1
- Example** Response
 If headers are on :SYSTEM:OPTION:COUNT 1
 If headers are off 1
- Error** If the response message is longer than 300 bytes, a query error is generated.

:SYSTem:OPTion:ENDLess

Sets the endless timer function.

- Syntax** :SYSTem:OPTion:ENDLess_<data>
- <data>** Numerical data in NR1 format between 0 and 1
- Function** Sets the endless timer function.
 0: Not set
 1: Set
 The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
- Note** When the endless timer function is set, the ON/OFF setting for the test time is not reflected in the test.
- Example** Transmission :SYSTem:OPTion:ENDLess 1
 The endless timer function is set.
- Error** If <data> is other than numerical value described above, an execution error occurs.
 The execution of this command in a state other than the following states causes an execution error:
- READY state
 - Optional function setting screen

:SYSTem:OPTion:ENDLess?

Queries the endless timer function.

- Syntax** :SYSTem:OPTion:ENDLess?
- Function** Returns the endless timer function setting as a numerical value in NR1 format.
- <data>** Numerical data in NR1 format between 0 and 1
- Example** Response
 If headers are on :SYSTem:OPTion:ENDLess 1
 If headers are off 1
- Error** If the response message is longer than 300 bytes, a query error is generated.

:SYSTem:OPTion:FREQuency

Sets the output current frequency.

- Syntax** :SYSTem:OPTion:FREQuency_<data>
- <data>** Numerical data in NR1 format between 0 and 1
- Function** Sets the output current frequency.
 0: 50 Hz
 1: 60 Hz
 The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
- Example** Transmission :SYSTem:OPTion:FREQuency 1
 The output current frequency is set to 60 Hz.
- Error** If <data> is other than numerical value described above, an execution error occurs.
 The execution of this command in a state other than the following states causes an execution error:
- READY state
 - Optional function setting screen

:SYSTem:OPTion:FREQuency?

Queries the output current frequency.

- Syntax** :SYSTem:OPTion:FREQuency?
- Function** Returns the output current frequency setting as a numerical value in NR1 format.
- <data>** Numerical data in NR1 format between 0 and 1
- Example** Response
 If headers are on :SYSTEM:OPTION:FREQUENCY 1
 If headers are off 1
- Error** If the response message is longer than 300 bytes, a query error is generated.

:SYSTem:OPTion:HOLD

Sets the hold function.

- Syntax** :SYSTem:OPTion:HOLD_<data>
- <data>** Numerical data in NR1 format between 0 and 1
- Function** Sets the hold function.
0: Not held
1: Held
The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
- Example** Transmission :SYSTem:OPTion:HOLD 1
The hold function is set to "Held."
- Error** If <data> is other than numerical value described above, an execution error occurs.
The execution of this command in a state other than the following states causes an execution error:
- READY state
 - Optional function setting screen

:SYSTem:OPTion:HOLD?

Queries the hold function.

- Syntax** :SYSTem:OPTion:HOLD?
- Function** Returns the hold function setting as a numerical value in NR1 format.
- <data>** Numerical data in NR1 format between 0 and 1
- Example** Response
If headers are on :SYSTEM:OPTION:HOLD 1
If headers are off 1
- Error** If the response message is longer than 300 bytes, a query error is generated.

:SYSTem:OPTion:LOWer

Sets the minimum test value.

- Syntax** :SYSTem:OPTion:LOWer_<data>
- <data>** Numerical data in NR1 format between 0 and 1
- Function** Sets the minimum test value.
 0: Not set
 1: Set
 The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
- Note** The ":START" command works in a state in which the momentary OUT settings are disabled even though the momentary OUT settings have been set.
- Example** Transmission :SYSTem:OPTion:LOWer 1
 The minimum test value is set.
- Error** If <data> is other than numerical value described above, an execution error occurs.
 The execution of this command in a state other than the following states causes an execution error:
- READY state
 - Optional function setting screen

:SYSTem:OPTion:LOWer?

Queries the minimum test value.

- Syntax** :SYSTem:OPTion:LOWer?
- Function** Returns the minimum test value setting as a numerical value in NR1 format.
- <data>** Numerical data in NR1 format between 0 and 1
- Example** Response
 If headers are on :SYSTEM:OPTION:LOWER 1
 If headers are off 1
- Error** If the response message is longer than 300 bytes, a query error is generated.

:SYSTem:OPTion:MOMentary

Sets the momentary OUT function.

- Syntax** :SYSTem:OPTion:MOMentary_<data>
- <data>** Numerical data in NR1 format between 0 and 1
- Function** Sets the momentary OUT function.
 0: Not set
 1: Set
 The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
- Note** The ":START" command works in a state in which the momentary OUT settings are disabled even though the momentary OUT settings have been set.
- Example** Transmission :SYSTem:OPTion:MOMentary 1
 The momentary OUT function is set.
- Error** If <data> is other than numerical value described above, an execution error occurs.
 In the continuous test mode, setting the momentary OUT function causes an execution error.
 The execution of this command in a state other than the following states causes an execution error:
- READY state
 - Optional function setting screen

:SYSTem:OPTion:MOMentary?

Queries the momentary OUT function.

- Syntax** :SYSTem:OPTion:MOMentary?
- Function** Returns the momentary OUT function setting as a numerical value in NR1 format.
- <data>** Numerical data in NR1 format between 0 and 1
- Example** Response
 If headers are on :SYSTEM:OPTION:MOMENTARY 1
 If headers are off 1
- Error** If the response message is longer than 300 bytes, a query error is generated.

:SYSTem:OPTion:PFHold

Sets the PASS/FAIL hold function.

Syntax :SYSTem:OPTion:PFHold_<data>

<data> Numerical data in NR1 format between 0 and 3

Function Sets the PASS/FAIL hold function.

0: PASS not held, FAIL held

1: PASS held, FAIL held

2: PASS not held, FAIL not held

3: PASS held, FAIL not held

The numerical value can be in NRf format, but any digits after the decimal point will be rounded.

Example Transmission :SYSTem:OPTion:PFHold 3

The PASS/FAIL hold function is set to "PASS held, FAIL not held."

Error If <data> is other than numerical value described above, an execution error occurs.

The execution of this command in a state other than the following states causes an execution error:

- READY state
- Optional function setting screen

:SYSTem:OPTion:PFHold?

Queries the PASS/FAIL hold function.

Syntax :SYSTem:OPTion:PFHold?

Function Returns the PASS/FAIL hold function setting as a numerical value in NR1 format.

<data> Numerical data in NR1 format between 0 and 3

Example Response

If headers are on :SYSTEM:OPTION:PFHOLD 3

If headers are off 3

Error If the response message is longer than 300 bytes, a query error is generated.

:SYSTem:OPTion:PRINter

Sets the printer output function.

- Syntax** :SYSTem:OPTion:PRINter_<data>
- <data>** Numerical data in NR1 format between 0 and 2
- Function** Sets the printer output function.
 0: Not used
 1: Automatically print for PASS/FAIL screening.
 2: Print selectively when the PASS/FAIL state is held.
 The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
- Example** Transmission :SYSTem:OPTion:PRINter 0
 The printer output function is set to "Not used."
- Error** If <data> is other than numerical value described above, an execution error occurs.
 The execution of this command in a state other than the following states causes an execution error:
- READY state
 - Optional function setting screen

:SYSTem:OPTion:PRINter?

Queries the printer output function.

- Syntax** :SYSTem:OPTion:PRINter?
- Function** Returns the printer output function setting as a numerical value in NR1 format.
- <data>** Numerical data in NR1 format between 0 and 2
- Example** Response
 If headers are on :SYSTEM:OPTION:PRINTER 0
 If headers are off 0
- Error** If the response message is longer than 300 bytes, a query error is generated.

:SYSTem:OPTion:TMODe

Sets the test mode.

Syntax :SYSTem:OPTion:TMODe_<data>

<data> Numerical data in NR1 format between 0 and 2

Function Sets the test mode.

0: Soft start mode

1: Normal mode

2: Continuous test mode

The numerical value can be in NRf format, but any digits after the decimal point will be rounded.

Note When the momentary OUT function is set, if the continuous test mode is set, the momentary OUT function is automatically set to "Not set."

Example Transmission :SYSTem:OPTion:TMODe 2
The test mode is set to Continuous test mode.

Error If <data> is other than numerical value described above, an execution error occurs.

The execution of this command in a state other than the following states causes an execution error:

- READY state
- Optional function setting screen

:SYSTem:OPTion:TMODe?

Queries the test mode.

Syntax :SYSTem:OPTion:TMODe?

Function Returns the test mode setting as a numerical value in NR1 format.

<data> Numerical data in NR1 format between 0 and 2

Example Response

If headers are on :SYSTEM:OPTION:TMODE 2

If headers are off 2

Error If the response message is longer than 300 bytes, a query error is generated.

:TIMER

Enables and disables the test time.

Syntax :TIMER_<data>

<data> ON/OFF (character data)

Function Enables and disables the test time.

Note When the endless timer function is set, the ON/OFF setting for the test time is not reflected in the test.

Example Transmission :TIMER ON
The test time is set to ON.

Error If <data> is other than character data and numerical value described above, a command error occurs.
The execution of this command in a state other than the following states causes an execution error:

- READY state
- Optional function setting screen

:TIMER?

Queries the test time enablement.

Syntax :TIMER?

Function Returns the current enablement state of the test time as character data.

<data> ON/OFF (character data)

Example Response
If headers are on :TIMER ON
If headers are off ON

Error If the response message is longer than 300 bytes, a query error is generated.

:UNIT

Sets the unit of the maximum and minimum test values.

Syntax :UNIT_<data>

<data> OHM: resistance (character data)
VOLT: voltage (character data)

Function Sets the unit of the maximum and minimum test values.

Note If the unit of the maximum and minimum test values is set to "OHM" (resistance), the maximum and minimum test values (resistance) settings are reflected in the test.
If the unit of the maximum and minimum test values is set to "VOLT" (voltage), the maximum and minimum test values (voltage) settings are reflected in the test.

Example Transmission :UNIT OHM
The unit of the maximum and minimum test values is set to OHM.

Error If <data> is other than character data and numerical value described above, a command error occurs.
The execution of this command in a state other than the following states causes an execution error:

- READY state
- Optional function setting screen

:UNIT?

Queries the unit of the maximum and minimum test values.

Syntax :UNIT?

Function Returns the setting for the unit of the maximum and minimum test values as character data.

<data> OHM/VOLT (character data)

Example Response
If headers are on :UNIT OHM
If headers are off OHM

Error If the response message is longer than 300 bytes, a query error is generated.

:UPPer

Enables and disables the maximum test value.

Syntax :UPPer_<data>

<data> ON/OFF (character data)

Function Enables and disables the maximum test value.

Example Transmission :UPPer ON
The maximum test value is set to ON.

Error If <data> is other than character data and numerical value described above, a command error occurs.

The execution of this command in a state other than the following states causes an execution error:

- READY state
- Optional function setting screen

:UPPer?

Queries the maximum test value enablement.

Syntax :TImEr?

Function Returns the current enablement state of the maximum test value as character data.

<data> ON/OFF (character data)

Example Response
If headers are on :UPPER ON
If headers are off ON

Error If the response message is longer than 300 bytes, a query error is generated.

7.5 Response Format for Queries as Numerical Value

The response formats are as follows.

- (1) Output current value and measured current value

.
.

Two or three digits (in NR2 format)

- (2) Maximum test value (voltage), minimum test value (voltage) and measured voltage value

.

Three digits (in NR2 format)

- (3) Maximum test value (resistance), minimum test value (resistance) and measured resistance value

.

Four digits (in NR2 format)

- (4) Test time and test time elapsed

.
.

Two, three or four digits (in NR2 format)

- (5) Number of test data

One or two digits (in NR1 format)

7.6 Initialization Items

The following table shows which items are initialized and which not, under various conditions.

Initialization method Item	Powering on	*RST command	*CLS command
RS-232C communication conditions			
Device specific functions (ranges etc.) *1			
Output queue			
Input buffer			
Event registers	*2		
Current path			
Headers on/off			
Measurement resister			

*1: When the power is turned on, item is discriminated.

*2: Except the PON bit (bit 7)

Chapter 8

Sample Programs


8.1 Sample program Flowchart

(1) Basic settings and testing

This program sets the 3157 to the following test values:

- Output current value: 25.0 A
- Maximum test value: 0.100
- Test time: 60.0 s

It carries out a single test measurement, and displays the result on the screen.




8.1 Sample program Flowchart

(2) Saving the basic settings


This program sets the 3157 to the following test values, and then save them in Setting memory.

	Setting memory				
	1	2	3	4	5
Output current value	25.0 A	10.0 A	25.0 A	15.0 A	10.0 A
Maximum test value	0.100	1.00 V	0.100	1.50 V	0.100
Test time	60.0 s	10.0 s	5.0 s	OFF	5.0 s




(3) Inquiry on, and the loading of, the contents of memory

This program loads the contents of Setting memory in the 3157 after making this inquiry



(4) Testing at five positions and outputting of a text data file

After test settings, five tests are made, and their results are outputted in a text data file.



8.2 Sample programs

The following sample programs are all written for the Microsoft Quick BASIC. For more details on the Quick BASIC, refer to the Quick BASIC documentation.

All commands in the sample programs are used in the short form, and the communication condition setting switches of the 3157 is taken as 00000010 (baud rate: 9600bps, data length: 8 bits, parity: non, stop bit: 1 bit, delimiter: CR).

(1) Basic settings and testing

This program sets the 3157 to the following test values:

- Output current value: 25.0 A
- Maximum test value: 0.100
- Test time: 60.0 s

It carries out a single test measurement, and displays the result on the screen.

Program List

```

100 OPEN "COM1:9600,N,8,1" FOR RANDOM AS #1
110 STATE.CK1:
120 PRINT #1,":STAT?"
130 LINE INPUT #1,A$
140 IF A$="READY" THEN GOTO SETTING
150 PRINT #1,":STOP"
160 GOTO STATE.CK1
170 SETTING:
180 PRINT #1,":HEAD OFF"
190 PRINT #1,":CONF:CURR 25.0"
200 PRINT #1,":UNIT OHM"
210 PRINT #1,":UPP ON"
220 PRINT #1,":CONF:RUPP 0.100"
230 PRINT #1,":TIM ON"
240 PRINT #1,":CONF:TIM 60.0"
250 KEY.IN:
260 INPUT "Press any key to start",B$
270 PRINT #1,":STAR"
280 STATE.CK2:
290 PRINT #1,":STAT?"
300 LINE INPUT #1,C$
310 IF C$="TEST" THEN GOTO STATE.CK3
320 GOTO STATE.CK2
330 STATE.CK3:
340 PRINT #1,":STAT?"
350 LINE INPUT #1,D$
360 IF D$="TEST" THEN GOTO STATE.CK3
370 RESULT:
380 PRINT #1,":MEAS:RES:RES?"
390 LINE INPUT #1,E$
400 PRINT E$
410 CLOSE
420 END

```

Program comments

Line	Comment
100	Open the RS-232C circuit file.
110-160	Confirm that the 3157 is in the READY state.

- 170-240 Make test settings.
- 250-270 Check that a test has started.
- 280-320 Confirm that the 3157 is in the TEST state.
- 330-360 Check that a test has finished.
- 370-400 Query the test results.
- 410 Close the RS-232C circuit file.

Sample display

Press any key to start
25.0,0.020,60.0,PASS

(2) Saving the basic settings

This program sets the 3157 to the following test values, and then save them in Setting memory.

Setting memory 1
Output current value: 25.0 A Maximum test value: 0.100 Test time: 60.0 s

Setting memory 2
Output current value: 10.0 A Maximum test value: 1.00 V Test time: 10.0 s

Setting memory 3
Output current value: 25.0 A Maximum test value: 0.100 Test time: 5.0 s

Setting memory 4
Output current value: 15.0 A Maximum test value: 1.50 V Test time: OFF

Setting memory 5
Output current value: 10.0 A Maximum test value: 0.100 Test time: 5.0 s

Program List

```

100 OPEN "COM1:9600,N,8,1" FOR RANDOM AS #1
110 STATE.CK1:
120 PRINT #1,":STAT?"
130 LINE INPUT #1,A$
140 IF A$="READY" THEN GOTO SETTING1
150 PRINT #1,":STOP"
160 GOTO STATE.CK1
170 SETTING1:
180 PRINT #1,":CONF:CURR 25.0"
190 PRINT #1,":UNIT OHM"
200 PRINT #1,":UPP ON"
210 PRINT #1,":CONF:RUPP 0.100"
220 PRINT #1,":TIM ON"
230 PRINT #1,":CONF:TIM 60.0"
240 PRINT #1,":MEM:SAVE 1"
250 STATE.CK2:
260 PRINT #1,":STAT?"
270 LINE INPUT #1,B$
280 IF B$<>"READY" THEN GOTO STATE.CK2
290 SETTING2:
300 PRINT #1,":CONF:CURR 10.0"
310 PRINT #1,":UNIT VOLT"
320 PRINT #1,":UPP ON"
330 PRINT #1,":CONF:VUPP 1.00"
340 PRINT #1,":TIM ON"
350 PRINT #1,":CONF:TIM 10.0"
360 PRINT #1,":MEM:SAVE 2"

```

```

370 STATE.CK3:
380 PRINT #1,":STAT?"
390 LINE INPUT #1,C$
400 IF C$<>"READY" THEN GOTO STATE.CK3
410 SETTING3:
420 PRINT #1,":CONF:CURR 25.0"
430 PRINT #1,":UNIT OHM"
440 PRINT #1,":UPP ON"
450 PRINT #1,":CONF:RUPP 0.100"
460 PRINT #1,":TIM ON"
470 PRINT #1,":CONF:TIM 5.0"
480 PRINT #1,":MEM:SAVE 3"
490 STATE.CK4:
500 PRINT #1,":STAT?"
510 LINE INPUT #1,D$
520 IF D$<>"READY" THEN GOTO STATE.CK4
530 SETTING4:
540 PRINT #1,":CONF:CURR 15.0"
550 PRINT #1,":UNIT VOLT"
560 PRINT #1,":UPP ON"
570 PRINT #1,":CONF:VUPP 1.50"
580 PRINT #1,":TIM OFF"
590 PRINT #1,":MEM:SAVE 4"
600 STATE.CK5:
610 PRINT #1,":STAT?"
620 LINE INPUT #1,E$
630 IF E$<>"READY" THEN GOTO STATE.CK5
640 SETTING5:
650 PRINT #1,":CONF:CURR 10.0"
660 PRINT #1,":UNIT OHM"
670 PRINT #1,":UPP ON"
680 PRINT #1,":CONF:RUPP 0.100"
690 PRINT #1,":TIM ON"
700 PRINT #1,":CONF:TIM 5.0"
710 PRINT #1,":MEM:SAVE 5"
720 CLOSE
730 END

```

Program comments

Line	Comment
100	Open the RS-232C circuit file.
110-160	Confirm that the 3157 is in the READY state.
170-240	Perform test settings in Setting memory 1.
250-280	Make sure that saving has been completed.
290-360	Perform test settings in Setting memory 2.
370-400	Make sure that saving has been completed.
410-480	Perform test settings in Setting memory 3.
490-520	Make sure that saving has been completed.
530-590	Perform test settings in Setting memory 4.
600-630	Make sure that saving has been completed.
640-710	Perform test settings in Setting memory 5.
720	Close the RS-232C circuit file.

(3) Inquiry on, and the loading of, the contents of memory

This program loads the contents of Setting memory in the 3157 after making this inquiry

Program List

```

100 OPEN "COM1:9600,N,8,1" FOR RANDOM AS #1
110 STATE.CK1:
120 PRINT #1,":STAT?"
130 LINE INPUT #1,A$
140 IF A$="READY" THEN GOTO FILE.CK:
150 PRINT #1,":STOP"
160 GOTO STATE.CK1
170 FILE.CK:
180 PRINT #1,":MEM:FILE? 1"
190 LINE INPUT #1,B$
200 PRINT B$
210 KEY.IN:
220 INPUT "Load?(Y/N)=",C$
230 IF C$="Y" THEN GOTO FILE.LOAD
240 IF C$="N" THEN GOTO EXIT1
250 GOTO KEY.IN
260 FILE.LOAD:
270 PRINT #1,":MEM:LOAD 1"
280 EXIT1:
290 CLOSE
300 END

```

Program comments

Line	Comment
100	Open the RS-232C circuit file.
110-160	Confirm that the 3157 is in the READY state.
170-200	Query the contents of Setting memory 1.
210-250	Check if loading is workable.
260-270	Load Setting memory 1.
290	Close the RS-232C circuit file.

Sample display

```

25.0,0.100,0.000,60.0
Load?(Y/N)=Y

```

(4) Testing at five positions and outputting of a text data file

After test settings, five tests are made, and their results are outputted in a text data file.

Program List

```

100 OPEN "COM1:9600,N,8,1" FOR RANDOM AS #1
110 N=0
120 INPUT"Drive";D$
130 INPUT"File";F$
140 OPEN D$+"."+F$+".DAT" AS #2
150 STATE.READY:
160 PRINT #1,":STAT?"
170 LINE INPUT #1,R$
180 IF R$="READY" THEN GOTO SETTING
190 PRINT #1,":STOP"
200 GOTO STATE.READY
210 SETTING:
220 PRINT #1,":HEAD OFF"
230 PRINT #1,":CONF:CURR 25.0"
240 PRINT #1,":UNIT OHM"
250 PRINT #1,":UPP ON"
260 PRINT #1,":CONF:RUPP 0.100"
270 PRINT #1,":TIM ON"
280 PRINT #1,":CONF:TIM 5.0"
290 TESTING:
300 GOSUB KEY.IN
310 PRINT #1,":STAR"
320 GOSUB STATE.TEST
330 GOSUB STATE.TESTEND
340 GOSUB RESULT
350 IF N=5 THEN GOTO EXIT1
360 GOTO TESTING
370 EXIT1:
380 PRINT#2,CHR$(&HD);
390 PRINT#2,CHR$(&HA);
400 CLOSE
410 END
420 KEY.IN:
430 INPUT "Press any key to start",B$
440 RETURN
450 STATE.TEST:
460 STATE.TEST1:
470 PRINT #1,":STAT?"
480 LINE INPUT #1,T$
490 IF T$="TEST" THEN GOTO STATE.TEST2
500 GOTO STATE.TEST1
510 STATE.TEST2:
520 RETURN
530 STATE.TESTEND:
540 STATE.TESTEND1:
550 PRINT #1,":STAT?"
560 LINE INPUT #1,TE$
570 IF TE$="TEST" THEN GOTO STATE.TESTEND1
580 RETURN
590 RESULT:
600 N=N+1
610 PRINT #1,":MEAS:RES:RES?"
620 LINE INPUT #1,RES$
630 PRINT #2,STR$(N);+";";
640 PRINT #2,RES$
650 PRINT STR$(N);+";";
660 PRINT RES$
670 IF TE$="UFAIL" THEN PRINT #1,":STOP"
680 RETURN

```

Program comments

Line	Comment
100	Open the RS-232C circuit file.
110	Initialize variables.
120-140	Open a file
150-200	Confirm that the 3157 is in the READY state.
210-280	Make test settings.
290-360	Make five tests.
400	Close the RS-232C circuit file.
420-440	Check that a test has started.
450-520	Confirm that the 3157 is in the TEST state.
530-580	Check that a test has finished.
590-680	Display the test results and outputs them to a file.

Sample display

```

Drive? A
File? XXX
Press any key to start
 1,25.1,0.090,5.0,PASS
Press any key to start
 2,25.2,0.098,5.0,PASS
Press any key to start
 3,24.6,0.101,0.1,UFAIL
Press any key to start
 4,24.7,0.102,0.1,UFAIL
Press any key to start
 5,24.7,0.101,0.1,UFAIL

```

Sample output

```

1,25.1,0.090,5.0,PASS
2,25.2,0.098,5.0,PASS
3,24.6,0.101,0.1,UFAIL
4,24.7,0.102,0.1,UFAIL
5,24.7,0.101,0.1,UFAIL

```


Chapter 9

Troubleshooting

If the RS-232C appears to be malfunctioning, refer to the information below before calling for servicing.

Symptom	Cause / Treatment
The RS-232C has stopped working completely.	Are the cables properly connected?
	Are all the devices powered on?
	Has the communication condition been correctly set?
Although a command has been transmitted, nothing has happened.	Using the "*ESR?" query, inspect the standard event status register, and check what type of error has occurred.
	Using the ":SYSTem:ERRor?" query, and check whether transmission error occurred on the RS-232C.
Sending several queries, produces only one response.	Has an error occurred?
	Send the queries one at a time, and read the responses individually. When you want to read them in all at once, try doing so by putting them all on one line separated by the message separator character.
The response message to a query differs from the display on the front panel of the 3157.	Due to the response message being produced at the instant that the 3157 receives the query, there is a possibility that it may not agree with the display at the instant that the controller reads it in.

Service

If the unit is not functioning properly, check the "Troubleshooting" list. If a problem is found, contact your dealer or HIOKI representative.

Warranty Certificate

HIOKI

Model	Serial number	Warranty period Three (3) years from date of purchase (___ / ___)
-------	---------------	--

Customer name: _____
Customer address: _____

Important

- Please retain this warranty certificate. Duplicates cannot be reissued.
- Complete the certificate with the model number, serial number, and date of purchase, along with your name and address. The personal information you provide on this form will only be used to provide repair service and information about Hioki products and services.

This document certifies that the product has been inspected and verified to conform to Hioki's standards. Please contact the place of purchase in the event of a malfunction and provide this document, in which case Hioki will repair or replace the product subject to the warranty terms described below.

Warranty terms

1. The product is guaranteed to operate properly during the warranty period (three [3] years from the date of purchase). If the date of purchase is unknown, the warranty period is defined as three (3) years from the date (month and year) of manufacture (as indicated by the first four digits of the serial number in YYMM format).
2. If the product came with an AC adapter, the adapter is warranted for one (1) year from the date of purchase.
3. The accuracy of measured values and other data generated by the product is guaranteed as described in the product specifications.
4. In the event that the product or AC adapter malfunctions during its respective warranty period due to a defect of workmanship or materials, Hioki will repair or replace the product or AC adapter free of charge.
5. The following malfunctions and issues are not covered by the warranty and as such are not subject to free repair or replacement:
 - 1. Malfunctions or damage of consumables, parts with a defined service life, etc.
 - 2. Malfunctions or damage of connectors, cables, etc.
 - 3. Malfunctions or damage caused by shipment, dropping, relocation, etc., after purchase of the product
 - 4. Malfunctions or damage caused by inappropriate handling that violates information found in the instruction manual or on precautionary labeling on the product itself
 - 5. Malfunctions or damage caused by a failure to perform maintenance or inspections as required by law or recommended in the instruction manual
 - 6. Malfunctions or damage caused by fire, storms or flooding, earthquakes, lightning, power anomalies (involving voltage, frequency, etc.), war or unrest, contamination with radiation, or other acts of God
 - 7. Damage that is limited to the product's appearance (cosmetic blemishes, deformation of enclosure shape, fading of color, etc.)
 - 8. Other malfunctions or damage for which Hioki is not responsible
6. The warranty will be considered invalidated in the following circumstances, in which case Hioki will be unable to perform service such as repair or calibration:
 - 1. If the product has been repaired or modified by a company, entity, or individual other than Hioki
 - 2. If the product has been embedded in another piece of equipment for use in a special application (aerospace, nuclear power, medical use, vehicle control, etc.) without Hioki's having received prior notice
7. If you experience a loss caused by use of the product and Hioki determines that it is responsible for the underlying issue, Hioki will provide compensation in an amount not to exceed the purchase price, with the following exceptions:
 - 1. Secondary damage arising from damage to a measured device or component that was caused by use of the product
 - 2. Damage arising from measurement results provided by the product
 - 3. Damage to a device other than the product that was sustained when connecting the device to the product (including via network connections)
8. Hioki reserves the right to decline to perform repair, calibration, or other service for products for which a certain amount of time has passed since their manufacture, products whose parts have been discontinued, and products that cannot be repaired due to unforeseen circumstances.

HIOKI E.E. CORPORATION

<http://www.hioki.com>

18-07 EN-3

HIOKI

<http://www.hioki.com>



**Our regional
contact
information**

HEADQUARTERS

81 Koizumi
Ueda, Nagano 386-1192 Japan

HIOKI EUROPE GmbH

Rudolf-Diesel-Strasse 5
65760 Eschborn, Germany
hioki@hioki.eu

1808EN

Edited and published by HIOKI E.E. CORPORATION

Printed in Japan

- CE declarations of conformity can be downloaded from our website.
- Contents subject to change without notice.
- This document contains copyrighted content.
- It is prohibited to copy, reproduce, or modify the content of this document without permission.
- Company names, product names, etc. mentioned in this document are trademarks or registered trademarks of their respective companies.