

**INSTRUCTION MANUAL** 

# 8845 MEMORY HICORDER

HIOKI E.E. CORPORATION

Introduction	i
Inspection	ii
Safety Notes	iii
Notes on Use	
Chapter Summary	
Chapter 1 Product Overview	1
1.1 Major Features	
1.2 Identification of Controls and Indicators	
Chapter 2 Specifications	11
2.1 General Specifications	
2.2 Trigger Unit Specifications	
2.3 Memory Recorder Function Specifications	
2.4 Recorder Function Specifications	
2.5 FFT Function Specifications	
2.6 Auxiliary Functions Specifications	18
2.7 Accessories and Options	21
2.8 System Operation	22
Chapter 3 Logic and Analog Inputs	23
3.1 Logic Inputs	23
3.1.1 Logic Probes	24
3.2 8916 ANALOG UNIT	25
3.2.1 Specifications	
3.2.2 Safety Requirements	
3.3 8917 DC/RMS UNIT	
3.3.1 Specifications	
3.3.2 Safety Requirements	
3.4 8918 TEMPERATURE UNIT	
3.4.1 Specifications	
3.4.2 Safety Requirements	
3.4.3 Notes on Installation Site	
3.5 8919 FFT ANALOG UNIT	
3.5.1 Specifications	
3.5.2 Safety Requirements	33

Contents

	3.6	8927 ANALOG UNIT	34
		3.6.1 Specifications	34
		3.6.2 Safety Requirements	35
	3.7	8928 STRAIN UNIT	36
		3.7.1 Specifications	36
		3.7.2 Safety Requirements	37
		3.7.3 Strain Unit Settings	37
	3.8	Replacement Procedure	38
	3.9	Input Cables	39
	3.10	Measurement Errors Caused by Signal Source Internal	
		Resistance	40
Chap	oter	4 Installation and Preparation	41
	4.1	Installation of the Unit	41
	4.2	Power Supply and Ground Connection	44
	4.3	Power On/Off	47
	4.4	Probe and Thermocouple Connection	48
	4.5	Connection to a Strain Gauge Adapter	51
	4.6	Connecting the Voltage Transformer	52
	4.7	Loading Recoding Paper	54
	4.8	Storage and Handling Precautions	57
	4.9	Notes on Measurement	58
Chap	oter	5 Basic Operation and Measurement	59
		Basic Operation	
		5.1.1 Basic Display Operation	59
		5.1.2 JOG/SHUTTLE Control and Select Key	60
		5.1.3 Setting Items	
		5.1.4 Measurement Start and End	62
;	5.2	Basic Measurement and Setting Procedures	63
		5.2.1 Measuring and Recording a Voltage (Memory Recorder,	
		Recorder)	63
		5.2.2 Frequency Analysis of Measured Voltage (FFT)	74

4

7

127	
127	
128	
128	
129	
130	
132	
134	
136	
138	
140	
141	
146	
	·
170	
	127         128         129         130         132         134         136         138         140         141         142         144         146         147         148         150         151         152         154         156         158         159         160         162         164         165         168         170

9 Input Channel Settings	175
Overview	175
Selecting Units (SYSTEM Screen)	176
Selecting Functions	177
Selecting the Input Type	178
Making Logic Input Settings (FFT Excluded)	180
Making Analog Input Settings	181
9.6.1 Waveform Display Color (FFT Excluded)	181
9.6.2 Display Graph Type (FFT Excluded)	183
9.6.3 Setting the Voltage Axis, Temperature Axis,	
Strain Axis Ranges	184
9.6.4 Setting the Input Coupling (Not Required for 8918, 8928)	187
9.6.5 Setting Voltage Axis, Temperature Axis, and Strain Axis	}
Magnification/ Compression	188
9.6.7 Setting the Low-Pass Filter	191
9.6.8 Setting the Thermocouple Type (8918 Only)	192
9.6.9 Setting the Antialiasing Filter (8919 Only)	193
9.6.10 Arbitrary Setting if Voltage Axis Magnification/	
9.6.11 Copying Channel Settings	197
9.6.12 Making Channel Settings on Display Screen	198
10 Trigger Functions	199
Overview	199
Setting the Trigger Mode	201
Setting Trigger Source AND/OR Linking	202
Setting the Pretrigger (Memory recorder, FFT)	203
Using the Analog Trigger Function	205
10.5.1 Level Trigger	206
10.5.2 Window-In, Window-Out Trigger	209
Using the Logic Trigger Function	211
Using the External Trigger Function	215
Using the Timer Trigger Function	216
Trigger Output Connector	219
	Selecting Units (SYSTEM Screen)  Selecting Functions  Selecting Functions  Selecting the Input Type  Making Logic Input Settings (FFT Excluded)  Making Analog Input Settings  9.6.1 Waveform Display Color (FFT Excluded)  9.6.2 Display Graph Type (FFT Excluded)  9.6.3 Setting the Voltage Axis, Temperature Axis, Strain Axis Ranges  9.6.4 Setting the Input Coupling (Not Required for 8918, 8928)  9.6.5 Setting Voltage Axis, Temperature Axis, and Strain Axis Magnification/ Compression  9.6.6 Setting the Zero Position  9.6.7 Setting the Low-Pass Filter  9.6.8 Setting the Antialiasing Filter (8919 Only)  9.6.9 Setting the Antialiasing Filter (8919 Only)  9.6.10 Arbitrary Setting if Voltage Axis Magnification/ Compression and Display Range  9.6.11 Copying Channel Settings  9.6.12 Making Channel Settings on Display Screen  10 Trigger Functions  Overview  Setting the Trigger Mode  Setting Trigger Source AND/OR Linking  Setting the Pretrigger (Memory recorder, FFT)  Using the Analog Trigger Function  10.5.1 Level Trigger  10.5.2 Window-In, Window-Out Trigger  Using the Logic Trigger Function  Using the External Trigger Function  Using the Timer Trigger Function

Chapter	11 S`	YSTEM Screen Settings	221
11.1	Overv	iew	- 221
11.2	How t	o Use the SYSTEM Screen	222
11.3	Initiali	zation [ INITIALIZE ]	. 223
	11.3.1	Setting the Clock [ TIME SET ]	. 223
	11.3.2	Clear Waveform Data [ DATA CLEAR ]	- 224
	11.3.3	System Reset [ SYSTEM RESET ]	- 225
11.4	Specia	al Function Settings [ SETUP ]	228
	11.4.1	Channel Selection [ using unit ]	- 229
	11.4.2	Start Key Backup [ start backup ]	- 230
	11.4.3	Setting the Grid [ grid type ]	- 231
	11.4.4	Channel Marker Function [ channel marker ]	- 233
	11.4.5	Time Axis Display [ time axis ]	. 234
	11.4.6	List and Gauge Functions [ list & gauge ]	- 235
	11.4.7	Backlight Saver Function [ backlight saver ]	. 236
	11.4.8	Setting Screen Colors [ LCD color type ]	. 237
	11.4.9	Setting the Volume [ volume ]	- 238
	11.4.10	Intermittent Printing [ intermittent print ]	. 239
11.5	Scalin	g Function [ SCALING ]	. 240
	11.5.1	Conversion Ratio Scaling	- 241
	11.5.2	2-Point Scaling	- 242
	11.5.3	Scaling Setting Example	·· 245
11.6	Adding	g Comments to a Graph [ COMMENT ]	. 247
	11.6.1	Comment and File Name Entry Procedure	- 248
11.7	Self C	heck ·····	- 249
	11.7.1	ROM/RAM Check	- 250
	11.7.2	LED Check	- 251
	11.7.3	Printer Check	252
	11.7.4	Key Check	- 253
	11.7.5	Display Check	254
	11.7.6	DAT Check	. 255
	11.7.7	D/A Unit Output Check	- 256
11.8	Interfa	ce Settinas	. 257

Chapter	12 Printout of Waveform Data and Processing	
	Data	259
12.1	Overview	259
12.2	Selecting Waveform or Numeric Print	260
12.3	Using the Smooth Print Function	262
12.4	Print Settings on SYSTEM Screen	··· 263
12.5	Printing Procedure	··· 264
	12.5.1 Normal Print (Manual) (All Functions)	264
	12.5.2 Normal Print (Auto) (Memory Recorder, FFT)	266
	12.5.3 Real-Time Print (Recorder Function)	267
	12.5.4 Partial Print (Memory Recorder, Recorder)	··· 269
	12.5.5 Screen Hard Copy (All Functions)	271
	12.5.6 A4 Print (Memory Recorder, Recorder)	272
	12.5.7 List Print (All Functions)	273
	12.5.8 Paper Change During Printing	274
12.6	Reading the Display and Printout	··· 275
Chapter	13 Storing Data on DDS Tape/Reading Date	
onapto.	FromDDS Tape	<b>၅</b> 22
12 1	Overview	
	Using the Tape	
	DAT Drive Operation	
	Displaying File List and File Information	
13.4	13.4.1 Displaying a File List	
	13.4.2 Displaying File Information	
12.5	Storing Data on a DDS Tape	
10.0	13.5.1 Storing Memory Recorder and FFT Data	
	13.5.2 Storing Recorder Data	
	13.5.3 Automatic File Name Assignment	
	13.5.4 File Contents and Size	
13.6	Reading Data From DDS Tape	
, , , ,	13.6.1 Reading Stored Data	
	13.6.2 Playback of Stored Data	
13.7	Searching file	
	Sorting files	
	Deleting Stored Data	
	Renaming File	

13.1	1 Reformatting a Tape	313
13.1	2 Checking and Restoring File Data	314
13.1	3 Recording the Recorder Waveform Data Stored on	
	Tape in Memory Recorder Function/FFT Function	316
13.1	4 Preparing to Record	318
Chapter	14 Calculating Waveform Data	319
14.1	Overview	319
14.2	Preparing for Waveform Processing	320
14.3	Defining the Processing Equation	322
	14.3.1 Entering the Equation	322
	14.3.2 Deleting an Equation	325
	14.3.3 Copying an Equation	326
14.4	Setting the Channel for Recording Processing Results	327
14.5	Setting the Display Scale	328
14.6	Specifying the Waveform Processing Range	329
14.7	Setting Example for Waveform Processing	330
14.8	Details on Operators	333
Chapter	15 Determining Waveform Parameters / Evaluati	ng
	Parameter Values	339
15.1	Overview	339
15.2	Making Settings for Waveform Parameter Calculation	340
15.3	Making Settings for Waveform Parameter Evaluation	344
	Using the NG Output	
	Specifying a Range for Waveform Parameter Calculation	
	Printing Out Waveform Parameter Calculation Results	
	Waveform Parameter Calculation and Waveform Param	
	Evaluation Examples	
15.8	Parameter Calculation Details	
Chapter	16 Waveform GO/NG Evaluation	357
16.1		
	Waveform Evaluation Settings	
	Creating the Evaluation Area	
	Editor Command Details	
	Using the NG Output	
	Setting Example for Waveform Evaluation	
TO.C	, John Lambio IVI VVAVGIVIII LVAIUALIVII	$\sigma \sigma \sigma$

21.2 Using the External Start, Stop, and Print Terminals ----- 430

21.3 Using the External Trigger Input (EXT TRIG)
21.4 Using the External Trigger Output (TRIG OUT)
21.5 Using the External Sampling Input (EXT SMPL)
432

21.6 Using the NG Evaluation Output (NG)
21.7 Using the Microphone Input (MIC)
21.8 Using the Key Lock Function
435
437
438

6

APP

Chapter 22 Using the D/A Output Unit 9539 (O	ption) 439
22.1 Overview	439
22.2 Specifications	440
22.3 Usage Precautions	442
22.4 Replacing Units	443
22.5 Output of a Waveform Recorded With the Me	emory
Recorder or Recorder Function	444
Chapter 23 Maintenance	447
23.1 Cleaning of the Unit and Parts	447
23.2 Replacing the DC Power Supply Fuse	450
23.3 Removing the Battery Before Discarding the	8845 451
23.4 Troubleshooting	453
Chapter 24 Error and Warning Messages	455
24.1 Overview	455
24.2 Error Messages	456
24.3 Warning Messages	457
Appendix	APPENDIX 1
Appendix 1 Glossary	APPENDIX 1
Appendix 2 Reference	APPENDIX 5
Appendix 2.1 Memory Recorder Function,	
Recorder Function	APPENDIX 5
Appendix 2.2 FFT Function	APPENDIX 8

# Introduction

Thank you for purchasing this HIOKI "8845 MEMORY HiCORDER." To get the maximum performance from the unit, please read this manual first, and keep this at hand.

# Inspection

- · When the unit is delivered, check and make sure that it has not been damaged in transit. In particular, check the accessories, panel switches, and connectors.
- $\cdot$  If the unit is damaged, or fails to operate according to the specifications, contact your dealer or HIOKI representative.

Accessories	
$\square$ Power cord	1
$\square$ DC power cord	1
☐ Recording paper (roll paper)	1
☐ Spare fuse	1
(DC supply 10 - 30 V: class A i	melting fuse (NM) 12 A/250 V
6.4 dia.×31.8 mm)	
☐ Instruction Manual	1
☐ Protect cover	1
☐ DDS tape (90M)	1
☐ Recording paper attachment	2
$\square$ DDS cleaning tape	1

# **Safety Notes**

This Instruction Manual provides information and warnings essential for operating this equipment in a safe manner and for maintaining it in safe operating condition. Before using this equipment, be sure to carefully read the following safety notes.



During high voltage measurement, incorrect measurement procedures could result in injury or death, as well as damage to the equipment. Please read this manual carefully and be sure that you understand its contents before using the equipment. The manufacturer disclaims all responsibility for any accident or injury except that resulting due to defect in its product.

#### Safety symbols

	<ul> <li>This symbol is affixed to locations on the equipment where the operator should consult corresponding topics in this manual (which are also marked with the symbol) before using relevant functions of the equipment.</li> <li>In the manual, this mark indicates explanations which it is particularly important that the user read before using the equipment.</li> </ul>
	Indicates a grounding terminal.
	Indicates a grounding terminal for measurement.
	Indicates a fuse.
$\sim$	Indicates AC (Alternating Current).
	Indicates DC (Direct Current).
$\overline{\sim}$	Indicates both DC (Direct Current) and AC (Alternating Current).
PEAK	Indicates a peak value.

#### Conventions used in this manual

The following symbols are used in this Instruction Manual to indicate the relative importance of cautions and warnings.

<b>⚠ DANGER</b>	Indicates that incorrect operation presents extreme danger of accident resulting in death or serious injury to the user.
<b>⚠ WARNING</b>	Indicates that incorrect operation presents significant danger of accident resulting in death or serious injury to the user.
⚠ CAUTION	Indicates that incorrect operation presents possibility of injury to the user or damage to the equipment.
NOTE	Denotes items of advice related to performance of the equipment or to its correct operation.

#### Symbols used for setting and operating steps

Method Operation Step	Indicates a setting or operating procedure. Follow the numbered sequence and perform the indicated steps.			
Reference	Reference Additional information about setting and operating procedures.			
Example	Indicate practical examples for setting and operating procedures.			
	Example			
(Bold character)	Set to FFT	Indicates display items or selection items.		
<b>3</b>	( <b>I</b> Section)	Indicates sections for reference.		
	F1	Indicates operation keys.		
[ ]	[ FFT ]	Indicates function key displays.		

#### Notes on Use

In order to ensure safe operation and to obtain maximum performance from the unit, observe the cautions listed below.

#### (1) Installation environment



The unit should always be operated in a range from 5°C to 40°C and 35% to 80% RH or less. Do not use the unit in direct sunlight, dusty conditions, or in the presence of corrosive gases.

#### (2) Power supply connections



- Before connecting the unit, make sure that the power supply voltage matches the rated power supply voltage of the 8845 ( section 4.2, "Power Supply and Ground Connection".
- Before connecting the unit to a battery or other DC source, make sure that the intermediate switch is set to OFF. If the switch is ON, there is a risk of sparks.

#### (3) Protective grounding

- Be sure to connect the ground terminal to a good ground ( Section 4.2, "Power Supply and Ground Connection"). If the AC outlet is grounded, using the supplied power cord with 3-prong plug will establish the ground connection.
- Also when powering the unit from a battery or other DC source, connect the ground terminal to a good ground.

#### (4) Before powering on

- · Check that the power supply is correct for the rating of the unit. Also check that the correct fuse is fitted. ( Fection 4.2, "Power Supply and Ground Connection". (The AC fuse is integrated in the unit.)
- The power switches of this unit are separate for AC power (power switch on 8845) and DC power (intermediate switch on DC power supply cable). If DC power is being supplied and the intermediate switch is set to ON, the 8845 will operate also if the power switch is set to OFF.

#### (5) Probe Connection, Measurement Voltage Input



- Maximum input ratings for the analog units 8916 8919, 8927, and 8928 and the input terminals of the 8845 are shown below. To avoid the risk of electric shock and damage to the unit, take care not to exceed these ratings.
- The 8918 TEMPERATURE UNIT is designed specifically for thermocouples. Do not use it with any other components. (Circuit protection is provided for up to 100 V DC or AC, but any voltage above this value will destroy the unit.)
- The maximum floating voltage of 8916 to 8919, 8928 (voltage between input and 8845 frame ground, and between inputs of other analog units) is shown below. To avoid the risk of electric shock and damage to the unit, take care that voltage between channels and between a channel and ground does not exceed these ratings.
- The maximum floating voltage rating applies also if an input attenuator or similar is used.
- When measuring power line voltages with the 8916, 8917, or 8919, always connect the probe to the secondary side of the circuit breaker.
   Connection to the primary side involves the risk of electric shock and damage to the unit.
- Always use the supplied input cables (units 8916, 8917, and 8919 use the input cable 9574, and unit 8927 uses the connecting cable 9437).
   Any exposed metal sections in an input cable consist a risk of electric shock.

Input/output terminal	Maximum input rating	Maximum floating voltage	
8916 inputs 8917 inputs 8919 inputs	500 V DC+AC peak	450 V AC/DC	
8918 inputs	100 V AC/DC	250 V AC/DC	
8927 inputs	50 V DC+AC peak	No floating	
8928 inputs	10 V DC+AC peak	40 V DC+AC peak	
EXT TRIG START STOP PRINT EXT SMPL	-5 V to 10 V	No floating	
MIC	0 V to 5 V DC+AC peak	No floating	
TRIG OUT NG	-20 V to +30 V 500 mA max 200 mW max	No floating	

**⚠ WARNING** 

The logic units all have and the 8845 have a common ground.

#### (6) Replacing the fuse and input units



- Use a DC power supply fuse of the proper rating (12 A/250 V).
- In order to avoid accidents from electric shock, before removing or replacing an input unit or changing a fuse, check that the input cables are disconnected, turn off the power, and remove the power cable.
- Normally keep all eight input units installed permanently. If a unit is not fitted, it must be replaced by a blanking panel. If the unit is operated with an input unit not in place it poses a shock hazard.

#### (7) Recording paper

**⚠** CAUTION

- This unit uses a thermal printer. The recording paper supplied has
  characteristics finely tuned for use with the printer.
   Using recording paper of a different specification may not only result in
  impaired printing quality, but even prevent the printer from operating. Always
  use the HIOKI specified product.
- Insert the paper with correct orientation ( F Section 4.6, "Loading Recording Paper").

#### (8) Using a printer



Using the printer in a high-temperature or high-humidity environment should be avoided at all costs. This can seriously reduce the printer life.

#### (9) Storing



When the unit is not to be used for an extended period, set the head up/down lever to the "head up" position. This will protect the printer head and prevent deformation of the rubber roller.

#### (10) Shipping



Remove the printer paper from the unit. If the paper is left in the unit, paper support parts may be damaged due to vibrations.



- · Remove the tape from the unit.
- · If reshipping the unit, preferable use the original packing.

#### (11) Others



- · In the event of problems with operation, first refer to Section 23.5, "Trouble shooting".
- Carefully read and observe all precautions in this manual.

# **Chapter Summary**

#### Chapter 1 Product Overview

Contains an overview of the unit and its features.

#### Chapter 2 Specifications

Contains general specifications and detailed function specifications.

#### Chapter 3 Logic Input Section and Analog Input Unit

Contains specifications and precautions for logic input section and input amplifier units.

#### Chapter 4 Setup and Preparations

Explains how to set the unit up for measurement.

#### Chapter 5 Operation Steps for Basic Measurement

Explains how to operate the keys and JOG/SHUTTLE control for carrying out basic measurement functions.

#### Chapter 6 Memory Recorder Function Settings

Explains how to use the memory recorder functions of the unit.

#### **Chapter 7** Recorder Function Settings

Explains how to use the recorder functions of the unit.

#### Chapter 8 FFT Function Settings

Explains how to use the FFT analysis functions of the unit.

#### Chapter 9 Input Channel Settings

Explains how to make settings using the channel setting screen.

#### Chapter 10 Trigger Functions

Explains how to use the trigger functions of the unit.

#### Chapter 11 System Screen Settings

Explains how to make settings using the system setting screen.

#### Chapter 12 Printout of Waveform Data and Processing Data

Explains how to print out data and how to read printed charts.

#### Chapter 13 Storing Data On DDS Tape

Explains how to store data on DDS tape and how to read stored data.

#### Chapter 14 Calculating Waveform Data

Explains the waveform processing functions of the unit and how to input processing equations.

#### Chapter 15 Determining Waveform Parameters / Evaluating Parameter Values

Explains waveform parameter processing functions and waveform parameter evaluation. 14 parameters of the input waveform are determined and used for GO/NG evaluation.

#### Chapter 16 Waveform GO/NG Evaluation

Explains the waveform evaluation function which uses an evaluation area created by the user for GO/NG evaluation.

#### Chapter 17 Memory Segmentation Function

Explains the memory segmentation function which splits the internal memory into blocks for storing waveform data.

#### **Chapter 18 Waveform Averaging**

Explains the waveform averaging function which serves to remove noise components from the waveform.

#### Chapter 19 Using the A/B Cursors / Waveform Scrolling

Explains how to use the A/B cursors and how to perform waveform scrolling.

#### Chapter 20 LEVEL MON. Key, CH.SET Key, HELP Key

Explains how to use the LEVEL MON., CH.SET, and HELP keys.

#### Chapter 21 External Input/Output Connectors / Key Lock Function

Gives specifications and usage details of the external input/output connectors.

#### Chapter 22 Using the D/A Output Unit 9539 (Option)

Gives specifications and usage details of the optional D/A output unit 9539.

#### Chapter 23 Maintenance

Describes maintenance and fuse replacement procedures.

#### Chapter 24 Error and Warning Messages

Describes error and warning messages and lists reference sections in the manual.

# **Appendix** Contains a glossary of terms used in this manual and gives some basic

reference information.

# Chapter 1 Product Overview

# 1.1 Major Features

- (1) Storage capability using DDS tape
  Waveform data and parameter information can be recorded on DDS tape.
- (2) Easy to read, large color display The 9.5-inch TFT color screen with a resolution of  $640 \times 480$  dots shows all information at a glance.
- (3) Built-in thermal printer for A4-size printouts
  - · The built-in printer delivers waveform printouts on the spot.
  - · The printer can also be used to print screen shots and parameter information.
- (4) 16-channel, 14-bit high-resolution recording capability

Using the analog unit 8927 (designed specifically for the 8845, not isolated from ground), waveform recording can be performed in up to 16 channels with 14-bit resolution.

- (5) Expansion units designed for 8840 can be used
  - · The 8916 ANALOG UNIT, 8917 DC/RMS UNIT, 8918 TEMPERATURE UNIT, and 8919 FFT UNIT can be used in the 8845.
  - · Units designed for 8840 are connected in a floating configuration (isolated from ground).
- (6) Playback of recorded waveform data

The optional 9539 D/A OUTPUT UNIT allows output of recorded waveform data (2 channels) as an analog waveform with a +6.4 to -6.4 V range.

(7) Voice memo capability

Simply by connecting a microphone to the unit, the user can record a voice memo along with waveform data.

#### (8) Simple function key interface

Thanks to its GUI-inspired design using large function key graphics, the unit is easy to set up and operate.

#### (9) 3 incorporated functions

- · Memory recorder with up to 200 kS/s and 2 M word capacity (using 1 unit/1 channel); X-Y plotting also possible.
- · Continuous real-time recording capability to tape or paper in recorder function
- · FFT function with 12 analysis patterns

#### (10) Trigger function

- · Digital trigger circuit
- · 4 trigger types: level trigger, window-in trigger, window-out trigger, logic trigger

#### (11) Waveform data processing

Absolute waveform values, integral values, and differential values can be calculated, and arithmetic processing of multiple waveform data is also possible.

#### (12) Waveform parameter calculation

14 waveform values including maximum, minimum, and effective values can be determined.

#### (13) Waveform evaluation

A good/no-good decision (GO/NG) can be performed depending on whether the waveform is in a standard area or not. The standard area can be easily set up using the graphics editor.

#### (14) Scaling function

By setting the physical amount and the unit to be used for 1 V input, the measurement result can be converted into any desired scale.

#### (15) Strain gauge adapter

The measurement with a strain gauge adapter is possible by using the 8928 STRAIN UNIT.

#### (16) GP-IB interface


The optional 9537 GP-IB INTERFACE applied to IEEE-488.2 can be used. It is possible to input and output data and remotely control.

#### (17) SCSI interface

The optional 9538 SCSI INTERFACE applied to ANSI-X3.131-1986, JIS-X6051 can be used. The waveform data recorded on a DDS tape can be transferred to a personal computer with using the supplied utility software.


# 1.2 Identification of Controls and Indicators

Controls and indicators of the unit are listed on the following pages, along with a simple explanation of their function.




**Front Panel** 

① STATUS key	Causes the display to show the STATUS screen which serves for setting most measurement parameters.
② CHAN key	Causes the display to show the CHANNEL screen which serves for making input channel settings.
③ DISP key	Causes the display to show measurement and analysis results.
4 SYSTEM key	Causes the display to show the SYSTEM screen which serves for making system-wide settings such as for the scaling function (    Chapter 11).
⑤ FILE key	Causes the display to show the DAT screen which serves for making DAT recorder settings ( $\square$ Chapter 13).
6 AUTO key	Pressing this key activates automatic setting of X and Y axis range values for easy reading ( $\square$ Sections 6.3, 7.3).
7 PRINT key	Serves to print out stored waveforms ( F Chapter 12).
® COPY key	Serves to print out a hard copy of the current screen display (
9 FEED key	Causes the printer paper to advance for as long as the key is pressed (  Chapter 12).
10) Select <b>key</b>	Selects the function that is controlled by the JOG/SHUTTLE knob. With each push of the key, the functions is toggled between VALUE and WAVE A B CSR. The respective LED lights up (
① JOG key	Rotary control knob that serves to change values, move the A/B cursors, and scroll the waveform.
12) SHUTTLE <b>key</b>	Concentric ring that serves to move the flashing cursor, A/B cursors, and to scroll the waveform. The speed of movement is proportional to the rotation angle (
① CURSOR keys	These keys serve to move the flashing cursor in the four directions.
(14) START key	Initiates the measurement and analysis. During measurement, the LED above the key is lit.
15 STOP key	Stops measurement and analysis.
16 LEVEL MON. key	Serves to check the input signal level ( F Chapter 20).
⑦ CH. SET key	Serves to display and change measurement parameters for the various channels (
18 HELP key	Serves to indicate the position of the currently displayed screen information in relation to the entire recording length (
19 F1 - F5 keys	Serve to select setting items.
20 LCD screen	



Left Side View



**Right Side View** 

(21) Printer

2 AC POWER switch Serves to turn the unit on and off.

23 Protective ground terminal (GND)

24 AC connector The supplied power cord must be plugged in here.

(25) Input unit slots These slots accept various input units, such as

the 8916 ANALOG UNIT, 8917 DC/RMS UNIT,

8918 TEMPERATURE UNIT, 8919 FFT ANALOG UNIT,

8927 ANALOG UNIT, and 8928 STRAIN UNIT.

26 Analog input connector (on 8927 ANALOG UNIT) Unbalanced analog input

② Ventilation slots

28 Fastening screw Secures the plug-in unit.

② Expansion slot Accepts the optional unit.

The 9537 GP-IB INTERFACE, 9538 SCSI INTERFACE,

and 9539 D/A OUTPUT UNIT can be used.

39 Analog output connector (of the 9539 D/A OUTPUT UNIT)


③ Indicator DAT drive activity indicator, showing whether a tape is

inserted and indicating the operation status


( Chapter 13).

② DAT insertion slot The DDS tape is inserted here.

③ Tilt support Serves to tilt the unit upwards.



**Top View** 



**Bottom View** 

34 Ventilation slots 35 Handle Serves for transporting the 8845. 36 Logic probe connectors Input connector for the logic input section, designed for the dedicate logic probes (CH A, CH B, CH C, CH D) ( Chapter 3). ③ MIC (microphone) connector 38 Trigger connectors Can be used to synchronize multiple units, using the EXT TRIG input and TRIG OUT output ( Chapter 21). 39 KEY LOCK switch When this switch is set to ON, all keys of the 8845 are inactive. The key lock condition is maintained also when (40) Remote terminals Start, stop, and print operation can be controlled via external signals ( F Chapter 21). 4) NG evaluation output When the waveform evaluation based on waveform terminal parameters has resulted in NG, a signal is output from this terminal ( Chapter 21). External sampling Allows input of an external sampling signal terminal ( Chapter 21). Allows use of an external DC source to power the unit (43) DC power supply

# Chapter 2 | Specifications

# 2.1 General Specifications

#### Basic specifications

Number of units	Analog 8 units		
(maximum)	Analog 8 units 8 channels when using with only the 8916, 8917, 8918, 8919, 8928 16 channels when using with only the 8927 (The logic channels are standard equipment for the 8845, common ground with main unit)		
Memory capacity	2 M words 8916, 8917, 8918, 8919, 89	28 8927	
When 1 unit is in use	12 bits×2 M words /channel	14 bits $ imes$ 1 M words /channel	
When 2 units are in use	12 bits×1 M words /channel	14 bits $\times 500$ K words /channel	
When 4 units are in use	12 bits×500 K words /channe	l 14 bits $\times$ 200 K words /channel	
When 8 units are in use	12 bits×200 K words /channe	l 14 bits×100 K words /channel	
	one unit of the 8928 equals tw	vo units of the 8916 to 8919	
Maximum sampling speed	Memory recorder, FFT	200 kS/s (8927 is not in use) 100 kS/s (8927 is in use)	
	Recorder 80 kS/s		
Input method	Plug-in analog input units floating input 8916, 8917, 8918, 8919, 8928 no floating 8927		
Time measurement functions	Auto calendar with automatic	leap year, 24 hour clock	
Time measurement precision (maximum)	20 ppm (25℃)		
Backup battery and lifetime	Used for clock and to preserve settings, 8 years (reference value at $25^{\circ}\!$		
Operational ranges for temperature and humidity	Temperature: $5^{\circ}$ to $40^{\circ}$ Relative humidity: $35\%$ to $80\%$ RH (with no condensation)		
Temperature and humidity ranges for assured accuracy	Temperature: $23\%\pm5\%$ Relative humidity: 35% to 80% RH (with no condensation)		
Temperature and humidity ranges for storage	Temperature: $-10\%\pm50\%$ Relative humidity: 35% to 80% RH (with no condensation)		

Insulation resistance and dielectric strength	At least 100 M $\Omega/500$ VDC, one minute at 1.5 kVAC (between the frame and the AC power supply) At least 100 M $\Omega/500$ VDC, one minute at 700 VDC (between the frame and the DC power supply) At least 100 M $\Omega/500$ VDC, one minute at 2 kVAC (between the input units (excluding 8927) and the frame) At least 100 M $\Omega/500$ VDC, one minute at 2 kVAC (between the input units (excluding 8927))
Power supply	90 to 250 VAC (50/60 Hz) 10 to 30 VDC
Fuse	10 to 30 VDC class A melting fuse (NM) 12 A/250 V 6.4 dia.×31.8 mm (DC power supply)
Maximum rated power	AC: 350 VA (when printer off, 130 VA) DC: 130 VA (when printer off, 70 VA)
Dimensions	Approx. 280 (W)×306 (H)×140 (D) mm (excluding projections)
Mass	Approx. 7 kg

# Display

Screen	9.5 inch LCD display (TFT color LCD, 640×480 dots)	
Display resolution	Waveform: 20 DIV f.s. $\times$ 15 DIV f.s. Text: 60 characters $\times$ 40 characters (1 DIV= 32 dots (vertically) $\times$ 32 dots (horizontally)	
Dots spacing	$0.30~\mathrm{mm} imes0.30~\mathrm{mm}$	
Maximum display defect ratio	Always-on dots + always-off dots = max. 15	

#### Recorder

Method of recording	Thermosensitive recording method using a thermal line head	
Recording paper	Roll type thermosensitive recording paper, 216 mm $ imes$ 30 m (long)	
Width of recording	Total recording width: 212 mm±1mm (1696 dots) Waveform portion: 200 mm±1mm f.s. (1 DIV=10 mm)	
Recording speed	Approx. 25 mm/s max	
Paper feed accuracy	±1% (25℃, 60% RH)	

## External data storage

Device	DAT drive
Capacity	2 GB (90 M), 1.3 GB (60M)
Data format	DDS format
Recorded data	Waveform data (memory recorder, recorder, FFT), settings, waveform decision area

## External input /output terminals

START	Input signal	active LOW				
STOP		HIGH level	2.5 to 5.0 V	LOW level	0 to 1.0 V	
PRINT	Pulse width	HIGH level	20 ms at least	LOW level	10 ms at least	
	Maximum allow	able input	-5 to 10 V			
EXT TRIG	Input signal	active LOW				
		HIGH level	2.5 to 5.0 V	LOW level	0 to 1.0 V	
	Pulse width	LOW level	5 $\mu$ s at least			
	Maximum allow	•	-5 to 10 V			
	Input terminal	mini-jack co	nnector, 3.5 mm o	liameter		
EXT SMPL	Input signal	active LOW				
		HIGH level	2.5 to 5.0 V	LOW level	0 to 1.0 V	
	Pulse width	LOW level	1 $\mu$ s at least			
	Frequency	180 kHz ma	(90 kHz max when using the 8927)			
	Maximum allowable input		-5 to 10 V			
MIC	Maximum allow	Maximum allowable input		0 to 5.0 V DC+AC peak		
	Input terminal	mini-jack co	nnector, 3.5 mm o	or, 3.5 mm diameter		
TRIG OUT	Output signal	active LOW				
		HIGH level	4.5 to 5.0 V	LOW level	0 to 0.5 V	
	Pulse width	LOW level	$1.5\pm0.5~\mathrm{ms}$			
	Maximum allowable input		-20 to 30 V, 500 mA max, 200 mW max			
	Output terminal	terminal mini-jack connector, 3.5 mm diameter				
NG	Output signal	active LOW				
		HIGH level	4.5 to 5.0 V	LOW level	0 to 0.5 V	
	Pulse width	HIGH level	20 ms at least	LOW level	70 ms approx.	
	Maximum allowa	able input	-20 to 30 V, 500	mA max 20	0 mW max	
	Maximum anowa	abic iliput	20 00 00 1,000	mir man, 20	o min man	

# 2.2 Trigger Unit Specifications

Trigger Method	Digital comparison		
Trigger modes	Memory recorder, F functions Recorder function	FT Single, repeat, auto, auto-stop Single repeat	
Trigger source		Analog waveform to input for each channel Logic waveform to input for each channel Input signal to EXT TRIG terminal Start, stop, interval selectable on or off. When all sources are off, the unit is in	
	the free-run state.  Trigger conditions can be set for each source individually.		
Analog trigger	Uses analog input waveform (channel 1 - 16) as trigger source.  Level trigger  Trigger level is set as voltage. Triggering of when the signal passes the trigger level we selected slope (rising edge, falling edge).		
	Window-in trigger	Upper and lower trigger levels can be set. Triggering occurs when the waveform enters the defined area.	
	Window-out trigger	Upper and lower trigger levels can be set. Triggering occurs when the waveform leaves the defined area.	
Logic trigger	Uses the logic input waveform (CH A - CH D) as trigger source.  Triggering occurs when the set pattern is matched.		
Trigger source AND, OR	AND, OR logic can be used to link trigger sources.  AND Triggering occurs when all sources have been triggered.  OR Triggering occurs when one trigger source has been triggered.		
Trigger filter	Trigger width can be set by number of sampling points.  OFF, 10, 20, 50, 100, 150, 200, 250, 500, 1000		
Trigger level resolution	0.25 % f.s. (f.s. = 20 DIV)		
Pre-trigger	0, 2, 5, 10, 20, 30, 40, 50, 60, 70, 80, 90, 95, 100, -95 % (in the memory recorder function,) unsettable at external sampling		
Trigger output	Signal is output from TRIG OUT terminal when triggering occurs.		

## 2.3 Memory Recorder Function Specifications

Time axis	500 $\mu$ s/DIV (not available when 8927 is used) 1, 1.25, 2, 2.5, 5, 10, 20, 50, 100, 200, 500 ms/DIV 1, 2, 5, 10, 20 s/DIV 1, 2, 5 min/DIV
Time axis resolution	100 points/DIV (time axis magnification $\times$ 1)
Time axis precision	$\pm 0.001\%$ (relative scale vs. time error)
Sampling period	1/100 of the time axis
Recording length	25, 50, 100, 200, 500, 1000 <sup>(*1)</sup> , 2000 <sup>(*2)</sup> , 5000 <sup>(*3)</sup> , 10000 <sup>(*4)</sup> , 20000 <sup>(*5)</sup> DIV *1: when 16 channels are in use *2: when 8 channels are in use *3: when 4 channels are in use *4: when 2 channels are in use *5: when 1 channel is in use (when using the 8927, not selectable)
Display format	Single, dual, quad, oct screen display, X-Y single, X-Y dual display
Recording line display	16-color (LCD) dark, medium dark, normal, light (printer)
Interpolation function	dot (no interpolation), line (linear interpolation)
Waveform magnification/ compression	Time axis $\times 10, \times 5, \times 2, \times 1, \times 1/2, \times 1/5, \times 1/10, \times 1/20, \times 1/50, \times 1/100, \times 1/200, \times 1/500, \times 1/1000$ Voltage axis $\times 20, \times 10, \times 5, \times 2, \times 1, \times 1/2, \times 1/5, \times 1/10$
Variable display function	① Settable upper and lower limit (-9.9999E+29 to 9.9999E+29) ② 0 V (position) fixed; magnification/compression from 0.0001E-29V/DIV to 9.9999E+28V/DIV
Automatic store function	ON/OFF switchable. Automatic recording of waveform data on tape after completion of measurement.
Auto-print	ON/OFF switchable. Automatically prints the memorized waveform
Manual print	Prints by pressing the PRINT key
Partial print	Prints between the A and the B cursors
Print smoothing function	ON/OFF switchable. Doubles density along time axis for smooth printout (at lower speed).
Logging function	Numeric printout of waveform data
Memory segmentation function	Memory area of each channel can be divided into max. 63 blocks.  ① Multi-block memory (memory segmentation) ② Sequential save
Superimposition function	ON/OFF switchable
Waveform scrolling	Available in both the left/right and the up/down directions

## 2.4 Recorder Function Specifications

Time axis	$^{(*1)}1.25,2,^{(*2)}2.5,^{(*3)}5,^{(*4)}10,^{(*5)}20,50,100,200,500$ ms/DIV
	1, 2, 5, 10, 20 s/DIV
	1, 2, 5, 10, 20 s/DIV 1, 2, 5, 10, 20 min/DIV
	1 h/DIV
	*1: when 1 channel is in use
	*2: when 2 channels are in use
	*3: when 4 channels are in use *4: when 8 channels are in use
	*5: when 16 channels are in use
Time axis resolution	100 points/DIV (time axis magnification $\times$ 1)
Time axis precision	$\pm 0.001\%$ (relative scale vs. time error)
Recording time	Continuous or settable from 1 second to 366 days 23 h 59 min 59 s in 1-second intervals
Display format	Single, dual, quad, oct screen display
Recording line display	16-color (LCD)
	dark, medium dark, normal, light (printer)
Interpolation function	dot (no interpolation), line (linear interpolation) line only when measurement
Waveform magnification/ compression	Time axis $\times 10, \times 5, \times 2, \times 1, \times 1/2, \times 1/5, \times 1/10, \times 1/20, \times 1/50, \times 1/100, \times 1/200, \times 1/400, \times 1/500, \times 1/800, \times 1/1000, \times 1/2000, \times 1/10000, \times 1/10000, \times 1/100000$
	Voltage axis $\times 20$ , $\times 10$ , $\times 5$ , $\times 2$ , $\times 1$ , $\times 1/2$ , $\times 1/5$ , $\times 1/10$
Variable display function	① Settable upper and lower limit (-9.9999E+29 to 9.9999E+29) ② 0 V (position) fixed; magnification/compression from 0.0001E-29 V/DIV to 9.9999E+28 V/DIV
Data storage medium	OFF, printer, DAT
Data transferring	Transfer the recorded data in memory recorder function to memory recorder function.
Manual printing	Activated by pressing the PRINT key Printout of data in memory at completion of recording Printout of all recording data when data are read
Partial print	Prints between the A and the B cursors
Waveform scrolling	Available in both the left/right and the up/down directions
Logging function	Numeric printout of waveform data

## 2.5 FFT Function Specifications

ГГТ измене в «Міне»	
FFT range setting	133, 333, 667 mHz 2, 4, 8, 20, 40, 80, 200, 400, 800 Hz 2, 4, 8, 16, 20, 32, 40, 80* kHz (*:not available when 8927 is used)
Frequency resolution	1/400
Number of sampling points	1000 (storage waveform)
Dynamic range	72 dB (logical value for 8916, 8917, 8918, 8919, 8928) 84 dB (logical value for 8927)
Antialiasing filter	ON/OFF switchable. Automatic cutoff frequency selection linked to frequency range (for channels using 8919 FFT unit)
Window functions	Rectangular, Hanning, Exponential
FFT analysis modes	Storage waveform, linear spectrum, RMS spectrum, power spectrum, auto-correlation function, histogram, transfer function, cross-power spectrum, cross-correlation function, unit-impulse response, coherence function, octave analysis
X-axis setting	Time, frequency (linear, logarithmic), real-number voltage (Nyquist only)
Y-axis setting	Voltage (real-number, imaginary number, absolute value, logarithmic)
FFT channel mode	1 channel FFT, 2 channel FFT
Analysis channels	2 channels selectable from all analog channels
Reference data	Newly read waveform, waveform stored with memory recorder function
Display format	Single, dual screen display, Nyquist display
Recording line display	Identical fixed color for g1, g2 (display), Dark (printer)
Interpolation function	dot (no interpolation), line (linear interpolation)
Waveform magnification/ compression	Selectable upper and lower limit (only voltage values set with STATUS screen; settings made with CHANNEL screen are valid only for histogram of X-axis)
Automatic store function	ON/OFF switchable. Automatic recording of waveform data on tape after completion of measurement.
Auto-print	ON/OFF switchable. Automatically prints the memorized waveform
Manual print	Prints by pressing the PRINT key
	Numeric printout of waveform data

## 2.6 Auxiliary Functions Specifications

#### Averaging function

Memory recorder	Averaging count (OFF, 2 - 256, summing averaging up to specified count, then exponent averaging)
FFT	Averaging count (OFF, 2 - 4096) Selectable functions: summing averaging, exponent averaging (each on time axis or frequency axis), peak hold (frequency axis)

#### ■ Waveform decision function

Waveform area evaluation	Comparison to reference area Memory recorder (single, X-Y single display) FFT (single, Nyquist display)
Decision modes	Out NG (fail) if any part of the waveform goes out of the decision area.  All out NG (fail) if the waveform is entirely outside the decision area.
Stop modes	Go stop, NGstop, GO&NG stop On stop, printer output and waveform save can be selected.
Decision time	20 ms approx.
Decision period	$1.75$ s approx. (1 ch, 1 mS/DIV, 25 DIV, $\times 1$ , line display during compressed display or when the recoding length is long, this becomes slower.
Reference area editor	Graphic editor
Editor commands	Line (dotted line), Paint, Read Waveform, Erase, Parallel Move (with overwrite), Reverse, Clear (partial deletion), All Clear (screen deletion), Undo, Save
Waveform parameter evaluation (memory recorder, recorder)	Upper and lower trigger limits for waveform parameter processing can be set
Evaluation modes	Out NG when parameter leaves specified range In NG when parameter enters specified range
Evaluation output	Signal is output from NG terminal when NG occurs.

#### M Calculation processing

Waveform processing (Memory recorder)	Arithmetic calculation, absolute value, exponent, common logarithm, square root, displacement average, 1st and 2nd differential, 1st and 2nd integral, parallel displacement on time axis, trigonometric functions (sin, cos, tan), reverse trigonometric functions (asin, acos, atan)
Waveform parameter (Memory recorder, recorder)	Average value, effective value, peak-to-peak value, maximum value, time to maximum value, minimum value, time to minimum value, period, frequency, rise time, fall time, area, standard deviation, area value, XY area value,

#### Other function

(1) System screen	
Start condition backup	ON/OFF switchable. (Retains measurement status.)
Grid settings	OFF, standard, fine, standard (dark), fine (dark), standard (shaded), fine (shaded) (only OFF and standard for display)
Channel marker	ON/OFF switchable. Waveform numbered with channel number. Always used (regardless of ON/OFF setting) for logic waveforms. Not valid for FFT.
List/gauge print function	ON/OFF switchable. Together with measurement waveform, measurement settings (list) and Y-axis scale (gauge) information is printed.
LCD backlight saver function	ON/OFF switchable. Turns LCD backlight off automatically after 10 minutes of key inactivity.
Comment input function	Input and printout of comments possible.
Scaling function	ON/OFF switchable. Converts voltage values into any unit. Can be set separately for each channel.
Subsampling print function	ON/OFF switchable. Omits interpolation in envelope display.

(2) Key operation	
A4 print function	Activated by pressing FEED key and COPY key simultaneously. Displayed waveform is printed out in A4 size.
Display copy function	Activated by pressing COPY key. Produces a hard copy of display contents.
List print function	Activated by pressing PRINT key when display shows setting information. Produces a list of parameter settings.
Auto-range function	Activated by pressing AUTO key (not valid in FFT mode). Selects optimum time axis and voltage axis for input waveform.
Level monitor function	Activated by pressing LEVEL MON. key. Serves to verify voltage range position for input waveform in each channel.
Help function	Activated by pressing HELP key. Shows relative position of displayed data within entire recorded data. When voltage axis is enlarged, relative position of displayed data to full-scale point for each channel is shown (memory recorder, recorder). When memory segmentation is used, usage condition of each block is shown (memory recorder).

(3) External terminal and	switches
Remote control	Measurement start, stop, and print control via rear- panel connectors.
External sampling	Signal input to EXT SMPL connector (max. 180 kHz) can be used for sampling (limited by number of recording channels and input units).
Voice memo function	Microphone connected to MIC connector can be used to record a voice memo for any unit.
Key lock	ON/OFF switchable
(4) Oll	
(4) Others	
Comment printing	Function, channel, input range, 0 V position, trigger time, DIV and other information can be printed.
Cursor measurement function	Time, potential, temperature, frequency difference between A and B cursor can be measured.  Potential, time from trigger, frequency at A or B cursor can be measured.

## 2.7 Accessories and Options

#### Accessories

Power cord 1 Cord for DC power supply 1 Recording paper (roll) 1 Recording paper attachment 2 Instruction Manual 1 Protect cover 1 1 (DC power supply 10 to 30 V: class A melting Spare fuse fuse (NM), 12 A/250 V, 6.4 dia.  $\times$  31.8 mm) DDS tape (90M) 1 DDS cleaning tape 1

#### **Options**

8916 ANALOG UNIT
8917 DC/RMS UNIT
8918 TEMPERATURE UNIT
8919 FFT ANALOG UNIT
8927 ANALOG UNIT (2 channel/one unit)
8928 STRAIN UNIT
9537 GP-IB INTERFACE
9538 SCSI INTERFACE
9539 D/A OUTPUT UNIT (for output of data recorded with recorder function)
9606 DATA CONVERSION UTILITY


#### Optional accessories

9231 RECORDING PAPER (6 rolls)
9303 PT
9305 TRIGGER CORD
9306 LOGIC PROBE
9307 LINE LOGIC PROBE
9308 LINE DIP DETECTOR??
9369 CARRYING CASE
9370 CARRYING CASE
220H PAPER WINDER

## 2.8 System Operation

System operation is explained according to the block diagram.

- (1) All system operations are controlled by a 32-bit CPU.
- (2) The input units 8916, 8917, 8918, and 8919 incorporate high-speed 12-bit A/D converters which are connected to the main unit via a photocoupler integrated in each input unit. Each channel has its own power supply, to assure electrical isolation from the main unit.
- (3) The analog unit 8927 incorporates a 14-bit A/D converter and uses a common ground with the main unit.
- (4) The input signals for each channel are converted into digital form by the A/D converter, and the resulting data are stored in the memory by the memory control circuit.
- (5) Measurement data stored in memory are processed by the CPU and displayed on the LCD screen. The waveform displayed on the screen can be printed out.
- (6) Waveforms can be recorded on DAT and redisplayed using the D/A output unit (option).




## Chapter 3 Logic and Analog Inputs

## 3.1 Logic Inputs

- · The logic input is located on the top side of the unit. Up to four probes can be connected.
- · Since one logic probe can record 4 channels, the combined maximum recording capability for logic waveforms is 16 channels.

**⚠ WARNING** 

- The 8845 has separate inputs for four probes, but the ground lines of these inputs are not isolated from each other and from the frame ground of the unit (common ground).
- Do not connect logic probes other than supplied by HIOKI to the logic inputs.



NOTE

If no logic probe is connected, the corresponding logic waveform is displayed on the screen ad high level.

## 3.1.1 Logic Probes



Carefully read the documentation supplied with the probe.

#### **■ 9306 LOGIC PROBE**

Input can be switched between voltage input and contact input. Suitable for a wide range of applications, from checking electronic circuits to measuring relay timing.

**⚠** DANGER

The 8845 has separate inputs for four probes, but the ground lines of these inputs are not isolated from each other and from the frame ground of the unit (common ground). If voltages with different ground levels are input, probe short-circuiting may occur and lead to accidents.

#### **■ 9307 LINE LOGIC PROBE**

- · Can be used to detect the on/off status of AC line voltage. Maximum input voltage is 250 V. The probe is suitable for timing measurements of relay sequencers or similar.
- · The probe provides internal isolation between channels and between input and output.

**⚠** DANGER

The maximum floating (insulation) voltage between channels and between input and output is 250 V AC. To avoid the risk of electric shock and damage to the unit, make sure that the voltage in each channel and between input and output does not exceed this value.

#### **9308 LINE DIP DETECTOR**

- · Serves to detect momentary voltage drops in commercial power supply lines (100, 120 V AC).
- · Dip level switchable between 80% and 90%.
- · Requires 8916 ANALOG UNIT, 8917 DC/RMS UNIT or 8919 FFT UNIT.

**⚠** DANGER

The banana plug on the LOW side (black) is directly connected to the input clip (black). Take suitable precautions against the risk of electric shock.

## **3.2 8916 ANALOG UNIT**

- · The 8916 is the analog unit for the 8840 and 8845 MEMORY HiCORDER.
- · Follow carefully the advice of Section 3.2.2, "Safety Requirements."

## 3.2.1 Specifications

Accuracy at  $23^{\circ}C \pm 5^{\circ}C$ , after 1 hour warming-up time Accuracy guaranteed for six months.

Measurement ranges	5, 10, 20, 50, 100, 200, 500 mV/DIV 1, 2, 5, 10, 20 V/DIV
DC amplitude accuracy	$\pm0.25\%$ f.s.
Zero position accuracy	$\pm 0.1\%$ f.s.(after zero adjustment)
Temperature characteristic	Gain: $\pm 0.02\%$ f.s./ $^{\circ}$ C Zero position: $\pm 0.015\%$ f.s./ $^{\circ}$ C
Frequency characteristic	DC to 100 kHz, -3 dB
Noise	180 $\mu$ Vp-p (typical) maximum sensitivity range, with input shorted
Common mode rejection ratio	100 dB minimum (at 50/60 Hz and with signal source resistance 100 $\Omega$ maximum)
Low-pass filter	Cutoff frequency 5, 50, 500 Hz, 5 kHz approx. Can be turned on and off
Input type	Unbalanced (floating)
Input resistance and capacitance	1 M $\Omega$ $\pm$ 1% (at power supply off, 500 k $\Omega$ ) approx. 20 pF (at 100 kHz)
A/D resolution	12 bits
Maximum sampling speed	200 kS/s
Input terminals	2 terminals (for banana plugs)
Maximum allowable input voltage	500 V (DC+AC peak)
Maximum floating voltage	450 V AC/DC (between input unit and frame, and between input units)
Dimensions and mass	110 (W) $\times$ 20 (H) $\times$ 88 (D) mm (excluding projections), 110 g approx.
Accessories	9574 INPUT CABLE (1)

### 3.2.2 Safety Requirements




- The maximum floating voltage (voltage between 8916 input and 8845 frame, and between inputs of other analog units) is 450 V AC/DC. To avoid the risk of electric shock and damage to the unit, take care that voltage between 8916 input and 8845 frame, and between inputs of other analog units does not exceed these ratings.
- The maximum allowable input to the 8916 is 500 V (DC+AC peak). To avoid the danger of electric shock or damage to the equipment, ensure that the applied voltage never exceeds this level.



- The maximum floating voltage rating applies also if an input attenuator or similar is used.
- When measuring voltages in power lines with high current capability, always connect the probe to the secondary side of the circuit breaker, to avoid the risk of electric shock and damage to the unit.

**⚠** CAUTION

- For safety reasons, only use the 9574 INPUT CABLE provided with the unit for measurement.
- Before using the unit, <u>make sure that the sheathing on the input cables is not damaged and that no bare wire is exposed</u>. If there is damage, using the unit could cause electric shock. Replace with the specified 9574 INPUT CABLE.



## 3.3 8917 DC/RMS UNIT

- $\cdot$  The 8917 DC/RMS UNIT is the analog unit for the 8840 and 8845 MEMORY HiCORDER.
- · Records the voltage level converted into RMS values.
- · Follow carefully the advice of Section 3.3.2, Safety Requirements."

## 3.3.1 Specifications

Accuracy at  $23^{\circ}C \pm 5^{\circ}C$ , after 1 hour warming-up time Accuracy guaranteed for six months.

Measurement ranges	5, 10, 20, 50, 100, 200, 500 mV/DIV 1, 2, 5, 10, 20 V/DIV
DC amplitude accuracy	$\pm 0.3\%$ f.s.
Zero position accuracy	$\pm 0.1\%$ f.s. (after zero adjustment)
RMS accuracy	$\pm 1\%$ f.s. (DC, 40 to 1 kHz), $\pm 8\%$ f.s. (1 to 100 kHz),
Temperature characteristic	Gain: $\pm 0.02\%$ f.s./°C Zero position: $\pm 0.05\%$ f.s./°C
Frequency characteristic	DC to 100 kHz, -3dB
RMS response rate	100 ms typical (0→90%f.s.) 200 ms typical (100→10%f.s.)
Crest factor	2
Noise	250 $\mu$ Vp-p (typical) maximum sensitivity range, with input shorted
Common mode rejection ratio	100 dB minimum (at 50/60 Hz and with signal source resistance 100 $\Omega$ maximum)
Low-pass filter	Cutoff frequency 5, 500 Hz, approx. Can be turned on and off
Input type	Unbalanced (floating)
Input resistance and capacitance	1 M $\Omega$ $\pm$ 1% (at power supply off, 500 k $\Omega$ ) approx. 20 pF (at 100 kHz)
A/D resolution	12 bits
Maximum sampling speed	200 kS/s
Input terminals	2 terminals (for banana plugs)
Maximum allowable input voltage	500 V (DC+AC peak)
Maximum floating voltage	450 V AC/DC (between input unit and frame, and between input units)
Dimensions and mass	110 (W) $\times$ 20 (H) $\times$ 88 (D) mm (excluding projections), 110 g approx.
Accessories	9574 INPUT CABLE (1)

## 3.3.2 Safety Requirements




- The maximum floating voltage (voltage between 8917 input and 8845 frame, and between inputs of other analog units) is 450 V AC/DC.
   To avoid the risk of electric shock and damage to the unit, take care that voltage between 8917 input and 8845 frame, and between inputs of other analog units does not exceed these ratings.
- The maximum allowable input voltage to the 8917 is 500 V (DC+AC peak). To avoid the danger of electric shock or damage to the equipment, ensure that the applied voltage never exceeds this level.



- The maximum floating voltage rating applies also if an input attenuator or similar is used.
- When measuring voltages in power lines with high current capability, always connect the probe to the <u>secondary side of the circuit breaker</u>, to avoid the risk of electric shock and damage to the unit.

**⚠** CAUTION

- For safety reasons, only use the 9574 INPUT CABLE provided with the unit for measurement.
- Before using the unit, make sure that the sheathing on the input cables is not damaged and that no bare wire is exposed. If there is damage, using the unit could cause electric shock. Replace with the specified 9574 INPUT CABLE.



## 3.4 8918 TEMPERATURE UNIT

- The 8918 TEMPERATURE UNIT is a thermocouple unit that is used the 8840 and 8845 MEMORY HiCORDER for measuring temperature.
- · Using the 8918, temperature can be measured by any of three types of thermocouples: K, J, T.
- · Follow carefully the advice of Section 3.4.2, Safety Requirements."

## 3.4.1 Specifications

Accuracy at  $23^{\circ}C \pm 5^{\circ}C$ , after 1 hour warming-up time Accuracy guaranteed for six months.

Measurement ranges	10 (0.125), 20 (0.25), 50 (0.625) $^{\circ}\text{C/DIV}$ ( ): minimum resolution
Measurement input range	K (CA) -90 to 1200°C J (IC) -90 to 800°C T (CC) -90 to 400°C
Zero position	-110 to 110% of recording width in 1% steps (no zero adjustment)
Reference contact compensation	Automatic compensation
Accuracy	$\pm 0.25\% \mathrm{f.s.} \pm 2\%$
Temperature characteristic	±0.05%f.s./℃
Frequency characteristic	DC to 500 Hz, -3dB typical
Response time	1 ms typical (0→90%f.s.), (100→10%f.s.) Low-pass filter 5 Hz ON 100 ms typical (0→90%f.s.) 100 ms typical (100→10%f.s.) Low-pass filter 1.5 Hz ON 300 ms typical (0→90%f.s.) 300 ms typical (100→10%f.s.)
Normal mode rejection ratio	50 dB typical (at 50/60 Hz with 1.5 Hz low-pass filter ON)
Common mode rejection ratio	100 dB minimum (at 50/60 Hz and with signal source resistance 100 $\Omega$ maximum)
Low-pass filter	Cutoff frequency 1.5, 5 Hz approx. Can be turned on and off
Input resistance	5 MΩ approx.
A/D resolution	12 bits
Maximum sampling speed	50 kS/s
Input terminals	Press-screw type terminal board
Maximum allowable input voltage	100 V rms
Maximum floating voltage	250 V AC/DC (between input unit and frame, and between input units)
Dimensions and mass	110 (W) $\times$ 20 (H) $\times$ 88 (D) mm (excluding projections), 110 g approx.
Accessories	Flat blade screwdriver (1)

## 3.4.2 Safety Requirements




- The maximum floating voltage (voltage between 8918 input and 8845 frame, and between inputs of other analog units) is 250 V AC/DC. To avoid the risk of electric shock and damage to the unit, take care that voltage between 8918 input and 8845 frame, and between inputs of other analog units does not exceed these ratings.
- The maximum permitted input to the 8918 is 100 V rms. To avoid the danger of electric shock or damage to the equipment, ensure that the applied voltage never exceeds this level.



When using an non-insulated thermocouple to measure temperature in a place where voltage is present, be careful to avoid touching the terminals, since voltage may be present.



The 8918 TEMPERATURE UNIT input terminal is only for connection to a thermocouple. Never apply any input other than that from a thermocouple to this input terminal.






The 8918 input and the 8845 frame are insulated.

#### 3.4.3 Notes on Installation Site

- · Strong wind striking the input terminal can disrupt the thermal balance of the input circuit, resulting in incorrect readings. When taking measurements in windy environments, arrange the equipment to prevent wind from directly striking the input terminal.
- · Abrupt changes on ambient temperature can also disrupt the thermal balance of the input circuit. To prevent measurement error, allow the unit to adjust to the new temperature for about 30 minutes before starting measurement.



## 3.5 8919 FFT ANALOG UNIT

- $\cdot$  The 8919 FFT ANALOG UNIT is used for the 8840 and 8845 MEMORY HiCORDER.
- · The 8919 is equipped with a builed-in anti-aliasing filter to suppress aliasing.
- · The anti-aliasing filter's cutoff frequency is automatically set according to the setting of the frequency axis (or time axis) range.
- · The anti-aliasing filter can be turned on or off using the Memory recorder or FFT function.
- · Follow carefully the advice of Section 3.5.2, "Safety Requirements."

## 3.5.1 Specifications

Accuracy at  $23^{\circ} \pm 5^{\circ}$ , after 1 hour warming-up time Accuracy guaranteed for six months.

Measurement ranges	5, 10, 20, 50, 100, 200, 500 mV/DIV 1, 2, 5, 10, 20 V/DIV	
DC amplitude accuracy	$\pm 0.25\%$ f.s.	
Zero position accuracy	$\pm 0.1\%$ f.s. (after zero adjustment)	
Temperature characteristic	Gain: $\pm 0.02\%$ f.s./°C Zero position: $\pm 0.015\%$ f.s./°C	
Frequency characteristic	DC to 100 kHz, -3dB	
Noise	180 $\mu$ Vp-p (typical) maximum sensitivity range, with input shorted	
Common mode rejection ratio	100 dB minimum (at 50/60 Hz and with signal source resistance 100 $\Omega$ maximum)	
Low-pass filter	Cutoff frequency 5, 500 Hz approx., can be turned on and off Attenuation is -6 dB/OCT	
Anti-aliasing filter	Cutoff frequency (fc) of 20, 40, 80, 200, 400, 800 Hz, 2, 4, 8, 20, 40 kHz	
Input type	Unbalanced (floating)	
Input resistance and capacitance	1 M $\Omega$ ±1%, approx. 27 pF (at 100 kHz)	
A/D resolution	12 bits	
Maximum sampling speed	200 kS/s	
Input terminals	2 terminals (for banana plugs)	
Maximum allowable input voltage	500 V (DC+AC peak)	
Maximum floating voltage	450 V AC/DC (between input unit and frame, and between input units)	
Dimensions and mass	110 (W) $\times$ 20 (H) $\times$ 88 (D) mm (excluding projections), 110 g approx.	
Accessories	9574 INPUT CABLE (1)	

## 3.5.2 Safety Requirements




- The maximum floating voltage (voltage between 8919 input and 8845 frame, and between inputs of other analog units) is 450 V AC/DC.
   To avoid the risk of electric shock and damage to the unit, take care that voltage between 8919 input and 8845 frame, and between inputs of other analog units does not exceed these ratings.
- The maximum permitted input to the 8919 is 500 V (DC+AC peak).
   To avoid the danger of electric shock or damage to the equipment, ensure that the applied voltage never exceeds this level.



- The maximum floating voltage rating applies also if an input attenuator or similar is used.
- When measuring voltages in power lines with high current capability, always connect the probe to the secondary side of the circuit breaker, to avoid the risk of electric shock and damage to the unit.

**⚠** CAUTION

- For safety reasons, only use the 9574 INPUT CABLE provided with the unit for measurement.
- Before using the unit, make sure that the sheathing on the input cables is not damaged and that no bare wire is exposed. If there is damage, using the unit could cause electric shock. Replace with the specified 9574 INPUT CABLE.



## **3.6 8927 ANALOG UNIT**

- $\cdot$  The 8927 is the analog unit for the 8845 MEMORY HiCORDER. It cannot be used for the 8840 MEMORY HiCORDER.
- One unit has input facilities for 2 channels with 14- bit resolution, allowing detailed waveform recording.
- · Follow carefully the advice of Section 3.6.2, "Safety Requirements."

## 3.6.1 Specifications

Accuracy at  $23^{\circ}C \pm 5^{\circ}C$ , after 1 hour warming-up time Accuracy guaranteed for six months.

Measurement ranges	20, 50, 100, 200, 500 mV/DIV 1 V/DIV	
DC amplitude accuracy	$\pm 0.25\%$ f.s.	
Zero position accuracy	$\pm 0.2\%$ f.s.(after zero adjustment)	
Temperature characteristic	Gain: $\pm 0.02\%$ f.s./°C Zero position: $\pm 0.025\%$ f.s./°C	
Frequency characteristic	DC to 50 kHz, -3dB	
Noise	375 $\mu$ Vp-p typical, 625 $\mu$ Vp-p maximum (sensitivity range, with input shorted)	
Crosstalk between channels	-56 dB max. (same range, 50/60 Hz at full-span voltage input)	
Low-pass filter	Cutoff frequency 5, 50, 500 Hz, 5 kHz approx. Can be turned on and off	
Input type	Unbalanced (one side grounded; input ground connected directly to unit ground)	
Input resistance and capacitance	1 M $\Omega$ $\pm$ 1% (at power supply off, 700 k $\Omega$ ) approx. 20 pF (at 50 kHz)	
A/D resolution	14 bits	
Maximum sampling speed	100 kS/s	
Input terminals	BNC connector	
Maximum allowable input voltage	50 V (DC+AC peak)	
Dimensions and mass	110 (W) $\times$ 20 (H) $\times$ 88 (D) mm (excluding projections), 125 g approx.	
Accessories	9437 CONNECTION CABLE (between BNC and clip, cable contains fuses $\times 2$ Spare fuse F0.5 A/250 V rating (spark killer) $\times 2$	


### 3.6.2 Safety Requirements



- The input ground lines of the analog units 8927 are not isolated against each other and against the frame ground of the 8845. In particular, input GND and frame GND are connected directly. Therefore it is essential to connect the protective ground terminal of the 8845 to a good ground.
   Otherwise, a potential may exist between the input of the 8927 ANALOG UNIT and exposed metal parts of the 8845.
- Never use the 8927 ANALOG UNIT for power line measurements, to avoid the risk of electric shock and damage to the unit.
- The maximum allowable voltage for the 8927 is 50 V (DC + AC peak).
   Make sure that this rating is not exceeded, to avoid the risk of electric shock and damage to the unit.

**⚠** CAUTION

For safety reasons, only use the 9437 CONNECTION CABLE provided with the unit for measurement.



## **3.7 8928 STRAIN UNIT**

- The 8928 STRAIN UNIT is an option for the 8840 and 8845 MEMORY HiCORDERs.
- · This unit for measurement with a strain gauge adapter.
- · Follow carefully the advice of Section 3.7.2, "Safety Requirements."

## 3.7.1 Specifications

Accuracy at  $23^{\circ}C \pm 5^{\circ}C$ , after 1 hour warming-up time Accuracy guaranteed for six months.


Measurement ranges	20, 50, 100, 200, 500, 1000 $\mu$ $\epsilon$ /DIV	
DC amplitude accuracy	$\pm$ (0.5% f.s. + 2 $\mu$ $\epsilon$ ) (after auto-balancing)	
Zero position accuracy	$\pm 0.5\% \mathrm{f.s.}$ (after auto-balancing)	
Temperature characteristic	Gain: $\pm 0.05\%$ f.s./°C max (after auto-balancing) Zero position: $\pm 2\mu$ $\varepsilon$ /°C max (20, 50 $\mu$ $\varepsilon$ /DIV ranges), $\pm 0.1\%$ f.s./°C max (100, 200, 500, 1000 $\mu$ $\varepsilon$ /DIV)	
Frequency characteristic	DC to 16 kHz $^{+1}_{-3}$ dB	
Appropriate adapter	Strain gauge adapter Bridge resistance: 120 $\Omega$ to 1 k $\Omega$	
Gauge ratio	2.00 (fixed)	
Bridge voltage	3±0.05 V	
Balancing	Electronic auto-balancing	
Balance adjustment range	$\pm 10000\mu$ $\varepsilon$ max	
Low-pass filter	Cutoff frequency OFF, 10 Hz, 30 Hz, 300 Hz, 3 kHz $\pm 30\%$	
Number of input channels	2	
A/D resolution	12 bits	
Maximum sampling speed	200 kS/s	
Input terminals	TAJIMI PRC03-23A10-7F	
Maximum allowable input voltage	10 V (DC+AC peak)	
Maximum floating voltage	40V (DC+ACpeak)	
Dimensions and mass	$110(W) \times 40(H) \times 88(D)$ mm (not including projection), 245 g approx.	
Standards applying	Safety: Pollution Degree 2 Overvoltage Category I (anticipated transient overvoltage 330 V)	

## 3.7.2 Safety Requirements




- The maximum floating voltage is 40 V (DC+ACpeak). To avoid the risk of electric shock and damage to the unit, take care that voltage between 8928 input and 8840, 8845 frames, and between inputs of other analog units does not exceed these ratings.
- The maximum permitted input (between BD terminals) to the 8928 is 10
   V (DC+ACpeak).

To avoid the damage to the equipment, ensure that the applied voltage never exceeds this level.



### 3.7.3 Strain Unit Settings

- The upper input on the unit is the lower-numbered channel, and the lower input is the higher-numbered channel.
- · When the unit is inserted in the slot shown, the channel assignments are as in the figure below.




## 3.8 Replacement Procedure

- This section describes how to replace the input units; 8916, 8917, 8918, 8919, 8927, and 8928.
- · The following procedure describes how to remove the input unit.
- · Install the units by reversing the procedure for removal.



- To avoid the danger of electric shock, never operate the unit with an input unit removed. If you should wish to use the unit after removing an input unit, fit a blank panel over the opening of the removed unit.
- To prevent electrical shock, before adding or replacing the input unit, check that the power for the unit is off and the power cord and input cables are disconnected. The fixing screws must be firmly tightened or the input unit may not function up to specification, or may even fail.
- 1. Remove the input cables and thermocouples from all input units.
- 2. Power off the 8845 main unit, and disconnect the power cord.
- 3. Remove the two or four fixing screws with a Phillips screwdriver, as shown in the figure below.
- 4. Grasp the handle on 8916 8919, 8928 units or the BNC connector on 8927 unit and pull the unit out, as shown in the illustration.



## 3.9 Input Cables

#### **9574 INPUT CABLE (8916, 8917, 8919)**


- · Only use the special-purpose 9574 INPUT CABLE for connection to the 8916 ANALOG UNIT, 8917 DC/RMS UNIT, and 8919 FFT ANALOG UNIT.
- · A plastic cover on the unit connector serves as protection against electric shock.

Operating temperature and humidity range	0 to 40℃, 80%RH max (with no condensation)
Dimensions	Approx. 1.7 m
Mass	Approx. 100 g




#### **9437 CONNECTION CABLE**

Operating temperature and humidity range	5 to 40℃, 20 to 80%RH max (with no condensation)
Dimensions	Approx. 1.7 m
Mass	Approx. 90 g
Fuse	Fast-blow, high-insulation type fuse (0.5 A/250 V) with spark killer 5.2 mm dia $\times$ 20 mm



To remove the fuse





## 3.10 Measurement Errors Caused by Signal Source Internal Resistance

If the signal source impedance is higher than the input impedance of the unit, a measurement error will occur.

Example


The input impedance of the 8916 ANALOG UNIT is 1 M $\Omega$ . If the signal source impedance is 1 k $\Omega$ , an error of about 0.1% will occur.

Measurement errors=Es 
$$\left(1 - \frac{R \text{in}}{R \text{s} + R \text{in}}\right)$$
 [V]

Es:Signal voltage

Rs: Signal source resistance

Rin: Input resistance





# Chapter 4 Installation and Preparation

## 4.1 Installation of the Unit


#### Installation orientation

Install the unit on a flat, level surface.





The unit can also be propped up at an angle, using the stand.



#### Ambient conditions

Temperature 5 to  $40^{\circ}$ C,  $23\pm5^{\circ}$ C recommended for high-precision

measurements


Humidity 35 - 80% RH (no condensation);  $50 \pm 10\%$  RH (no

condensation) recommended for high-precision measurements

Ventilation Take care not to block the ventilation openings and assure

proper ventilation. When using the unit in an upright

position, take care not to block the openings on the bottom.



NOTE

Avoid the following locations:

- · Subject to direct sunlight
- · Subject to high levels of dust, steam, or corrosive gases
- · Subject to vibrations
- · In the vicinity of equipment generating strong electromagnetic fields



## 4.2 Power Supply and Ground Connection

**⚠ WARNING** 

Take care never to exceed the power supply ratings given below, to avoid the risk of electric shock and damage to the unit.

#### • Power supply, fuse

Rated power supply voltage 90 - 250 V AC

10 - 30 V DC

Rated AC power supply frequency 50/60 Hz

Fuses AC incorporated in power supply


(not user- replaceable)

DC class A melting fuse (NM) 12 A/250 V,

 $6.4 ext{ dia.} imes 31.8 ext{ mm}$ 

#### Grounding

- · To ensure safety during operation, always ground the unit.
- · Connect the GND terminal on the side of the unit to a good ground.



#### Check the following points before connecting the unit to a power supply:

- · The power supply matches the ratings shown above.
- The AC power switch of the 8845 and the intermediate switch in the DC cable are set to OFF.
- · The ground connection is established.
- · Use only the supplied AC power cord or DC power supply cable.


#### Connecting the unit to a power supply:

(1) AC power supply

**⚠ WARNING** 

Make sure that the AC power switch of the 8845 is set to OFF.

- 1. Verify that the AC power switch of the 8845 is set to OFF.
- 2. Plug the supplied AC power cord into the AC power connector on the side of the 8845.
- 3. Plug the power cord into an AC outlet corresponding to the rating of the 8845.



#### (2) DC power supply




Before connecting the unit to a battery or other DC source, make sure that the intermediate switch is set to OFF. If the switch is ON, there is a risk of sparks.



- When connecting the DC cable, take care not to mix up the red (+) and black (-) leads. If polarity is reversed, the 8845 may be damaged.
- When wishing to extend DC cable, use a cable of identical or better rating as the supplied cable.

- 1. Verify that the intermediate switch in the DC cable is set to OFF.
- 2. Align the ridge of the connector on the unit with the groove in the plug and insert the plug fully.
- 3. Connect the red alligator clip to the positive side (+) and the black alligator clip to the negative side (-) of the power supply.
- 4. To remove the plug of the DC cable, rotate it as shown in the illustration.



#### • Estimated battery operation hours (at room temperature)

Battery type: 12 V, 38 Ah, fully charged

8845: channels 8927 installed in channels 1 - 16, GP-IB not installed

Operation condition	Running time
Printer not used (trigger waiting)	Approx. 5 h 30 min
Printer used Recorder function 500 ms/DIV, all store	Approx. 3 h 30 min

- · Actual running time may differ, depending on battery age, charge condition, ambient temperature, and other factors.
- · Running time is approximately proportional to battery capacity. Increasing battery voltage to 24 V will extend running time by a factor of about 1.5 for identical capacity.

NOTE

- · This unit is not equipped to charge an external battery.
- · When using a battery, take care not to deplete it completely.


### 4.3 Power On/Off

#### (1) Check before power-on

- · Unit is correctly installed ( F Section 4.1).
- Power cord is correctly connected and unit is properly grounded ( Section 4.2).


#### (2) Power switch on/off

- · There is no need for the user to manually select AC or DC power.
- · When both AC and DC power are connected, AC power has priority.
- · When AC power is disconnected (or falls under 90 V), the 8845 automatically switches to DC (if both the AC power switch of the 8845 and the intermediate switch of the DC cable are set to ON).
- · If a DC power source is connected and the intermediate switch of the DC cable is set to ON, the 8845 will be operative even if the AC power switch on the unit is set to OFF.



#### (3) To assure high measurement precision

Turn the unit on and let it warm up for about one hour, to allow internal temperature to fully stabilize. Then carry out zero adjustment and start the measurement.



#### (4) Power-off

When the unit is turned off, it memorizes the currently used settings and reestablishes the same settings the next time the unit is turned on again.


## 4.4 Probe and Thermocouple Connection

#### Logic probe connection



The 8845 has separate inputs for four probes, but the ground lines of these inputs are not isolated from each other and from the frame ground of the unit (common ground).

If voltages with different ground levels are input, probe short-circuiting may occur and lead to accidents.




Connect the probe by aligning the groove on the plug with the ridge on the connector.

#### Connection cable ( @ Section 3.8)



Never connect the probe to the 8845 while the probe is already connected to the measurement object. Otherwise there is a risk of electric shock.

#### (1) 9574 INPUT CABLE (8916, 8917, 8919)



Connect the cable so that H and L of the cable match H (red) and L (black) on the unit.


#### (2) 9437 CONNECTION CABLE (8927)



- Use only the specified type of fuse. ( @ Section 3.9, "Input Cables")
- The input ground line is directly connected to the frame ground of the unit. Be sure to connect the reference connector of the probe (black) and the ground pin of the input BNC connector to the ground potential of the measurement object.
- Before measurement, connect the protective ground terminal of the 8845 to a good ground.
- Never use the cable for a power line connection.

**⚠** CAUTION

When disconnecting a BNC connector, be sure to release the lock first, then hold the connector and pull carefully. Using force to pull the connector without releasing the lock, or pulling on the cable instead of the connector may damage the connector.



- 1. The 9437 CONNECTION CABLE is equipped with a protective fuse. Before starting the measurement, verify that the fuse has not blown.
- 2. Match the grooves on the plug with the ridges on the connector when inserting the plug.

NOTE

Before using the 8927 ANALOG UNIT to measure, be sure to read the following notes.


- · With some measurement objects (equipment), a noise current may flow in the ground line, leading to a degradation of S/N ratio. This is especially apparent at high sensitivity range settings.
- · Do not connect any unnecessary input cables. For minimum noise, the use of BNC-BNC cables is recommended.


#### Thermocouple connection (8918)



When an uninsulated thermocouple is used to measure temperature at a point carrying electric potential, take care not to touch the terminals and connector screws. Otherwise there is a risk of electric shock.

1. Strip off the insulation as shown in the illustration.





- 2. Loosen the connector screws on the unit with a flat blade screwdriver.
- 3. Connect the thermocouple + and leads to the H (+) and L (-) connectors on the unit, taking care to observe correct polarity.
- 4. Tighten the screws.




- · Do not use thermocouples other than the specified types (K, J, T).
- · If the thermocouple is connected in reverse, the temperature reading will not be correct.

# 4.5 Connection to a Strain Gauge Adapter

This section describes connection to a strain gauge adapter.

- 1. Align the projecting portion of the connector on the main unit with the cutout portion of the connector, and plug it in. (Hold the portion colored in the illustration.)
- 2. When removing the connector, hold the connector (the portion colored in the illustration), and pull it toward you and out.




# 4.6 Connecting the Voltage Transformer


Explains how to connect the 8916, 8917, 8919, or 8927 and PT (voltage transformer)

#### 8916, 8917, 8919

① When the voltage transformer has a ground terminal



2 When the voltage transformer has no ground terminal




NOTE


- · The 8916, 8917, 8919 input and the 8845 frame are insulated.
- · When making measurements on as AC power line for example, using a voltage transformer, be sure to connect the transformer input to the secondary side of the breaker.
- · Be sure to connect the protective ground terminal to ground.

#### 8927

① When the voltage transformer has a ground terminal (9303)




② When the voltage transformer has no ground terminal




NOTE

- · The 8927 input and the 8845 have a common ground.
- · When making measurements on as AC power line for example, using a voltage transformer, be sure to connect the transformer input to the secondary side of the breaker.
- · Be sure to connect the protective ground terminal to ground.
- · When using the cable supplied with the 9303, use a commercially available BNC-to-banana-plug adapter.


# 4.7 Loading Recoding Paper




1. Press the stock cover and open it.



2. Raise the had up/down lever.




3. Insert the attachments into the ends of the roll of recording paper and set the paper into its holder.



4. Insert the leading edge of the recording paper from above into the gap behind the printer roller, and pull it out to the other side.

#### NOTE

Do not insert it into the gap between the roller and the black sheet metal portion.




5. Pull the end of the recording paper out at least 10 cm, and make sure that it is positioned quite straight.

#### NOTE

Do this very carefully, because if the recording paper is slanted with respect to the roller there is a danger that later a paper jam will occur.

- 6. Put down the head up/down lever.
- 7. Pull the recording paper to the outside through the printer exit slot in the stock cover.



8. Close the stock cover, and finish by tearing off the recording paper against the edge of the printer exit slot. **⚠** CAUTION

Before shipping, remove the printer paper from the unit. If the paper is left in the unit, paper support parts may be damaged due to vibrations.

NOTE

- · Always put the unit in the head up condition when it is to be transported or if it is to be stored for a long period of time. If the unit is left to lie in the state where the roller is being subjected to pressure by the head, then the roller may become deformed or the characters may become uneven.
- · Particularly care should be taken not to put the recording paper in back to front by mistake, because if this happens the waveform cannot be drawn.


# 4.8 Storage and Handling Precautions

- · While unopened, thermal paper will not be affected by the environment, provided that ambient temperature and humidity do not exceed normal levels. For long-term storage, temperature should be lower than 40. Low temperatures cause no problem.
- · After opening, protect the paper from strong light, to prevent discoloration.

#### Storing recordings

The recording paper uses a thermochemical reaction. Note the following points:

- · To avoid discoloration, do not leave recording paper in direct sunlight.
- · Store at not more than  $40^{\circ}$ C and 90% RH.
- · To keep definitive data, make photocopies of the recordings.
- · Thermal paper will blacken when brought into contact with alcohol, ester, ketone, or other volatile organic substances.
- · If the thermal paper absorbs an organic solvent such as alcohols or ketones it may no longer develop properly, and recorded information may fade. Soft PVC film and transparent contact adhesive tape contain such solvents, so avoid using them with recordings.
- · Avoid interleaving the thermal recordings with damp diazo copies.



#### 4.9 Notes on Measurement

# **⚠** DANGER

- Maximum input ratings for the analog units 8916 8919, 8927, and 8928 and the input terminals of the 8845 are shown below. To avoid the risk of electric shock and damage to the unit, take care not to exceed these ratings.
- The 8918 TEMPERATURE UNIT is designed specifically for thermocouples. Do not use it with any other components. (Circuit protection is provided for up to 100 V DC or AC, but any voltage above this value will destroy the unit.)
- The maximum floating voltage of 8916 to 8919, 8928 (voltage between input and 8845 frame ground, and between inputs of other analog units) is shown below. To avoid the risk of electric shock and damage to the unit, take care that voltage between channels and between a channel and ground does not exceed these ratings.

Input/output terminal	Maximum allowable input rating	Maximum floating voltage			
8916 inputs 8917 inputs 8919 inputs	500 V DC+AC peak	- 450 V AC/DC			
8918 inputs	100 V AC/DC	250 V AC/DC			
8927 inputs	50 V DC+AC peak	No floating			
8928 inputs	10 V DC+AC peak	40 V DC + AC peak			
EXT TRIG START STOP PRINT EXT SMPL	-5 V to 10 V	No floating			
MIC	0 V to 5 V DC+AC peak	No floating			
TRIG OUT NG	-20 V to +30 V 500 mA max 200 mW max	No floating			

**⚠** WARNING


The logic units all have and the 8845 have a common ground.

# Chapter 5 Basic Operation and Measurement

# 5.1 Basic Operation

This section explains basic steps and settings for measurement.

## 5.1.1 Basic Display Operation



STATUS key Calls up the STATUS screen.

Serves to switch pages.

Serves to make main settings for various functions.

CHAN key Calls up the CHANNEL screen.

Serves to switch pages.

Serves to set voltage range, position, etc. for input channels.

DISP key Calls up the display screen.

Serves to display and observe waveforms.

SYSTEM key Calls up the SYSTEM screen.

Serves to switch pages.


Serves to make common settings for all functions (clock

setting, comment input, etc.).

FILE key Calls up the DAT screen.

Serves to display, store, read, and delete files.

# 5.1.2 JOG/SHUTTLE Control and Select Key



#### Entering numbers and setting items

Function key display Meaning

: Item up, value up

: Item down, value down

Function key display Meaning

: Value up, large step

: Value up, small step

: Value down, small step

: Value down, large step

Function key display

Meaning

: Value up, 10-units

: Value up, 1-units

: Value down, 1-units

10 +

: Value down, 10-units

Function key display

Meaning



: Channel number up

CH ↔

: Channel number down

Function key display

Meaning



: Function number up

© z•

: Function number down

#### Scroll waveform, move A/B cursors


JOG/SHUTTLE control can be used to scroll the waveform and to move the A and B cursors (  $\square$  Chapter 19).

#### Switch between numeric input and waveform scroll/cursor movement

Use the select key when the screen is in measurement display mode.

LED	JOG/SHUTTLE control function			
VALUE	Numeric input of values			
WAVE·A.B CSR	Waveform scrolling, movement of A/B cursors			

# 5.1.3 Setting Items



CURSOR keys

Serve to move the flashing cursor.


F1 to F5

Select items.

(Function key)

The respective items are shown in the function key display.

# 5.1.4 Measurement Start and End



#### Start measurement

Press the START key and the LED lights.

#### Stop measurement


Press the STOP key.

# 5.2 Basic Measurement and Setting Procedures

This section uses some representative examples to describe basic measurement steps and settings.

# 5.2.1 Measuring and Recording a Voltage (Memory Recorder, Recorder)


**Example** Monitor and record a power supply voltage, as shown in the illustration.




#### Measuring voltage with memory recorder function

The following measurement is carried out:

- · Monitor input waveform on one screen.
- · Print waveform or record on tape after measurement is completed.



Only steps which require changing from factory default condition are described.




#### Step 1 Setup and measurement preparations ( @ Chapter 4)

- · Install the 8845 in a proper location.
- · Install analog units 8927 in the CH1 and CH2 slots.
- · Connect the power cord and turn the unit on.
- · Use the connecting cable to connect the input connectors to the measurement object.

#### Step 2 CHANNEL screen settings (page 1) ( @ Chapter 9)

- · Press the CHAN key to call up the CHANNEL screen (page 1).
- · Press the CH. SET key to select the screen for CH1 CH8 or CH9 CH16.




- ① Set function to **MEMORY** (Memory recorder).
- 1. Move the flashing cursor to the function item.
- 2. Press Fl [MEMORY].
- ② Set CH1 to analog input.

  Move the flashing cursor to the graph for CH1 and press F1 [ ANALOG ].
- 3 Set CH1 waveform to be shown on display with color 1 (printout: dark).
- 1. Move the flashing cursor to the **color** item.
- 2. Press F2 [ # 1 (dark) ]. (Set CH2 to OFF.)
- Select suitable voltage range for input.
  - · Since input voltage in this example is 10 Vp-p, select 1V/DIV.
  - · Automatic setting by pressing the AUTO key is also possible ( Section 6.3.3).
- 1. Move the flashing cursor to the range item.
- 2. Use the JOG control or the function keys F1 [+] and F2 [-] to select the 1V/DIV range.

#### Step 3 STATUS screen settings (page 1) ( @ Chapter 6)

Press the STATUS key to call up the STATUS screen (page 1).



- 1) Set function to MEMORY (Memory recorder).
- 1. Move the flashing cursor to the function item.
- 2. Press Fl [ MEMORY ].
- 2 Set time axis range.
  - Since the frequency in this example is 60 Hz, one cycle is 1/60 = 16.67 ms.


To observe two cycles on the display (15 DIV), the time axis should be  $16.67~\mathrm{ms}\times2/15~\mathrm{DIV}=2.22~\mathrm{ms/DIV}.$ 

Therefore the setting 2.5 ms/DIV should be selected.

- · If the frequency is unknown, search for a suitable range, starting with high sampling frequencies.
- · Automatic setting by pressing the AUTO key is also possible ( Section 6.3.3).
- 1. Move the flashing cursor to the time/div item.
- 2. Use the JOG control or the function keys F1 [+] and F2 [-] to select the **2.5ms/DIV** range.
- 3 Set recording length (recording time)
  - · Recording time = time axis range (s/DIV)  $\times$  recording length (DIV)
  - · If recording length is to be 25 DIV, the recording time is  $2.5 \text{ ms/DIV} \times 25 \text{ DIV} = 62.5 \text{ ms}.$
- 1. Move the flashing cursor to the **shot** item.
- 2. Use the JOG control or the function keys F1 [+] and F2 [-] to select **25DIV**.


#### Step 4 Trigger settings ( @ Chapter 10)

Press the STATUS key to call up the STATUS screen (page 2).



- ① Set the trigger mode.
  - · Determine whether triggering is to be used continuously.
  - · Four trigger types are available: SINGLE, REPEAT, AUTO, and AUTO STOP.
  - For continuous trigger-activated waveform sampling and recording, choose **REPEAT**.
  - · For automatic setup, choose **AUTO**.
- 1. Move the flashing cursor to the **trig mode** item.
- 2. Press F2 [ REPEAT ].
- ② Select input waveform of CH 1 as trigger source.
  - · Waveform data recording starts when the input waveform crosses the 0 V level from below (rising edge).
  - · When the AUTO | key was used, the setting becomes **LEVEL**.
- 1. Move the flashing cursor to the CH 1 position.
- 2. Press F2 [ LEVEL ].
- 3. Use the JOG control or function keys F1 F4 to set the voltage level to **0V**.
- 4. Select F1 [UP] for slope.


#### Step 5 Measurement start



Press the START key. The LED above the key lights up and measurement starts.

#### Step 6 Measurement end


Since trigger mode is set to **REPEAT**, measurement continues until the STOP key is pressed. Press the STOP key to terminate the measurement.




#### Step 7 Recording waveform data


The most recently acquired waveform data can be printed out or stored on tape.

#### (1) Printing the waveform




#### (2) Storing waveform data on DAT






- ① Press the DAT key to call up the DAT screen.
- ② Press function key F1 [ File list ] and then F3 [ SAVE ].



③ Since waveform data are to be stored, select F1 [ WAVE ].




- 4 Press F2 [enter name] and input the file name ( r Section 11.6.1).
- ⑤ Press F1 [ exec ].


#### Measuring voltage with recorder function

The following measurement is carried out:

- · Monitor input waveform on one screen.
- · Record waveform on tape for one hour.



Only steps which require changing from factory default condition are described.




#### Step 1 Setup and measurement preparations ( @ Chapter 4)

- · Install the 8845 in a proper location.
- · Install 8927 ANALOG UNIT in the CH1 and CH2 slots.
- · Connect the power cord and turn the unit on.
- · Use the connecting cable to connect the input connectors to the measurement object.

#### Step 2 CHANNEL screen settings (page 1) ( @ Chapter 9)

- · Press the CHAN key to call up the CHANNEL screen (page 1).
- · Press the CH. SET key to select the screen for CH1 CH8 or CH9 CH16.




- ① Set function to **RECORDER** (Recorder).
- 1. Move the flashing cursor to the function item.
- 2. Press | F2 | [ RECORDER ]. (Set CH2 to OFF.)
- ② Set CH1 to analotg input.

  Move the flashing cursor to the graph for CH1 and press F1 [ ANALOG ].
- 3 Set CH1 waveform to be shown on display with color 1 (printout: dark).
- 1. Move the flashing cursor to the **color** item.
- 2. Press F2 [ # 1 (dark) ].
- Select suitable voltage range for input.
  - · Since input voltage in this example is 10 Vp-p, select 1V/DIV.
  - · Automatic setting by pressing the  $\boxed{\text{AUTO}}$  key is also possible (  $\square$  Section 7.3.3).
- 1. Move the flashing cursor to the range item.
- 2. Use the JOG control or the function keys F1 [+] and F2 [-] to select the 1V/DIV range.

#### Step 3 STATUS screen settings (page 1) ( @ Chapter 7)

Press the STATUS key to call up the STATUS screen (page 1).



- 1) Set function to RECORDER.
- 1. Move the flashing cursor to the function item.
- 2. Press F2 [ RECORDER ].
- 2 Set time axis range.

Since the frequency in this example is 60 Hz, one cycle is 1/60 = 16.67 ms.

The setting **20 ms/DIV** should be selected.


- 1. Move the flashing cursor to the time/div item.
- 2. Use the JOG control or the function keys F1 [+] and F2 [-] to select the **20ms/DIV** range.
- 3 Set recording time

Set recording time to 1 hour.

- 1. Move the flashing cursor to the recording time item.
- 2. Use the JOG control or function keys F1 F4 to set the recording time to 1h.
- 4 Choose recording medium.
- 1. Move the flashing cursor to the **recording medium** item and select | F2 | [ DAT ].

#### Step 4 Trigger settings ( @ Chapter 10)

Press the STATUS key to call up the STATUS screen (page 2).



- ① Set the trigger mode.
  - · Determine whether triggering is to be used continuously.
  - · Four trigger types are available: SINGLE, REPEAT.
  - · For stop recording after 1 hour, choose SINGLE.
  - · For automatic setup, choose **SINGLE**.
- 1. Move the flashing cursor to the **trig mode** item.
- 2. Press F1 [SINGLE].
- ② Select input waveform of CH 1 as trigger source.
  - · Waveform data recording starts when the input waveform crosses the 0 V level from below (rising edge).
  - · When the AUTO key was used, the setting becomes LEVEL.
- 1. Move the flashing cursor to the CH 1 position.
- 2. Press F2 [ LEVEL ].
- 3. Use the JOG control or function keys | F1 | | F4 | to set the voltage level to **0V**.
- 4. Select | F1 | [UP] for **slope**.

#### Step 5 Measurement start

Press the START key. The LED above the key lights up and measurement starts.

#### Step 6 Measurement end


After recording the waveform data for 1 hour, the measurement is terminated.

# 5.2.2 Frequency Analysis of Measured Voltage (FFT)


**Example** Monitor and record a power supply voltage, as shown in the illustration in Section 5.2.1, and analyze the frequency content of the measured voltage, using FFT (Fast Fourier Transform).

The following measurement is carried out:

- · Analyze the linear spectrum.
- · Display the analysis result on one screen.
- · Print out the waveform or record data on tape after measurement is completed.



Only steps which require changing from factory default condition are described.




#### Step 1 Setup and measurement preparations ( @ Chapter 4)

- · Install the 8845 in a proper location.
- · Install 8927 ANALOG UNIT in the CH1 and CH2 slots.
- · Connect the power cord and turn the unit on.
- · Use the connecting cable to connect the input connectors to the measurement object.

#### Step 2 CHANNEL screen settings (page 1) ( @ Chapter 9)

- · Press the CHAN key to call up the CHANNEL screen (page 1).
- · Press the CH. SET key to select the screen for CH1 CH8 or CH9 CH16.




- 1 Set function to FFT.
- 1. Move the flashing cursor to the function item.
- 2. Press | F3 | [FFT].
- ② Set CH1 to analog input.

  Move the flashing cursor to the graph for CH1 and press F1 [ ANALOG ].
- ③ Select suitable voltage range for input.
  Since input voltage in this example is 10 Vp-p, select 1V/DIV.
- 1. Move the flashing cursor to the range item.
- 2. Use the JOG control or the function keys F1 [+] and F2 [-] to select the 1V/DIV range.

#### Step 3 STATUS screen settings (page 1) ( @ Chapter 8)

Press the STATUS key to call up the STATUS screen (page 1).



- 1) Set function to FFT.
- 1. Move the flashing cursor to the function item.
- 2. Press F3 [FFT].
- ② Set the frequency range.


Since frequencies up to 8 kHz are to be observed, set the range to 8kHz.

- 1. Move the flashing cursor to the max. frequency item.
- 2. Use the JOG control or the function keys F1 [+] and F2 [-] to select 8kHz.
- 3 Set the analysis mode.
  - · 12 different analysis settings are available.
  - · Select the linear spectrum in this example.
- 1. Move the flashing cursor to the **mode** item of g1.
- 2. Select F2 [LIN].
- 4 Set the analysis channel.
- 1. Move the flashing cursor to the w1 item.
- 2. Use the JOG control or the function keys F1 [+] and F2 [-] to select CH1.
- ⑤ Set the Y-axis (vertical axis).
  - · The setting differs, depending on the analysis mode.
  - · In this example, the magnitude of the frequency components is to be observed. The setting therefore should be linear amplitude.
- 1. Move the flashing cursor to the **y-axis** item.
- 2. Select | F3 | [LIN-MAG] (linear amplitude).

- 6 Set the X-axis (horizontal axis).
  - · The setting differs, depending on the analysis mode.
  - · In this example, the frequency is to be observed on a logarithmic scale. The setting therefore should be logarithmic frequency.
- 1. Move the flashing cursor to the **x-axis** item.
- 2. Select F2 [LOG-Hz] (logarithmic frequency).


#### Step 4 Trigger settings ( @ Chapter 10)

Press the STATUS key to call up the STATUS screen (page 2).



- ① Set the trigger mode.
  - · Determine whether triggering is to be used continuously.
  - · Four trigger types are available: SINGLE, REPEAT, AUTO, and AUTO STOP.
  - For continuous trigger-activated waveform sampling and recording, choose **REPEAT**.
  - · For automatic setup, choose **AUTO**.
- 1. Move the flashing cursor to the **trig mode** item.
- 2. Press F2 [ REPEAT ].
- ② Select input waveform of channel 1 (ch1) as trigger source.
  - · Waveform data recording starts when the input waveform crosses the 0 V level from below (rising edge).
  - · When the AUTO | key was used, the setting becomes LEVEL.
- 1. Move the flashing cursor to the **ch1** position.
- 2. Press F2 [ LEVEL ].
- 3. Use the JOG control or function keys F1 F4 to set the voltage level to **0V**.
- 4. Select F1 [UP] for slope.


#### Step 5 Measurement start



Press the START key. The LED above the key lights up and measurement starts.

#### Step 6 Measurement end


Since trigger mode is set to REPEAT, measurement continues until the STOP key is pressed. Press the STOP key to terminate the measurement.




#### Step 7 Recording waveform data


The most recently acquired waveform data can be printed out or stored on tape.

#### (1) Printing the waveform




#### (2) Storing waveform data on DAT






- ① Press the DAT key to call up the DAT screen.
- ② Press function key F1 [ File list ] and then F3 [ SAVE ].



③ Since waveform data are to be stored, select F1 [WAVE].



- 4 Press F2 [enter name] and input the file name ( r Section 11.6.1).
- ⑤ Press F1 [ exec ].



# Chapter 6 Memory Recorder Function

#### 6.1 Outline

- (1) After being stored in the internal memory, input signal data can be displayed and printed.
- (2) All input channel data are recorded on the same time axis.

  Since data for all channels can be superimposed, the relative relationship between input signals can be observed visually.
- (3) Time axis setting Up to 20 steps: 500  $\mu$  s/DIV (8927 not installed), 1 ms/DIV 5 min/DIV.
- (4) Time axis resolution 100 points/DIV
- (5) Storage capacity
  - 2 M words (8916 8919 one unit or 8928 one channel: 20,000 DIV; 8927 one unit: 10,000 DIV)
- (6) Waveform magnification/compression display and print
  - · Time axis direction:  $\times 10$  to  $\times 1/1000$
  - · Voltage axis direction: user-variable display range
- (7) Voltage axis resolution 320 dots/DIV (8927), 80 dots/DIV (8916 8919, 8928) (magnification factor  $\times$ 1)
- (8) Display format
  - · Time axis waveform: single, dual, quad, oct screen display
  - · X-Y waveform: X-Y single, X-Y dual display
- (9) Printing

Normal print, A4 print, partial print, screen hard copy. Multiple printing possible.

- (10) High-quality print
  - Smooth print function approximates analog waveform.
- (11) Logging function

Numeric printout of waveform data

#### (12) Pretrigger function

Allows monitoring of signal also before triggering.

#### (13) Memory segmentation function

Helps to reduce dead time. Up to 63 waveforms corresponding to 25 DIV can be stored per channel.

- (14) Waveform evaluation function detects abnormal waveforms
- (15) Processing functions


Waveform processing (arithmetic processing, differential processing etc.)
Waveform parameter processing (frequency measurement, rms measurement etc.)


# 6.2 Making Settings


### 6.2.1 Setting the Function Mode

- The 8845 has three function modes: the memory recorder function mode, the recorder function mode, and the FFT function mode
- · Select the memory recorder function.

Method Screen: STATUS (page 1), CHANNEL(page1), DISPLAY







- 1. Move the flashing cursor to the position shown in the figure on the left.
- 2. Press F1 [ MEMORY ].

Function key display

Meaning



: Memory recorder function



Recorder function




FFT function


## 6.2.2 Setting the Time Axis Range

- · Set the speed for inputting and storing the waveform of the input signal.
- · Time axis range setting expresses the time for 1 DIV.
- $\cdot$  The sampling period is 1/100th of the set value for the time axis range. (100 samples/DIV)


Method Screen: STATUS (page 1), DISPLAY



- 1. Move the flashing cursor to the time/div item.
- 2. Use the JOG control or the function keys to make the selection.








- · When analog unit 8927 is used, 500  $\,\mu$  s/DIV cannot be selected.
- · Sampling rate is shown below time axis range.
- · When time axis range is changed during measurement, measurement starts again with the new setting.
- · When using the external sampling,: F Section 21.5


# 6.2.3 Setting the Recording Length


The length of recording for one measurement operation (number of DIV) can be set.

#### Method Screen: STATUS (page 1), DISPLAY



- 1. Move the flashing cursor to the **shot** item.
- 2. Use the JOG control or the function keys to make the selection.





#### NOTE

- · Depending on the number and types of units, the recording length is limited as shown in the table below.
- · When recording length is changed during measurement, measurement starts again with the new setting.

#### Number of Units and Maximum Recording Length

Number of units	1		2		4		8	
	1ch	2ch	1ch	2ch	1ch	2ch	1ch	2ch
Maximum recording length DIV	20000	100	000	50	00	20	00	1000

1ch: Only 8916 - 8919, 8928 can be used.


2ch: 8916 - 8919, 8927, 8928 can coexist, or 8927 can be used exclusively. (For the 8928, one channel corresponds to one unit.)

# 6.2.4 Setting the Format

- · The style can be set for showing input signal waveforms on the screen display and recording them on the printer.
- The styles single, dual, quad, oct, X-Y single, and X-Y dual are available. (For X-Y single and X-Y dual: IF Section 6.2.5, "Using the X-Y Waveform Plots")


#### (1) Single

Display and record as one graph. (At the most, 16 analog signals and 14 analog + 16 logic signals)




#### (2) Dual

- · Display and record as two graphs. (On each graph, at most, 16 analog signals and 14 analog + 16 logic signals)
- · Specify which input channel to use for waveform graph display and recording.




#### (3) Quad

- · Display and record as four graphs. (On each graph, at most, 16 analog signals and 14 analog + 8 logic signals)
- · Specify which input channel to use for waveform graph display and recording.




#### (4) Oct


- · Display and record as eight graphs. (On each graph, at most, 16 analog signals and 14 analog + 4 logic signals)
- · Specify which input channel to use for waveform graph display and recording.





#### Method Screen: STATUS (page 1)




- 1. Move the flashing cursor to the format item.
- 2. Use the function keys to select the display format.









- ① Press the CHAN key to call up the CHANNEL screen.
- ② Move the flashing cursor to the point shown in the illustration at left.
  - The illustration shows the setting for CH1.
  - · Settings for CH2 CH16 should be made in the same way.
- ③ Use the function keys to select the graph.







\*1: displays when the quad or oct screen display is selected

\*2: displays when the oct screen display is selected


# 6.2.5 Using the X-Y Waveform Plots

- · Setting the display format to X-Y single or X-Y dual allows up to four X-Y waveforms to be combined.
- · Assign any analog channel to the X axis and Y axis to form the combined plot.
- · Voltage axis magnification/compression is active also when using X-Y combined plotting.
- · Using the A/B cursors, it is possible to specify the data between the cursors for partial plotting.

#### (1) X-Y single screen


- · Display and recording is carried out using only one X-Y graph.
- The X-Y waveforms of graph 1 graph 4 are shown on one screen.

  Input waveform




#### (2) X-Y dual screen

- · Display and recording is carried out using only two X-Y graphs.
- The X-Y waveforms of graph 1 graph 4 use superimposition of graph 1 and 3 and graph 2 and 4, respectively.




#### Method

#### (1) STATUS screen settings



- 1. Move the flashing cursor to the format item.
- 2. Use the function key to call up page 2/2.
- 3. Select F1 [X-Y single] or F2 [X-Y dual] using the function keys.

#### (2) CHANNEL screen settings



1. Press the CHAN key to call up the CHANNEL screen.

If X-Y single or X-Y dual was selected with the STATUS screen, the graph items are shown, as follows.

Graph 1: x1 and y1 combined plot Graph 2: x2 and y2 combined plot


Graph 3: x3 and y3 combined plot

Graph 4: x4 and y4 combined plot

2. Move the flashing cursor to the point shown in the illustration and use the function keys to specify display OFF and waveform color.

OFF, color 1 - color 16

3. Set the X-axis channel.



- 4. Set the Y-axis channel in the same way as the X-axis channel.
- 5. Make the same setting for graphs 2 4.

#### Reference


The graph setting can also be carried out with the CH. SET key while the screen is in measurement display mode ( Section 20.3).

#### Partial X-Y plot

Using the A/B cursors, it is possible to specify a range for partial X-Y plotting. (Normal X-Y plotting covers all data of the recording length.)

#### Method


- 1. Display the captured waveform data, using a format other than X-Y single or X-Y dual.
- 2. Use the A/B cursors to specify the desired portion for plotting ( F Section 19.2).
- 3. Press the STATUS key to call up the STATUS screen.
- 4. Carry out combined plotting as described above.




Specified portion for X-Y plotting

# 6.2.6 Setting the Interpolation Function

This setting determines whether the input waveform (sampling data) is to be displayed and printed as a series of dots or a line using linear interpolation.




Line Display (with interpolation)



Dot Display

Method Screen: STATUS (page 1)



- 1. Move the flashing cursor to the **dot-line** item.
- 2. Use the function keys to make the selection.

# Function key display

# DOT

#### Meaning


- Linear interpolation is not performed.

  The sampled data is displayed just as it comes.
- Linear interpolation is performed. The display is easier on the eye. High speed display is available when compression is being performed.

## 6.2.7 Setting the Roll Mode


- · This mode can be used at a time axis range setting of 20 ms/DIV or slower.
- · In normal recording, the waveform is displayed only after all data of the recording length have been captured. At low sampling speed settings, this will cause a considerable delay between the start of measurement and the appearance of the waveform on the display.
- · When local mode is set to ON, the waveform is displayed immediately at the start of recording (the screen scrolls).

#### Method Screen: STATUS (page 1)



Time axis magnification	Logging interval
×10 ×5 ×2 ×1 ×1/2 ×1/5 ×1/10 ×1/20 ×1/50 ×1/200 ×1/500 ×1/1000	100 100 100 100 50 100 50 5 5 5 1


- 1. Move the flashing cursor to the **roll mode** item.
- 2. Use the function keys to make the selection.




- · When the roll mode function is ON, the superimposition function and averaging function can not be used.
- · Local mode is not available when an external sampling signal is used.
- · When the roll mode function is on and then the numerical output is carried out with normal print (auto), the maximum output interval for the time axis magnification is as shown in the left table. It is not possible to print more than these output intervals.

# 6.2.8 Superimpose


- · Overlay is performed without clearing the currently displayed waveform (if trigger mode is REPEAT, AUTO, or AUTO STOP).
- · This allows comparison to the immediately preceding waveform.



Method Screen: STATUS (page 1)



- 1. Move the flashing cursor to the **superimpose** item.
- 2. Use the function keys to make the selection.



Meaning

: Not perform superimpose


: Perform superimpose




- · If trigger mode is **SINGLE**, measurement terminates after one set of data has been collected. Therefore the overlay setting is invalid.
- · While the overlay function is being used, waveform scrolling and waveform evaluation cannot be carried out.
- · When normal printing ( Section 19.2.1) is carried out, only the last waveform will be printed.
- · If one of the following settings is changed, the overlay waveform display terminates and only the last waveform is shown:
  - ① Screen zoom ratio (along time axis or voltage axis)
  - 2 Display format
  - 3 Waveform interpolation
  - Waveform display or store channel
  - ⑤ X axis or Y axis during X-Y display
- · When the START key is pressed again during recording, all overlaid waveforms are erased (including the last waveform).

# 6.2.9 Other Settings (STATUS Screen)


For details, refer to the following sections.




Status Screen (page 1)



Status Screen (page 2)



Status Screen (page 3)




Status Screen (page 4)

# 6.3 Settings on the Display Screen and Auto Settings


Explains the setting items on the Display screen and the auto-setting of the voltage axis and time axis.

# 6.3.1 Setting Magnification/Compression Along the Time Axis


- · The magnification/compression ratio along the time axis can be set.
- · By magnifying the waveform, detailed observations can be made. By compressing the waveform, an entire change can be promptly apprehended.



#### Method Screen: DISPLAY



- 1. Move the flashing cursor to the position shown in the figure on the left.
- 2. Use the JOG control or the function keys to select the magnification/compression ratio.




NOTE

- · The magnification/compression factor can be changed also after measurement is completed.
- · To display the long recording length with compressed when the interpolation function is set to dot, it takes about maximum 80 seconds.

Reference

The HELP key can be used to check which position within the entire recording length is occupied by the currently shown waveform ( Section 20.4).

# 6.3.2 Making Channel Settings




CH. SET key:

Serves to make channel settings in measurement display mode.

# 6.3.3 Automatic Setting of Time Axis and Voltage Axis (Auto Range Function)

This function automatically selects the time axis range (TIME/DIV), voltage axis range (V/DIV) and zero position.

Method 1. Press the AUTO key.



2. Use the function keys to make the selection.

Function key display Meaning

Auto Range : Auto range (only display)

Enable auto range function

: Disable auto range function

3. Press F2 [ exec ]. The automatic range setting is made and measurement starts.

When the auto range function is used to start the measurement, the following items are changed.

#### (1) Channel settings

· Range and position Automatically set

· Low-pass filter OFF (all channels)

· Input coupling ..... DC

#### (2) Trigger parameters

· Trigger source AND/OR OR

· Internal trigger Only channel with lowest number of all

> active display channels is set to ON, other channels are OFF (if difference between maximum and minimum value is large).

· Trigger type Level trigger: trigger level automatically set

20%

(only 1 channel)

· Trigger mode Auto

· Trigger filter OFF

· Pretrigger · External trigger, timer trigger OFF

#### (3) STATUS settings


- · Time axis range (TIME/DIV) ····· Automatically set
- · Time axis magnification/compression, voltage axis magnification  $\sim$  ×1
- · Memory segmentation · · · · OFF

NOTE

- · The time axis range is set using the channel with lowest number of all active display channels. (The setting is made so that out of 25 DIV units, a cycle of 1 - 2.5 is recorded.)
- · If the channel for which the time axis range has been set is at the maximum sensitivity range (8916, 8917, 8919: 5 mV/DIV, 8918: 10°C/DIV, 8927: 20 mV/DIV, 8928: 20  $\mu$   $\varepsilon$ ) and the difference between the maximum and minimum input signal level is 1 DIV or less, the next higher channel is used for time axis range setting.
- · If range setting cannot be performed for all active channels, the measurement is terminated with a warning message.
- · When the WAVE·A.B CSR LED is lit on the DISPLAY screen, the AUTO | key is invalid.


# 6.4 Start and Stop Measurement Operation

#### Method




#### Trigger mode and measurement operation

- (1) When trigger mode is SINGLE
  - · After START key has been pressed, data recording starts when trigger conditions are met.
  - · When data corresponding to recording length have been stored in memory, measurement stops also without pressing the STOP key.




- (2) When trigger mode is REPEAT
  - · After START key has been pressed, data recording starts when trigger conditions are met.
  - · Each time when trigger conditions are met, data are recorded and memory contents are overwritten.
  - · When STOP key is pressed, measurement stops after data corresponding to recording length have been stored in memory.




#### (3) When trigger mode is AUTO

- · When START key is pressed, unit waits for about 1 second for trigger conditions to be met. After this interval, data recording starts, regardless of trigger state.
- · Data are recorded repeatedly and memory contents are overwritten.
- · When STOP key is pressed, measurement stops after data corresponding to recording length have been stored in memory.




#### (4) When trigger mode is AUTO STOP

- · When START key was pressed and trigger conditions are met, data recording starts and continues until data corresponding to recording length have been stored in memory.
- · Unit waits for about 1 second. If trigger conditions are not met, data recording starts and continues until data corresponding to recording length have been stored in memory. This process is repeated until trigger conditions are met.
- · When STOP key is pressed in trigger standby condition, measurement stops after data corresponding to recording length have been stored in memory.



#### Stopping measurement



- ① Press STOP key once to terminate measurement after recording length data are stored.
- ② Press STOP key twice to terminate measurement immediately.

#### (1) Pressing STOP key once

- · When STOP key is pressed once, data recording continues until data corresponding to recording length have been stored in memory. (LED above START key is lit.)
- · If START key is pressed after STOP key was pressed once and before waveform data recording is completed, the measurement is restarted.

#### (2) Pressing STOP key twice

- · When STOP key is pressed twice, waveform recording is stopped immediately.
- · If trigger mode is **SINGLE**, or if recording length is maximum length, the waveform is not displayed.
- · If trigger mode is **REPEAT**, **AUTO**, or **AUTO STOP** and if recording length is below maximum length, the previously stored waveform is displayed.
- · If time axis range is 20 ms/DIV or slower, the waveform up to the current point is displayed.

# Chapter 7 Recorder Function

#### 7.1 Outline

- (1) Real-time recording of input signal data on tape or printer paper
- (2) All input channel data are recorded on the same time axis.

  Since data for all channels can be superimposed, the relative relationship between input signals can be observed visually.
- (3) Time axis setting
  Up to 21 steps: 1.25 ms//DIV 1 h/DIV.
- (4) Time axis resolution 100 points/DIV
- (5) Waveform magnification/compression display and printout
  - · Time axis direction:  $\times 10$  to  $\times 1/1000$
  - $\cdot$  Voltage axis direction: variable display range up to 10  $\,\mu$  V/DIV 100 V/DIV, 10  $\,\mu$  V steps
- (6) Voltage axis resolution 320 dots/DIV (8927), 80 dots/DIV (8916 8919, 8928) (magnification factor  $\times$ 1)
- (7) Display format


  Time axis waveform: single, dual, quad, octo screen display
- (8) High-quality print
  Smooth print function approximates analog waveform.
- (9) Logging functionNumeric printout of waveform data
- (10) Waveform parameter processing (frequency measurement, rms measurement etc.)
- (11) Voice memo function using a microphone (using a DDS tape)
- (12) Recorded waveform data can be transferred to memory recorder function


# 7.2 Making Settings


# 7.2.1 Setting the Function Mode

- The 8845 has three function modes: the memory recorder function mode, the recorder function mode, and the FFT function mode
- · Select the recorder function.

Method Screen: STATUS (page 1), CHANNEL(page1), DISPLAY







- 1. Move the flashing cursor to the position shown in the figure on the left.
- 2. Press F2 [ RECORDER ].

Function key display

Meaning



Memory recorder function



: Recorder function




: FFT function


# 7.2.2 Setting the Time Axis Range


- · Set the speed for inputting and storing the waveform of the input signal.
- · Time axis range setting expresses the time for 1 DIV.
- · The sampling period is 1/100th of the set value for the time axis range.

Method Screen: STATUS (page 1), DISPLAY



- 1. Move the flashing cursor to the time/div item.
- 2. Use the JOG control or the function keys to make the selection.





NOTE

· Time axis range settings depend on the number and type of installed units.

#### Time Axis Range and Number of Units

Number of units		1	2	2	4	1	8	
Number of units	1ch	2ch*	1ch	2ch	1ch	2ch	1ch	2ch
Upper time axis range limit ms/DIV	1.25	2.	.5	Ę	5	1	0	20

1ch: (1 channel) Only 8916 - 8919, 8928 can be used.

2ch: (2 channels) 8916 - 8919, 8927, 8928 can coexist, or 8927 can be used exclusively.

(For the 8928, one channel corresponds to one unit.)

- \* When using only one 8927 unit, range selection up to 1.25 mV/DIV is possible, but only 1 channel can be used.
- · When using external sampling for the recorder, data dropouts may occur at sampling frequencies above 80 kHz.
- · When time axis range is changed during measurement, measurement starts again with the new setting.
- The magnification ratio of the screen display using external sampling depend on the number of installed units.

#### Magnification Ratio and Number of Units (at external sampling)

Number of units			2	2	4	1	8		
Number of units	1ch	2ch	1ch	2ch	1ch	2ch	1ch	2ch	
Magnification ratio (maximum value)	1/800	1/4	100	1/2	200	1/1	00	1/50	

1ch: Only 8916 - 8919, 8928 can be used.


2ch: 8916 - 8919, 8927, 8928 can coexist, or 8927 can be used exclusively.

(For the 8928, one channel corresponds to one unit.)


# 7.2.3 Setting the Magnification Along the Time Axis


- · The magnification ratio along the time axis can be set and changed.
- · By magnifying the waveform, detailed observations can be made. By compressing the waveform, an entire change can be promptly apprehended.

Method Screen: STATUS (page 1), DISPLAY



- 1. Move the flashing cursor to the time/div zoom item.
- 2. Use the JOG control or the function keys to set the the magnification ratio.






# NOTE

- · Compression of a waveform takes longer than magnification. The higher the compression factor, the more time will be required until the display appears.
- · The magnification ratio during measurement depend on the time axis


For higher-resolution time axis compression


By choosing a different ratio setting, you can increase the detail resolution of time axis compression.

#### Method Screen: STATUS (page 1), DISPLAY



- 1. Move the flashing cursor to the position shown in the figure on the left.
- 2. Use the JOG control or the function keys to change the time for one division.





NOTE

The setting values are shown in the table below.

#### Time axis (TIME/DIV) and compression ratio (reciprocal for magnification ratio)

time axis	time axis display																				
(TIME/DIV)	1.25 ms	2 ms	2.5 ms	5 ms	10 ms	20 ms	50 ms	100 ms	200 ms	500 ms	1 s	2 s	5 s	10 s	20 s	1 min	2 min	5 min	10 min	20 min	1 h
1.25 ms	1	_	2	4	8	16	40	80	160	400	800	1.6k	4k	8k	16k	48k	96k	240k	480k	960k	2880k
2 ms	_	1		-	5	10	25	. 50	100	250	500	1k	2.5k	5k	10k	30k	60k	150k	300k	600k	1800k
2.5 ms			1	2	4	8	20	40	80	200	400	800	2k	4k	8k	24k	48k	120k	240k	480k	1440k
5 ms	_			1	2	4	10	20	40	100	200	400	1k	2k	4k	12k	24k	60k	120k	240k	720k
10 ms	_	_	_	_	1	2	5	10	20	50	100	200	500	1k	2k	6k	12k	30k	60k	120k	360k
20 ms			_		_	1		5	10	25	50	100	250	500	1k	3k	6k	15k	30k	60k	180k
50 ms	_		_	_	_		1	2	4	10	20	40	100	200	400	1.2k	2.4k	6k	12k	24k	72k
100 ms	-	_	_	-	_	_	_	1	2	5	10	20	50	100	200	600	1.2k	3k	6k	12k	36k
200 ms	_	_		_		_	_	_	1	_	5	10	25	50	100	300	600	1.5k	3k	6k	18k
500 ms	_	1	-	_	-	_	_	_		1	2	4	10	20	40	120	240	600	1.2k	2.4k	7.2k
1 s				_							1	2	5	10	20	60	120	300	600	1.2k	3.6k
2 s			_		_	_	_	_		_	_	1		5	10	30	60	150	300	600	1.8k
5 s	_	_			_	_	_	_	_	_	_	-	1	2	4	12	24	60	120	240	720
10 s	_	_	_	_	_	_		_	_		_	_	_	1	2	6	12	30	60	120	360
20 s	_	_	_	_	_	-	_	1		-		_	_	ı	1	3	6	15	30	60	180
1 min	-	_	_	_	_	_			_	_	-		_	_	_	1	2	5	10	20	60
2 min	_	_	_		_		_				_				_		1		5	10	30
5 min	_		_			_	_	_		_					_		_	1	2	4	12
10 min	_	_	_		_	_	_	_									_	_	1	2	6
20 min	_	_	_	_	_	_		_		-	_		_	_	_	_				1	3
1 h	_	_			_	_					_	_	_	_						_	1

-: cannot be set

Time axis settings depend on the number of installed units.

#### Time Axis Range and Number of Units

Number of units	1	2	4	8	16
Magnification ratio	to 960 k	to 480 k	to 280 k	to 120 k	to 60 k


#### Reference

The HELP key can be used to check which position within the entire recording length is occupied by the currently shown waveform ( Section 20.4).


# 7.2.4 Setting the Recording Time

This setting determines for how long the input signal will be recorded.

Method Screen: STATUS (page 1), DISPLAY



- 1. Move the flashing cursor to the **recording time** item.
- 2. Use the JOG control or the function keys to select the recording time.
- · When time setting is enabled



· When continuous recording is enabled

Meaning

Function key

display

the new setting.

· When recording length is changed during measurement, measurement starts again with

Switch to time setting


· Data immediately preceding the recording stop operation are stored in internal memory. For the length of the stored data, see NOTE in Section 7.2.7," Setting the Recording Medium".

# 7.2.5 Setting the Format

- · The style can be set for showing input signal waveforms on the screen display and recording them on the printer.
- · The styles single, dual, quad, and oct are available.


#### (1) Single

Display and record as one graph. (At the most, 16 analog signals and 14 analog + 16 logic signals)




#### (2) Dual

- · Display and record as two graphs. (On each graph, at most, 16 analog signals and 14 analog + 16 logic signals)
- · Specify which input channel to use for waveform graph display and recording.




#### (3) Quad

- · Display and record as four graphs. (On each graph, at most, 16 analog signals and 14 analog + 16 logic signals)
- · Specify which input channel to use for waveform graph display and recording.





#### (4) Oct

- · Display and record as eight graphs. (On each graph, at most, 16 analog signals and 14 analog + 16 logic signals)
- · Specify which input channel to use for waveform graph display and recording.



#### Method Screen: STATUS (page 1)





- \*1: displays when the quad or oct screen is selected
- \*2: displays when the oct screen is selected

- 1. Move the flashing cursor to the format item.
- 2. Use the function keys to select the format.

Function key display Meaning

: Single (one division only)

: Dual (divided into two)

: Quad (divided into four)

: Oct (print only divided into eight)

- 3. If dual, quad, or octo screen display was chosen in step 2, determine which input channel to display on which graph. This setting is made with the CHANNEL screen.
- ① Press the CHAN key to call up the CHANNEL screen.
- ② Move the flashing cursor to the point shown in the illustration at left.
- · The illustration shows the setting for CH1.
- · Settings for CH2 CH16 should be made in the same way.
- · Use the function keys to select the graph.
- Function key display Meaning

  GRAPH1: Graph 1

  GRAPH2: Graph 2

  GRAPH3: Graph 3 (\*1)

  GRAPH4: Graph 4 (\*1)

  GRAPH4: Switch to page 2/2

• 2/2
Function key display Meaning

GRAPH5: Graph 5 (\*2)

GRAPH6: Graph 6 (\*2)


GRAPH7: Graph 7 (\*2)


GRAPH8: Graph 8 (\*2)

GRAPH8: Switch to page 1/2


# 7.2.6 Setting the Interpolation Function

Set the input waveform (sampling data) to display or print as dot or linear interpolation.






Method Screen: STATUS (page 1)



- 1. Move the flashing cursor to the **dot-line** item.
- 2. Use the function keys to make the selection.




When carrying out real-time printing (waveform is printed as it is being captured

(  $\square$  Section 12.9.3), the display is a line also when **DOT** is selected.


### 7.2.7 Setting the Recording Medium

This setting determines whether the measurement data are printed out in real time, recorded on tape, or not recorded (recorded in the internal memory).

Method Screen: STATUS (page 1), DISPLAY



- 1. Move the flashing cursor to the **recording medium** item.
- 2. Use the function keys to make the selection.



Also when **recording medium** is OFF, data immediately preceding the recording stop operation are stored in internal memory. The length of the stored data is determined by the following equations  $(1 \ M = 10^6)$ .

- Only 8916 8919, 8928 can be used Recording time (s) =  $\frac{\text{Time axis range(s/DIV)} \times 1.8 \text{ M}}{\text{Number of units} \times 100}$
- 8927 one unit can be used


  Recording time (s) =  $\frac{\text{Time axis range(s/DIV)} \times 1.8 \text{ M}}{\text{Number of channels} \times 100}$
- 8916 8919, 8927, and 8928 can coexist, or 8927 can be used exclusively Recording time (s) =  $\frac{\text{Time axis range(s/DIV)} \times 1.8 \text{ M}}{\text{Number of units} \times 200}$

(For the 8928, one channel corresponds to one unit.)

## 7.2.8 Recording a Voice Memo

- · When **DAT** is selected as a recording medium, a voice memo can be recorded along with the waveform data.
- During playback, the voice memo is reproduced along with the monitored output ( Section 13.6.2).

Method Screen: STATUS (page 1)




- 1. Set the items time/div and recording medium on the STATUS screen (page 1) as follows.
- time/div
   Choose a setting between 1.25 ms/DIV and 10 ms/DIV
- · recording medium DAT



When time axis sampling is set to a slow setting such as 20 ms/DIV or more, the voice memo will become garbled.

- 2. Move the flashing cursor to the **mic** item.
- 3. Use the JOG control or the function keys to make the setting.



NOTE

When the microphone is used, one channel will become unavailable. (On the CHANNEL screen, **mic** is displayed.

4. Connect the microphone to the MIC jack.

NOTE

For information on microphone types and connection: 

Section 21.7.

5. Press the START key to start the measurement. When trigger has occurred and the waveform is being recorded, voice memo recording is possible.

Speak into the microphone from a distance of about 10 to 20 cm, to prevent distortion.

# 7.2.9 Transferring Data to the Memory Recorder Function

The waveform data stored in recorder function can be transferred to memory recorder function.

#### Data which can be transferred


- · Waveform data stored in memory immediately before stopping recording operation.
- · Waveform data recorded on a DDS tape. (REC file)

#### Data length transferred


The waveform of the following data length is transferred from the left end of the display screen.

Data length transferred (s) = time axis (s/DIV) when recording  $\times$  recording length in memory recorder function which is set before transferring.

**Method** Screen: DISPLAY (recorder) → STATUS, DISPLAY (memory recorder) → STATUS (recorder)




- 1. Record the data in recorder function, or load the waveform data from a DDS tape.
- 2. Scroll the waveform on the display screen and specify the start position (left end of the screen) to transfer data.




3. Set the item **shot** on the STATUS screen (page 1) or display screen in memory recorder function.

(F Section 6.2.3)



4. Move the flashing cursor to the **change to MEMORY function** item on the STATUS screen in recorder function (page 3), and press the F1 [exec] key.




5. The data is transferred and the waveform is displayed on the display screen in memory recorder function.

# NOTE


- · If the recording length in memory recorder function is set to maximum recording length, the data can not be transferred. ( Section 6.2.3)
- The waveform data which is measured by using the 8927 unit, with 1.25 or 2ms/DIV time axis range cannot be transferred.
- · When measuring with time axis range (10, 20 min, or 1h/DIV) in recorder function only, the waveform data can be transferred.

# 7.2.10 Other Settings


For details, refer to the following sections.



Status Screen (page 1)



Status Screen (page 2)




Status Screen (page 3)

## 7.3 Settings on the Display Screen and Auto Settings

Explains the setting items on the Display screen and the auto-setting of the voltage axis and time axis.

## 7.3.1 Making Channel Settings

While the screen is in measurement display mode, the CH. SET key can be used to make settings for the various channels ( Section 20.3).



CH. SET key:


Serves to make channel settings in measurement display mode.

## 7.3.2 Automatic Setting of Time Axis and Voltage Axis (Auto Range Function)

This function automatically selects the time axis range (TIME/DIV), voltage axis range (V/DIV) and zero position.

Method

1. Press the AUTO key.



2. Use the function keys to make the selection.

Function key display Meaning

Auto Range : Auto range (only display)

: Enable auto range function

( cancel : Disable auto range function

3. Press F2 [exec]. The automatic range setting is made and measurement starts.

When the auto range function is used to start the measurement, the following items are changed.

(1) Channel settings

· Range and position ——— Automatically set

· Low-pass filter · · · · · OFF (all channels)

· Input coupling ----- DC

(2) Trigger parameters

· Trigger source AND/OR ········ OR

· Internal trigger — Only channel with lowest number of all active display channels is set to ON, other channels are OFF (if difference between maximum and minimum value is large).

· Trigger type ———— Level trigger: trigger level automatically set (only 1 channel)

· Trigger mode ———Auto

· Trigger filter · · · · OFF

· External trigger, timer trigger OFF

#### (3) STATUS settings

· Time axis range (TIME/DIV) · · · · · Automatically set


· Time axis magnification/compression, voltage axis magnification  $\times 1$ 

NOTE

- The time axis range is set using the channel with lowest number of all active display channels. (The setting is made so that out of 25 DIV units, a cycle of 1 2.5 is recorded.)
- · If the channel for which the time axis range has been set is at the maximum sensitivity range (8916, 8917, 8919: 5 mV/DIV, 8918: 10°C/DIV, 8927: 20 mV/DIV, 8928: 20  $\mu$   $\epsilon$ ) and the difference between the maximum and minimum input signal level is 1 DIV or less, the next higher channel is used for time axis range setting.
- · If range setting cannot be performed for all active channels, the measurement is terminated with a warning message.


## 7.4 Start and Stop Measurement Operation

#### Method




#### Recording length, trigger mode and measurement operation

- (1) When time setting is enabled:
- ① Trigger mode: SINGLE
  - · After START key has been pressed, data recording starts when trigger conditions are met.
  - · When data corresponding to recording length have been stored in memory, measurement stops also without pressing the STOP key.




#### 2 Trigger mode: REPEAT


- · After START key has been pressed, data recording starts when trigger conditions are met.
- · Each time when trigger conditions are met, data are recorded and memory contents are overwritten.
- · When STOP key is pressed, measurement stops after data corresponding to recording length have been stored in memory.



- (2) When continuous recording is enabled
- 1 Trigger mode: SINGLE or REPEAT
  - · After START key has been pressed, data recording starts when trigger conditions are met.
  - · When STOP key is pressed, measurement stops.



#### Stopping measurement



- ① To terminate measurement after recording length data are stored:

  Press STOP key once.
- ② To terminate measurement immediately: Press STOP key twice.
- (1) Pressing STOP key once
  - · When STOP key is pressed once, data recording continues until data corresponding to recording length have been stored in memory. (LED above START key is lit.)
  - · If START key is pressed after STOP key was pressed once and before waveform data recording is completed, the measurement is restarted.
- (2) Pressing STOP key twice
  - · When STOP key is pressed twice, waveform recording is stopped immediately.
  - · The waveform until the current point is displayed.

# Chapter 8 FFT Function

### 8.1 Outline

- (1) FFT (Fast Fourier Transform) processing can be performed on input signal data for frequency analysis.
- (2) Frequency range
  133 mHz to 40 kHz or 80 kHz (when 8927 is not used), 20 steps
- (3) Frequency resolution 1/400 of frequency range
- (4) 12 types of analysis functions

  Storage waveform, linear spectrum, RMS spectrum, power spectrum, autocorrelation function, histogram, transfer function, cross-power spectrum, crosscorrelation function, unit-impulse response, coherence function, octave analysis
- (5) Analysis modes 1-channel FFT, 2-channel FFT
- (6) Analysis of data stored with memory recorder function possible
- (7) Switchable antialiasing filter


  Automatic selection of cutoff frequency to match frequency range (8919 FFT unit)
- (8) Waveform evaluation function using evaluation area


## 8.2 Item Settings


## 8.2.1 Setting the FFT Function

- The 8845 has three function modes; the memory recorder function, the recorder function, the FFT function.
- · Select the FFT function for performing FFT analysis.

Method Screen: STATUS (page 1), CHANNEL(page1), DISPLAY







- 1. Move the flashing cursor to the position shown in the figure on the left.
- 2. Press F3 [ FFT ]. Function key Meaning

display

Memory recorder function




: FFT function


## 8.2.2 Setting the FFT Channel Mode

- · This setting determines whether only one channel (1ch-FFT) or two channels (2ch-FFT) are used for FFT processing.
- · When "1ch-FFT" is selected, certain FFT analysis modes will not be available.

#### Method Screen: STATUS (page 1)



- 1. Move the flashing cursor to the **FFT mode** item.
- 2. Use the function key to make the selection.



Used for simultaneous FFT analysis of two channels.

NOTE

The following analysis functions are not possible in 1-channel FFT mode:


2CH-FFT

Transfer function (TRF), cross-power spectrum (CSP), cross-correlation function (CCR), impulse response (IMP), coherence function (COH)


## 8.2.3 Setting the Frequency Range


- · The frequency range (frequency axis maximum value) can be set as follows.
- The frequency range corresponds to the time axis range (TIME/DIV) setting of the memory function.

Method Screen: STATUS (page 1), DISPLAY



- 1. Move the flashing cursor to the max. frequency item on the STATUS screen or the freq item on the DISPLAY screen.
- 2. Use the JOG control or the function keys to make the selection.





#### NOTE

- · When the analog unit 8927 is used, the 80 kHz range cannot be selected (maximum setting 40 kHz).
- The antialiasing filter (8919 FFT unit) cutoff frequency is the same as the selected frequency range
- · When **EXT** was selected, octave analysis cannot be carried out.
- · To use external sampling: 

  Section 21.5

Frequency Range, Frequency Resolution, Window Width, Corresponding Time Axis Range

Frequency rai	nge	Frequency resolution [ Hz ]	Window width	Time axis [/DIV]
80 k	*1	200	5 ms	500 μs
40 k		100	10 ms	1 ms
32 k	*2	80	12.5 ms	1.25 ms
20 k		50	20 ms	2 ms
16 k	*3	40	25 ms	2.5 ms
8 k		20	50 ms	5 ms
4 k		10	100 ms	10 ms
2 k		5	200 ms	20 ms
800		2	500 ms	50 ms
400		1	1 s	100 ms
200		500 m	2 s	200 ms
80		200 m	5 s	500 ms
40		100 m	10 s	1 s
20		50 m	20 s	2 s
8	*4	20 m	50 s	5 s
4	*4	10 m	100 s	10 s
2	*4	5 m	200 s	20 s
667 m	*4	1.67 m	10 min	1 min
333 m	*4	0.83 m	20 min	2 min
133 m	*4	0.33 m	50 min	5 min
(67 m)	*4	0.17 m	100 min	10 min
(33 m)	*4	0.08 m	200 min	20 min
(11 m)	*4	0.03 m	10 hour	1 hour

The cutoff frequency of the antialiasing filter is the same as the selected frequency range, except for the cases listed below.

<sup>\*1:</sup> Antialiasing filter is OFF.

<sup>\*2:</sup> Cutoff frequency is 40 kHz.

<sup>\*3:</sup> Cutoff frequency is 20 kHz.

<sup>\*4:</sup> Cutoff frequency is 20 Hz.

<sup>( )</sup> indicates range for DATtoFFT mode. Normally it can not be used.

## 8.2.4 Setting the Window Function


- The window function defines the segment of the input signal that will be processed.
- · Window processing can be used to minimize leakage error.

  Rectangular (rectangular window function): effective on discrete waveforms.


  Hanning (hanning window function): effective on continuous waveforms.

  Exponential (exponential window function): effective on decaying waveforms.


Method Screen: STATUS (page 1), DISPLAY




- 1. Move the flashing cursor to the window item.
- 2. Use the function keys to make the selection.




3. If **EXPO** was selected in step 2, the **coefficient** item is displayed. Select the attenuation ratio in percent, using the function keys or the JOG control.





If **coefficient** (attenuation ratio) is set to 0%, processing will be carried out as 0.1%.

#### **Example** Attenuation ratio set to 10%



Setting: Exponential window function Attenuation ratio 10%

NOTE


When measurements are taken using the Hanning window or exponential window, note that the calculation results in the display of a value that is lower than the amplitude obtained when using a rectangular window.

## 8.2.5 Setting the Display Format

- · You can set the format for displaying input signal waveforms on the screen and recording them on the printer.
- · The SINGLE, DUAL, and NYQUIST formats are available.

#### (1) Single


Displays the waveform on a single screen.



#### (2) Dual


Divides the waveform display screen into upper and lower screens.

A input waveform is analyzed in two ways




#### (3) Nyquist


For the linear spectrum, cross power spectrum, and transfer function, displays the real-number portion of the data for the FFT calculation result on the X-axis, and the imaginary number portion of the data on the Y-axis.



Method Screen: STATUS (page 1)



- 1. Move the flashing cursor to the **format** item.
- 2. Use the function keys to make the selection.




## 8.2.6 Selecting Reference Data

Select data to be used for FFT processing.

#### **New data**


When START key is pressed, data for 1000 points are captured and used for FFT processing.




1000 points of input signal are sampled

#### **Memory waveform**

- · When START key is pressed, FFT processing is carried out using data stored in memory with the memory function.
- · Processing start point can be specified on the memory recorder display, using the A/B cursors.
- · When the A/B cursors are used, data for 1000 points from the first cursor are used for FFT processing.



#### Method Screen: STATUS (page 1)



- 1. Move the flashing cursor to the **reference** item.
- 2. Use the function keys to select the data.

display

\text{VM-FFT}
NEW DATA
:
FROM MEM::

Function key

Meaning


Capture new waveform data for FFT processing

Use stored waveform data for FFT processing


NOTE

When stored waveform data are used, the trigger setting is not required. But the trigger mode is active, and when REPEAT, AUTO, or AUTO STOP is selected, FFT analysis is performed continuously for 1000-point data at a time, until the end of data. (Calculation is not performed if less than 1000 points.)

Trigger mode set to SINGLE



Trigger mode set to REPEAT, AUTO, AUTO STOP




## 8.2.7 Setting the Peak Display

- · From the sampling points and FFT processing results, the 10 peak values or maximum values can be shown.
- · This setting is available only in single-screen mode.


#### Peak value

- · When data at one point are higher than data within the vicinity, the point is a peak.
- · The 10 highest peaks are shown.




#### Maximum value

Points with the 10 highest values are shown.



#### Method Screen: STATUS (page 1)



- 1. Move the flashing cursor to the **peak** item.
- 2. Use the function keys to make the selection.


Function key display Meaning
: OFF

OFF PEAK

MAX

: Shows the 10 peak values


: Shows the 10 highest peaks



## 8.2.8 Setting the FFT Analysis Mode

Used to select the FFT calculation method.

Method Screen: STATUS (page 1), DISPLAY



x: (Time)

- 1. Move the flashing cursor to the **mode** item.
- 2. Use the function keys to select the FFT calculation.
  - 1/3
    Function key
    display
    Meaning

Storage Waveform ( F Section 8.3.1)

Linear Spectrum ( F Section 8.3.2)

RMS Spectrum ( FSection 8.3.3)

RMS Power

PSP : Power spectrum ( F Section 8.3.4)

to page 2/3 : Switch to page 2/3

• 2/3

\* FFT \* [1ch, new]

ŠİNGLE OFF

pre-t: 0%

freq: 40kHz

window: RECTAN

csr: OFF

Linear Spectrum LIN

Power Spectrum PSP

1 2

2

RMS Spectrum RMS

S1

CH1

Function key display Meaning

Auto correlation function

ACR

Auto correlation function

( Section 8.3.5)

 $\frac{|Histogram|}{|HIS|}$ : Histogram ( F Section 8.3.6)

 $\left[\frac{\text{Transfer}}{\text{TRF}}\right]$ : Transfer function (  $\square \mathcal{F}$  Section 8.3.7)

Cross Power spectrum

CSP

Cross power spectrum

Section 8.3.8)

to page 3/3 : Switch to page 3/3

• 3/3

Function key display Meaning

Cross correlation function

CCR : ( Section 8.3.9)

Impulse Response : Impulse response ( Section 8.3.9)

Response | Impulse response ( F Section 8.3.10)

Coherence | Coherence | Coherence function

COH ( F Section 8.3.11)

 $\begin{bmatrix} uctave \\ 0ct \end{bmatrix}$ : Octave analysis (  $\Box$  Section 8.3.12)

Switch to page 1/3

NOTE


STR y: (Linear)


The transfer, cross-power spectrum, cross-correlation, unit-impulse response, and coherence functions use 2 channels.

## 8.2.9 Setting the Analysis Channel


Select the channel for FFT analysis.

Method Screen: STATUS (page 1), DISPLAY





- 1. Move the flashing cursor to the w1 item.
- 2. Use the JOG control or the function keys to select the channel.
- 3. When 2CH-FFT was selected, the w2 item is displayed. Select the channel in the same way as for w1.




For the transfer function and impulse response, calculation is performed from "(w2)/(w1)".

## 8.2.10 Setting the X-axis and Y-axis Displays

- · Set the X and Y axis for display of FFT calculation results.
- · Different units can be selected for the X and Y axis.
- · With some FFT analysis modes, one of the axis cannot be set.

Method Screen: STATUS (page 1), DISPLAY



- 1. Move the flashing cursor to the **x-axis** item.
- 2. Use the function keys to make the selection.
- 3. For the y-axis, select in the same way as for x-axis.

#### · X-axis

Function key display Meaning

Frequency
(linear)
LIN-Hz
Frequency
(log)
LOG-Hz

Frequency (linear display)

: Frequency (logalism display)

(when octave analysis)

Function key display

Meaning

1/3 OCT

1/3 octave

1/1 0CT :

1/1 octave

· Y-axis

Function key display

Meaning

Real part
LIN-REAL
Imaginary
part
LIN-IMAG

Real number part (linear display)

Imaginary number part (linear display)

Magnitude (linear) LIN-MAG


Amplitude (linear display)

Magnitude (dB) LOG-MAG

: Amplitude (decibel display)

Phase (deg)

Phase (degree display)



X and Y Axis Settings Available with each FFT Analysis Mode

FFT analysis mode		X-axis (horizontal axis)	Y-axis (vertical axis)
STR	Storage Waveform	(Time)	(Linear)
LIN	Linear Spectrum	LIN-Hz LOG-Hz	LIN-REAL LIN-IMAG LIN-MAG LOG-MAG PHASE
RMS	RMS Spectrum	LIN-Hz LOG-Hz	LIN-REAL LIN-IMAG LIN-MAG LOG-MAG PHASE
PSP	Power Spectrum	LIN-Hz LOG-Hz	LIN-MAG LOG-MAG
ACR	Auto Correlation Function	(Time)	(Linear)
HIS	Histogram	(Volt)	(Linear)
TRF	Transfer Function	LIN-Hz LOG-Hz	LIN-REAL LIN-IMAG LIN-MAG LOG-MAG PHASE
CSP	Cross Power Spectrum	LIN-Hz LOG-Hz	LIN-REAL LIN-IMAG LIN-MAG LOG-MAG PHASE
CCR	Cross Correlation Function	(Time)	(Linear)
IMP	Unit Impulse Response	(Time)	(Linear)
СОН	Coherence Function	LIN-Hz LOG-Hz	(Linear)
ОСТ	Octave Analysis	1/3 OCT 1/1 OCT	LIN-MAG LOG-MAG

NOTE

When external sampling is used, the X-axis (horizontal axis) expresses the data count.

## 8.2.11 Setting the Display Scale

The display scale for showing the FFT processing result can either be set manually or automatically.

#### **AUTO**


The vertical axis (Y-axis) scale is set automatically, depending on the processing result.

#### **MANUAL**


The vertical axis (Y-axis) scale can be set as desired, to match the purpose of the measurement.

This is useful for enlarging or reducing the amplitude and for shifting the waveform up or down.

#### Method Screen: STATUS (page 1) )



- 1. Move the flashing cursor to the **scale** item.
- 2. Use the function keys to make the selection.




#### (1) When AUTO is selected

Upper and lower limits are set automatically, according to the processing result.


#### (2) When MANUAL is selected

- · The upper and lower limits for the display scale can be set by the user.
- · Make settings to match processing results.
- · Setting range is -9.9999E+29 to 9.9999E+29. (exponent is E-29 to E+29).

#### Method Screen: STATUS (page 1)



- 1. Move the flashing cursor to the lower item.
- 2. Use the JOG control or the function keys to select the lower limit for each digits.
- 3. Set the upper limit in the same manner.



#### Displaying the display scale units

- · The selected unit is displayed with "scaling" in the system screen.
- · When scaling is turned OFF, V (volts) or  $^{\circ}$ C is displayed.



The X-axis setting for the histogram can be changed on the channel setting page (page 1) or the variable setting page (page 2) of the CHANNEL screen.

## 8.2.12 Octave Filter Setting

When octave analysis has been selected, two different filter types can be chosen.


#### Normal

Filter characteristics approximate the characteristics used for conventional octave analyzers with analog filters.


#### Sharp

Spectrum components outside the octave band are excluded totally and only the spectrum in the octave band is bundled and used for analysis. (The characteristics of both filter types are within ANSI CLASS 3 tolerance

limits.)




1/1-octave (1/3-octave) normal filter characteristics




1/1-octave (1/3-octave) sharp filter characteristics

Method Screen: STATUS (page 1)



- 1. When the octave analysis is selected in analysis mode, the **oct-filter** item is shown.
- 2. Move the flashing cursor to the **oct-filter** item.
- 3. The function key display appears, allowing you to make the selection.




NOTE

This unit does not use analog filters. It first determines the entire power spectrum and then uses weighting by bundling the spectrum to achieve the desired filter characteristics.

## 8.2.13 Setting the Interpolation Function


The input signal (sampled data) and FFT waveform can be displayed and recorded as is, or after linear interpolation.

Method Screen: STATUS (page 3)



- 1. Move the flashing cursor to the **dot-line** item.
- 2. Use the function keys to make the selection.

Function key display Meaning




Linear interpolation is not performed. The sampled data is displayed just as it comes.


Linear interpolation is performed. The display is easier on the eye.

## 8.2.14 Other Settings


For details, refer to the following sections.



Status Screen (page 1)



Status Screen (page 2)



Status Screen (page 3)

## 8.3 Analysis Function

The following waveform data can be analyzed.

STR Storage waveform Linear spectrum LIN RMS spectrum RMS **PSP** Power spectrum Auto correlation function ACR Histogram HIS Transfer function TRF Cross power spectrum CSPCross correlation function CCR Unit impulse response IMP Coherence function COHOctave analysis OCT

## 8.3.1 Storage Waveform [STR]

Displays the time domain waveform of the input signal. Displays the time domain waveform of the input signal.

Function fa

Horizontal cursor

Time axis display

Indicates the value of the specified TIME/DIV frequency range.

(Refer to the table of the frequency range and time axis in


Section 8.2.3.)

Vertical Linear cursor

Indicates the value of the measurement range of the input unit in voltage units.

Vertical axis	Display
LIN-REAL (real-number part)	_
LIN-IMAG (imaginary-number part)	
LIN-MAG (amplitude)	fa
LOG-MAG (logarithmic amplitude)	
PHASE (phase)	

#### Example Stored waveform



**Function** 

## 8.3.2 Linear Spectrum [LIN]

 $Fa = \Im(fa)$ 

- The frequency domain waveform of the input signal, including magnitude and phase information.
- Major applications include:
- · Determining the peaks of waveform frequency components
- · Determining the levels of high and low harmonics

 $= |Fa| \exp(j \theta a)$ =  $|Fa| \exp(\cos \angle \theta a + j\sin \angle \theta a)$ LIN-Hz Frequency spectrum display as linear units. Horizontal cursor The range is from DC to the maximum frequency range value. LOG Hz Frequency spectrum display as logarithmic units. The range is from 1/400 the maximum frequency range value to the maximum frequency range value. Real Linear display of real-number part of the data as voltage (Nyquist mode) LIN-REAL Linear display of real-number part of the data as voltage Vertical cursor

Cursor

Lin-IMAG

Linear display of imaginary-number part of the data as voltage

LIN-IMAG

Linear display of analysis data as voltage

LOG-MAG

Logarithmic display of analysis data as dB

(0dB reference value: 1 V peak= α V p-p)

PHASE

Degrees (deg) display of phase component of data


Linear display of imaginary-number part of the data as voltage

(Nyquist mode)


Vertical axis	Display
LIN-REAL (real-number part)	lFal·cos ∠ θ a
LIN-IMAG (imaginary-number part)	lFal·sin ∠ θ a
LIN-MAG (amplitude)	lFal
LOG-MAG (logarithmic amplitude)	20·log  Fal
PHASE (phase)	∠ θ a

#### Examples Linear spectra waveforms


#### Stored waveform




#### Y-axis: LIN-REAL (X-axis: LOG-Hz)




Y-axis: LIN-IMAG (X-axis: LOG-Hz)




Y-axis: LIN-MAG (X-axis: LOG-Hz)




Y-axis: LOG-MAG (X-axis: LOG-Hz)



Y-axis: PHASE (X-axis: LOG-Hz)



#### Nyquist



## 8.3.3 RMS Spectrum [RMS]

- Displays the frequency domain waveform of the input signal, including magnitude (effective value) and phase information.
- Major applications include:
- · Determining the peaks of waveform frequency components.
- · Determining the effective values of frequency components.

**Function** 

Ra = 
$$\frac{1}{\sqrt{2}}$$
 Fa

DC components: Ra = Fa

=  $|\text{Ra}| \exp(j \theta \text{ a})$ 

=  $|\text{Ra}| (\cos \angle \theta \text{ a} + j\sin \angle \theta \text{ a})$ 

Horizontal cursor

LIN-Hz Frequency spectrum display as linear units. The range is from

DC to the maximum frequency range value.

LOG-Hz Frequency spectrum display as logarithmic units. The range is

from 1/400 the maximum frequency range value to the maximum

frequency range value.

Vertical cursor

LIN-REAL Linear display of real-number part of the data as voltage

LIN-IMAG Linear display of imaginary-number part of the data as voltage

LIN-MAG Linear display of analysis data as voltage

LOG-MAG Logarithmic display of analysis data as dB (0dB reference value:

1 Vrms)

PHASE Degrees (deg) display of phase component of data


Vertical axis	Display
LIN-REAL (real-number part)	lRal·cos ∠ θ a
LIN-IMAG (imaginary-number part)	lRal•sin ∠ θ a
LIN-MAG (amplitude)	IRal
LOG-MAG (logarithmic amplitude)	20·log  Ral
PHASE (phase)	∠ θ a

NOTE


The RMS spectrum display and the LOG-MAG display express the same processing result.

#### Example RMS spectra waveform


#### Stored waveform




#### Y-axis: LIN-REAL (X-axis: LOG-Hz)




#### Y-axis: LIN-IMAG (X-axis: LOG-Hz)




#### Y-axis: LIN-MAG (X-axis: LOG-Hz)



#### Y-axis: LOG-MAG (X-axis: LOG-Hz)



#### Y-axis: PHASE (X-axis: LOG-Hz)



## 8.3.4 Power Spectrum [PSP]

- Displays the energy spectrum of the input signal, consisting of only magnitude information.
- Major applications include:
- · Determining the peaks of waveform frequency components
- · Determining the energy levels of high and low harmonics

**Function** 

Gaa = 
$$\frac{1}{2}$$
 Fa\*·Fa

Fa\*: complex conjugate of Fa

Re (Fa): real number component of Fa

Im (Fa): imaginary number component of Fa

=  $\frac{1}{2}$  |Fa|

Dc component:

Gaa = 
$$Fa^* \cdot Fa$$
  
=  $\{Re^2(Fa) + Im^2(Fa)\}$   
=  $|Fa|^2$ 

Horizontal cursor

LIN-Hz Frequency spectrum display as linear units. The range is from DC to the maximum frequency range value.

LOG Hz Frequency spectrum display as logarithmic units. The range is from 1/400 the maximum frequency range value to the maximum frequency range value.

Vertical cursor

LIN-MAG

Linear display of analysis data as binary exponential voltage This expresses the energy component.

LOG-MAG Logarithmic display of analysis data as dB (0dB reference value: 1 V<sup>2</sup> rms)


Vertical axis	Display
LIN-REAL (real-number part)	_
LIN-IMAG (imaginary-number part)	_
LIN-MAG (amplitude)	Gaa
LOG-MAG (logarithmic amplitude)	10 log lGaal
PHASE (phase)	-

NOTE


The LOG-MAG display and the RMS spectrum display express the same processing result.

#### Example Power spectra waveforms


#### Stored waveform



Y-axis: LIN-MAG (X-axis: LOG-Hz)



Y-axis: LOG-MAG (X-axis: LOG-Hz)



#### Overall value

The overall value is the total effective value obtained from the frequency spectrum contained in the input signal. It is obtained by taking the square root of the total of power spectra for all frequencies.

(Overall value) 
$$\sqrt{PSPo + \sum_{i=1} PSPi}$$
 (Vrms)

PSPo DC component

**PSPi** ith AC component

NOTE

Compensation is applied to data for 1000 points captured before starting FFT processing, to achieve the same overall value, also when a window function other than rectangular window is used.

Window compensation value:  $\gamma$ 

Square wave:  $\gamma = 1$ 

Hanning: 
$$\gamma = \sqrt{\frac{8}{3}}$$

Hanning: 
$$\gamma = \sqrt{\frac{8}{3}}$$
 Exponential:  $\gamma = \sqrt{\frac{2 \log(\alpha/100)}{(\alpha/100)^2 - 1}}$ 

(  $\alpha$  is a percentage with a range of  $0 \le \alpha < 100$ .)

If  $\alpha$  is set to 0 with the exponential window function, processing will be carried with  $\alpha = 0.1$ .

## 8.3.5 Auto Correlation [ACR]

- ullet Displays the degree of similarity between two points in the input signal separated by time difference (au).
- Major applications:
- · Detecting a periodic signal contained in a noisy signal with an improvement in signal-to-noise ratio.
- · Checking the periodic signal components contained in a noisy waveform, and periodic noise.

Function

Raa (
$$\tau$$
) =  $\Im^{-1}$  (Gaa)  
=  $\frac{1}{2\pi} \int_{-\infty}^{+\infty} \text{Gaa}(\omega) \exp(j\omega \tau) d\omega$ 

Horizontal Time cursor

Time display. The center indicates the reference (  $\tau$  =0), the right side indicates time lag (+  $\tau$  ), and the left side indicates time lead (-  $\tau$  ).

Vertical Linear cursor

Readings are between +1 and -1 (without units).

+1: the highest similarity for time differential  $\tau$ 


0: the lowest similarity, -1: the polarity is completely opposite.

Due to the characteristics of the function,  $\tau = 0$  always results in +1.


Vertical axis	Display
LIN-REAL (real-number part)	_
LIN-IMAG (imaginary-number part)	_
LIN-MAG (amplitude)	Raa
LOG-MAG (logarithmic amplitude)	
PHASE (phase)	_

#### Example Auto correlation function waveforms

#### Stored waveform



#### Auto correlation function



Because the input waveform is the frequency waveform, peaks are repeated at regular intervals.

The time until the first peak is the input signal period.

# 8.3.6 Histogram [HIS]

- Displays the frequencies of the magnitudes of sampled points.
- Major applications include:
- · Determining waveform imbalance
- · Determining whether a waveform is artificial or natural from the waveform distribution (most natural waveforms are regular sine waves).

Function Pa

Horizontal cursor

Volt

Linear display of the measurement range of the input unit.

Vertical cursor


Linear

Number of sample points for the time axis data (total: 1000 points).


Vertical axis	Display
LIN-REAL (real-number part)	_
LIN-IMAG (imaginary-number part)	-
LIN-MAG (amplitude)	Pa
LOG-MAG (logarithmic amplitude)	_
PHASE (phase)	-

### Example Histogram function waveforms

#### Stored waveform



High amplitude indicates high number of data



## 8.3.7 Transfer Function [TRF]

- Displays the transfer function (frequency characteristics) of the system being measured calculated from input and output signals.
- Nyquist diagrams can also be displayed, including magnitude and phase information.
- Major applications include:
- · Determining filter frequency characteristics.
- · Determining feedback control system stability through Nyquist diagrams.
- · Determining the physical resonant frequency using an impulse hammer and pick-up sensor.

**Function** 

$$\begin{aligned} \text{Hab} &= \frac{\text{Fb}}{\text{Fa}} = \frac{\text{Fb} \cdot \text{Fa}^*}{\text{Fa} \cdot \text{Fa}^*} = \frac{\text{Gab}}{\text{Gab}} \\ &= \frac{|\text{Gab}|}{|\text{Gaa}|} \{\cos(\angle \theta \, \mathbf{b} - \angle \theta \, \mathbf{a}) + j\sin(\angle \theta \, \mathbf{b} - \angle \theta \, \mathbf{a}) \} \end{aligned}$$

Horizontal cursor

LIN-Hz

Frequency spectrum display as linear units. The range is from

DC to the maximum frequency range value.

LOG-Hz

Frequency spectrum display as logarithmic units. The range is

from 1/400 the maximum frequency range value to the maximum

frequency range value.

Real

Linear display of the real-number part of the input-to-output

ratio (Nyquist mode)

Vertical cursor

RIN-REAL

Linear display of the real-number part of the input-to-output

ratio (no units).

LIN-IMAG

Linear display of the imaginary-number part of the input-to-

output ratio (no units).

LIN-MAG

Linear display of input-to-output ratio (no units)

This expresses the amplitude component.

LOG-MAG

Logarithmic display of input-to-output ratio as dB (no units)

This expresses the amplitude component.

**PHASE** 

Degrees (deg) display of phase component of data of input-to-

output ratio

Imag


Linear display of the imaginary-number part of the input-to-

output ratio (Nyquist mode).


	T
Vertical axis	Display
LIN-REAL (real-number part)	IHabl·cos ∠ θ b−∠ θ a
LIN-IMAG (imaginary-number part)	lHabl·sin ∠ θ b−∠ θ a
LIN-MAG (amplitude)	lHabl
LOG-MAG (logarithmic amplitude)	20 log lHabl
PHASE (phase)	∠ θ b−∠ θ a

### Example Transfer function spectra waveform


### Stored waveform (input signal)




### Stored waveform (output signal)




Y-axis: LIN-REAL (X-axis: LOG-Hz)




Y-axis: LIN-IMAG (X-axis: LOG-Hz)




Y-axis: LIN-MAG (X-axis: LOG-Hz)




Y-axis: LOG-MAG (X-axis: LOG-Hz)



Y-axis: PHASE (X-axis: LOG-Hz)



### Nyquist



## 8.3.8 Cross Power Spectrum [CSP]

- Displays the product of the spectra of two input signals.
- The magnitude and phase information of the frequency components that are common to both signals can be displayed.
- Major applications:
   Obtaining frequency components common to two signals.

Function Gab = 
$$\frac{1}{2}$$
 Fa\*·Fb   
=  $\frac{1}{2}$  |Fa|·|Fb| $\{\cos(\angle \theta b - \angle \theta a) + j\sin(\angle \theta b - \angle \theta a)\}$ 

Horizontal cursor

Cursor

LIN-Hz

Frequency spectrum display as linear units. The range is from DC to the maximum frequency range value.

LOG Hz

Frequency spectrum display as logarithmic units. The range is from 1/400 the maximum frequency range value to the maximum frequency range value.

Real

Linear display of real-number part of the data as voltage

Real Linear display of real-number part of the data as voltage (Nyquist mode).

Vertical cursor

LIN-REAL Linear display of real-number part of the data as binary exponential voltage

LIN-IMAG Linear display of imaginary-number part of the data as binary exponential voltage

LIN-MAG Linear display of amplitude component as binary exponential voltage

LOG-MAG Logarithmic display of the amplitude component as dB  $(0dB \text{ reference value; } 1V^2\text{rms.})$ 


PHASE Degrees (deg) display of phase component of data

Imag Linear display of imaginary-number part of the data as binary exponential voltage (Nyquist mode)


Vertical axis	Display						
LIN-REAL (real-number part)	IGabl·cos ∠ θ b−∠ θ a						
LIN-IMAG (imaginary-number part)	IGabl·sin ∠ θ b—∠ θ a						
LIN-MAG (amplitude)	lGabl						
LOG-MAG (logarithmic amplitude)	10 log lGabl						
PHASE (phase)	∠ θ b−∠ θ a						

### Example Cross power spectra waveforms


### Stored waveform 1




### Stored waveform 2




Y-axis: LIN-REAL (X-axis: LOG-Hz)




Y-axis: LIN-IMAG (X-axis: LOG-Hz)




Y-axis: LIN-MAG (X-axis: LOG-Hz)




Y-axis: LOG-MAG (X-axis: LOG-Hz)



Y-axis: PHASE (X-axis: LOG-Hz)



### Nyquist



# 8.3.9 Cross Correlation [CCR]

- ullet Displays the degree of similarity between two points separated by a time difference ( au ) on two signals.
- The degree of similarity is expressed as a function of the time difference ( $\tau$ ).
- Major applications:
- · Obtaining the phase difference between two signals in time units.
- · Obtaining a speed or distance by measuring the time delay.

**Function** 

Rab (
$$\tau$$
) =  $\Im^{-1}$  (Gab)  
=  $\frac{1}{2\pi} \int_{-\infty}^{+\infty} \text{Gab }(\omega) \exp(j\omega \tau) d\omega$ 

Horizontal Time cursor

Time display. The center indicates the reference (  $\tau$  =0), the right side indicates time lag (+  $\tau$  ), and the left side indicates time lead (-  $\tau$  ).

Vertical Linear cursor


Readings are from +1 to -1 (no units).

+1: the highest similarity between the input and output signals for time differential  $\tau$ , 0: the lowest similarity, -1: the polarity is completely opposite


Vertical axis	Display
LIN-REAL (real-number part)	_
LIN-IMAG (imaginary-number part)	
LIN-MAG (amplitude)	Rab
LOG-MAG (logarithmic amplitude)	_
PHASE (phase)	_

### Example Cross correlation function waveforms


### Stored waveform (input waveform)



### Stored waveform (output waveform)



### Cross correlation function



Phase differences between input signal and output signal

# 8.3.10 Unit Impulse Response [IMP]

- Displays the frequency response of a system in the time domain.
- A response waveform equivalent to the unit impulse function is obtained by analyzing the input and output signals of the system being measured.
- Major applications
  Checking circuit time constants.

Function  $IMP = \Im^{-1}(Hab)$ 

Horizontal Time cursor

Time display. The center indicates the reference ( $\tau = 0$ ), the right side indicates time lag (+ $\tau$ ), and the left side indicates time lead

(-τ).


Vertical Linear cursor

Inverse Fourier conversion value of the transfer function (Hab) (no units).


Vertical axis	Display
LIN-REAL (real-number part)	_
LIN-IMAG (imaginary-number part)	_
LIN-MAG (amplitude)	IMP
LOG-MAG (logarithmic amplitude)	
PHASE (phase)	

### Example Unit impulse response waveforms


### Stored waveform (input signal)



### Stored waveform (output signal)



### Unit impulse response



- Input point of impulse signal

# 8.3.11 Coherence [COH]

- Displays the output signal component that is coherent (interference possible) to the input signal, yielding a value from 0 to 1.
- Major applications include:
- · Evaluation of transfer functions.
- · Determining the contribution of individual input lines to the output of multiinput systems.

Function 
$$COH = \frac{Gab^* \cdot Gab}{Gaa \cdot Gbb}$$

Horizontal cursor

LIN-Hz

Frequency spectrum display as linear units. The range is from  $\,$ 

DC to the maximum frequency range value.

LOG-Hz

Frequency spectrum display as logarithmic units. The range is from 1/400 the maximum frequency range value to the maximum

frequency range value.

Vertical Linear cursor

The relationship between the two input signals. The degree of relationship is indicated from 0 to 1 on a linear scale (no units).


Vertical axis	Display
LIN-REAL (real-number part)	
LIN-IMAG (imaginary-number part)	_
LIN-MAG (amplitude)	COH
LOG-MAG (logarithmic amplitude)	-
PHASE (phase)	

NOTE


For a single measurement, the coherence function returns 1 for all frequencies. When measuring, be sure to use frequency averaging.

### Example Coherence function waveforms


### Stored waveform (input signal)



### Stored waveform (output signal)



### Coherence



Frequencies in this range have high coherence.

## 8.3.12 Octave Analysis [OCT]

• This function displays the spectrum of a noise signal or other signal, using 1/1-octave or 1/3-octave band filters with fixed ratio.

Main uses
 Frequency analysis of noise

Function OCT

Horizontal

1/1 OCT

1/1-octave band filtering

cursor <sub>1/</sub>

1/3 OCT

1/3-octave band filtering

Vertical cursor

LIN-MAG LOG-MAG Linear display of octave analysis value as voltage Logarithmic display of octave analysis value as dB

Vertical axis	Display
LIN-REAL (real number)	_
LIN-IMAG (imaginary number)	_
LIN-MAG (amplitude)	OCT
LOG-MAG (logarithmic amplitude)	10log (OCT)
PHASE	

- · For frequency analysis of a noise signal or similar, the signal is passed through fixed-ratio band filters with 1/1-octave or 1/3-octave bandwidth.
- · As opposed to the power spectrum function, where the signal is divided into bands of identical width and the power in each band is displayed, octave analysis divides the frequency axis evenly on a logarithmic scale and expresses the level as a bar for each band.
- · In analog octave analysis, the octave band center frequencies and filter characteristics are determined according to the ANSI CLASS 3 standard. In the 8845, the power spectrum is measured first and bundling is then used to perform 1/1-octave or 1/3-octave analysis. This allows the following analysis functions:

5-band 1/1-octave analysis 15-band 1/3-octave analysis

· 15-band 1/3-octave analysis and filter characteristics of the 8845 correspond to the ANSI CLASS 3 standard. However, in the upper bands of frequency analysis, there are no leak components from higher frequencies.

For example, the 20 kHz band contains no leak components from the 25 kHz band or other bands.


· 15-band 1/3-octave analysis
In this mode, the 400 spectrum lines of regular frequency analysis are bundled into 1/3 octave bands and shown as a bar graph.

· 5-band 1/1-octave analysis


In this mode, the 400 spectrum lines of regular frequency analysis are bundled into 1/1 octave bands and shown as a bar graph.

### Example Octave analysis waveforms


### Stored waveform



### 1/1 octave analysis



### 1/3 octave analysis



# Frequency ranges and measurable range widths (0: 1/3 OCT, X: 1/1 OCT)

Ba N	nd o.	Center		Frequency ranges (Hz)																		
1/1	1/3	frequency (Hz)	133 m	333 m	667 m	2	4	8	20	40	80	200	400	800	2 k	4 k	8 k	16 k	20 k	32 k	40 k	80 k
-8	-24 -23	4 m 5 m	X 0X																			
-7	-22 -21 -20	6.3 m 8 m 10 m	0X 0X 0X	X 0X																		
-6	-19 -18 -17	12.5 m 16 m 20 m	0X 0X 0X	0X 0X 0X	X 0X																	
-5	-16 -15 -14	25 m 31.5 m 40 m	0X 0X 0X	0X 0X 0X	0X 0X 0X																	
-4	-13 -12 -11	50 m 63 m 80 m	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X																
-3	-10 -9 -8	100 m 125 m 160 m	0X 0X 0	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X															
-2	-7 -6 -5	200 m 250 m 315 m		0X 0X 0	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X													-	
-1	-4 -3 -2	400 m 500 m 630 m			0X 0X 0	0X 0X 0X	0X 0X 0X	0X 0X 0X	X 0X													
0	-1 0 1	800 m 1 1.25				0X 0X 0X	0X	0X 0X 0X	0X 0X 0X	X 0X												
1	2 3 4	1.6 2 2.5				0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	X 0X											
2	5 6 7	3.15 4 5					0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X											
3	8 9 10	6.3 8 10						0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0 0X 0X										
4	11 12 13	12.5 16 20							0X 0X 0	0X 0X 0X	0X 0X 0X	0X 0X 0X	0 0X 0X									
5	14 15 16	25 31.5 40								0X 0X 0	0X 0X 0X	0X 0X 0X	0X 0X 0X	0 0X 0X								
6	17 18 19	50 63 80									0X 0X 0	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X							
7	20 21 22	100 125 160										0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X	,					
8	23 24 25	200 250 315										0X X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X					
9	26 27 28	400 500 630											0X X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X	X 0X			

Ba N	nd o.	Center frequency		Frequency ranges (Hz)																		
1/1	1/3	(Hz)	133 m	333 m	667 m	2	4	8	20	40	80	200	400	800	2 k	4 k	8 k	16 k	20 k	32 k	40 k	80 k
10	29 30 31	800 1 k 1.25 k												0X X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X	X 0X	
11	32 33 34	1.6 k 2 k 2.5 k										·			0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	X 0X
12	35 36 37	3.15 k 4 k 5 k														0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X
13	38 39 40	6.3 k 8 k 10 k															0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X	0X 0X 0X
14	41 42 43	12.5 k 16 k 20 k																0X 0X	0X 0X 0	0X 0X 0X	0X 0X 0X	0X 0X 0X
15	44 45 46	25 k 31.5 k 40 k																		0X 0X	0X 0X 0	0X 0X 0X
16	47 48 49	50 k 63 k 80 k																				0X 0X 0

# Chapter 9 Input Channel Settings


(For all functions)

### 9.1 Overview

- · Input channel settings are made with the CHANNEL screen of each function.
- · The 8845 can use up to 16 analog channels or 14 analog and 16 logic channels.
- · Settings are made separately for one analog channel or four logic channels (1 probe).
- · Using the CH. SET key, channel settings can also be made from the display screen. ( Section 20.3).
- · Before making input channel settings, use the SYSTEM screen to select the units to be used.

# 9.2 Selecting Units (SYSTEM Screen)

- · Perform this setting before making the input channel settings.
- · This setting on the SYSTEM screen determines the number of units in use.
- · Use the menu items **SETUP** and **(1) using unit**.
- · For details, see Section 11.4.1.






- Depending on the number of units in use, the time axis of the recorder function differs ( Section 7.2.2).

# 9.3 Selecting Functions

- · Press the CHAN key to call up the CHANNEL screen.
- · Select the function.

#### Method




- 1. Move the flashing cursor to the position shown in the figure.
- 2. Use the function keys to make the selection.





: Memory recorder function






: FFT function

# 9.4 Selecting the Input Type

Specifies whether analog input or logic input is used for each channel.

Method Screen: STATUS (page 1), CHANNEL (page 1), DISPLAY)



- 1. Move the flashing cursor to a channel with an odd number, as shown in the illustration.
- 2. Use the function keys to make the selection.
- · If a unit is installed in specified channel

display Se


Function key

Meaning

Select analog input



: Select logic input



Function key display


Meaning



Set channel to non-use



Select logic input



Channel where 8927 is installed

Channel where 8916 is installed

Channel where 8917 is installed


Channel where 8918 is installed



- · When the units 8916 8919 are installed, even channel numbers cannot be used. (Example: If an 8916 unit is installed in CH1/CH2, CH2 cannot be used.)
- · When a logic input has been assigned to an odd channel number, the next even channel number cannot be used. (Example: If CH3 has been set to logic input, CH4 cannot be used.)
- If an odd channel number has been assigned to "Miclophone" in the recorder function, the next even channel number cannot be used. (Miclophone setting: Section 7.2.8)
- · One unit of the 8928 corresponds to two units of the 8916 to 8919.

### Switching the setting screen between CH1-CH8 and CH9- CH16


While the CHANNEL screen is displayed, use the CH. SET key to switch the display between CH1-CH8 and CH9- CH16.




# 9.5 Making Logic Input Settings (FFT Excluded)


- · When a channel has been set to logic input as described in Section 9.4, the logic channel setting items are displayed.
- $\cdot$  Select the display positions for CH A CH D (1 probe).

#### Method



- 1. Specify the display colors for each channel ( Section 9.6.1).
- 2. Specify the display position for the logic waveform.







For channels where a logic waveform is recorded, the indication **logic** is shown at the (/div) location.

to page 1/2


# 9.6 Making Analog Input Settings

## 9.6.1 Waveform Display Color (FFT Excluded)

Set the display color for the waveform.


#### Method


- 1. Move the flashing cursor to the point shown in the illustration.
- 2. Use the function keys to make the selection. The indication in brackets refers to the printout color (dark, medium dark, normal, light).



: Switch to page 4/5

to page 4/5






( NOTE

- · When the display color is changed using the **SETUP** item on the SYSTEM screen, the waveform display color also changes.
- · The FFT waveform display color is fixed to color 1.


### 9.6.2 Display Graph Type (FFT Excluded)


- · Specify which graph type to use when display format has been set to DUAL, QUAD, or OCT screen display on the STATUS screen.
- · When the display format has been set to SINGLE, this item is not available.
- · When the display format has been set to XY SINGLE or XY DUAL display, refer to Section 6.2.5.

#### Method



- 1. Move the flashing cursor to the position shown in the figure.
- 2. Use the function keys to make the selection.






- (\*1): Setting available when "quad" or "octo" screen display has been selected.
- (\*2): Setting only available when "octo" screen display has been selected.

NOTE


# 9.6.3 Setting the Voltage Axis, Temperature Axis, Strain Axis Ranges

- · Set the voltage axis range for each channel.
- The voltage axis range is the voltage unit per 1 DIV on the vertical axis (when magnification/compression is set to 1).
- · The available settings depend on the type of unit that is installed.
- · When histogram analysis of the FFT function is used, the range setting affects the X-axis.

#### Method



- 1. Move the flashing cursor to the range item.
- 2. Use the JOG control or the function keys to select the range.





When the histogram analysis of the FFT function is used, the change in voltage axis (X axis) only becomes active after a restart.

### Auto-balancing


Align the reference output level of the adapter with the specified origin position. (Zero position Section 9.6.6)

NOTE


- · Auto-balancing is carried out for the strain units only. It is not carried out for other input units (8916, 8917, 8918, 8919, and 8927).
- · When the next setting or change is made, carry out auto-balancing again. Changing the setting range, changing the strain gauge adapter, change of reference state, powering on, or unit replacement

### Measurement voltage range

With 8916, 8917, 8919, 8927, 8928:



With 8918:



NOTE

- · When the input has exceeded the lower measurement limit of the thermocouple, the display extends fully to the lower saturation level.
- · When the input has exceeded the upper measurement limit of the thermocouple, or if burnout has occurred, the display extends fully to the upper saturation level.

Thermocouple types and measurement range

K(CA) -90 to 1200°C


J(IC) -90 to 800℃

T(CC) -90 to 400°C


### 9.6.4 Setting the Input Coupling (Not Required for 8918, 8928)

- · For the 8917 DC/RMS unit, two types of input coupling (DC or RMS conversion) can be selected.
- · The ground level can be checked.
- This item does not appear for channels set to the 8918 TEMPERATURE UNIT.

### Method



- 1. Move the flashing cursor to the position as shown in the figure.
- 2. Use the function keys to select the input coupling.






When one channel of the 8927 analog unit has been set to GND, the setting for the other channel automatically also becomes GND.


# 9.6.5 Setting Voltage Axis, Temperature Axis, and Strain Axis Magnification/ Compression

- · Set the magnification/compression ratio for each channel.
- · Magnification/compression can be used to make the waveform easy to read.
- · When histogram analysis of the FFT function is used, the magnification/compression setting affects the X axis.
- · When wishing to set the voltage axis to an arbitrary magnification/compression value, refer to Section 9.6.10.

#### Method



- 1. Move the flashing cursor to the position as shown in the figure.
- 2. Use the function keys to make the selection.




NOTE

Based on the voltage axis range and the magnification/compression, the display range (/div) is determined.


## 9.6.6 Setting the Zero Position

- This setting determines the DIV position at which the 0 V, 0  $^{\circ}$ C, or 0  $^{\mu}$   $^{\varepsilon}$  is located for each channel.
- · The available setting range depends on the magnification/compression setting.
- · When histogram analysis of the FFT function is used, the setting affects the X axis.

#### Method




- 1. Move the flashing cursor to the **position** item.
- 2. Use the JOG control or the function keys to make the selection.



Magnification ratio	Setting range (units: DIV)
×20	-502.0 to 522.0
×10	-246.0 to 266.0
X5	-118.0 to 138.0
X2	-41.2 to 61.2
X1	-15.6 to 35.6
×1/2	-2.8 to 22.8
×1/5	0.0 to 20.0
×1/10	0.0 to 20.0

NOTE


The zero position is as follows:



### Zero adjustment

This function calibrates the 0 V position (ground position) to the selected zero position. Use it to assure precise results.

#### Method



- · Allow the unit to warm up for at least 1 hour to ensure that the internal temperature of the input units has stabilized.
- · Compensation for the voltage axis range or frequency axis range (8919 FFT unit) is performed.
- 1. Move the flashing cursor to the **position** item.
- 2. Press F5 [ 0 Adjust ]. All channels (all units installed) will be calibrated together.


( NOTE

- · Zero adjustment cannot be performed during measurement.
- · Repeat the zero adjustment when the input unit was changed, when the power is on/off, or when the system is set to reset.
- The 8918 TEMPERATURE UNIT does not have a zero adjustment function. The function applies only to other input units.
- · For the 8928 STRAIN UNIT, the zero adjustment is not also carried out.
- · When there is a sudden change in ambient temperature, the zero position may drift. To assure continued measurement precision, perform the zero adjustment again.
- · Zero adjustment may take up to 80 seconds. During this time, the keys are inactive.

### 9.6.7 Setting the Low-Pass Filter

- · Set the cutoff frequency for the low-pass filter, which limits the frequency bandwidth.
- · When the observed waveform has high ripple content or noise, causing the recording line to become thick, or if pulse type noise is present, the low-pass filter should be enabled.

#### Method



- 1. Move the flashing cursor to the position shown in the figure.
- 2. Use the JOG control or the function keys to make the selection. Available setting items depend on the type of input unit.
  - 8916, 8927 Analog units

Function key Meaning display



: No low pass filter is used.



: A filter with 5 kHz cutoff is used.



: A filter with 500 Hz cutoff is used.

5 Hz 🛭

: A filter with 50 Hz cutoff is used.

: A filter with 5 Hz cutoff is used.

• 8917 DC/RMS, 8919 FFT units

Function key display

Meaning



: No low pass filter is used.



· A filter with 500 Hz cutoff is used.



: A filter with 5 Hz cutoff is used.

8918 Temperature unit

Function key display

Meaning



: No low pass filter is used.



A filter with 5 Hz cutoff is used.



A filter with 1.5 Hz cutoff is

used.

8928 Strain unit

Function key display

Meaning



OFF (cutoff 20 kHz)



: 3 kHz Cutoff filter



: 300 Hz Cutoff filter



30 Hz Cutoff filter




10 Hz Cutoff filter


# 9.6.8 Setting the Thermocouple Type (8918 Only)

The temperature unit 8918 can use three types of thermocouples. Choose the correct setting for the thermocouple in use.

#### Method



- 1. Move the flashing cursor to the point shown in the figure. (This item is not displayed for channels where the temperature unit 8918 is not installed.)
- 2. Use the function keys to make the selection.




NOTE


If the setting and the actually used thermocouple are different, the measurement reading will be wrong.

# 9.6.9 Setting the Antialiasing Filter (8919 Only)

- The FFT unit 8919 incorporates an antialiasing filter designed to prevent aliasing distortion ( Appendix 2). The filter can be set to ON or OFF. The cutoff frequency of the filter is set automatically, according to the frequency range and time axis setting.
- · This item is only available when the FFT unit 8919 is installed.

#### Method






- 1. Move the flashing cursor to the point shown in the figure. (This item is not displayed for channels where the FFT unit 8919 is not installed.)
- 2. Use the function keys to make the selection.

NOTE

When the antialiasing filter is set to ON, the measurement is slightly shifted.



• Antialiasing filter cutoff frequency and range settings for each function The cutoff frequency is the same value as the frequency range (except when a different value is specified in brackets).

Frequenc FFT fui		Time axis range Memory recorder, recorder function
[ Hz	z ]	[ /DIV ]
80 k	(OFF)	500 μs*
40 k		1 ms *
32 k	(40 k)	1.25 ms
20 k		2 ms
16 k	(20 k)	2.5 ms
8 k		5 ms
4 k		10 ms
2 k		20 ms
800		50 ms
400		100 ms
200		200 ms
80		500 ms
40		1 s
20		2 s
8	(20)	5 s
4	(20)	10 s
2	(20)	20 s
667 m	(20)	1 min
333 m	(20)	2 min
133 m	(20)	5 min


Ranges marked with an asterisk (\*) are available only for the memory recorder function.

## 9.6.10 Arbitrary Setting if Voltage Axis Magnification/ Compression and Display Range

(Variable Display Function) (FFT Excluded)


- This function allows setting the 1 DIV value on the voltage axis or the display range in voltage axis direction to any setting.
- (1) Voltage axis magnification/compression
  - · Set the value which should correspond to 1 DIV on the voltage axis.
  - · Set the zero position to any position.
- (2) Display range in voltage axis direction
  - · Set the lower and upper limit of the display to any desired setting.
- The variable function can be set to ON or OFF for each channel individually.
- (1) Setting the 1 DIV value and zero position for the voltage axis

#### Method Screen: CHANNEL (page 2)




Move the flashing cursor in the order shown below to make the setting.

- 1. Use the CHAN key to call up the CHANNEL screen (page 2).
- 2. Set the variable function for the desired channels to ON.
- 3. Set the voltage axis range (Display range/div).
- The zero position is fixed, and the voltage axis 1 DIV value changes.
- · Setting range: +0.0001E-29 to +9.9999E+28



4. Set the **position** item.

(Same as in step 3.)




NOTE

When voltage axis range or zero position are changed, the upper limit and lower limit values also change.


(2) Setting the upper and lower display limit

Method Screen: CHANNEL (page 1)



Move the flashing cursor in the order shown below to make the setting.

- 1. Use the CHAN key to call up the CHANNEL screen (page 2).
- 2. Set the variable function for the desired channels to ON.
- 3. Set the lower and upper items.
- · Setting range: +0.0001E-29 to +9.9999E+29
- The setting must be (lower limit)  $\geq$  (upper limit)
- · Move the flashing cursor to the respective digits to make the setting.



NOTE

When the upper limit and lower limit values are changed, the voltage axis range or zero position also change.

#### Reset

When the flashing cursor is on the items range/div, position, lower, or upper, pressing this key causes the upper and lower limit values to be calculated from the voltage axis range setting and zero position setting (page 1). The calculated values are automatically inserted in the respective positions.



- · If no input unit is installed, "--" is displayed and the item cannot be set.
- · Channels for which the variable function has been set to ON are denoted by the indication variable below the lower upper indication on page 1 of the CHANNEL screen.


#### Reference

The settings for one channel can be copied to another channel ( $\square$  Section 9.6.11).

## 9.6.11 Copying Channel Settings

- · While using the CHANNEL screen, settings made for one channel can be copied to another channel.
- The **copy source** is the channel whose settings are being copied to the "copy target" channel.

#### Method



- 1. Move the flashing cursor to the number of the channel to be used as copy source.
- 2. Use the function keys or the JOG control to specify the copy target channel.

Function key display Meaning

Copy Source: (display only)

: Increase channel number

: Copy source is shown (display only)

CH 1

: Decrease channel number

: Execute copy

: Execute copy


3. When F5 [exec] is pressed, the settings of the copy source channel are copied to the copy target channel.



- · When making a copy settings for channel between temperature unit and other units (8916, 8917, 8919, 8927, 8928), only display color of the waveform and graph display can be copied.
- · In case of copying between strain unit (8928) and voltage unit (8916, 8917, 8919, 8927), the settings for range and lowpass filter cannot be copied.

## 9.6.12 Making Channel Settings on Display Screen

- · With the CH. SET key, individual channel setting items and the variable function setting can be superimposed on the current display screen. The item is switched with each push of the button.
- · Move the flashing cursor to the item and make the setting in the same way as described for the CHANNEL screen. Results can be judged immediately by observing the waveform.
- · For details, see Section 20.3.



# Chapter 10 Trigger Functions

(For all functions)

#### 10.1 Overview

- · The term "trigger" refers to a signal which is used to control the timing for recording start or stop.
- The term "triggering has occurred" refers to the state when such a signal has activated recording start or stop.
- · Trigger parameters for the various functions are set using the STATUS screen (page 2).
- · There are four types of signals which can be used for triggering (as trigger source).

#### (1) Analog trigger

- The input signal to analog units (CH1 CH16) is used as trigger source.
- The input signal is constantly monitored, and triggering occurs when the preset trigger conditions are met.

#### (2) Logic trigger

- · The input signal to logic channels (CH A CH D) is used as trigger source.
- The input signal is constantly monitored, and triggering occurs when the preset trigger conditions are met.

#### (3) External trigger

- Triggering occurs when the EXT TRIG connector is shorted or when a high-level signal (2.5-5.0 V) at this connector changes to low-level (0-1.0 V).
- · External triggering is used for example when several Memory HiCorder units are connected in parallel for synchronized operation.

#### (4) Timer trigger

- · Triggering occurs from a preset start time to a preset stop time.
- · Serves for real-time recording.

- · The above trigger sources can be combined with AND/OR.
- · The trigger mode setting determines whether repeated triggering is used.
- The pretrigger setting can be used to record the waveform not only after but also before triggering has occurred (memory recorder, FFT).


NOTE


If the trigger settings (trigger source AND, OR, trigger source parameters, pretrigger) are changed during recording, the measurement is restarted, using the new settings.


## 10.2 Setting the Trigger Mode


- The trigger mode determines the way triggering is used to control operation of the 8845.
- · When all trigger sources are OFF, the waveform is recorded continuously in the interval between pressing the START key and the STOP key (free-run operation).

#### Method Screen: STATUS (page 2), DISPLAY










- 1. Move the flashing cursor to the **trig mode** item.
- 2. Use the function keys to make the selection.



- ① Trigger is registered only once. After START key was pressed, unit starts waveform recording when triggering occurs and continues for preset recording length. Measurement then ends automatically.
- ② Trigger is registered continuously. Unit is in trigger standby condition when trigger conditions are not met. Measurement ends when STOP key is pressed.
- ③ Trigger is registered continuously. If trigger conditions are not met within 1 second, waveform recording starts automatically and continues for preset recording length.

  Measurement ends when STOP key is pressed (memory recorder, FFT).
- When triggering occurs, waveform recording is carried out for preset recording length. If trigger conditions are not met within 1 second, waveform recording starts automatically and continues for preset recording length (memory recorder, FFT).

## 10.3 Setting Trigger Source AND/OR Linking

The analog trigger, logic trigger, and timer trigger can be linked with the AND/OR logical operators.

AND: Triggering occurs when conditions for all triggers are met.

OR: Triggering occurs when conditions for one trigger are met.


( NOTE

The external trigger cannot be AND/OR linked with other trigger sources.

Function key

display

#### Method Screen: STATUS (page 2)



- 1. Move the flashing cursor to the **trigger source** item
- 2. Use the function keys to select the AND or OR.

#### Meaning

Link trigger sources with logical operator OR.


Link trigger sources with logical operator AND.

**Example** The figures below show the effect of AND/OR linking.

CH1: level trigger; level 0.00 V, slope ℑ; filter OFF CH2: level trigger; level 0.00 V, slope ℑ; filter OFF

AND linking

OR linking




CH1 and CH2 level both intersect 0 V line from below


CH1 or CH2 level intersects 0 V line from below

## 10.4 Setting the Pretrigger (Memory recorder, FFT)


- The pretrigger function serves to record the waveform not only after but also before triggering has occurred.
- · Using the recording start point as 0% and the recording end point as 100%, the trigger point can be specified in percent.
- · When all trigger sources are set to OFF, pretrigger cannot be set.





#### Method Screen: STATUS (page 1), CHANNEL (page 1), DISPLAY



- 1. Move the flashing cursor to the **pre-trig** item.
- 2. Use the JOG control or the function keys to make the selection.







#### NOTE


- · When the pretrigger is set (memory recorder or FFT: 2 100%), the trigger will not be registered for a certain period after the start of measurement. (During this interval, **Pretrigger standby** is shown on the display.)
- · When the trigger can be registered, the indication Waiting for trigger is shown on the display.

## 10.5 Using the Analog Trigger Function


The analog signal input channels (CH1 - CH16) can be used as trigger source.

Method Screen: STATUS (page 2)


(1) While STATUS (page 2) screen is shown




- 1. Move the flashing cursor to the point shown in the figure.
- 2. Use the function keys to select the trigger type.




(2) While display screen is shown



1. Move the flashing cursor to the point shown in the illustration, and use the function keys or the JOG control to specify the source channel.






2. When the source channel has been specified, move the flashing cursor to the right and specify the trigger source in the same way as on the STATUS screen.


## 10.5.1 Level Trigger

- Triggering occurs when the input signal crosses the preset trigger level (voltage) with the preset trigger slope ( $\mathfrak{I}$ ,  $\mathfrak{I}$ ).
- · When a trigger filter is used, triggering occurs only within the filter width. This is useful to exclude noise.




#### Trigger filter

- · Triggering occurs when the trigger conditions are met within the filter width.
- · This is useful to prevent spurious triggering by noise.
- · The filter width is specified by number of sampling points.




#### Method Screen: STATUS (page 2), DISPLAY

Can be used when the specified channel is an analog input channel.





- 1. Move the flashing cursor to the position as shown in the figure, and press F2 [LEVEL].
- 2. Set the trigger level.


Use the JOG control or the function keys to make the selection.




3. Select the trigger direction (slope).
Use the function keys to make the selection.








Function key display Meaning



- 4. Set the trigger filter
- This setting cannot be made from the display screen.
- · Use the function keys or the JOG control to make the setting.
- · Filter width is specified using sampling points.




NOTE

- · To cause triggering at point A or point B with the sine wave shown below, make the following settings.
- · When using the recorder function, the filter width is limited by the time axis range setting.

Time axis range (/DIV)	Filter width (maximum value)
1.25 ms - 200 ms	all settable
500 ms	250
1 s	200
2 s	100
5 s	20
10 s	20
20 s	10
1 min -	all unsettable

#### **Example**

- ① Point A trigger level: 200 mV, trigger direction (slope): rising ( )
- ② Point B trigger level: -600 mV, trigger direction (slope): falling (1)



## 10.5.2 Window-In, Window-Out Trigger

#### Window-in trigger


Set upper limit level and lower limit level and activated when the input signal enters the range between these limits.

#### Window-out trigger


Set upper limit level and lower limit level and activated when the input signal leaves this range.

Window-in-trigger

Window-out-trigger



Method Screen: STATUS (page 2), DISPLAY




Can be used when the specified channel is an analog input channel.

1. Move the flashing cursor to the point shown in the figure.


Press  $\boxed{\mathsf{F3}}$  [ WINDOW-IN ] or  $\boxed{\mathsf{F4}}$  [ WINDOW-OUT ].


2. Set the lower trigger level.


Use the  ${\tt JOG}$  control or the function keys to make the selection.




• The value must be larger than the upper trigger level.








- 3. Set the upper trigger level
- · Make the setting as in step 2.
- The value must be smaller than the lower trigger level.
- 4. Set the trigger filter
- · This setting cannot be made from the display screen.
- · Use the function keys or the JOG control to make the setting.
- · Filter width is specified using sampling points.



#### Setting example of the window trigger

In order to cause triggering when the signal as shown in the figure below leaves the hatched area, the following settings are made:



## 10.6 Using the Logic Trigger Function


- The signal of a logic channel can be used as trigger source.
- The channel must be set to LOGIC on the CHANNEL screen ( F Section 9.4).
- · A trigger pattern and logical operator (AND/OR) are specified, and triggering occurs when the trigger conditions are met.
- · A trigger filter can be specified, so that triggering occurs only when the trigger conditions are met within the filter width.

NOTE

If no channel has been set to **LOGIC** on the CHANNEL screen, the logic trigger cannot be set.

Method Screen: STATUS (page 2), DISPLAY

(1) While STATUS (page 2) screen is shown




- 1. Move the flashing cursor to the position as shown in the figure.
- 2. Press F2 [ ON (PATN) ].

Function key display Meaning

OFF
: Logic trigger is not used.

ON (PRIN)
: Logic trigger is used.

- 3. Set the trigger pattern
- · When "CH A" is selected, the setting is for logic input CH A1 CH A4 from left to right.
- · Make the setting with the function keys.



#### 4. Set the AND/OR operator.

Determine whether to use the AND or OR logical operator.

Function key display




- Meaning
- Triggering occurs if any one of the logic input signals conforms to the trigger pattern.
- Triggering only occurs if all of the logic input signals conforms to the trigger pattern.



If the conditions are met already when measurement is started (AND: all trigger patterns are met, OR: one trigger pattern is met), triggering does not occur at this slope. Triggering only occurs if the conditions are removed and then met again.


- 5. Set the trigger filter.
- · Use the function keys or the JOG control to make the setting.
- · Filter width is specified using sampling points.


Function key display Meaning




#### (2) While display screen is shown








1. Move the flashing cursor to the point shown in the illustration, and select a channel that is set to logic input.




2. Move the flashing cursor to the point shown in the illustration, and select a logic channel.




3. Set the logic trigger conditions (same as steps 1 to 4 when using the STATUS screen).

#### Setting example of the logic trigger

(1) If the trigger pattern has been set to "10××" with the operator OR, then triggering occurs as shown in the figure below.




(2) If the trigger pattern has been set to " $10 \times \times$ " with the operator AND, then triggering occurs as shown in the figure above.




## 10.7 Using the External Trigger Function

- · An external signal can be used as trigger source.
- · The EXT TRIG connector is used for this purpose.
- · For details, refer to Section 21.3.



Method Screen: STATUS (page 2)




NOTE


The external trigger cannot be linked to other trigger sources with the logical AND operator.

## 10.8 Using the Timer Trigger Function

- · This function serves to activate recording at preset times.
- · Triggering can be performed at constant intervals within a preset start time and end time.




Method Screen: STATUS (page 2)



- 1. Move the flashing cursor to the timer source item.
- 2. Press F2 [ ON ].


Function key Meaning display : Timer trigger is not used. OFF : Timer trigger is used.

- 3. Set the start time (month, day, hour, minute).
- ① Move the flashing cursor to the **start** item.
- ② Use the function keys or the JOG control to make the setting.



- 4. Set the end time (month, day, hour, minute).
- ① Move the flashing cursor to the **stop** item.
- ② Use the function keys or the JOG control to make the setting.
- 5. Set the trigger interval (day, hour, minute, second).
  - · The setting range is 0 s to 10 d 23 h 59 m 59 s.
- ① Move the flashing cursor to the **interval** item.
- ② Use the function keys or the JOG control to make the setting.

Function key display Meaning




NOTE

Set the start time and end time to a point after the pressing of the START key.

#### Relation between timer trigger and AND/OR linking


(1) When trigger sources are set to OR

All trigger sources are valid. If other trigger sources have been set, triggering can also occur before the start time or after the end time.



#### (2) When trigger sources are set to AND

- · Measurement is carried out from the start time to the end time. Triggering occurs at the preset intervals if the conditions for the other trigger sources are also met at these points.
- · If the interval has been set to 0s, triggering occurs at any point between the start and end time, if if the conditions for the other trigger sources are met.



NOTE

- · When the trigger mode has been set to **SINGLE**, only one triggering action occurs after the measurement was started.
- · To perform recording at regular intervals, establish the following settings.


Trigger mode: continuous

Trigger source linking: AND or OR

Other trigger sources: all OFF

## 10.9 Trigger Output Connector

- · When triggering occurs, a signal is output from the TRIG OUT connector.
- · This can be used to synchronize several 8845 units.
- · For details, refer to Section 21.4.





# Chapter 11 SYSTEM Screen Settings

(For all functions)

## 11.1 Overview

The SYSTEM screen serves to set the following items which are common to all functions.


(Refer to the following Sections)


Setting the clock	······ (11.3.1)
· Clearing waveform data	(11.3.2)
System reset	(11.3.3)
· Channel selection	······ (11.4.1)
· Start key backup	(11.4.2)
• Setting the grid ·····	(11.4.3)
· Channel marker function	(11.4.4)
· Time axis display	(11.4.5)
· List and gauge functions	····· (11.4.6)
Backlight saver function	(11.4.7)
· Setting screen colors	(11.4.8)
Setting the volume	(11.4.9)
Intermittent printing	···· (11.4.10)
· Scaling function	(11.5)
· Appending comments ·····	(11.6)
• Self-test	(11.7)
· Interface settings	(11.8)

## 11.2 How to Use the SYSTEM Screen

- · Press the SYSTEM key to call up the SYSTEM screen.
- · On the SYSTEM screen, items common to all functions are displayed.
- · Use the function keys to select the item you wish to set and then make the setting. (Press the SYSTEM key to switch items.)
- · When the flashing cursor is at the point shown in the illustration, the function keys have the following assignments.

#### Method






## 11.3 Initialization [INITIALIZE]

Setting the clock (TIME SET), clearing waveform data (DATA CLEAR), and initialization of setting items (SYSTEM RESET) are available.

#### Method Screen: SYSTEM (INITIALIZE)




- 1. Press F1 [ INITIALIZE ].
- 2. Move the flashing cursor to the setting item, and press the function key to make the selection.

For details on settings, see Sections 11.3.1 to 11.3.3.


## 11.3.1 Setting the Clock [TIME SET]

- This unit incorporates a calendar with automatic leap year compensation and 24-hour clock.
- The clock is used for the following functions:
- · Display of year/month/day/hour/minutes/seconds on STATUS, CHANNEL, and SYSTEM screens
- · Timer trigger function
- · Trigger time list printout
- · Date/time printout at every 5 DIV when time axis is set to DATE

#### Method Screen: SYSTEM (INITIALIZE)




- 1. Move the flashing cursor to the year, month, day, hour, minute, second items of (1) TIME SET and make the settings.
- 2. Press F5 [ set ] to start the clock.



## 11.3.2 Clear Waveform Data [ DATA CLEAR ]

Clears waveform data stored in memory.

Method Screen: SYSTEM (INITIALIZE)



- 1. Move the flashing cursor to (2) DATA CLEAR.
- 2. Press F1 [ exec ].

  Function key display Meaning

  (exec) : Clear waveform data




When memory segmentation ( F Chapter 17) is used, data in all blocks are cleared.

## 11.3.3 System Reset [ SYSTEM RESET ]

- · Resets all settings to the factory default values.
- The same effect can be achieved by turning power to the unit on while holding down the STOP key ( F Section 23.4).

Method Screen: SYSTEM (INITIALIZE)



- 1. Move the flashing cursor to the (3) SYSTEM RESET item.
- 2. Press F1 [ exec ].

Function key display Meaning

: Reset all system items



System reset list

(1) STATUS screen

Memory recorder function

Settings	Display items	Initial settings
Time axis range	time/div	500 $\mu$ s/DIV (8927 not installed), 1 ms/DIV
Recording length	shot	25 DIV
Display format	format	SINGLE
Interpolation	dot-line	LINE
Superimpose	superimpose	OFF
Printer recording format	print mode	WAVEFORM
Smooth print Auto print Auto save	smooth print auto print auto save	OFF
Trigger mode	trig mode	SINGLE
Pretrigger	pre-trig	0%
Trigger source AND/OR	trigger source	OR
Trigger source	analog trigger	all OFF
Memory segmentation Averaging Waveform decision Waveform parameter calculation Waveform processing	memory div averaging wave comparison measurement wave calculation	OFF

#### Recorder function

Settings	Display items	Initial settings
TIme axis range	time/div	10 ms/DIV (8927 not installed), 20 ms/DIV
Time axis magnification	time/div zoom	×1
Recording time	recording time	0 s
Display format	format	SINGLE
Interpolation	dot-line	LINE
Recording medium	recording medium	OFF
Printer recording format	print mode	WAVEFORM
Smooth print Microphone	smooth print mic	OFF
Trigger mode	trig mode	SINGLE
Trigger source AND/ OR linking	trigger source	OR
Trigger source	analog trigger	all OFF
Waveform parameter calculation	measurement	OFF

#### FFT function

Settings	Display items	Initial settings
FFT mode	FFT mode	1CH FFT
Frequency range	max.frequency	80 kHz(8927 not installed), 40 kHz
Window function	window	RECTAN .
Display format	format	SINGLE
Peak value display Averaging	peak average	OFF
Reference data	reference	NEW DATA
Mode	(mode)	STRAGE
w1	(w1)	CH1
Scale	(scale)	AUTO
Trigger mode	trig mode	SINGLE
Pretrigger	pre-trig	0%
Trigger source AND/OR	trigger source	OR
Trigger source	analog trigger	all OFF
Interpolation	dot-line	LINE
Printer recording format	print mode	WAVEFORM
Auto print Auto save Waveform evaluation	auto print auto save wave comparison	OFF

#### (2) Channel screen

Setting displays	Initial settings
Input type	ANALOG
Waveform display color	Same color as channel number (not in FFT)
Voltage axis range	Minimum range of installed amplifier
Zooming	X1
Zero position	10 DIV
Filter	OFF

#### (3) System screen


Display items	Initial settings
(1) using unit	8
(2) start backup	OFF
(3) grid type	STANDARD
(4) channel marker	ON
(5) time axis	TIME
(6) list&gauge	OFF
(7) backlight saver	ON
(8) LCD color type	TYPE 1
(9) volume	LOW
(10) intermittent print	OFF
scaling	all OFF
Comment	OFF
title	SETTING
channel	OFF

## 11.4 Special Function Settings [ SETUP ]

The following 10 functions are available.

- (1) Channel selection ( 27 11.4.1)
- (2) Start key backup ( @ 11.4.2 )
- (3) Setting the grid ( 2 11.4.3 )
- (4) Channel marker function ( 2 11.4.4)
- (5) Time axis display ( 2 11.4.5 )
- (6) List and gauge functions ( at 11.4.6)
- (7) Backlight saver function ( 2 11.4.7)
- (8) Setting screen colors ( 2 11.4.8)
- (9) Setting the volume ( 2 11.4.9 )
- (10) Intermittent printing ( 11.4.10 )

#### Method Screen: SYSTEM (SETUP)




- 1. Press F2 [ SETUP].
- 2. Move the flashing cursor to the various items and use the function keys to make the selection.

For details, see Sections 11.4.1 - 11.4.10.


## 11.4.1 Channel Selection [using unit]

- · This function allows limiting the number of units to be used.
- · Be sure to make this setting before measurement.
- · Units in use are assigned to channels in ascending order.


( NOTE



Method Screen: SYSTEM (SETUP)



- 1. Move the flashing cursor to the (1) using unit item.
- 2. Use the JOG control or the function keys to make the selection.




## 11.4.2 Start Key Backup [ start backup ]


When this function is enabled, the unit will operate as follows: If the power supply is interrupted during measurement (while the START key LED is lit), recording is restarted immediately as soon as the power is restored. If the trigger function is used, the unit goes into trigger standby mode.

If power fails during recording...


...recording is restarted when power is restored.



#### Method Screen: SYSTEM (SETUP)



- 1. Move the flashing cursor to (2) start backup item.
- 2. Press the function key to make the settings.



Meaning


: Start key backup is not enabled.

: Start key backup is enabled.


# 11.4.3 Setting the Grid [ grid type ]

- · Sets the type of grid to be used for printout.
- The following seven settings are available: OFF (no grid), standard, fine, standard (dark), fine (dark), standard (shaded), fine (shaded).
- · Only OFF and standard (used at any other setting) are available for the display.


#### The DISPLAY screen



#### Method Screen: SYSTEM (SETUP)



- 1. Move the flashing cursor to (3) grid type item.
- 2. Press the function key to make the settings.




: Switch to page 1/2

NOTE


For the FFT function, the settings are "Standard (shaded)"  $\rightarrow$  "Standard (dark)", "Fine (shaded)"  $\rightarrow$  "Fine (dark)".

# 11.4.4 Channel Marker Function [channel marker]


This function adds channel numbers to the waveforms on the printout.



#### Method Screen: SYSTEM (SETUP)



- 1. Move the flashing cursor to the **(4) channel marker** item.
- 2. Press the function keys to make the selection.



Meaning

: Channel numbers will not be printed.


: Channel numbers will be printed.




- · When using the X-Y screen of the memory recorder function or the FFT function, channel numbers are not printed.
- · Logic channel numbers are printed regardless of the channel marker setting.

# 11.4.5 Time Axis Display [time axis]


Determines the way the time from the trigger point is printed out.



#### Method Screen: SYSTEM (SETUP)



- 1. Move the flashing cursor to the (5) time axis item.
- 2. Use the function keys to make the selection.






- · When using the FFT function, DIV and DATE are identical to TIME.
- · When external sampling is used, the following applies.
- (1) If printer format is set to WAVE, the "Scale" setting is used in any case.
- (2) If printer format is set to **LOGGING**, the setting except "Scale" is the sampling count.


If printer format is set to **LOGGING** and "Date" is used,  $\mu$  s and lower values are discarded.

# 11.4.6 List and Gauge Functions [list & gauge ]

When a waveform is being printed (except for screen hard copies), a gauge (vertical scale) and list of setting items can be added.



Method Screen: SYSTEM (SETUP)



- NOTE
- · The gauge is only printed for channels for which the waveform is being displayed.
- · When the X-Y plot of the memory recorder function is used, the number of gauges for the X axis is restricted to 2.
- · When single screen display is used, channels using the same voltage range, magnification/compression factor, zero position, variable setting, and scaling setting are displayed with the same gauge.


# 11.4.7 Backlight Saver Function [backlight saver]

· When this function is enabled, LCD backlighting is turned off automatically if no key is pressed for about 10 minutes.

\_\_\_\_\_ O N

- · Pressing any key will turn the backlight on again.
- · This increases the service life of the backlight.

#### Method Screen: SYSTEM (SETUP)



- 1. Move the flashing cursor to the (7) backlight saver item.
- 2. Use the function keys to make the selection.


# Function key display Meaning Backlight is always on

: Backlight is turned off automatically

#### LCD backlight ON/OFF

- · To turn the LCD backlight off: press the up and down cursor keys simultaneously.
- · To turn the LCD backlight on: press any key.






Turning the LCD backlight off


# 11.4.8 Setting Screen Colors [LCD color type]

The user can choose between various color patterns for the display.

#### Method Screen: SYSTEM (SETUP)




- 1. Move the flashing cursor to the (8) LCD color type item.
- 2. Use the function keys to make the selection.




Changing the display color has no effect on the printout (normal printing, screen hard copy, A4 print).

# 11.4.9 Setting the Volume [ volume ]


- · This setting controls the volume of the error and warning beep that is also produced when a waveform decision result is NG, and when stop mode is entered.
- · The setting also affects the volume with which a voice memo is played back when using the recorder function.






# 11.4.10 Intermittent Printing [intermittent print]

- · When the interpolation function is set to ON and the envelope waveform exceeds 0.5 DIV, printout is carried out with reduced frequency.
- · When operating the unit on DC, this can help to conserve power.
- · The intermittent printing setting can be chosen also when operating the unit on AC.
- · Print speed will differ depending on the density of the screen display.
- · Real-time printing when the unit is operated from a DC source is intermittent, also when the setting is OFF.




Intermittent printing OFF




Intermittent printing ON

Method Screen: SYSTEM (SETUP)



- 1. Move the flashing cursor to the (10) intermittent print item.
- 2. Use the function keys to make the selection.




- · In dot display mode the intermittent printing function has no effect.
- · In FFT mode the intermittent printing function has no effect.

# 11.5 Scaling Function [ SCALING ]

- The scaling function can be used to convert an output voltage from a sensor or similar into a physical quantity.
- · Two types of scaling functions are available.


#### Method 1 (conversion ratio method)

Scaling is performed by specifying a physical quantity to correspond to a 1V input signal (conversion ratio: eu/v), an offset value, and the unit (eu: engineering units). This will cause the measurement voltage to be converted into the selected units.



#### Method 2 (2-point method)


Scaling is performed by specifying two input signal points (voltage values) and the conversion values for these two points in engineering units (eu). This will cause the measurement voltage to be converted into the selected units.




- · The gauge scale (maximum and minimum values of horizontal axis) and A/B cursor measurement values are displayed in the scaled units.
- · Scaling can be performed for every channel.

# 11.5.1 Conversion Ratio Scaling


#### Method Screen: SYSTEM (SCALING)




- 1. Press F3 [SCALING] to call up the scaling screen.
- 2. Move the flashing cursor to **scale kind** and select **RATIO**.



3. Move the flashing cursor to the channel for which you want to perform scaling and change the setting to ON.




- 4. Enter the "Conversion ratio: eu/V" and "Offset".
  - The setting range for both these items is -9.9999E+9 to +9.9999E+9 (exponent E-9 to E+9).
  - · Move the flashing cursor to each item and make the setting.




- 5. Enter the "Unit name: eu".
  - · The unit name can be up to 7 characters long.
- · When the flashing cursor is moved within the [ ] brackets, the function key display for comment input appears.
- · For details on how to enter the unit name, refer to Section 11.6.1

# 11.5.2 2-Point Scaling


Method Screen: SYSTEM (SCALING)



- 1. Press F3 [ SCALING ] to call up the scaling screen.
- 2. Move the flashing cursor to **scale kind** and select **POINT**.




3. Move the flashing cursor to the channel for which you want to perform scaling and change the setting to ON.



- 4. Enter the two points.
- · Enter the voltage value on the left and the corresponding converted value on the right.
- Enter the higher voltage value in the top row and the lower voltage value in the bottom row.
- The setting range is -9.9999E+29 to +9.9999E+29.

· Move the flashing cursor to each item and make the setting.



- 5. Enter the "Unit name: eu".
  - · The unit name can be up to 7 characters long.
  - · When the flashing cursor is moved within the [ ] brackets, the function key display for comment input appears.
  - · For details on how to enter the unit name, refer to Section 11.6.1

NOTE

When the 2-point method is used, scaling is performed using the following equation.

$$Y = \boxed{\frac{SC_H - SC_L}{V_H - V_L}} X + \boxed{\frac{V_H \times SC_L - V_L \times SC_H}{V_H - V_L}}$$

V<sub>H</sub>: Voltage high point

S C <sub>H</sub>: Scaling high point

V <sub>∟</sub>: Voltage low point

S C L: Scaling low point

· The ranges for the parts enclosed in dotted lines are as follows.

 $-9.9999E+9 \le \text{value of enclosed part} \le -1.0000E-9$ 

Value of enclosed part = 0

-1.0000E-9  $\leq$  value of enclosed part  $\leq$  +9.9999E+9

- · When a setting outside of the above range is attempted, a warning indication is given and the setting becomes "converted value" = "voltage value" (no scaling).
- · For channels in which waveform processing result data are recorded, only the unit is valid (scaling is invalid).
- The scaling value is used for the gauge scale, upper and lower display limits, and for A/B cursor readings.

Reference

The settings for one channel can be copied to another channel ( Section 9.6.10).

#### Relationship between scaling function and variable function

When both the scaling and variable functions are to be used, the setting procedure differs, depending on the order the functions are enabled.

#### **Method 1** Scaling setting → Variable setting

- 1. Make the settings for the scaling function (conversion ratio method or 2-point method).
- 2. Call up the CHANNEL screen (page 2) with the setting item for the variable function.
- 3. Make the variable setting to be used after conversion to a physical quantity.

#### **Method 2** Variable setting → Scaling setting

- 1. Call up the CHANNEL screen (page 2) with the setting item for the variable function.
- 2. Set the input voltage range to be displayed or the voltage value for 1 DIV.
- 3. Make the settings for the scaling function.



· When using both the scaling and variable functions, the upper and lower limits for the variable display after scaling are as follows.


```
-9.9999E+29 \leqsetting value \leq -1.0000E - 29
Setting value = 0
+1.0000E-29 \leq setting value \leq +9.9999E+29
```

· When a setting outside of the above range is attempted, a warning indication is given and the setting for the upper and lower limit becomes as follows.


```
When setting value < -9.9999E+29: -1.0000E+29
When -1.0000E-29 < setting value < 0.0000E+00: -1.0000E-29
When 0.0000E+00 < setting value < +1.0000E-29: +1.000E-29
When +9.9999E+29< setting value: +1.0000E+29
```

#### Relationship between scaling function and waveform processing functions

When both the scaling and waveform processing functions are to be used, the operation sequence becomes as follows.




Scaling is not applied to processing results recorded in a channel



# 11.5.3 Scaling Setting Example

**Example** In a circuit as shown below, the measure voltage in CH2 is to be converted into current.




To determine current from voltage, Ohm's law is applied as follows.

$$Y = 200X - (1)$$

X: Current flowing in resistor (A)

Y: Voltage between resistor terminals (V)

Method 1 (conversion ratio method)



Equation (1) is transformed into

$$X = 0.005Y \cdots (2)$$

From equation (2), the settings for "Conversion ratio (eu/V)" and "Offset" are as follows.


Conversion ratio (eu/V) = 5.0000E-3

Offset = 0.0000E+0

Unit: A

Use these value to make the setting. This will cause the voltage measured in CH2 to be converted into current (A) for observation.

#### Method 2 (2-point method)



Equation (1) is transformed into

X=0.005Y .....(2)

From equation (2), two points are chosen.

Point A:

When voltage Y=0 (V), then current X=0 (A)

Point B:

When voltage Y=10 (V), then current X=0.05 (A)

These two points are converted.

A:  $(0.0000E+0 \rightarrow 0.0000E+0)$ 

B:  $(1.0000E+1 \rightarrow 5.0000E-2)$ 


Unit: A


This will cause the voltage measured in CH2 to be converted into current (A) for observation.

# 11.6 Adding Comments to a Graph [COMMENT]


Comments for titles or each channel can be added. The maximum length for a comment is 20 characters in normal print (see Section 12.5).

#### Method Screen: SYSTEM (COMMENT)






- 1. Press the F3 [COMMENT] key to call up the comment setting screen.
- 2. Move the flashing cursor to title item.
- 3. Use the function key to select the item to be printed.



- 4. When [COMMENT] or [SET&CMT] is selected, enter the comment.
- · When the flashing cursor is moved with the CURSOR keys, the following function key indication appears.
- For details on comment input refer to Section 11.6.1.



5. Move the flashing cursor to the **channel** item and select the item to be printed, using the function keys. (The function key indication is the same as for step 3.)

6. If **comment** or **SET & CMT** was selected, enter the comment for each channel.


Reference


The settings entered for one channel can be copied to another channel. ( Section 9.6.11)

# 11.6.1 Comment and File Name Entry Procedure


When the mode for input of a comment, file name, or unit is activated, the display changes as follows.

#### Method





- 1. Move the cursor to select a character.
- 2. Press F1 [ set char ].
- 3. After input characters, press F3 [end].




# 11.7 Self Check

The following tests can be carried out.

- (1) ROM/RAM check ( 12 11.7.1 )
- (2) LED check ( @ 11.7.2 )
- (3) Printer check ( 2 11.7.3 )
- (4) Key check ( 2 11.7.4 )
- (5) Display check ( 2 11.7.5)
- (6) DAT check ( @ 11.7.6 )
- (7) D/A unit output check (when D/A output unit 9539 is installed) ( 11.7.7)

#### Method Screen: SYSTEM (SELF-TEST)



- 1. Press the 2/2 function key and then the FI [SELF CHECK] key.
- 2. Move the flashing cursor to the various items and use the [exec] function key to start the test.

For details on the various tests, refer to Sections 11.7.1 - 11.7.7.




When the result of a self-test is "NG", or if another problem is observed during the test, the unit should be returned for servicing.

#### 11.7.1 ROM/RAM Check

- · This test checks the internal memory (ROM and RAM) of the 8845.
- · The test is non-destructive; it does not affect the contents of RAM.
- · The result is displayed as follows. OK: Passed, NG: Failed


#### Method Screen: SYSTEM (SELF-TEST)



- 1. Move the flashing cursor to the (1) ROM/RAM check item.
- 2. Press F1 [exec] to start the test...




- · During the test, all keys are disabled.
- · When "OK" appears, the test result was normal.
- 3. When the test is completed, press any key to return to the self-test setting screen.




### 11.7.2 LED Check

- · This test checks the LED indicators.
- The three LED indicators on the front panel (START key, VALUE, WAVE · A.B CURSOR) flash simultaneously, and a beep should be heard from the speaker.



Method Screen: SYSTEM (SELF CHECK)




- 1. Move the flashing cursor to the **(2) LED check** item.
- 2. Press F1 [exec] to start the test.
- 3. When the test is completed, press any key to return to the self-test setting screen.


### 11.7.3 Printer Check

This test checks the printer operation.

### Method Screen: SYSTEM (SELF CHECK)



- 1. Move the flashing cursor to the (3) PRINTER check item.
- Press F1 [exec] to start the test.
   To cancel the test pattern printout, press the STOP key.




NOTE


When operated from a DC source, the black sections are printed using intermittent printing.

# 11.7.4 Key Check

This test checks the key operation.

#### Method Screen: SYSTEM (SELF CHECK)





- 1. Move the flashing cursor to the (4) **KEY check** item.
- 2. Press F1 [ exec ]. The key test screen appears.
- 3. Press any key on the front panel. If the corresponding field on the display changes to reverse, the key is operating normally.
- 4. Turn the JOG and SHUTTLE controls at least one turn fully clockwise and counterclockwise. When all key fields on the screen are shown in reverse, the test is completed.



Rotate the SHUTTLE control slowly and with care.

5. Press any key to return to the self-test setting screen.


# NOTE

- · If any key is defective, the key test cannot not be completed normally.
- · In this case, press the START key while holding down the STOP key to return to the self-test setting screen.


# 11.7.5 Display Check

This test checks the display.

#### Method Screen: SYSTEM (SELF CHECK)




- 1. Move the flashing cursor to the (5) DISPLAY check item.
- 2. Press F1 [exec] to start the test.
- 3. When the test is completed, press any key to return to the self-test setting screen.



### 11.7.6 DAT Check

- · This test checks whether the DAT drive and the 8845 main unit are communicating properly.
- · The result is displayed as follows. (OK: Passed, NG: Failed)

#### Method Screen: SYSTEM (SELF CHECK)




- 1. Move the flashing cursor to the **(6) DAT check** item.
- 2. Press Fl [ exec ] to start the test.



During the test, all keys are disabled.

3. When the test is completed, press any key to return to the self-test setting screen.



# 11.7.7 D/A Unit Output Check


- · This item is available when the 9539 D/A OUTPUT UNIT is installed in the expansion slot.
- · Use an oscilloscope or similar to check the waveform.

#### Method Screen: SYSTEM (SELF-TEST)

- 1. Move the flashing cursor to the (7) D/A OUTPUT check item.
- 2. Press the F1 [exec] key to start the test.
- 3. Items for 0 V to  $\pm 6.4$  V DC and sawtooth waveform (12.8 Vp-p, approx. 0.3 Hz) are displayed.


Move the flashing cursor to the respective item and press [F1] [exec].

- 4. The indication **Output active** appears. When the function key for channel 1 (F2) or channel 2 (F3) is pressed, the display appears in reverse and the waveform is output.
- 5. Press the STOP key to terminate the self test.




# 11.8 Interface Settings

- · Serves to set up the optional GP-IB interface and SCSI interface.
- This item is available when the 9537 GP-IB INTERFACE or 9538 SCSI INTERFACE is installed in the expansion slot.
- · For details on setting method, refer to the Instruction Manual of each optional units.



GP-IB Setting Screen



SCSI Setting Screen

#### 7070 mode:

By connecting the HIOKI 7070 WAVEFORM GENERATOR and the 8845 using the GP-IB interface, the waveform data of the 8845 can be transferred to the 7070.

The HIOKI 7070 WAVEFORM GENERATOR can be purchased in Japan only.

# Chapter 12 Printout of Waveform Data and Processing Data


(For all functions)


# 12.1 Overview

- Waveform data can be printed out in two formats: waveform or numeric.
- A smooth print function is available for waveform printout.
- The following seven printing modes are available:
  - · Normal print (manual)
  - · Normal print (auto)
  - · Real-time print
  - · Partial print
  - · Screen hard copy
  - · A4 print
  - · List print


# 12.2 Selecting Waveform or Numeric Print

- · This item lets the user select waveform or numeric print.
- · Making this setting is required for normal print, real-time print, and partial print.






**Method** Screen: STATUS (page 1) in the memory recorder and recorder functions, STATUS (page 3) in the FFT function



Memory Recorder Function


- 1. Move the flashing cursor to the **print mode** item.
- 2. Use the function keys to make the selection.




Meaning

: Perform waveform print


: Perform numeric print



3. When numeric was selected in step 2, specify the data sample interval to be used.



Recorder Function



When numeric is selected in FFT mode, the number of output data is fixed and depends on the analysis type.


NOTE


Item		Data
Storage waveform Auto correlation function Cross-correlation function Impulse response		1000
Octave analysis	1/1 octave	6
	1/3 octave	16
Other functions		401

FFT Function


# 12.3 Using the Smooth Print Function

- · When waveform print is selected, the smooth print function can be used.
- · When smooth print is enabled, dot density along the time axis increases by a factor of 2, to achieve a smooth waveform shape. Print speed will decrease.
- This option can be selected when using the memory recorder or recorder function.






Method Screen: STATUS (page 1) in the memory recorder and recorder functions




Memory Recorder Function



Recorder Function

- 1. Move the flashing cursor to the **smooth print** item.
- 2. Use the function key to make selection.



During real-time printing, the smooth print setting has no effect.

# 12.4 Print Settings on SYSTEM Screen

- Assign channel number to waveform for printout ( Section 11.4.4)

  Waveforms can be printed out with channel markers.
- Intermittent printing ( Section 11.4.10)

  When interpolation is set to "line, intermittent printing can be carried out.
- Add comment to printout ( Section 11.6)
   Titles and channel comments can be appended to the printout.

# 12.5 Printing Procedure

The following seven printing modes are available:

- (1) Normal print (manual) (PRINT key, DISPLAY screen)
- (2) Normal print (auto) (set with STATUS screen)
- (3) Real-time print (set with STATUS screen)
- (4) Partial print (A/B cursors, PRINT key, display screen)
- (5) Screen hard copy (COPY key)
- (6) A4 print (FEED key + COPY key)
- (7) List print (PRINT key, any screen except display screen)

### 12.5.1 Normal Print (Manual) (All Functions)

- This mode serves to print waveform data from the internal memory or stored on tape, or processing results.
- Memory recorder

Measurement data from one measurement (entire recording length) are printed.

Recorder

If recording on tape was carried out:

Data read from tape (entire recording length) are printed.

If recording on tape was not carried out:

Last data set stored in memory before the end of measurement is printed.

• FFT

Processing results for one processing run are printed.

- SYSTEM screen "Setup" can be used to set:
- Time axis display ( Section 11.4.5)
- Grid ( @ Section 11.4.3)
- Channel number for waveform ( @ Section 11.4.4)
- Intermittent print ( Section 11.4.10)
- · Comment ( ☐ Section 11.6)

#### Method Screen: DISPLAY

• After the measurement is completed, press the PRINT key.

Memory, FFT Data for one measurement are printed.

Recorder Last data in memory before end of measurement are printed.

• After measurement data have been read from tape, press the PRINT key at the display screen.


Memory, FFT Measurement results, processing results stored on tape are

printed.

Recorder Measurement data (entire recording length) stored on tape

are printed.

- · Since data are stored, they can be printed as often as desired.
- · When magnification/compression was used, the printout reflects this condition.



NOTE

Waveform


If gauge print was selected at the SYSTEM screen, the number of gauges for the X axis of the X-Y plot is restricted to 2 channels.

Numeric


# 12.5.2 Normal Print (Auto) (Memory Recorder, FFT)

Printing is carried out automatically when a measured waveform is displayed on the screen.

Method Screen: STATUS




Memory Recorder Function



FFT Function

- 1. Move the flashing cursor to the auto print item.
- 2. Use the function keys to make the selection.



- 3. Press the DISP key to call up the display screen.
- 4. Press the START key to start the measurement.

  Printout starts when waveform is displayed on screen.




If gauge print was selected at the SYSTEM screen, the number of gauges for the X axis of the X-Y plot is restricted to 2 channels.

# 12.5.3 Real-Time Print (Recorder Function)

The input waveform is printed out continuously in real time.

#### Method Screen: STATUS, DISPLAY



- 1. Move the flashing cursor to the **recording medium** item.
- 2. Press F2 [ PRINTER ] for the recording target.

OFF
OFF
PRINTER
DAT

Function key

Meaning

 $: \ Disable \ store \ (screen \ display \ only)$ 

: Print data on paper

: Record data on DDS tape

3. When measurement starts, waveform appears on screen and printout starts.

NOTE

- Printer recording format: WAVE
- · When real-time printing is used, magnification on the time axis is fixed, as shown below.
- · When a larger value is set, the setting is automatically corrected at the start of measurement, according to the values shown below.

Time Axis Magnification for Real-time Print

Time axis range (/DIV)	Magnification of the time axis (maximum value)
1.25 ms	1/800
2 ms	1/500
2.5 ms	1/400 (unsettable for 1/500)
5 ms	1/200
10 ms	1/100
20 ms	1/50
50 ms	1/20
100 ms	1/10
200 ms	1/5
500 ms	1
1 s	1
2 s	1
5 s	1
10 s	1
20 s	1
1 min	1
2 min	1
5 min	1
10 min	1
20 min	1
1 h	1

- The waveform color for real-time printing can be normal or light only. (Dark becomes normal, and medium dark become light.)
- · During real-time printing, the smooth print function has no effect.
- · During real-time printing, setting interpolation to **DOT** has no effect (**LINE** will be used).
- Printer recording format: LOGGING (numerical value)
- · When magnification/compression is set to 1/2 or lower, the output value is the envelope maximum value, not the instantaneous value.
- · During real-time printing, the magnification/compression and output increment (minimum value) are limited by the time axis setting, as shown below. (If a smaller value is set, the setting is automatically corrected at the start of measurement, according to the values shown below.)
- · The output interval is for time axis/magnification ratio.

Time Axis Magnification, Output Interval (minimum value) for Real-time Print

Magnifi-							Time	axis	range	(/DI	<b>V</b> )					
cation	1.25 ms	2 ms	2.5 ms	5 ms	10 ms	20 ms	50 ms	100 ms	200 ms	500 ms	1 s	2 s	5 s	10 s	20 s	1 min or more
X1							_			100	100	50	20	10	5	1
×1/2			_	_	_	_	_			100	50	25	10	5	2	1
×1/5					_				100	25	20	10	2	2	1	1
×1/10				_				100	50	20	10	5	2	1	1	1
×1/20					_		100	50	25	10	5	2	1	1	1	1
×1/50		_			_	100	25	20	10	2	1	1	1	1	1	1
×1/100	_	_		_	100	50	20	10	5	2	1	1	1	1	1	1 .
×1/200				100	50	25	10	5	2	1	1	1	1	1	1	1
×1/400	_		100	50	25	10	5	2	1	1	1	1	1	1	1	1
×1/500		100		25	20	10	2	1	1	1	1	1	1	1	1	1 .
×1/800	100	50	50	25	10	5	2	1	1	1	1	1	1	1	1	1
×1/1000	25	50	25	20	10	5	2	1	1	1	1	1	1	1	1	1
×1/2000	25	25	20	10	5	2	1	1	1	1	1	1	1	1	1	1
×1/5000	10	10	5	2	2	1	1	1	1	1	1	1	1	1	1	1
×1/10000	5	5	2	2	1	1	1	1	1	1	1	1	1	1	1	1
×1/20000	2	2	2	1	1	1	1	1	1	1	1	1	1	1	1	1
×1/50000-	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

Example

When 20 ms/DIV,  $\times 1/100$ :

Because of 50 sampling interval;  $20 \text{ ms} \div 1/100 = 2 \text{ s/DIV}$  (1 DIV = 100 sampling), the data of 1 second interval is output.

# 12.5.4 Partial Print (Memory Recorder, Recorder)

- This function prints the waveform between the A and B cursors (vertical or trace cursors).
- · Memory recorder Specified range (out of entire data recorded from a measurement) is printed.
- · Recorder

If recording on tape was carried out:

Specified range (out of entire data read from tape) is printed.


If recording on tape was not carried out:

Specified range (out of last set of data in memory) is printed.

- The function is available also when the A/B cursors are currently outside the range displayed on screen.
- For details regarding the use of the A/B cursors, refer to section 19.2.
- Printing is possible also when the print format is currently set to "numeric".

#### Method Screen: DISPLAY

- 1. Position cursor A at the start point of the range to be printed.
- 2. Move cursor B to the right. When the cursor is at the rightmost edge of the screen, the waveform scrolls to the left, and cursor B scrolls with it.
- 3. Specify the end point of the range with cursor B. Then press the PRINT key. The specified range is printed, also if cursor A is currently off screen.



NOTE


- · If gauge print was selected at the SYSTEM screen, the number of gauges for the X axis of the X-Y plot is restricted to 2 channels.
- The range is printed also if the positions of cursor A and cursor B are reversed.
- · If the horizontal cursor is selected, it is printed along with the waveform. (Partial print is not carried out.)
- · When real-time printing is carried out, the waveform is printed together with the cursor. (Partial print is not carried out.)


# 12.5.5 Screen Hard Copy (All Functions)

The display contents of the STATUS screen, CHANNEL screen, display screen, SYSTEM screen, and DAT control screen can be printed out as is.

#### Method

- 1. Call up the desired screen.
- 2. Press the COPY key.





NOTE


The screen hard copy function is not available during measurement or during playback of data from tape.


# 12.5.6 A4 Print (Memory Recorder, Recorder)

- · This function prints the waveform range shown on the display, along with the active settings, on an A4 size ( $210 \times 297$  mm,  $8.27 \times 11.69$  in.) printout.
- · If the A and B cursors are displayed on the screen, they are also printed.

#### Method Screen: DISPLAY

Call up the desired display screen and press the FEED key and COPY key simultaneously. (Press and hold the FEED key and then press the COPY key.)






A 15 DIV segment of the waveform shown on the display is printed.


# 12.5.7 List Print (All Functions)

The settings for the various functions made with the STATUS screen, CHANNEL screen etc. can be printed out in list format.

Method Screen: Respective function setting screen, except DISPLAY Screen

While the setting screen (STATUS, CHANNEL, SYSTEM, DAT) is displayed, press the PRINT key.






# 12.5.8 Paper Change During Printing

If the paper runs out during printing, or if the printer lever is raised, the following action should be performed.

#### Method



- 1. Insert new printer paper and raise the printer lever ( section 4.6)
- 2. Press the PRINT key.




- · During normal print (manual), partial print, screen hard copy, A4 print, and list print, printing resumes from the point where it was stopped.
- During real-time printing, the data that were captured during the time when the printer is stopped are not printed.
- · During normal print (auto) with trigger mode set to **REPEAT**, no data recording is carried out during the time when the printer is stopped. After paper has been inserted and the PRINT key pressed, the rest of the data is printed, and then the measurement resumes.

# 12.6 Reading the Display and Printout


The relationship between the display indication and printout for the various functions is shown in this section.

#### Memory recorder function


- (1) Y-T screen (dual in this example)
  - Display



#### Normal print




#### · A4 print




15 DIV segment (same as on display) is printed.

## (2) X-Y screen (X-Y dual)


Display



Normal print



#### • A4 print




#### (3) Numeric printout


									Logic
Trig-time:	197-04-	-04 11:47:	51						
TIME	CH1 CH9	CH2 CHI9	CH3 CHII	CH4 CH12	CH5 CH13	CH6 CH14	CH7 CHI5	CHS CH16	A B C D 1234 1234 1234 1234
Es:	53. 125mV	2.2281 V	2. 2156 V	25. 636aV					1818 0101
+1.25ms	2. 1313 V	2.7656 V	2.7531 V	2. 1963 V					1111 1111
+2.5ms	3.7758 V	2.7406 V	2.7281 V	3. 7589 V					1111 1111
+3.75ms	4. 6438 V	2.1500 V	2. 1344 V	4.6188 V	*******				1111 1111
+5ns	4.5250 V	1.1183 V	1. 1031 V	4.5880 V	******				0101 1010
+6.25ms	3. 4563 V	-118.75 <sub>N</sub> V	-134.39nV	3.4313 V				*******	0101 1010
+7.5ms	1.6750 V	-1. 2969 V	-1. 3125 V	1.6500 V			***		0101 1010
+8. 7Ems	-437.58nV	-2. 1594 V	-2.1750 V	-465. 63nV					9888 6989
+18ms	-2.4188 V	-2.5156 V	-2.5344 V	-2. 4438 V				********	8029 6020
+11. 25ms	-3.8375 V	-2.2969 V	-2.3125 V	-3.8656 V					8080 6080
+12. 5ns	-4. 3813 V	-1.5426 V	-1.5594 V	-4. 4125 V					0000 0000
+13.75==	-3.9375 V	-415. 63nV	-428. 13eV	-3. 9656 V					0000 0000
+15es	-2.5969 V	834. 38mV	521.88nV	-2.6250 V		*******			0293 0023
+16. 25ras	-662.58mV	1.9375 V	1.9219 V	-687.50mV					1010 0101
+17.5ms	1, 4563 V	2.6469 V	2.6344 V	1. 4344 V			*****	*******	1111 1111
+18.75ms	3.2969 V	2.8156 V	2.8831 V	3.2750 V			***************************************	*******	1111 1111
+28ms	4. 4531 V	2. 4831 V	2.3906 V	4. 4313 V					1111 1111
+21. 25ag	4.6683 V	1.5000 V	1. 4844 V	4.6588 V					m
+22.5ms	3.9031 V	296. 88nV	284. 38eV	3.8844 V					
-92 TFees	2. 3250 V	-928. 13nV	-943. 75nV	2.3969					

#### Recorder function


- (1) Y-T screen (dual in this example)
  - Display




· Normal print, real time print



#### · A4 print




#### (2) Numerical recording




#### FFT function


## Display



#### · Normal print



#### · Numeric printout



# E

# Chapter 13 Storing Data on DDS Tape/ Reading Data From DDS Tape

# 13.1 Overview

- · Data can be stored on commercially available DDS tape.
- · Waveform data, measurement setting data, and waveform parameter evaluation data can be stored in separate files.
- · Stored data can be used in two ways: "data read" or "playback".


# 13.2 Using the Tape

#### Tape type


- · Use only tapes marked DDS (Digital Data Storage) with this unit.
- · Conventional DAT tapes designed for audio applications are not suitable, because the use of such tapes can lead to data reliability problems.

#### Write protection

- · The DDS tapes have a provision for write protection which serves to prevent accidental erasure or overwriting of data.
- · When wishing to record or erase data, the tab on the tape must be set to write enable first.



The write protect or write enable status of the tape is shown on the DAT screen, below the function key display.






- Observe the following precautions for using DDS tape.
- · Do not turn off power to the 8845 while a tape is inserted. Otherwise the tape may be damaged or data may be lost.
- · Do not use tapes which give frequent errors. Otherwise the recording time may become very long, and data may be partially or entirely lost.
- Tape format
- · Always format to use a new tape.
- · <u>Do not turn off power to the 8845 while a tape is formatted.</u> The tape may be unusable.

# 13.3 DAT Drive Operation

#### Inserting the tape

Insert the tape into the tape slot with the DDS logo facing to the right, as shown in the illustration.




#### Removing the tape

#### Method 1

(DAT screen)

- 1. Press the FILE key to call up the DAT screen.
- 2. Press the [tape ope ] function key for tape operation (2/2).
- 3. Press the [eject] function key.

#### **Method 2** Press the EJECT button on the DAT drive.




NOTE

- · Before turning the unit off, be sure to remove the tape.
- · Depending on the usage condition of the tape, up to 5 minutes may elapse before the tape is ejected.

#### **DAT** drive indicators

The function of the DAT drive indicators is shown below.

Indicator	Status	Meaning				
TAPE	Lit	Tape is inserted.				
(green)	Flashing slowly	Tape is damaged or worn. Perform head cleaning ( F Section 23.1). If this brings no improvement, use a different tape.				
	Flashing rapidly	Normal write could not be performed (error).				
BUSY	Lit	Read or write operation is being performed				
(amber)	Flashing rapidly	DAT drive is defective, or condensation has occurred.				
TAPE+BUSY	Flashing slowly	Recorded audio tape was inserted.				



## Drive head cleaning

Use a commercially available cleaning tape. For details, see Section 23.1.


# 13.4 Displaying File List and File Information


- · You can display a list of files contained on a tape (file list).
- · You can check the contents of stored files (file information).
- · To use these functions, first insert a tape into the drive.

# 13.4.1 Displaying a File List

File name, file type (mode), and file date are displayed.

Method Screen: DAT





• File type (mode) display

M WAVE Memory recorder: M WAVE: Waveform data, Recorder: R measurement settings FFT: F FUNC : Measurement settings AREA: Evaluation area

Depending on the usage condition of the tape, up to 3 minutes may elapse before the file list is

#### Error correction

- · When the list display is called, the error correction count (number of read errors that have been corrected) is shown above the function key
- · When the drive head is dirty or the tape is damaged, the error count will increase.


# 13.4.2 Displaying File Information

The measurement settings that were used to store the file and title comments can be displayed.

#### Screen: DAT Method


- 2. Move the flashing cursor to the desired file, and press F1 [ Information ].


#### Moving the flashing cursor



STOP key: To first file

START key: To last file





Flashing cursor

NOTE

Depending on the usage condition of the tape, up to 3 minutes may elapse before the information is displayed.


# 13.5 Storing Data on a DDS Tape

# 13.5.1 Storing Memory Recorder and FFT Data

The following three store types are available.

- ① Storing data on tape after measurement is completed
- ② Storing data automatically during measurement (auto store)
- ③ Storing data between cursors after measurement is completed (memory recorder function only)
- (1) Storing data on tape after measurement is completed
  - · Waveform data gained with the memory recorder or FFT function are stored on tape.
  - · Measurement setting data and evaluation area data are stored in separate files.

Method Screen: Memory recorder or FFT→DAT



- 1. Record the waveform with the memory recorder or FFT function.
- 2. Insert a tape in the unit.
- 3. Without changing the measurement function, press the FILE key and then the F1 [ File list ] key.
- 4. When the list is displayed, press F3 [ SAVE ].

• 1/2 (or 1/3)
Function key
display

Information

Meaning

Display file information ( Section 13.4.2)


LOAD

SAVE


: Read data (CF Section 13.6.1)

Store data

: Switch to 2/2 (or 2/3)



5. Select the file type with the function keys.



NOTE

- The waveform data, settings, and evaluation area are stored only for the currently selected function.
- The stored data content depends on the file type ( Section 13.5.4).
- When the memory is segmented in the memory recorder function.

Press F1 [ wave ] to select the type of save.

Function key display Meaning


1 BLOCK

ALL BLOCKS

Store only waveform data selected.

Store all waveform data recorded in each blocks.


· When F2 [all blocks] is selected, files for all blocks as well as a file for reading the data in one operation (SQ\_ALL for sequential save and ML\_ALL for multi-block save) are created.



6. Enter the file name.

· Move the flashing cursor to the **file name** item and press F2 [enter name]. (For information on entry procedure, see Section 11.6.1.)

• If no file name is entered, a file name is assigned automatically ( Section 13.5.3). Input the file name.



(MEMORY) 97-4-4 \*\*\* DAT \*\*\* 10:11:24 SAVE command (exec) key to save. M-WAVE file name: [ 7 correction read: 13 ↓ × 12 ↓ 0 14 15 16 0 0 0 write: File list file name date time 0 X ot sav CH 1 CH 16 → (0 → 28, 374KB) 1,924,516KB free enable

7. When "waveform data" was selected, move the flashing cursor to the channel item and select the channel whose data are to be stored.

C: store, X: not store

Function key display Meaning

Execute the store process

(exec): Store data for selected channel

not save: Do not store data for selected channel


Store data for all channels

Return to file list screen


8. Press the Fi [ exec ] to store the data on the tape.

- (2) Storing data automatically during measurement
  - · After storing the input waveform in memory and displaying it on the screen, it is stored automatically on tape (data are stored each time when a waveform is captured).
  - · Waveform data (all data in all units in use) and measurement settings (WAVE file) are stored.
  - · Insert a DDS tape into the DAT unit before starting the measurement.






- 1. Move the flashing cursor to the **auto save** item on the STATUS screen.
- 2. Use the function keys to make the selection.



- 4. Start the measurement. Waveform data are recorded in memory, displayed on screen, and then stored automatically on tape.

- (3) Select the data between cursors. (memory recorder function)
  - · After recording the waveform data in memory recorder function, the data to be stored is specified by the A and B cursors.
  - · Using the vertical cursor or trace cursor specified range.

#### **Method** Screen: Memory recorder → DAT screen)



The data between A and B cursors is stored.


- 1. Records the waveform data in memory recorder function.
- 2. Specify the range to be stored using the A and B cursors (vertical or trace cursors).
- 3. Store data reffering to the step 3 to 8 in Section 13.5.1 (1).

# 13.5.2 Storing Recorder Data

There are following two methods of storing

- (1) Storing waveform data and measurement settings
- (2) Storing settings only
- (1) Storing waveform data and measurement settings
  - · Waveform data are stored on tape at the same time as being displayed on the screen.
  - · Waveform data and measurement settings are stored.
  - · Insert a DDS tape into the DAT unit before starting the measurement.

#### Method Screen: STATUS (page 1)



- 1. Move the flashing cursor to the **recording medium** item.
- 2. Press F3 [ DAT ].

Function key display

Disable data recording

PRINTER: Print waveform data

Store waveform data on tape

Standby: Move drive head to end of last file

3. Move the flashing cursor to the **file name** item and enter the file name (  $\square$  Section 11.6.1).

4. Start the measurement. Waveform data are displayed on screen and simultaneously stored on tape.



- · It is not possible to store only waveform data recorded in memory.
- This is useful for reading in waveform data and performing a search ( F Section 20.4).

#### **Event mark**


- · So-called "event marks" can be placed in the file, denoting the date and time and the elapsed time since the start of recording.
- · When playing back a waveform, playback can be started or stopped at these points.
- · It is useful to search the display position after loading a waveform.


  ( F Section 20.4)
- Method 1 During recording (while START key LED is lit), press the START key.

  Method 2 Apply a signal to the START connector ( Section 21.2).
  - (2) Storing measurement settings only

    Only the settings at the current point are stored on tape.

Method Screen: DAT (recorder function)





- 1. Make the settings for the recorder function.
- 2. Insert a tape into the DAT drive.
- 3. Press the FILE key and press the F1 [ File list ].
- 4. When the list is displayed, press F3 [ SAVE ].
- \*\*Hen the list is displayed, press [F3] [SAVE].

  \*\*1/2 (or 1/3)

  Function key display

  | Display file information (F Section 13.4.2)

  | Read data (F Section 13.6.1)

  | SAVE | Store data | Section 13.6.1 |
  | Section 13.6.1 | Section 13.6.1 |
  | Sec

If no file name is entered, a file name is assigned automatically ( Section 13.5.3).

6. Press the F1 [exec] key to store the current settings on tape.

# 13.5.3 Automatic File Name Assignment

If no file name is input when storing data, the file name is assigned automatically, as follows.

```
! (Function) — (File number)

MEM (Memory recorder) Sequential number (number of first file -1)

REC (Recorder) 000 to 999

FFT
```

## 13.5.4 File Contents and Size

- The contents of a file depend on the file type (WAVE, FUNC, or AREA) and the function of the 8845.
- The size of a file can be roughly calculated, using the equations shown in this Section.
- (1) File contents
  - : Items stored in the file are marked with a circle
- ① STATUS screen settings

Memory recorder

Setting item	Mode	WAVE	FUNC	AREA
Function		0	6	0
Time axis range		•	<b>©</b>	
Recording length		•	<b>©</b>	
Display format		0	0	
Interpolation			•	
Roll mode			<b>®</b>	
Superimpose			<b>©</b>	
Printout format	~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~		<b>®</b>	
Logging cycle			0	
Smooth print			•	
Auto print			0	
Auto save			<b>©</b>	
Trigger setting		6	0	
Memory segmentation	Sequential	•	0	
	Multi-block	0	•	
Averaging			•	
Waveform evaluation	Setting	0	•	
Eva	luation area			0
Waveform parameter	Calculation		•	
	Evaluation		•	
Waveform processing			•	

#### Recorder

Setting item	Mode	WAVE	FUNC
Function		•	•
Time axis range		•	•
Recording time		•	•
Display format			•
Interpolation			•
Recording target	DAT		•
Printo	ut format		•
Loggi	ing cycle		•
Microphone channel		•	•
Trigger setting		•	•
Waveform parameter Calculation			•
Evaluation			•

#### FFT

Setting item	Mode	WAVE	FUNC	AREA
Function		•	•	•
FFT channel mode		•	•	
Frequency range		•	•	
Window function		•	•	
Display format		•	•	
Averaging		•	•	
Reference data		•	•	
Peak display			•	
FFT analysis mode		•	•	
Analysis channel		•	•	
X-axis, Y-axis		•	•	
Display scale		•	•	
Octave filter		•	•	
Trigger setting		•	•	
Interpolation			•	
Printout format			•	
Auto print			•	
Auto store			•	
Waveform evaluation	Setting	•	•	
Evaluat	ion area			•

## ② Display screen settings

Function	Men	nory reco	Recorder		
Setting item	WAVE	FUNC	AREA	WAVE	FUNC
Time axis magnification/ compression		<b>(a)</b>			<b>©</b>

# ③ CHANNEL screen settings

Function	Memory recorder			Reco	order	FFT		
Setting item	WAVE	FUNC	AREA	WAVE	FUNC	WAVE	FUNC	AREA
Input format	0	0		•	0	0	0	
Display color	0	6		8	<b>Ø</b>	—	_	
Display position	0	0		0	<b>@</b>			_
Voltage range	•	6		0	0	<b>®</b>	0	
Input coupling	<b>®</b>	0		•	<b>®</b>	0	<b>©</b>	
Range magnification/ compression	<b>©</b>	<b>©</b>		•	<b>©</b>	•	•	
Zero position	•	<b>©</b>		•	0	0	•	
Variable setting	•	0		•	•	•	0	
Filter	•	0		0	<b>®</b>	<b>©</b>	•	
Thermocouple type	•	<b>③</b>		0	•	<b>Ø</b>	<b>®</b>	
Vernier function	0	0		•	•	0	0	

## SYSTEM screen settings

Function	Memory recorder			Reco	order	FFT		
Setting item	WAVE	FUNC	AREA	WAVE	FUNC	WAVE	FUNC	AREA
Number of units in use	6	<b>®</b>		0	0	0	8	
Start backup		0			0		0	
Grid		0			<b>@</b>		0	
Channel marker		<b>©</b>			<b>®</b>			
Time axis display		•			6		•	
List and gauge		۵			•		0	
Backlight saver		0			•		•	
Display color pattern		0			•		•	
Volume		0			•		0	
Intermittent print		<b>(a)</b>			<b>©</b>		•	
Scaling	۵	0		0	•	<b>©</b>	0	
Comment Setting	0	0		<b>®</b>	•	0	•	
Characters	•	<b>©</b>		<b>®</b>	•	<b>©</b>	•	
Interface		•			<b>©</b>		•	

#### (2) File size calculation

- · The approximate file size can be calculated as follows.
- · The "file number" is the number of the stored file or the file to be stored, as counted from the first file.



When the remaining space on the tape drops to about 15 M bytes, new data cannot be stored.

#### WAVE (waveform) file

Memory recorder function

When only 8916 - 8919 units are used:

File size (bytes) = number of units in use 
$$\times$$
 recording length (DIV)  $\times$  200 + (10 KB + file number  $\times$  128)

When only 8916 - 8919 units and 8927 units are used together, or only 8927 units are used:

File size (bytes) = number of units in use 
$$\times$$
 recording length (DIV)  $\times$  400 + (10 KB + file number  $\times$  128)

· Recorder function

When only 8916 - 8919 units are used, or when one 8927 unit is used in one channel:

```
File size (bytes) = number of units in use \times recording time (s)/
time axis (s/DIV) \times 200 + (10 KB + file number \times 128)
```

When only 8916 - 8919 units and 8927 units are used together, or only 8927 units are used:

File size (bytes) = number of units in use 
$$\times$$
 recording time (s)/  
time axis (s/DIV)  $\times$  400 + (10 KB + file number  $\times$  128)

FFT function

File size differs, depending on the analysis type.

Maximum file size (bytes) =  $60 \text{ KB} + \text{file number} \times 128$ 

#### Func (setting ) file

File size (bytes) = 10 KB + file number  $\times$  128

#### AREA (evaluation area) file


File size (bytes) = 40 KB + file number  $\times$  128

# 13.6 Reading Data From DDS Tape


# 13.6.1 Reading Stored Data

This procedure reads data that were stored with the memory recorder, recorder, or FFT function.

Method Screen: DAT



- 1. Insert the tape with the desired files into the DAT drive.
- 2. Press the FILE key and then the F1 [File list] key.
- 3. When the list is displayed, use the CURSOR keys to select a file and press the F2 [LOAD] key.




4. The file information is displayed.




Depending on the usage condition of the tape, up to 3 minutes may elapse before the information is displayed.

#### When M\_WAVE



# When other than M\_WAVE (Example: R\_WAVE file)



#### M\_WAVE file

(1) Select either (exec) or overwrite

(exec) The saved data, time axis, and record

length are read. (The data saved in

memory is discarded.)

overwrite Data saved in memory is overwritten

with the new data being read. (Data is read using the most-recently set

time axis and record length.)

Function key display Meaning

(exec)

: Normal reading is performed.

The screen for overwrite and reading settings appears.

(2) When "overwrite" is selected

Move the flashing cursor to select the channel into which to read the data.

If reading is not performed, decrease the channel number and display  $\boldsymbol{X}$ .

Function key display Meaning



: Execute the overwrite process



: Increase channel number



: Decrease channel number



Return to file list screen

(3) After specifying the channel, press the F1 [overwrite] key to read.

NOTE

- If the same number channel was selected, data in channels with lower numbers are overwritten. (If CH1 → 1, CH2 → 1 was selected, CH1 data are overwritten by CH2 data.)
- Files other than M\_WAVE files
   Press the F1 [exec] key.
- 5. When read-in is completed, the respective function display appears on the screen.

## 13.6.2 Playback of Stored Data

- · Waveform data captured with the recorder function can be continuously displayed on the screen in real time.
- · If the D/A output unit 9539 is installed, the analog waveform can be displayed in real time ( real time ( ).




The following data cannot be played back:

- · Waveform data recorded with external sampling
- · Waveform data recorded with a sampling frequency of 40 kHz or above (2.5 ms/DIV)

During playback, the waveform is not displayed.

#### Method (DAT screen)



- 1. Insert the tape with the desired files into the DAT drive.
- 2. Press the FILE key and then the F1 [ File list ] key.
- 3. When the list is displayed, use the CURSOR keys to select a R\_WAVE and press the F2 [ PLAYBACK ] key (3/3).
  - 3/3 Function key

ion key display Meaning



Display file information ( Section 13.4.2)





: Play back data

Record data stored on a tape in the memory recorder or FFT function.(©F Section 13.13)



: Switch to page 1/3






4. Make the settings on the playback command screen.


Move the flashing cursor to the respective items and make the settings with the function keys or the JOG control.

- ① Set start time and end time.
- Time setting (from 00:00:00 at beginning of file)


  Move the flashing cursor to the **start time** and **end time** items and make the settings with the function keys or the JOG control.




- Event mark setting (making time setting using event marks (\*) registered during recording) ( Section 13.5.2)
- start time and end time items can be entered using the event mark time.
- · Press the F1 [ start time ] or F2 [ end time ] key to activate the input mode for the respective item. Select the event mark with the JOG/SHUTTLE control and the CURSOR keys and make the entry by pressing F3 [ set ].




When "\*" is displayed to the left of **start time** or **end time**, a more detailed time value than the displayed value (ms,  $\mu$  s) is available.







2 Make "Playback mode" settings.

- 3 Set speaker output.
- · Select the channel data which are to be output from the speaker.
- · Channels for which a voice memo is recorded are marked with microphone.
- The volume can be set using the volume option under "SETUP" on the SYSTEM screen ( Section 11.4.9).



- ④ Set monitor output (monitor output channel 1, 2)
- This option appears when the D/A output unit 9539 is installed.
- $\cdot$  The maximum waveform output from the output channel is  $\pm 6.4~\mathrm{V}$ .
- The setting determines whether the data are output from channel 1 or channel 2 of the D/A output unit.





- 5. Move the flashing cursor to the **execute** position and press the Fl [exec] key.

  The voice is played back and then waveform is output from the D/A output unit without changing the screen.
- 6. When playback mode is set to REPEAT, press the STOP key when you wish to stop playback.


## NOTE

When playing back waveform data as sound from the speaker, the waveform will not be recreated faithfully, due to limitations such as D/A resolution (8 bit), post- filtering (cutoff frequency  $\doteqdot$  8 kHz, -48 dB/oct), and characteristics of the built-in power amplifier and speaker.

- Read data from playback screen
- · Select the range for reading data.
- · Carry out playback. The point where playback is interrupted can be specified as start time and end time.

#### Method 1


Specify range to read data.




- 1. Follow the steps 1 to 4 in Section 13.6.2, "Playback of Stored Data."
- 2. Move the flashing cursor to the **execute** position and press the F3 [LOAD] key.

#### Method 2

Playback and specify the point to interrupt playback to start and stop times to read.



Interrupt point mark





- 1. Follow the steps 1 to 4 in Section 13.6.2, "Playback of Stored Data."
- 2. Move the flashing cursor to the **execute** position and press the Figure [ exec ] key.
- After playback has started, press the STOP key at a desired point to interrupt playback.
   A mark is placed at that point.
- 4. Move the flashing cursor to the start and stop time items.
- 5. Pressing the [to pause] key changes the start and stop time to the point to interrupt playback.
- 6. Move the flashing cursor to the **execute** position and press the F3 [LOAD] key.

## 13.7 Searching file

Searches file.

#### Method (DAT screen)





- 1. Display the file list on the DAT screen.
- 2. Press the F2 [SEARCH] key on the function indication 1/2 or 1/3.
- · 2/2 (or 2/3) Function key display

Meaning

FILE TITLE <u>Information</u> A PROPERTY OF THE PROPERTY OF

Displays file information ( F Section

13.4.2)

: Searches file

SEARCH ₽∙f sort

Sorts file ( F Section 13.8)

tape ope 2

: Eject, prepare to record, erase

: Switch 1/2 (or 3/3) page to page 1/2

3. Press the F1 [[enter] key to input the character to search.

Function key display

Meaning



Enter character input mode




: Returns to file list screen


- 4. Press the | F3 | [end] key to search the file and display on the screen.
- 5. Pressing | F2 | [↑] or | F3 | [↓] key moves flashing cursor on the searching file.

## 13.8 Sorting files

Sort the files by type.

Method (DAT screen)





- 1. Display the file list on the DAT screen.
- 2. Call up screen 2/2 (or 2/3) with the function keys, and then press the F3 [sort] key.

· 2/2 (or 2/3) Function key Meaning display

FILE1 FUNC.

tape ope

A000 B00000 C0000

file name

Display file information ( F Section 13.4.2)

Information FQ. : Search file ( F Section 13.7) SEARCH

: Sort file sort : Eject, prepare to record, erase

 $\sqrt{2}$ : Switch to 1/2 (or 2/3) to page 1/

3. Select the type of sorting.

Function key Meaning display

> NO. 1 ... 2 ... 3 ... 1 Sort files by number in increasing order (old files last). ascend

NO.10 ... ↓ Sort files by number in descending order (new files last). descend

: Sort files by type. mode

: Sort files in alphabetic order.

: Returns to the file list screen.


## 13.9 Deleting Stored Data

This function erases all file data stored on a tape.


There are three methods of deleting

- · Deletes all file data
- · Deletes specified and following file data
- · Deletes specified data


#### Method (DAT screen)



- 1. Insert the tape into the DAT drive.
- 2. Press the FILE key and then the F1 [File list] key.
- 3. Call up screen 2/2 (or 2/3) with the function keys, and then press the F4 [ tape ope ] key.



4. Call up screen 2/2 with the function keys, and then select method of deleting.



5. When F2 [Del from] or F3 [Del here] were selected, move the flashing cursor to the start file or the file to be deleted, using the jog control or the CURSOR keys.

6. Press the F1 [exec]
Pressing this key again deletes files.





- · "Del here" means that the currently specified file is deleted from the file list. The data themselves are not deleted.
- $\cdot$  When "clear all" is selected, error indications are also cleared.
- · If a tape was not reformatted after performing "clear all", an error may occur when restoring data after a power failure. To prevent this, reformat the tape as described in Section 13.11.

## 13.10 Renaming File


Renames a file.

Method (DAT screen)





- 1. Display the file list on the DAT screen.
- 2. Press the F4 [tape ope] key on the function indication 1/2 or 1/3.
- · 2/2 (or 2/3) Function key Meaning display Display file information ( IF Section FUNC. TITLE 13.4.2)<u>Information</u> : Search file ( F Section 13.7) SEARCH Sort file ( Section 13.8) sort : Eject, prepare to record, erase tape ope 1 2 : Switch to 1/2 (or 2/3) to page 1/
- 3. Press F3 [rename] key with function key display 1/3.
- 4. Press F2 [enter] key to input a new file name. (See Section 11.6.1, "Comment and File Name Entry Procedure")





5. Press F1 [ exec ] key to change the file name.

## 13.11 Reformatting a Tape

Delete all file data and reformat a tape. Error indications are also cleared.

#### Method (DAT screen)





- 1. Display the file list on the DAT screen.
- 2. Call up screen 2/2 (or 2/3) with the function keys, and then press the F4 [tape ope] key.
- · 2/2 (or 2/3) Function key display

Meaning

FUNC. TITLE Information. 13.4.2)

Display file information ( Section

: Search file ( Section 13.7)

**andline** 

SEARCH

: Sort file ( F Section 13.8)

tape ope 2

: Eject, prepare to record, erase

- Switch to 1/2 (or 2/3)
- 3. Press | F2 | [reformat] key with 3/3 function key display.
- · 3/3

Function key display

Meaning

restore

Restore the data of a file ( IF Section

13.12)

reformat

Reformat a file



: Display 1/3

: Return to file list screen.

| F1 | [exec] key to format a tape. 4. Press the



The process of reformatting takes a very long time (about 3 hours)


It is not necessary to format again a new tape.

## 13.12 Checking and Restoring File Data

- · When a power failure occurs during recording, data may be damaged. This section describes how to check and restore such data.
- · The procedure can be carried out manually or automatically.

#### Manual operation

Method (DAT screen)



- 1. Display the file list on the DAT screen.
- 2. Call up screen 2/2 (or 2/3) with the function keys, and then press the F4 [tape ope ] key.
- · 2/2 (or 2/3)
  Function key
  display
  Meaning

∮•ां

Display file information ( Section 13.4.2)

Search file ( Section 13.7)

Search file ( F Section 13.7)

Sort file ( Section 13.8)

sort

Graph : Eject, prepare to record, erase


- 3. Press F1 [ restore ] key with function key display 1/3.
- · 3/3
  Function key
  display
  Meaning

: Restore file data damaged.

Reformat a file ( F Section 13.11)

: Display 1/3
: Return to file lest screen.

4. Press F1 [ exec ] key to restore data.



#### **Automatic operation**

Set as following, the recording resumes after checking and restoring data when a power failure occurs during recording.

System screen: start backup function "ON"
Status screen or Display screen in the recorder function: recording target "DAT"

NOTE


- · It may not be possible to completely restore data that were seriously damaged.
- · Depending on the number of files and the amount of data, the check and restore process may require a long time (up to several hours).
- · If a tape was not reformatted after performing "clear all", an error may occur when restoring data after a power failure. To prevent this, reformat the tape as described in Section 13.11.


# 13.13 Recording the Recorder Waveform Data Stored on Tape in Memory Recorder Function/FFT Function

(DATtoMEM/FFT)

Recorder waveform data stored on tape are recorded using the memory recorder function or FFT function.

**Method** (DAT → Memory recorder function or FFT function)





- 1. Insert a tape into the unit.
- 2. Press the FILE key and then press the FI [list] key to display the file list.
- 3. Select "R\_WAVE" file item using the cursor keys, and press the F3 [ DAT→ MEM·FFT ] key (3/3).
- · 2/2 (or 2/3)
  Function key display

  Meaning

  Display file information

Playback data

Playback data


Record a data stored on tape in memory recorder function or FFT function.


 $\begin{bmatrix} 3 \\ \text{to page 1/3} \end{bmatrix}$ : Switch to 1/3


4. Set on the DATtoMEM·FFT command screen. Set the start time and stop time.


Time setting (Specify the start of the file as the time point 00:00:00.)

Move the flashing cursor to the start time or stop time item to set using the jog control or function keys.









#### Event mark setting

Set the time where an event mark (\*) was placed during recording. (See Section 13.5.2)

- · "Start time" and "Stop time" use the time where an event mark was placed.
- · Press the "Start time" or "Stop time" function key to activate the respective input mode, select the event mark with the jog control or CURSOR keys, and enter the time by pressing "Set".

Function key display

Meaning



: Enter the start time input mode



: Enter the stop time input mode



"Start time" and "Stop time" use the time where an event mark was placed.



Switch to the time setting

NOTE

An asterisk to the left of the "Start time" or "Stop time" indicates that the actual time point is specified to a higher resolution (ms,  $\mu$ s) than the displayed value.


- 5. Select function to be recorded. Move the flashing cursor to the **set end** item and press the Fl [set end→MEM] or [set end→FFT] key to enter the specified function.
- 6. Press the START key to start measurement. Data are read from tape and recorded in specified function.
- 7. To release the DATtoMEM·FFT function, move the flashing cursor to the DAT to MEM or DAT to FFT and then press the OFF key.

NOTE

- The sampling cycle for the memory recorder function becomes the same as for the data recorded on tape. (Time axis setting is not possible.)
- The frequency range in FFT function corresponds with the time axis range of data recorded on tape. (Section 8.2.3, "Setting the Frequency Range")
- · When using the DAT to MEM/FFT function, operation is always "Continuous", also when the trigger is set to "Auto".


## 13.14 Preparing to Record

This function moves the drive head to the end of the last file on the tape, so that recording can start immediately. (The same condition exists after list display.)



It can decrease the dead time until the recording start.

#### Method



- 1. Insert the tape with the desired files into the DAT drive.
- 2. Press the FILE key and then the F4 [ tape ope ] key.

· 2/2 (or 2/3) Function key Meaning display Display file information ( Section FILE 1 FUNC. 13.4.2)<u>Information</u> : Search file ( F Section 13.7) SEARCH Sort file ( F Section 13.8) sort <u>ao lémb</u> Eject, prepare to record, erase tape ope  $\sum_{i} 2^{i}$ Switch to 1/2 (or 2/3)

3. Press the F2 [standby] key. The drive head moves to the end of the last file.

## NOTE

- · Depending on the usage condition of the tape, up to 3 minutes may elapse before the information is displayed.
- · It can be operated on the STATUS screen or DISPLAY screen in recorder function

Function key Meaning display



: Move drive head to end of last file



: Rename a file ( F Section 13.10)



: Switch to 2/3

: Eject tape



Return to file list screen


# Chapter 14 Calculating Waveform Data

## 14.1 Overview


- Waveform processing is possible only for the memory recorder function.
- The following operators can be used to define processing equations.
- · Arithmetic operators (+, -, \*, /)
- · Absolute value (ABS)
- · Exponent (EXP)
- · Logarithm (LOG)
- · Square root (SQR)
- · Displacement average (MOV)
- · Parallel displacement on time axis (SLI)
- · 1st and 2nd differential (DIF, DIF2)
- · 1st and 2nd integral (INT, INT2)
- · Trigonometric functions (SIN, COS, TAN)
- · Reverse trigonometric functions (ASIN, ACOS, ATAN)
- Processing results are displayed as a waveform.
- Vertical display scale can be set manually or automatically.

## 14.2 Preparing for Waveform Processing

- The settings are available on the STATUS screen (page 4), only when using the memory recorder function.
- · Press the STATUS key to call up the STATUS screen (page 4).



Method Screen: STATUS (page 4)



1. Move the flashing cursor to the wave calculation item and select ON.

The various setting items are displayed.


Function key display Meaning

Disable waveform processing


Enable waveform processing

- 3. Determine in which channel (CH1 CH16) to display the processing results (Z1 Z8) ( ☑ Section 14.4).
- 5. Set the vertical axis display scale
  ( Section 14.5).
  The setting can be made automatically or by manual input.

- 6. Perform waveform processing.
  - There are two methods for starting waveform processing
  - ① Waveform processing while capturing the waveform
  - 1. Set wave calculation to ON and make the required settings.
  - 2. Press the START key.
  - 3. Processing is carried out on the captured waveform, and the result is displayed on the screen.
  - 4. When auto print is set to ON, the processing results are printed out.



- ② Waveform processing of data in internal memory (loaded from DAT or already captured with memory recorder function)
- 1. Set wave calculation to ON and make the required settings.
- 2. Move the flashing cursor to the **execute** position at the top right of the screen and press the Fi [exec] key.
- 3. Processing is carried on the data stored in memory, and the result is displayed on the screen.



NOTE


- · When recording length is more than 1000 DIV, waveform processing is not possible.
- · When the memory segmentation function is used, waveform processing is not possible.
- · When scaling is set for the channel in which the processing result is to be stored, scaling is not carried out and only the unit is valid.

## 14.3 Defining the Processing Equation


- · Set wave calculation to ON.
- · Eight equations (Z1 Z8) can be defined.

### 14.3.1 Entering the Equation

#### Method




Cursor (move with JOG control)




Flashing cursor (move with CURSOR keys)

- 1. Move the flashing cursor to **Z1** to **Z8**.
- 2. Press Fl [enter eqn] for equation entry.



- 3. Move the flashing cursor to the operator (ABS, EXP,...), channel (CH1 CH16), equation (Z1 Z7), constant (a p), value (0 9, E: exponent) and make the entry with the F1 [set] key.
- The movement range of the flashing cursor is indicated by a border.
- Use the JOG control to move the cursor within the equation.



#### Operators


•	
	For details, see Section 14.8, (2) to (17).
ABS	Absolute value (2)
EXP	Exponential (3)
LOG	$Logarithm \cdots \cdots \cdots (4)$
SQR	Square root (5)
MOV	Displacement average(6)
SLI	Parallel displacement on time axis (7)
DIF	1st differential ······(8)
INT	1st integral(9)
DIF2	2nd differential ······(10)
INT2	2nd integral (11)
SIN	Sine(12)
COS	Cosine(13)
TAN	Tangent (14)
ASIN	Arc-sine (15)
ACOS	Arc-cosine(16)
ATAN	Arc-tangent (17)


#### NOTE

- · For multiplication, always use the "\*" sign.
- · Out of the MOV, SLI, DIF, DIF2, INT, and INT2 operators, up to two can be used in the same equation (for example two MOV operators or one MOV and one SLI operator, etc.).
- · The maximum number of digits for a constant is 30.
- $\cdot$  If division by 0 is specified (1/0), an overflow value is output.
- · Equations are calculated in ascending order, from Z1 to Z8.
- The following data (channel data, equation calculation results) can be used in equations (when 8 units, 16 channels are used).
  - Z1 CH1 CH16
  - Z2 CH1 CH16, Z1
- Z3 CH1 CH16, Z1, Z2
- Z4 CH1 CH16, Z1 Z3
- Z5 CH1 CH16, Z1 Z4
- Z6 CH1 CH16, Z1 Z5
- Z7 CH1 CH16, Z1 Z6
- Z8 CH1 CH16, Z1 Z7


4. When the equations have been input, press the F5 [exit] key.


If there are any syntax errors in the equations (incomplete bracketing, missing "\*", more than two MOV, SLI, DIF, DIF2, INT, INT2 operators, etc.), a "?" is displayed, and the cursor rests on the error, so that the problem can be corrected. When there are no syntax errors, a "=" is displayed.






No syntax error is present





- 5. Enter the constant values.
- · Select the equation with the CURSOR keys, move the flashing cursor to the desired digit, and use the function keys or the JOG control to enter the value.
- The setting range is -9.9999E+29 to +9.9999E+29 (exponent: -29 to +29).



6. Specify the floating decimal point.

If MOV or SLI was used in step 3, the floating decimal point must be specified (  $\square$  Section 14.8.(6), (7)).

#### Function key display Meaning



For MOV (moving average): 1 to 4000


 $\bigcirc$ Ö

10 ₺

: For SLI (parallel displacement): -4000 to +4000

## 14.3.2 Deleting an Equation

#### Method



97- 4- 3 (page4) 13:38:31 wave calculation: (EXEC) **Z**1 22 Z3 Z4 Z5 Z6 27 Z8 Z1=a\* enter egn ∑1=ئي% Z1 = a\*CH1+b Z2 = a\*CH1+b

- 1. Move the flashing cursor to one of the Z1 Z8 items.
- 2. Press | P3 | [ clear eqn ].

Function key display

Meaning

Z1=a\*<sup>©</sup> <u>enter egn</u>

: Enter equation ( F Section 14.3.1)

Z1=نينه <u>clear egn</u>

: Delete equation

Z1=a\*CH1+b Z2=a\*CH1+b

: Copy equation ( F Section 14.3.3)

3. The equation can be deleted.

Function key display

Meaning



: Clear equation




: Do not clear equation


## 14.3.3 Copying an Equation

An equation to which an equation number has been assigned (copy source) can be copied to another equation number (copy target).


#### Method



- 1. Move the flashing cursor to one of the Z1 Z8 items.
- 2. Press F5 [copy eqn].



3. Use the function keys or the JOG control to specify the number of the equation to be copied.



4. Press the F5 [exec] key. The copy source equation is copied to the copy target.



Z1=a\*&

enter egn


Z1=نگ

Z1=a\*CH1+b Z2=a\*CH1+b COPY eqn When the equation in the copy source contains a calculation number that is higher than in the copy target, the copy function is not carried out.


## 14.4 Setting the Channel for Recording Processing Results

- The calculation result of equations Z1 Z8 can be recorded and displayed in a specified channel.
- · Processing results can be recorded also in channels where no input unit is installed (but the range of the "number of units in use" setting cannot be exceeded).

#### Method



Move the flashing cursor to the position shown in the illustration and make the setting with the function keys or the JOG control.



Equations not to be used should be set to **NONE** (calculation result is not recorded).



- If the same channel is selected as source in the equation and as target for recording, the waveform data in the source channel are overwritten by the equation calculation result.
- · In the following cases, the calculation result is displayed with in the same color set as the channel number for the first processing run:
  - ① If results are recorded in a channel where no input unit is installed.
  - ② If the display color for the channel selected for recording is set to OFF.


When wishing to change the display color set, perform calculation once and then use the CHANNEL screen to make the setting.

## 14.5 Setting the Display Scale

- · Display scale can be set automatically or manually.
- The channel selected for recording is automatically set to variable display ( F Section 9.6.10).

#### Method

flashing cursor



Move the flashing cursor to the position shown in the illustration and make the setting with the function keys.

Function key display

Meaning

AUTO COM

MANUÁL

: Set display scale manually

: Set display scale automatically

#### Automatic setting

After calculation, the upper and lower limit is determined from the result, and the variable display settings are made accordingly.



Depending on the type of calculation, automatically display scale setting may not be satisfactory. In such a case, use the manual setting procedure.

#### Manual setting


Use the variable display setting function on the CHANNEL screen (page 2) to set the upper and lower limit ( F Section 9.6.10).

## 14.6 Specifying the Waveform Processing Range

- · Use the A/B cursors (or trace cursor) to specify the processing range for the waveform data.
- · Processing is carried out only for data between the A/B cursors.
- · If the A/B cursors are turned off, or if a horizontal cursor is used, processing is carried out for all data. (Waveform processing is not possible if recording length is more than 1000 DIV.)

NOTE


- When using the trace cursor, the trace point value is displayed as processed value.
- · When the cursors overlap, processing is carried out for that point.
- · When the A/B cursors are used, data outside of that range are considered invalid.




Processing is carried out for this range


## 14.7 Setting Example for Waveform Processing


**Example** Using the circuit shown in the illustration, the voltage applied to the load is measured in CH1, the voltage at the resistor in CH2, the waveform of the current flowing through the load in CH3, and instant power waveform data for



**Setting** Make settings on the memory recorder STATUS screen as shown below ( Section 5.2.1).








Status Screen (page 2)


Status screen (page 3): all settings OFF



CHANNEL screen

Make settings for CH2 as for CH1.

#### Method




- 1. Set wave calculation on STATUS screen (page 4) to ON.
- 2. Enter the processing equation.
- ① Move the flashing cursor to **Z1** and press the F1 [enter] key.
- ② Enter the following equation: Z1=CH2/a
- 3 Press the F5 [exit] key.
- Move the flashing cursor to Z2 and enter the following equation in the same way as for Z1: Z2=CH1\*Z1
- 3. Move the flashing cursor to the constant a and enter the resistance value.

a=+2.0000E+02

- 4. Set the result of Z1 to be recorded in channel 3 and the result of Z2 in channel 4.
- · Set Z3 Z8 to NONE.
- 5. Set the upper and lower limit to **AUTO**. (The variable display setting for CH3 and CH4 becomes ON. When wishing to make the setting manually, use the CHANNEL screen (page 2).

- 6. Press the DISP key to activate the display screen.
- 7. Press the START key to start processing.
- 8. Press the STOP key to interrupt the measurement.

The processing results of CH3 and CH4 are shown with color set 3 for CH3 and color set 4 for CH4. When wishing to change the color, make the setting from the CHANNEL screen (page 1).



- 9. Set the display unit for CH3 to **A** (ampere) and for CH4 to **VA** (volt-ampere).
- ① Press the SYSTEM key to call up the SYSTEM screen and press the F3 [SCALING] function key.
- ② Move the flashing cursor to the **eu** (unit name) item for CH3 and CH4 on the scaling setting screen and enter **A** and **VA** respectively ( **F** Section 11.6.1).
- 10. Press the DISP key again to activate the display screen and press the START key to start the measurement.
- 11. Press the STOP key when wishing to terminate the measurement.

#### **Details on Operators** 14.8

(1) The four arithmetical operations (+, -, \*, /)

According to the operators set, the four arithmetical operations are performed.

(2) Absolute value (ABS)

Equation:

$$b_i = |d_i| (i = 1, 2, ...., n)$$

b<sub>i</sub>: i-th data of calculation result d<sub>i</sub>: i-th data of source channel

(3) Exponential (EXP)

Equation:

$$b_i = \exp(d_i) (i = 1, 2, ...., n)$$

b<sub>i</sub>: i-th data of calculation result d<sub>i</sub>: i-th data of source channel

(4) Common logarithm (LOG)

Equation:

$$b_i = log_{10}di$$
 when  $d_i > 0$ 

$$\begin{aligned} b_i &= log_{10} di & & when \ d_i > 0 \\ b_i &= -\infty & & when \ d_i = 0 \ \ (overflow \ value \ is \ output) \end{aligned}$$

$$b_i = \log_{10} |d_i|$$
 when  $d_i < 0$  (i = 1, 2, ...., n)

b<sub>i</sub>: i-th data of calculation result

d<sub>i</sub>: i-th data of source channel

(Reference)

Use the following equation to convert to natural logarithm:

$$InX = logeX = \frac{log_{10}X}{log_{10}e} \qquad \frac{1}{log_{10}e} \stackrel{=}{=} 2.33E + 0$$

(5) Square root (SQR)

Equation:

$$b_i = \sqrt{di}$$
 when  $d_i \ge 0$ 

$$b_i = \sqrt{|di|}$$
 when  $d_i < 0$  (i = 1, 2, ...., n)

b<sub>i</sub>: i-th data of calculation result

d<sub>i</sub>: i-th data of source channel

(6) Moving average (MOV)

Equation:

$$b_i = \frac{1}{k} \sum_{t=i-k/2}^{i+k/2} d_i \; (i = 1, \, 2, \, ...., \, n)$$

b<sub>i</sub>: i-th data of calculation result

d<sub>i</sub>: i-th data of source channel

k: number of points for averaging (1 to 4000)

NOTE

1 DIV = 100 points

(7) Parallel displacement on time axis (SLI)

Shifts the value on the time axis by a certain number of points.

Equation:

$$b_i = d_{i-k}$$
 (i = 1, 2, ...., n)

b<sub>i</sub>: i-th data of calculation result

d<sub>i</sub>: i-th data of source channel

k: number of points for averaging (-4000 to 4000)

NOTE

- · After shifting the waveform, the part right or left without source channel data becomes 0 V.
- $\cdot$  1 DIV = 100 points
- (8) Differentiation once (DIF)
- (9) Differentiation twice (DIF2)
  - · 1st and 2nd differential are calculated using the 5th-order Lagrange interpolation equation, whereby data from a range of five surrounding points are used to determine the value of the current point.
  - $\cdot$  Data corresponding to sample time  $t_1$   $t_n$  are taken as  $d_1$   $d_n$  and used for calculating the differential.

NOTE

When the input voltage becomes small, processing results will show little variation. In such a case, apply the MOV operator.

· Equation for 1st differential:

$$\begin{array}{lll} \text{Point } t_1 & b_1 & = \frac{1}{12h} & [-25d_1 + 48d_2 - 36d_3 + 16d_4 - 3d_5] \\ \\ \text{Point } t_2 & b_2 & = \frac{1}{12h} & [-3d_1 - 10d_2 + 18d_3 - 6d_4 + d_5] \\ \\ \text{Point } t_3 & b_3 & = \frac{1}{12h} & [d_1 - 8d_2 + 8d_4 - d_5] \\ \\ \vdots & & & \\ \\ \text{Point } t_i & b_i & = \frac{1}{12h} & [d_{i-2} - 8d_{i-1} + 8d_{i+1} - d_{i+2}] \\ \\ \vdots & & & \\ \\ \text{Point } t_{n-2} & b_{n-2} & = \frac{1}{12h} & [d_{n-4} - 8d_{n-3} + 8d_{n-1} - d_n] \\ \\ \vdots & & & \\ \\ \text{Point } t_{n-1} & b_{n-1} & = \frac{1}{12h} & [-d_{n-4} + 6d_{n-3} - 18d_{n-2} + 10d_{n-1} + 3d_n] \\ \\ \text{Point } t_n & b_n & = \frac{1}{12h} & [3d_{n-4} - 16d_{n-3} + 36d_{n-2} - 48d_{n-1} + 25d_n] \\ \end{array}$$

 $b_i$  to  $b_n$ : data of calculation result  $h = \Delta t$ : sampling period (F Appendix 2.1)

· Equation for 2nd differential:

- (10) 1st integral (INT)
- (11) 2nd integral (INT2)
  - · The 1st and 2nd integral calculation uses the trapezoidal rule.
  - · Data corresponding to sample time t1 tn are taken as d1 dn and used for calculating the integral.
  - · Equation for 1st integral:

Point 
$$t_1 I_1 = 0$$

Point 
$$t_2 = \frac{1}{2} (d_1 + d_2)h$$

$$Point \ t_3 \qquad I_3 \ = \frac{1}{2} \ (d_1 + d_2)h \ + \frac{1}{2} \ (d_2 + d_3)h \ = I_2 \ + \frac{1}{2} \ (d_2 + d_3)h$$

Point 
$$t_n = I_{n-1} + \frac{1}{2} (d_{n-1} + d_n)h$$

 $I_1$  -  $I_n$ : processing result data

 $h = \Delta t$ : sampling cycle (  $\square$  Appendix 2.1)

· Equation for 2nd integral:

Point 
$$t_1$$
  $II_1 = 0$ 

Point 
$$t_2 = \frac{1}{2} (I_1 + I_2)h$$

$$\mbox{Point } t_3 \ \ II_3 = \frac{1}{2} \, (I_1 + I_2) h + \frac{1}{2} \, (I_2 + I_3) h = II_2 \, + \, \frac{1}{2} \, (I_2 + I_3) h$$

Point 
$$t_n = II_{n-1} + \frac{1}{2} (I_{n-1} + I_n)h$$

 $II_1$  -  $II_n$ : processing result data

#### (12) Sine (SIN)

Equation:

$$b_i = \sin(d_i)$$
 (i = 1, 2, ..., n)

b<sub>i</sub>: i-th data of calculation result

d<sub>i</sub>: i-th data of source channel

#### (13) Cosine (SOS)

Equation:

$$b_i = \cos(d_i)$$
 (i = 1, 2, ...., n)

 $\mathbf{b}_i$ : i-th data of calculation result  $\mathbf{d}_i$ : i-th data of source channel

#### (14) Tangent (TAN)

Equation:

$$b_i$$
 = tan (d<sub>i</sub>), and -10 $\leq$ bi $\leq$ 10 (i = 1, 2, ...., n)  
 $b_i$ : i-th data of calculation result

 $d_i$ : i-th data of source channel

#### (15) Arc-sine (ASIN)

Equation:

$$\begin{split} b_i &= \frac{\pi}{2} & \text{when } d_i > 1 \\ b_i &= asin(d_i) & \text{when } -1 \leqq d_i \leqq 1 \\ b_i &= -\frac{\pi}{2} & \text{when } d_i < -1 \ (i=1,\,2,\,....,\,n) \end{split}$$

 $\begin{aligned} b_i : i\text{-th data of calculation result} \\ d_i : i\text{-th data of source channel} \end{aligned}$ 

#### (16) Arc-cosine (ACOS)

Equation:

$$\begin{split} b_i &= 0 & \text{when } d_i > 1 \\ b_i &= acos(d_i) & \text{when } -1 \leqq d_i \leqq 1 \\ b_i &= \pi & \text{when } d_i < -1 \ (i = 1, \ 2, \ ...., \ n) \end{split}$$

bi: i-th data of calculation result di: i-th data of source channel

#### (17) Arc-tangent (ATAN)

Equation:

$$b_i = atan(d_i) (i = 1, 2, ...., n)$$

 $b_i$ : i-th data of calculation result  $d_i$ : i-th data of source channel

NOTE

The unit for the Trigonometric and inverse trigonometric functions (12) - (17) is rad (radian).

# Chapter 15 Determining Waveform Parameters / Evaluating Parameter Values

#### 15.1 Overview

#### Waveform parameter calculation

- · Available for memory recorder and recorder functions.
- · Parameters that were used for captured waveform data and for data after waveform processing can be determined. The result is shown in numeric form.
- · The following 14 types of calculations are possible:
  Average value, RMS value, peak-to-peak value
  Maximum value, time to reach maximum, minimum value,
  time to reach minimum, period, frequency, rise time, fall time,
  standard deviation, area, X-Y area
- · The A/B cursors (vertical, trace) can be used to determine the parameters of a certain range.


#### Waveform parameter evaluation

- · Available for memory recorder and recorder functions.
- · The result of waveform parameter calculation is compared to a reference range, for GO/NG evaluation.

#### 15.2 Making Settings for Waveform Parameter Calculation

- · Settings for waveform parameter calculation are made with the STATUS screen (page 3).
- · Press the STATUS key to call up the STATUS screen (page 3).


Method Screen: STATUS (page 3)




Move the flashing cursor to the items in the order as shown in the illustration.


1. Move the flashing cursor to the **measurement** item and press F2 [ ON ].

The various setting items are displayed.





- 3. Parameter calculation settings
- · Up to four parameter calculations (no. 1 4) can be set simultaneously.
- · Make the settings with the function keys.




· 2/4 Function key Meaning display : Maximum value ( Section 15.8 (4)) MAXIMUM : Time to maximum value( F Section 15.8 (5)) MAX-TIME : Minimum value ( F Section 15.8 (6)) MINIMUM Time to minimum value ( F Section 15.8 (7)) MIN-TIME 2 3 Switch to 3/4 to page 3/4 · 3/4 Function key Meaning display : Period ( Section 15.8 (8)) PERIOD : Frequency ( **F** Section 15.8 (9)) FREQUENCY : Rise time ( F Section 15.8 (10)) RISE-TIME : Fall time ( F Section 15.8 (11)) 3 4 Switch to 4/4 <u>to page 4/4</u> · 3/4 Function key Meaning display

‡ / JAVE : Standard deviation ( F Section 15.8 (12)) DEVIATION


> : Area ( F Section 15.8 (13)) AREA Ø. : X-Y area (  $\square$  Section 15.8 (14)) X-Y AREA

Switch to 1/4 to page 1/4

For details on the various calculation functions, refer to Section 15.8.




4. Calculation channel settings



Also when ALL is selected, channels where no units are installed and channels for which display/record is set to OFF will not be calculated.


- When "X-Y area" was selected
- · Move the flashing cursor to the point shown in the illustration and specify the channel for the X-axis and Y- axis.
- · Use the function keys or the JOG control to make the setting.
- 5. Waveform parameter evaluation settings

For details, see Section 15.3.




6. Waveform parameter evaluation range (upper and lower limit) setting For details, see Section 15.3.

- 7. Executing waveform parameter calculation
- · There are two methods for starting parameter calculation.
- ① Parameter calculation while capturing the waveform
  - 1. Set **measurement** to **ON** and make the required settings.
  - 2. Press the DISP key to activate the display screen, and then press the START key.
  - 3. Calculation is performed using the captured waveform data, and the calculation results are displayed.
  - 4. If **printer** was set to **ON**, the calculation results are printed out.



- ② Parameter calculation of measurement data loaded from DAT or already present in internal memory
  - 1. Set measurement to ON and make the required settings.
  - 2. Move the flashing cursor to the **execute** position at the top right of the screen and press the Fine execute position at the top right of the screen
  - 3. Calculation is carried on the data stored in memory, and the result is displayed on the screen.
  - 4. If **printer** was set to **ON**, the calculation results are printed out.



NOTE


- · Calculation is carried out in the order no. 1 through no. 4.
- · Also for channels where no input unit is installed, parameter calculation is carried out if waveform processing results or data loaded from tape are stored in the channel.
- · The scaling setting has no effect. (RMS value and area value are calculated after scaling.)
- · When wave calculation is set to ON, waveform data after waveform processing are used for parameter calculation.

#### 15.3 Making Settings for Waveform Parameter Evaluation

Depending on the results of the waveform parameter calculation, a GO (pass) or NG (fail) result is returned.


Out NG is returned when result is outside of specified range.

In NG is returned when result is inside specified range (excluding upper and lower limit).




Evaluation criteria can be set independently for each of the calculation sets no. 1 - no. 4.

#### Method Screen: STATUS (page 1)




Move the flashing cursor to the items in the order as shown in the illustration.

- 1. Make the settings for waveform parameter calculation ( settings for waveform parameter calculation ( settings for waveform parameter calculation ( settings for waveform parameter calculation).
- 2. Move the flashing cursor to the **comparison** item and select **OUT** or **IN**.



- 3. Set the upper and lower limits.
  - The setting range is -9.9999E+29 to +9.9999E+29 (exponent: -29 to +29).
  - · Move the flashing cursor to the various digits and make the setting with the function keys or the JOG control.






- · If the setting was made so that lower limit  $\geq$  upper limit, the evaluation result is always NG for the **OUT** setting and always GO for the **IN** setting.
- · When the evaluation result is NG, the calculation value for that channel is marked with an "\*" (on the display and the printout).


#### Stop mode and trigger mode

- · When waveform parameter evaluation has been set to **OUT** or **IN**, and the START key is pressed to start the measurement, operation will stop when the evaluation result is NG.
- · When auto print is set to ON, the waveform is printed out when operation stops.
- · When auto save is set to ON, data are stored on tape when operation stops.
- · When memory segmentation (sequential save) is ON, data are stored in the memory block only when operation stops.


#### Trigger mode: SINGLE



• Trigger mode: REPEAT, AUTO



Trigger mode: AUTO STOP




NOTE

When waveform parameter measurement and waveform evaluation are carried out simultaneously, the waveform evaluation stop mode is given priority.

#### 15.4 Using the NG Output

- · When the evaluation result is NG, an NG output signal can be obtained between the NG terminal and the GND terminal.
- · For details, please refer to the Section 21.6.




## 15.5 Specifying a Range for Waveform Parameter Calculation

- The A/B cursors (vertical, trace) can be used to specify a range of waveform data for processing.
- $\cdot$  When a range is specified, waveform parameters are calculated only for the data between the A/B cursors.
- · When not using the A/B cursors, or when using the horizontal cursor, waveform parameter calculation is carried out for all data.

NOTE


When the cursors overlap, calculation is carried out for that point.




## 15.6 Printing Out Waveform Parameter Calculation Results


Calculation results can be printed out.

Method Screen: STATUS (page 3)



Move the flashing cursor to the **printer** item and set it to **ON**.







Print Example

## 15.7 Waveform Parameter Calculation and Waveform Parameter Evaluation Examples


#### Example

- · Using the circuit shown in the illustration, the voltage at the resistor is measured in CH2, and the RMS (effective) voltage is determined.
- · Waveform parameter evaluation is carried out to determine whether the RMS voltage is within the permissible range that can be applied to the resistor (1/4 W).
- · When the waveform parameter evaluation result is NG, the measurement is terminated.
- · The memory recorder function is used.






Status Screen (page 1)



Channel Screen (page 1)


Change the trigger mode to SINGLE so that measurement stops when the evaluation result is NG.




Status Screen (page 2)

Make settings for CH1 in the same way as for CH1.

#### Method 15-05





- 1. Set "Waveform parameter calculation" on the STATUS screen (page 3) to **ON** by pressing the F2.
- 2. Set the printer to **OFF**.
- 3. Move the flashing cursor to the No. 1 item and select F3 [ RMS ].
- 4. Set the channel to CH2.
- 5. Select F2 [ OUT ] for waveform parameter evaluation.
- 6. Since the maximum RMS voltage that can be applied to the 1/4 W 200  $\Omega$  resistor is 7.07 V, set the evaluation range as follows.

0.0000E+0 - 7.0700E+0

- 7. Press the DISP key to activate the display screen.
- 8. Press the START key to start the measurement. When an NG result occurs, the measurement is terminated.

When wishing to terminate the measurement beforehand, press the STOP key.

#### 15.8 Parameter Calculation Details

- (1) Average value
  - · Calculates the average value (V) of the waveform data.
  - · Equation:

$$AVE = \frac{1}{n} \sum_{i=1}^{n} di$$

AVE: average value

n: number of data samples

d<sub>i</sub>: i-th data of the source channel

- (2) RMS value
  - · Calculates the RMS (effective) value (V) of the waveform data.
  - · When scaling is used, the value is calculated after scaling
  - · Equation:

$$RMS = \sqrt{\sum_{i=1}^{n} di^2}$$

RMS: effective value

n: number of data samples

d<sub>i</sub>: i-th data of the source channel

(3) Peak-to-peak value

Calculates the peak-to-peak (maximum-minimum) value of the waveform data.

(4) Maximum value

Calculates the maximum value of the waveform.

- (5) Time to maximum value
  - · Calculates the time interval from the triggering point to the maximum value of the waveform (in seconds).
  - · If there are two maximum value points, the time to the point nearest the trigger point is calculated.
- (6) Minimum value

Calculates the minimum value of the waveform.

#### (7) Time to minimum value

- · Calculates the time interval from the triggering point to the minimum value of the waveform (in seconds).
- · If there are two minimum value points, the time to the point nearest the trigger point is calculated.

#### (8) Period


#### (9) Frequency

- · Displays the period (s) and frequency (Hz) of the signal waveform.
- · The calculation is performed by determining the middle point of the signal amplitude and then measuring the interval from the point when that level is crossed (in rising or falling direction) to the point when it is next crossed.

#### (10) Rise time

#### (11) Fall time

- · From the captured waveform data, the 0% and 100% level is determined, and the rise time (s) is taken as the time required to go from 10% to 90% (fall time: from 90% to 10%).
- · In the captured waveform data, the first rising slope (or falling slope) is used to make the calculation.
- · If the A/B cursors (vertical, trace) are used, the first rising slope (or falling slope) within the range defined by the cursors is used.



#### (12) Standard deviation

- · Calculates the standard deviation (V) of the waveform data.
- · Equation:

$$\sigma = \sqrt{\frac{\sum_{i=1}^{n} (di - AVE)^{2}}{n}}$$

 $\sigma$ : standard deviation AVE: average value

n: number of data samples

d<sub>i</sub>: i-th data of the source channel

#### (13) Area value

· Calculates the area bordered by the signal waveform and the zero position (potential 0 V).

· If the A/B cursors (vertical, trace) are used, the area between the cursors is calculated.

· Equation:


$$S = \sum_{i=1}^n |di| \cdot h$$

S: Area value

n: number of data samples


 $d_i$ : i-th data of the source channel

 $h = \Delta t$ : sampling period




#### (14) X-Y area value

- · Calculates the area (V<sup>2</sup>) after X-Y plotting.
- The waveform is plotted on the X-Y screen, and the area enclosed by the plot lines is calculated.
- · In single, dual, quad, or octo screen, the A/B cursors (vertical, trace) can be used to specify the range (see Section on cursor use) for X-Y plotting and area calculation.
- · On the X-Y screen of the memory recorder function, it is not possible to specify the range with the A/B cursors.



X-Y waveform (no enclosed range)





- Depending on the signal waveform, values for parameters (8), (9), (10), and (11) may not be displayed.

## Chapter 16 Waveform GO/NG Evaluation

#### 16.1 Overview

- · GO (pass) or NG (fail) evaluation of the input signal waveform can be performed using an evaluation area specified by the user.
- · This can serve to detect irregular waveforms.
- · When the evaluation result is NG, an NG signal is output from the NG terminal.
- · The waveform evaluation function can be used from the following screens:

  Memory recorder (single screen, X-Y single screen)


  FFT (single screen, Nyquist screen)

#### 16.2 Waveform Evaluation Settings


The waveform evaluation function can be used from the following functions and screens:

- · Memory recorder function (single screen, X-Y single screen)
- · FFT (single screen, Nyquist screen)

**Method** Screen: STATUS (page 3) in the memory recorder and FFT functions Display the respective page of the STATUS screen and move the flashing cursor to the **wave comparison** item.




Memory recorder function




1. Waveform evaluation mode setting (wave comparison)


Select the waveform evaluation conditions (Out, All- Out).




- 2. Setting up the waveform evaluation area ( Section 16.3)
- · Define the area to be used as reference for waveform evaluation.
- · Press the F5 [Edit] key to activate the editor and create the area.
- 3. Setting the GO/NG stop mode
- · When waveform evaluation is activated (Out or All-Out setting is selected), the **stop mode** item appears.
- · This setting determines whether operation is stopped on the GO or NG result.



#### Waveform evaluation mode and stop mode






#### Stop mode and trigger mode

- · When the evaluation mode and stop mode conditions are fulfilled, measurement operation stops.
- · When auto print is set to ON, the waveform is printed out when operation stops.
- · When auto store is set to ON, data are stored on tape when operation stops.
- · When memory segmentation (sequential save) is ON, data are stored in the memory block only when operation stops.


#### ① Trigger mode: SINGLE

Measurement continues until stop mode conditions are fulfilled and then stops.




#### 2 Trigger mode REPEAT, AUTO

- · Recording and waveform evaluation is carried out continuously.
- · Press the STOP key to terminate the measurement.



#### 3 Trigger mode: AUTO STOP

Measurement stops when trigger mode conditions are fulfilled and triggering occurs.





- · Waveform evaluation consists of two actions, namely capturing data and performing the evaluation. These two actions are carried out in sequence, not simultaneously. Therefore data are not captured while the evaluation is in progress, which means that the input signal is not being continuously monitored. The time required for evaluation is on the order of 20 ms.
- · For reference, the table below shows the evaluation period when evaluating about two cycles of a sine wave on one screen.

(]	lnput	: wavet	orm s	so that	result	ıs a	lways	GU	) ın	evalua	tion	mode	O	U'.	$\Gamma$	
----	-------	---------	-------	---------	--------	------	-------	----	------	--------	------	------	---	-----	----------	--


Number of evaluation channels	Time axis (ms/DIV)	Recording length (DIV)	Magnificati on/compre ssion	Dot/line indication	Evaluation period (s)		
1	1	25	X1	Dot	Approx. 1.83		
1	1	25	X1	Line	Approx. 1.75		
2	1	25	X1	Line	Approx. 1.78		

- · If a high setting is chosen for recording length or if compression is used, the evaluation cycle becomes slower.
- · When waveform parameter measurement and waveform evaluation are carried out simultaneously, the waveform evaluation stop mode is given priority.


#### 16.3 Creating the Evaluation Area

- · The graphics editor serves to create the waveform evaluation area.
- · The area is created by drawing it on screen.

Method Screen: STATUS (page 3) in the memory recorder and FFT functions



- 1. Activating the editor
- $\cdot$  Move the flashing cursor to the  $\mbox{wave comparison}$  item.
- · Press F5 [Edit].



When the editor is active, the following commands are assigned to the function keys.

· 1/3

\* Edit \*

parallel

1 /2

2

Function key display Meaning

D→ My paint

: Fill in a closed area

\\\ → \\\
parallel

: Parallel shift



: Draw a straight line



: Erase



: Switch to 2/3



Function key display

Meaning



: Import waveform into editor



: Display filled-in area in reverse



: Clear screen



: Clear area



: Switch to 3/3

• 3/3
Function key display Meaning

(exec)

Undo immediately preceding command

Tuy Tuy save area

: Store area in memory

Edit end

: Quit editor

to page 1/3

: Switch to 1/3

For details see Section 16.4.

- 3. Use these commands to create the evaluation area.
- 4. When the area has been stored in memory, it can be used for waveform evaluation.
- 5. Press the F4 [end] function key to terminate the editor.

NOTE

When the message "printing" or a warning message is displayed on the screen, the immediately preceding command is canceled (same as the undo command).

#### 16.4 Editor Command Details

Paint Function key display: 1/3

Fills in an enclosed area.

\* Edit \*


/ CE

(exec)


2

- 3

#### Method



1. Press Fl [ paint ].



3. Press the F1 [ exec ] key. The area completely enclosed by lines is filled in.

Function key display


Meaning



: Execute paint



: Terminate paint mode



4. Press the F5 [exit] key to terminate the paint mode.




If the area is not completely enclosed, adjacent areas will also be filled in.

Parallel shift Function key display: 1/3

Shifts the line pattern in parallel direction, to create an area.

#### Method



right 01.00div left 00.00div

- 3

- 1. Press | F2 | [ parallel ].
- 2. Set the amount of shift.
- · Use the function keys or the JOG control to set the value.
- · Use the F3 [ move csr ] key (or the CURSOR keys) to set the shift amount in the up/down/right/left directions.
- · Minimum shift increments are shown in the following table.

Function	Screen	Movement		
Memory recorder	Single	0.04		
Memory recorder	X-Y single	0.04		
FFT	Single	0.05		
FF	Nyquist	0.05		

Function key display

Meaning



: Increase shift amount



: Decrease shift amount



Cycle the cursor through up/down/right/left



: Execute parallel shift




: Terminate parallel shift mode

- 3. Press the F4 [exec] key. The parallel shift is carried, thereby creating the evaluation area.
- 4. Press the | F5 | [exit] key to terminate the parallel shift mode.


Line Function key display: 1/3

Serves to draw a straight or polygonal line.

#### Method



1. Press F3 [ line ].



- 2. Use the CURSOR keys to move the mark to the start point of the line.
- 3. Press F1 [ set ].

Function key Meaning display




Set the point under the @ mark as start/end point


Cancel the immediately preceding set point



: Terminate line mode



- 5. Press the Fl [set] key again. The color of the line changes, and it is fixed.
- 6. Repeat steps 4 and 5 when wishing to draw a polygonal line.
- 7. Press the F5 [exit] key to terminate the line mode.





**Erase** Function key display: 1/3

Serves to erase unwanted sections.


e x i

#### Method





2



- 1. Press F4 [ erase ].
- 2. Use the CURSOR keys to move the M mark to the start point of the section to be erased.
- 3. Press F1 [ set ].

Function key display Meaning



: Set the eraser




: Terminate erase mode

- 4. Move the mark to erase the unwanted section.
- mode.

**Import waveform** Function key display: 2/3

Loads a waveform already stored in memory into the editor.

#### Method



Press F1 [ storage ].

The waveform that was displayed on the screen is loaded into the editor.


NOTE

The imported waveform is shown in a different color from the original setting.

Reverse Function key display: 2/3

Reverses the colors of a filled-in area and the surrounding area.

#### Method




Press F2 [ reverse ].

Displays filled in area in reverse.

■ Clear screen Function key display: 2/3

Clears the entire editor screen.

#### Method




Press F3 [ all clear ].

■ Clear area Function key display: 2/3


Clears a specified rectangular area of the editor screen.

#### Method



1. Press | F4 | [ clear area ].

- 2. Use the CURSOR keys to move the @ mark to the start corner of the area to be erased.
- 3. Press F1 [ set ].




- 4. Move the mark to the end corner of the area to be erased.
- 5. Press the F1 [set] key again. The rectangular area is cleared.
- 6. Press the F5 [exit] key to terminate the clear area mode.

#### ■ Undo Function key display: 3/3

- · Serves to undo the immediately preceding command.
- · Undo is applicable to all commands except STORE and QUIT EDITOR.

#### Method




 $\operatorname{Press}\left[ \operatorname{Fl}\right] [ \text{ undo }].$ 

Screen before "clear screen" is restored.

#### Store area in memory (function key display: 3/3)

- · Serves to store the created area in memory.
- · After an area has been stored, it can be used for waveform evaluation.

#### **Method** Press the F3 [ save area ] key.




#### Quit editor (function key display: 3/3)

Terminates the editor.

#### Method

- ① Store evaluation area in memory and quit editor
  - · Press the F4 [end] key and then the F3 [save area] key.
  - · The stored area can be used for waveform evaluation.
- 2 Quit editor without storing evaluation area in memory
  - · Press the F4 [end] key and then the F5 [kill area] function key.
  - · The created area will be discarded. 1.




NOTE

If the F4 [end] key is pressed without having done any editing or immediately after using the store command, the editor is terminated without confirmation.


#### 16.5 Using the NG Output

- · When the waveform evaluation result is NG, an NG output signal can be obtained between the NG terminal and the GND terminal.
- · For details, please refer to the Section 21.6.




# 16.6 Setting Example for Waveform Evaluation

**Example** Using the circuit shown in the illustration, the power supply voltage is monitored in CH1, and the measurement is stopped if noise spikes cause the voltage to exceed the prescribed range.



**Setting** Make settings on the memory recorder STATUS screen as shown below ( Section 5.2.1).



measurement stops when the evaluation result is NG.

pre-trig:

(page2)

0%

slope:1 flt: OFF ' 97- 4- 3

SINGLE

AUTO → STOP

AUTO STOP

20:37:12

Change the trigger mode to SINGLE so that

SINGLE

OFF

OFF

OR

trig mode:

analog trigger ch1 : LEVEL

ch2 : OFF ch3 : -


ch5 : ch6 : -

ch8 : -

timer source:


Status Screen (page 2)

- Status Screen (page 1)
  - · Set all items on STATUS screen (page 3) to OFF. (Settings for waveform parameter calculation and evaluation are to be made later.)
  - · Set all items on STATUS screen (page 4) to OFF.




Channel Screen (page 1)


#### Method



1. After having established the settings described above, record the waveform to be used as reference.




- 2. Move the flashing cursor to the waveform comparison item on the STATUS screen (page 3).
- 3. Set waveform evaluation to **OUT** (F2) and the stop mode to **NG** (F2).
- 4. Move the flashing cursor to the waveform comparison item and press F5 [ Edit ].



5. Press F1 [ storage ] (2/3) to import the reference waveform into the editor.

- 6. Press F2 [ parallel ] (1/3).
- · Shift the displayed waveform vertically and horizontally to create the evaluation area.



- 7. Use the F3 [move csr] key or the CURSOR keys to set the amount of up/down/right/left shift in DIV units.
- · Since the scale is 1 V/DIV, make the following settings to obtain a 1.0 V range in the up/down directions.

Up: 1.0

Down: 1.0

Left: 0

Right: 0

- 8. Press F4 [ exec ] to carry out the parallel shift.
- 9. Press F5 [exit] to terminate the parallel shift mode.
- 10. Press F4 [end] (3/3) and press F3 [save area] to quit the editor after storing the waveform.
- 11. Press the DISP key to activate the display screen.
- 12. Press the START key to start waveform evaluation (do not change the measurement parameters). If the input waveform leaves the evaluation area at any point, the measurement is terminated.

# Chapter 17 17 **Memory Segmentation** Function

## 17.1 Overview

- · This function divides the memory into separate blocks, each of which can be used for waveform recording.
- · The memory segmentation function has two modes: sequential save and multiblock.

#### Sequential save function

- · Memory space is divided into blocks.
- · Input signal capture is carried out continuously using the trigger, storing waveform data successively in each block.
- · During recording, no display or printout is carried out.
- · This reduces dead time (non-sensitivity periods due to display and printing delays).

#### Multi-block function

- · Memory space is divided into blocks.
- · Waveform data can be stored in a selected block.


# 17.2 Using the Sequential Save Function

- · Input signal capture is carried out continuously using the trigger, storing waveform data successively in each block.
- · Any block in which an input signal is recorded can be called up on the display.



During measurement, the display and print functions are totally disabled until data have been recorded in all blocks.

· When continuous print (auto print) is being performed in REPEAT trigger mode




Brief phenomena may not register




· Dead time (interval in which no sampling occurs due to display and print processing)

· Using sequential save



Data are divided into blocks and recorded in memory.

#### Method Screen: STATUS (page 3)



1. Memory segmentation settings

Meaning

Select F2 [ SEQUEN ].

Function key display

: Disable memory segmentation

OFF

A→A→A
SEQUEN

△,A,M

MULTI


: Enable sequential save function

Enable multi-block function

( Section 17.3)

#### 2. Number of memory blocks

- · The number of available memory blocks (3, 7, 15, 31, 63) is automatically set, depending on the recording length and the number of units in use (see "Relation between recording length (DIV), number of units, and maximum number of memory blocks" on the next page).
- · The user can select how many blocks to use out of the total available number.
- · Use the function keys or the JOG control to make this setting.



#### 3. Display block setting

- · Set the number of the memory block to display on screen.
- · Make the setting in the same way as in step 2.

# Relation between recording length (DIV), number of units, and maximum number of memory blocks

When using the sequential save function, recording length has priority over the number of memory blocks. When the recording length is changed, the number of memory blocks may automatically be adjusted.

Number of	1ι	ınit	2 u	nits	4 u	nits	8 u	nits
units Recording length (DIV)	1 ch	2 ch						
20000	1	, -	_	_		_		_
10000	1	-	1	-	_	_		- 1
5000	3	1		-	1		_	
2000	7		3	-	1	-	1	_
1000	15	7		3		1		1
500	31	15		7		3		1
200	63	31		15		7		3
100	63	63		31		15		7
50	63	63		63		31		15
25	63	6	3	6	3	6	3	31

1 ch (one channel): only 8916 - 8919, 8928


2 ch (two channels): 8916 - 8919, 8927, and 8928 used together, or only 8927

(For the 8928, one channel corresponds to one unit.)

#### Reference


#### Relation between trigger mode and sequential save

- 1 Trigger mode SINGLE
  - $\cdot$  When the <code>START</code> key is pressed, waveform data are stored sequentially from block 1 onwards.
  - · When the specified number of memory blocks has been recorded, measurement stops.
  - · After measurement is completed, the waveform of the block selected for display is shown on the screen.



#### 2 Trigger mode REPEAT


- · When the START key is pressed, waveform data are stored sequentially from block 1 onwards.
- · When the specified number of memory blocks has been recorded, storing of waveform data returns to block 1, and data continue to be recorded from block 1 onwards, overwriting the earlier data.
- · After the specified number of memory blocks has been recorded, the waveform of the block selected for display is shown on the screen. (If auto print is ON, printing is carried out.)
- · Pressing the STOP key once during measurement causes measurement to stop after the specified number memory blocks.
- · Pressing the STOP key twice during measurement causes measurement to stop immediately.



Measurement ends at specified block when STOP key was pressed.

#### ③ Trigger mode AUTO


- · When the START key is pressed, waveform data are stored sequentially from block 1 onwards, not only for waveforms captured by triggering but also waveforms captured at regular intervals.
- · When the specified number of memory blocks has been recorded, storing of waveform data returns to block 1, and data continue to be recorded from block 1 onwards, overwriting the earlier data.
- · After the specified number of memory blocks has been recorded, the waveform of the block selected for display is shown on the screen. (If auto print is ON, printing is carried out.)
- · Pressing the STOP key once during measurement causes measurement to stop after the specified number memory blocks.
- · Pressing the STOP key twice during measurement causes measurement to stop immediately.



Measurement ends at specified block when STOP key was pressed.

#### Trigger mode AUTO STOP


- · When the START key is pressed, only waveform data which were captured by triggering are stored sequentially from block 1 onwards (not waveforms captured at regular intervals).
- · When the specified number of memory blocks has been recorded, measurement stops.
- · After measurement is completed, the waveform of the block selected for display is shown on the screen.




Measurement ends at specified block (waveform data captured after 1-second interval has elapsed are not recorded).

# 17.3 Using the Multi-Block Function

- · Memory is divided into blocks which can be freely selected by the user for storing measurement data.
- · Data stored in any block can be called up on the display.
- · Data from two different blocks can be superimposed on screen for easy comparison. (it can be printed out)



Method Screen: STATUS (page 3)



1. Memory segmentation setting

Select F3 [ MULTI ].
Function key display Meaning

OFF

A→A→A

SEQUEN

M,A,M


MULTI

: Disable memory segmentation

Enable sequential save function ( FSection 17.2)

: Enable multi-block function


- 2. Number of memory blocks setting
- · Determine into how many blocks the memory is to be divided.
- · Use the function keys or the JOG control to make this setting.




NOTE

The recording length per block depends on the number of memory blocks and the number of units in use (see "Relation between number of memory blocks, number of units, and maximum recording length (DIV)" on the next page).

- 3. Number of memory block to use setting
- · Select the number of the memory block for display.
- · Use the function keys or the JOG control to make this setting.



- 4. Reference memory block
- · Select a memory block whose waveform data are to be superimposed on screen with the memory block selected for display.
- · Use the function keys or the JOG control to make this setting.



#### Reference

Scrolling can be carried out while the superimpose function is used ( F Section 19.3).



It is not possible to superimpose two memory blocks of different recording length.

# Relation between number of memory blocks, number of units, and maximum recording length (DIV)

When using the multi-block function, the number of memory blocks has priority over the recording length (DIV). When the number of memory blocks is changed, the recording length may automatically be adjusted.

Number of units to be used	-	1	2	2	4	1	8	3
Number of memory blocks	1 ch	2 ch						
3	5000	20	00	10	00	50	00	200
7	2000	10	00	50	00	20	00	100
15	1000	50	00	20	00	10	00	50
31	500	20	00	10	00	5	0	25
63	200	10	00	5	0	2	5	_

 $1\ \mbox{ch}$  (one channel) : only 8916 -  $8919,\,8928$ 

2 ch (two channels): 8916 - 8919, 8927, 8928 used together, or only 8927 (For the 8928, one channel corresponds to one unit.)


#### Reference

# Chapter 18 Waveform Averaging 18


#### 18.1 Overview

- · The averaging function allows capturing several instances of a waveform and determining the average.
- · This makes it possible to eliminate noise and irregular signal components.
- · Averaging is available for the memory recorder and FFT functions.
- · Time axis waveform averaging (memory recorder, FFT)
- · Frequency axis waveform averaging (FFT)
- · Frequency axis waveform peak hold (FFT)
- · The higher the number of averaging instances, the more effectively will noise be suppressed.

#### Time axis waveform averaging



#### Frequency axis waveform averaging




# 18.2 Setting the Averaging Function

## 18.2.1 When Using Memory Recorder Function

(1) Setting the averaging count

Method Screen: STATUS (page 3)



\* MENON \*

trig:
REPEAT
S1 LEVEL
OVJ

Pre-t:
OX


time/div:
2.5ms
×1
(2.5ms)
shot:
25DIV

csr: OFF

AVE: 160/32

Averaging time Specified number of times

- 1. Move the flashing cursor to the average item.
- 2. Use the JOG control or the function keys to set the averaging count.




After starting the measurement, the averaging count and the current waveform data count are shown on the screen.

### NOTE

- · Averaging does not apply to logic input channels, which simply show the last captured value.
- · When the memory segmentation function is used, averaging is not available.
- · Averaging and waveform processing cannot be carried out simultaneously.
- · Waveform processing can be carried out for an averaged waveform after measurement is completed.


#### Averaging and trigger mode

- ① Trigger mode: SINGLE
- 1. After the START key was pressed, data are captured whenever the trigger conditions are fulfilled, and summing averaging (\*1) is carried out.
- 2. When the specified number of data has been captured, measurement stops automatically.
- 3. If the measurement was stopped prematurely with the STOP key, the averaging result up to that point is displayed.



#### 2 Trigger mode: REPEAT

- 1. After the START key was pressed, data are captured whenever the trigger conditions are fulfilled, and summing averaging (\*1) is carried out until the specified averaging count. The averaging result is shown on the display.
- 2. After the specified averaging count was reached, exponential averaging (\*2) is carried out whenever data are captured, and the averaging result is shown on the display.
- 3. If the measurement was stopped prematurely with the STOP key, the averaging result up to that point is displayed.



#### 3 Trigger mode: AUTO and AUTO STOP

When the START key is pressed, data are captured even if trigger conditions are not fulfilled after a certain interval. If averaging is applied to unsynchronized input signals, the result will be meaningless.

NOTE

For details on summing averaging (\*1) and exponential averaging (\*2), refer to Section 18.3.

#### Recording length limit

The maximum recording length that can be set for averaging depends on the number of units.

Number of units	1		2		4		8	
Number of units	1 ch	2 ch						
Maximum recording length (DIV)	5000	20	00	10	00	50	00	200

1ch: Only 8916 - 8919, 8928 can be used.

2ch: 8916 - 8919, 8927, and 8928 can coexist, or 8927 can be used exclusively.


(For the 8928, one channel corresponds to one unit.)

## 18.2.2 When Using FFT Function


Select whether to use time axis waveform averaging or frequency axis waveform averaging and set the averaging count.


- Time axis waveform averaging Captured waveform data are averaged, and the averaged value is used for FFT processing.
- Frequency axis waveform averaging
  FFT processing is performed first, and the resulting data are averaged.

#### Method Screen: STATUS (page 1), DISPLAY



- 1. Move the flashing cursor to the average item on the STATUS screen or the average item on the display screen.
- 2. Use the function keys to select the type of averaging.





Function key display

Exp ave (freq axis)
F-EXP

Peak Hold (freq axis)
F-PEAK

Frequency axis waveform exponential averaging (\*4)


Frequency axis waveform peak hold (\*5)

F-PEAK


Switch to 1/2

NOTE

For details on frequency axis waveform summing averaging (\*3), exponential averaging (\*4), and peak hold (\*5), refer to Section 18.3.




- 3. After the settings of step 2 are completed, move the flashing cursor to the count item.
- 4. Use the function keys or the JOG control to set the averaging count.



- When averaging is used together with the waveform evaluation function, waveform evaluation is carried out after the specified averaging count is completed. The same applies to the auto store and auto print functions.
- · After averaging was carried out, the scaling setting cannot be changed.


#### Averaging and trigger mode

- (1) Time axis waveform averaging
- 1 Trigger mode: SINGLE
- 1. After the START key was pressed, data are captured whenever the trigger conditions are fulfilled. After averaging, FFT processing is performed and the result is displayed.
- 2. When the specified number of data has been captured, measurement stops automatically.
- 3. If the measurement was stopped prematurely with the STOP key, the averaging result up to that point is displayed.



#### 2 Trigger mode: REPEAT

- 1. After the START key was pressed, data are captured whenever the trigger conditions are fulfilled and averaging is carried out for the specified count. FFT processing is performed and the result is displayed.
- 2. When the specified averaging count is reached, data up to that point are discarded, and new data are captured for averaging.
- 3. If the measurement was stopped prematurely with the STOP key, the averaging result up to that point is displayed.




#### ③ Trigger mode: AUTO and AUTO STOP

When the START key is pressed, data are captured even if trigger conditions are not fulfilled after a certain interval. If averaging is applied to unsynchronized input signals, the result will be meaningless.


#### (2) Frequency axis waveform averaging

- · Captured data first undergo FFT processing. Then averaging is performed and the result is displayed.
- · Unlike time axis averaging, the results are valid also if no trigger synchronization is used. But if the characteristics of the input waveform allow triggering, using the trigger for synchronization is recommended.


#### 1 Trigger mode: SINGLE



#### 2 Trigger mode: REPEAT or AUTO



#### ③ Trigger mode: AUTO STOP



#### FFT analysis mode and averaging

Symbols in the table have the following meaning

- •: Setting is valid
- -: Setting is invalid (has no effect)

FFT analysis mode	Y-axis	Time axis averaging	Frequency axis averaging	Peak hold
Storage waveform	(Linear)	•	•	
Linear spectrum	LIN-REAL LIN-IMAG LIN-MAG LOG-MAG PHASE	•	•	- • •
RMS spectrum	LIN-REAL LIN-IMAG LIN-MAG LOG-MAG PHASE	•	•	- •
Power spectrum	LIN-MAG LOG-MAG	•	•	•
Auto correlation function	(Linear)	•	•	•
Histogram	(Linear)	•	_	
Transfer function	LIN-REAL LIN-IMAG LIN-MAG LOG-MAG PHASE	•	 • •	•
Cross power spectrum	LIN-REAL LIN-IMAG LIN-MAG LOG-MAG PHASE	•	• • •	- - • •
Cross correlation function	(Linear)	•	•	•
Unit impulse response	(Linear)	•	•	•
Coherence function	(Linear)	•	•	•
Octave analysis	LIN-MAG LOG-MAG	•	•	•

 $<sup>\</sup>ast\,$  Same for linear spectrum, and cross-power spectrum with Nyquist display.

# 18.3 Averaging Equations

#### Time axis waveform averaging (memory recorder, FFT)

For time axis averaging, summing averaging is synchronized by the trigger. If trigger synchronization is not performed, the results will be meaningless.

#### (\*1) Summing averaging

Captured data are added sequentially and the sum is divided by the number of samples.

Equation:

$$A_n = \frac{(n-1)A_{n-1} + Z_n}{n}$$

n: Averaging count

 $A_n$ : Result of n times averaging

 $Z_{\rm n}$ : nth measurement data

#### (\*2) Exponential averaging

Most recent data are given greatest weighting, and the weighting of older data is reduced with an exponential function.

Equation

$$A_n = \frac{(N-1)A_{n-1} + Z_n}{N}$$

N: Specified averaging count

n: Averaging count

 $A_n$ : Result of n times averaging

 $Z_{\rm n}$ : nth measurement data

#### Frequency axis waveform averaging (FFT)

Unlike time axis averaging, results are valid also if no trigger synchronization is used. But if the characteristics of the input waveform allow triggering, using the trigger for synchronization is recommended.

#### (\*3) Summing averaging

Equation is the same as for time axis averaging.

#### (\*4) Exponential averaging

Equation is the same as for time axis averaging.

#### (\*5) Peak hold (frequency axis: FFT)

The specified number of samples are captured, and the peak value is held (stored) for each frequency.

# Chapter 19 Using the A/B Cursors / Waveform Scrolling

# 19.1 Overview


- The following three types of A/B cursors are available:
- · Line cursor (vertical)
- · Line cursor (horizontal)
- · Trace cursor
  For FFT, only the trace cursor is available.
- The scroll function can be used to view a waveform (not available for FFT).

# 19.2 Using the A/B Cursors


- The A/B cursors can be used to read a time difference, frequency difference, potential difference, or temperature difference on screen. (When scaling is used, the difference is displayed in the scaling value. See the section on scaling.)
- The following three types of A/B cursors are available:
- · Line cursor (vertical) (not available for FFT)
- · Line cursor (horizontal) (not available for FFT)
- · Trace cursor
- (1) Line cursor (vertical, horizontal) (not available for FFT)

The value at cursor A and cursor B, and the value between the two cursors can be determined.

Value	Vertical cursor	Horizontal cursor
	t time from the trigger point	v voltage difference from 0 V
A or B	1/t frequency taking t as the period	or temperature difference from ℃
р. А	t time interval between the A and B cursors	v voltage difference or temperature difference
B - A	1/t frequency taking t as the period	between the A and B cursors.







Line Cursors (horizontal)

#### (2) Trace cursor


- The value at the point where the cursor crosses the waveform can be determined.
- · The trace point moves on the waveform of the specified channel.

#### ① A or B value

	Memory recorder, Recorder	FFT		
t	Time from trigger point to trace point	Time from left edge of screen to trace point		
V	Potential difference from 0 V (temperature difference from 0°C)			
f		Frequency		

#### ② B - A value

	Memory recorder, Recorder	FFT				
t	Time difference between the trace points					
V	Potential difference between the trace points					
f		Frequency difference between the trace points				




Trace Cursor

NOTE


When using external sampling, the following value is displayed.

	A or B	B - A		
t	Number of sampling point from the trigger point	Sampling points difference		
V	Voltage difference from 0 V or temperature difference from °C	Voltage difference		
f	Number of data points from left side of graph	Data point difference		
1/t	No display			


#### Method Screen: DISPLAY




- 1. Move the flashing cursor to the csr item.
- 2. The function key display changes as follows.




3. Specify the cursor shape.




To use the line cursor (vertical)
 Select F2 [ ↔ ] (Line cursor, vertical) key.




- To use the line cursor (horizontal)
- ① Select F3 [ ‡ ] (Line cursor, horizontal) key.
- ② The channel select option appears under the **csr** item. If 2 or more channels are being displayed, use the flashing cursor to select the channel for which you want to read the voltage (temperature) value with the A/B cursors.





- · This item does not appear when using the vertical line cursor.
- · Only channels for which a waveform is being displayed can be specified.
- · By specifying a different channel for the A and B cursors, a potential difference between the waveforms in the respective channels can be determined.




- To use the trace cursor
- ① Select F4 [TRACE].
- ② The channel select option appears under the csr item. Use the flashing cursor to select the channel for which you want to read the voltage (temperature) value with the A/B cursors. You can specify different channels for the two cursors.








Cursor type shown in reverse will be moved



Channel of cursor shown in reverse can be selected

- 4. Press the SELECT key so that the WAVE A.B CSR LED lights up. The JOG/SHUTTLE control now can be used for waveform scrolling and for operating the A/B cursors.
- 5. Each push of the function key F5 toggles between the waveform scroll mode and the A/B cursors mode. The display becomes as follows.




6. Use the function keys to select the cursor to be moved.

Press the desired function key, so that the display is shown in reverse. The respective cursor will be moved. Press the function key again to cancel.

7. The channel for the current cursor (shown in reverse) can be changed with the function keys (for horizontal and trace cursor).


- 8. Rotate the JOG control to move the cursor.
- · t, 1/t, v or f at the cursor position can be determined.
- · When the vertical cursor or trace cursor is used, cursor measurements are possible also when one of the cursors is currently off screen.





#### Cursor movement and waveform scrolling

- · Waveform scrolling behavior when the A/B cursors are moved differs, depending on whether the vertical/trace cursor or the horizontal cursor is used.
- · The FFT screen does not allow scrolling.
- ① Vertical cursor or trace cursor (Example: trace cursor) When cursor B is moved:
  - · When cursor B reaches the edge of the screen, the waveform scrolls to the left.
  - · Cursor A moves together with the waveform.




Cursor B is moved to the right

When cursor B is moved further, waveform scrolls to the left. Cursor A moves with waveform to the left.

#### ② Horizontal cursor

When cursor A is moved:

When cursor A reaches the edge of the screen, the waveform does not scroll.




Reference


When the vertical cursor or the trace cursor is off screen while using the memory recorder or recorder function, the HELP key can be used to check the cursor position within the total recording length ( F Section 20.4).

# 19.3 Scrolling the Waveform

- · The waveform on the display can be scrolled horizontally and vertically.
- · The FFT screen does not allow scrolling.

Screen: DISPLAY Method





Horizontal Scrolling

- 1. Press the SELECT key so that the WAVE A.B CSR LED lights up. The JOG/SHUTTLE control now can be used for waveform scrolling and for operating the A/B cursors.
- 2. Each push of the function key | F5 | toggles between the waveform scroll mode and the A/B cursors mode. Set the display as follows to use the scroll mode.
- · When horizontal scrolling is selected


Function key Meaning display : Horizontal scroll






A·B csr mode

Vertical scroll



(Position of current screen within recording length is also shown.)

Switch to A/B cursor operation screen ( Section 19.2).



Channel of currently scrolled waveform is displayed

· When vertical scrolling is selected

Function key display Meaning

scroll 1

CH 🎓

CH ↓

\* Horizontal scroll

: Vertical scroll


: Increase channel number: Decrease channel number

Switch to A/B cursor operation screen

ABCST mode : ( Section 19.2).


3. Use the function key display to select either vertical or horizontal scrolling. When vertical scrolling is selected, the channel of the scrolled waveform is shown.

4. Use the JOG/SHUTTLE control to scroll the waveform.




#### **Auto scroll**

Method (To scroll the waveform to the left)



Turn SHUTTLE control and hold for a few seconds






Auto scroll (also when control is released)

- 1. Move the SHUTTLE control in the direction into which you want to scroll the waveform and hold the control for a few seconds.
- 2. When the indication **Auto scroll** appears on the function key display, release the SHUTTLE control. The waveform continues to scroll.
- 3. By turning the SHUTTLE control once more in the same direction, you can increase the speed of the scrolling process.

Turning the control in the other direction reduces the scrolling speed. If you hold the control, the waveform will eventually scroll in the opposite direction.






The behavior of the A/B cursors during scrolling depends on whether the vertical/trace cursor or the horizontal cursor is used.

• When vertical or trace cursor is used (Example: vertical cursor)

When the waveform is scrolled, the cursor moves off screen together with the waveform.




Waveform is moved to the left

Waveform moves to left. Cursor also moves to left.

#### • When horizontal cursor is used

Cursor position on screen does not change, also when waveform is scrolled.



# Chapter 20 LEVEL MON. / CH.SET / HELP Keys

#### 20.1 Overview

This chapter explains the use of the following three keys:

- · LEVEL MON. key (input level check)
- · CH.SET key (input channel setting)
- · HELP key (waveform display position check)


#### 20.2 Checking the Input Level (LEVEL MON. Key)

- · The levels of all input waveforms can be monitored in real time.
- · Levels are displayed separately for CH1 CH16 and logical CH A CH D.
- · To select the input channel, use the CH.SET key. ( F Section 20.3)
- · This function is available in all modes.

#### Method

1. Press the LEVEL MON. key.

The level monitor function can be activated from any screen (STATUS, CHANNEL, display, SYSTEM, DAT, etc.).




- 2. The CH.SET key can be used to select the input channel while using the level monitor function ( section 20.3).
- 3. Press the LEVEL MON. key once more to terminate the function.




For the following channels, analog input level is not displayed:

- · Channels where no unit is installed
- · Channels outside the "units in use" range
- · Channels specified as logic input channels




#### Analog input display



#### Logic input level display

Logic inputs are displayed as follows.




## 20.3 Selecting the Input Channel on the Display Screen and Level Monitor Screen (CH.SET Key)

Channel settings can be made while a waveform is displayed on screen.

#### Method Screen: DISPLAY

- 1. Press the CH.SET key while the display screen or level monitor screen is shown. The channel setting screen appears.
- 2. The display content changes with each push of the CH.SET key.




3. Move the flashing cursor to the item you want to change and make the setting.

For details on settings, refer to Chapter 9.




- · During use of the FFT function, logic input settings cannot be made.
- During use of the STATUS screen (page 2) and the CHANNEL screen, the CH.SET key serves to switch the display between CH1 CH8 and CH9 CH16.
- · When the input channel setting screen was called up with the CH.SET key, the following functions are not available:
  - (1) Copying channel settings
  - (2) Input waveform selection
  - (3) Switching the variable function on and off



- · Adjusting the input voltage to any desired voltage (Vernier function)
- · Using fine adjustment, the input voltage can be matched to a desired reading.
- · For example, an actual input voltage of 1.2 V can be converted to a 1.0 V reading.

Method Screen: DISPLAY, level monitor



Channel for which the Vernier function is activated


- 1. Press **CH.SET** key on the DISPLAY screen or the level monitor screen, to display the channel setting screen.
- 2. Move the flashing cursor to the channel number.
- 3. Adjust the channel by using the jog control.



The Vernier function is not applicable to a waveform after waveform processing.

Copying the Vernier setting

Method Screen: DISPLAY, level monitor



- 1. Move the flashing cursor to the channel number of the copy destination.
- 2. Press the F5 [copy mode] key.
- 3. Using the [CH  $\uparrow$ ] or [CH  $\downarrow$ ] jog control, select channel of the copy source.

Function key display

Meaning

CH +

CH 3

CH →

: Increase the channel number

: Copy source channel

: Decrease the channel number

cancel

: Exit copy mode

4. Press the  $\boxed{\text{F4}}$  [ exec ] key to copy the settings.

#### 20.4 Checking the Waveform Display Position (HELP Key)

The HELP key serves to check the following items:

(1) Position display

Shows the position of the currently displayed waveform within the entire recording length (memory recorder, recorder).

(2) Bar graph


Shows the display position within the entire recorded waveform along the voltage axis (shown at the same time as the position display).

(3) Block display

Shows the memory segmentation status (memory recorder).

Method Screen: DISPLAY

1. Press the HELP key. The position display appears.




2. With each push of the F5 [ block↔position ] key, the display switches between the block display and the position display.




- · The memory segmentation function can only be used with the memory recorder.
- · When memory segmentation is disabled, the block display is not shown. (For details on memory segmentation, see Chapter 17.)

#### Position display




Block display (Memory recorder only)



- 3. To terminate the position display mode or block display mode, press the HELP key once more.
- 1 Position display

Position display

- · Indicates the position of the currently displayed waveform within the entire recording length.
- · When the trigger position and A/B cursors are used, their positions are also shown.
- · The position display mode can be used to rapidly shift the displayed waveform.



#### Shifting the display position

The waveform display position can be specified in three ways.


- (1) Position
  Specify the position of the shift point.
- (2) Time
  Specify the time (from recording start) of the shift point.
- (3) Event mark


  Specify the event mark of the shift point (For information on how to set event marks, refer to Section 13.5.2.)


NOTE


Methods (2) and (3) can be used only with the recorder function.


- 1. Record a waveform or read it from tape.
- 2. Press the HELP key.
- 3. Specify the part to be shown on the display. (The part is shown in detail.)












4. When the F4 [exec] key is pressed, high-speed shift is carried out and the display position changes.

NOTE

The display can be moved to the following 8 positions.

- (1) The start of 4 equal sections into which the recording length is divided
- (2) End of the recording length
- (3) Position of the A/B cursors
- (4) Trigger position


When the recording length is longer than four times the display screen range, the above may not apply.



#### Trigger searching


From waveforms recorded in memory or on tape, you can search for points which satisfy the current trigger conditions.

#### Method Screen: DISPLAY



- 1. Record a waveform, or read it from tape.
- 2. Press the HELP key.
- 3. Switch to the function key indication 4/4.
- 4. Use the CURSOR keys to move the flashing cursor and select the range in which trigger searching is to be carried out.


  Use the jog control or function keys to specify the range, starting from the data start, cursor A position, cursor B position, left edge of current screen, or data end.




5. Press the F4 [exec] key to start searching.

#### 2 Bar graph

- · In position display mode, the bar graph indication is also shown.
- · The bar graph indicates which part of the recorded waveform is currently being shown on the screen.
- · For all displayed waveforms, the bar graph is shown with the channel number.






#### ③ Block display (memory recorder function only)


- · When memory segmentation is being used, the memory block status is shown.
- · In block display mode, the memory block that is currently being shown on screen can be changed. (For details on memory segmentation, see Chapter 17.)
- · Display shift can be carried out in the same way as in position display mode.

Memory segmentation, 15 blocks, 9 used




#### Changing the currently displayed memory block

#### Method



#elp



- 1. When block display is selected, the currently displayed memory block is indicated.
- 2. Use the F2 [→] and F3 [←] keys to move the ☐ mark and specify the memory block you wish to display.

Function key display Meaning

Help: (Display only)

Specify shift position

Execute shift

3. Press the F4 [ exec ] key to shift the display to the selected memory block.

display

Toggle position display and block


# Chapter 21 External Input/Output Connectors / Key Lock Function

#### 21.1 Overview

The input/output connectors of the 8845 serve the following functions:

- · Measurement start/stop, printer output control
- · Trigger signal input/output
- · Sampling rate control via external signal
- · Waveform evaluation NG output
- · Microphone input

The KEY LOCK switch can be used to temporarily disable the other controls of the 8845.



#### 21.2 Using the External Start, Stop, and Print Terminals

**⚠** CAUTION

To prevent damage to the unit, take care never to exceed the voltage rating of the inputs.

Using the external input terminals, recording start/stop and printer output can be controlled for all functions.

START terminal Measurement starts when a signal is input here.
 STOP terminal Measurement stops when a signal is input here.
 PRINT terminal Printing starts when a signal is input here.

#### Signal input method

· Short the terminal to ground, or input a pulse signal (High level: 2.5 - 5.0 V, Low level: 0 - 1.0 V) or a square wave signal.

· Control is activated at the falling edge of the input waveform (active Low).


Voltage range High level: 2.5 - 5.0 V

Low level: 0 - 1.0 V


Pulse width High level: min. 20 ms

Low level: min. 10 ms

Maximum input rating -5 to 10 V



#### Using the terminals



1. Push the tab with a flatblade screwdriver or similar.

2. While keeping the tab depressed, insert a stripped wire into the connector opening.

3. Release the tab to lock the wire.

Recommended wire

Single strand: 1.0 mm dia. (AWG #18)

Multi-strand: 0.75 mm<sup>2</sup>

Usable limits


Single strand: 0.3 to 1.0 mm dia. (AWG #26 to #18) Multi-strand: 0.3 to 0.75 mm<sup>2</sup> (AWG #22 to #20)


Strand diameter: minimum 0.18 mm

Standard insulation

stripping length

10 mm





#### 21.3 Using the External Trigger Input (EXT TRIG)

**⚠** CAUTION

To prevent damage to the unit, take care never to exceed the voltage rating of the EXT TRIG input.

- · An external signal can be used as trigger source.
- · Several 8845 units can be synchronized for parallel operation.

#### Signal input method

- · Short the terminal to ground, or input a pulse signal (High level: 2.5 5.0 V, Low level: 0 1.0 V) or a square wave signal.
- · Triggering is activated at the falling edge of the input waveform (active Low).


Voltage range High level: 2.5 - 5.0 V

Low level: 0 - 1.0 V

Pulse width Low level: min. 5  $\mu$  s

Maximum input rating -5 to 10 V

Connector type miniature phone jack, 3.5 mm dia.



#### 21.4 Using the External Trigger Output (TRIG OUT)

**⚠** CAUTION

To prevent damage to the unit, take care never to exceed the voltage rating of the TRIG OUT input.

- · When triggering occurs, a signal is output from this connector.
- · Several 8845 units can be synchronized for parallel operation.

#### Trigger output signal

Signal type open-collector signal, active Low

Output voltage High level: 4.5 - 5.0 V range Low level: 0 - 0.5 V


Pulse width approx. 1.5 ms

Maximum input rating -20 to +30 V, max. 500 mA, max. 200 mW

Connector type miniature phone jack, 3.5 mm dia.

NOTE

When the auto range function is activated by pressing the AUTO key, a trigger output signal is generated. This should be taken into consideration when using both the trigger output and the auto range function (memory recorder, recorder).



#### 21.5 Using the External Sampling Input (EXT SMPL)

**⚠** CAUTION

To prevent damage to the unit, take care never to exceed the voltage rating of the EXT SMPL input.

An external signal can be used to set the sampling rate.

#### Signal input method

- · Between the terminal and ground, input a pulse signal (High level: 2.5 5.0 V, Low level: 0 1.0 V) or a square wave signal.
- · Sampling is activated at the falling edge of the input waveform (active Low).

Voltage range High level: 2.5 - 5.0 V

Low level: 0 - 1.0 V

Pulse width

Low level: min. 1  $\mu$  s

Frequency

Memory recorder, FFT function

max. 180 kHz

max. 90 kHz (when 8927 is used)


Recorder function

	Number of units in use	1		2		4		8	
		1 ch	2 ch						
	kHz max.	80	40		20		10		5

1ch: Only 8916 - 8919, 8928 can be used.

2ch: 8916 - 8919, 8927, 8928 can coexist, or 8927 can be used exclusively. (For the 8928, one channel corresponds to one unit.)

Maximum input rating  $\,$  -5 to 10~V



#### **Connection method**

Refer to Section 21.2.

#### 21.6 Using the NG Evaluation Output (NG)

**⚠** CAUTION

To prevent damage to the unit, take care never to exceed the voltage rating of the NG output.

When waveform evaluation or waveform parameter evaluation is used, a signal is output from this connector when the result is NG (fail).

#### NG output signal

Signal type

open-collector signal, active Low


Output voltage

High level: 4.5 - 5.0 V

range

Low level: 0 - 0.5 V

Maximum input rating -20 to +30 V, max. 500 mA, max. 200 mW



#### ① Evaluation output interval (min. 70 ms)

When the evaluation result is GO (pass), the output is High level, and when the result is NG (fail), the output is Low level. Between these states, there is an interval during which the next data are read and waveform data are created. The duration of this interval is inversely proportional to the time axis and proportional to the recording length.

#### 2 Evaluation interval (approx. 20 ms)

The output is High level. Evaluation is carried out during this interval.

#### Connection method

Refer to section 21.2.

#### Setting the output to be active on GO result

- (1) When waveform evaluation is used
- 1. Set the waveform evaluation mode to "All out".
- 2. Use the area editor to create the GO area.
- 3. Use the "reverse" command to reverse the evaluation area, so that the GO area is shown in white.

Now start the measurement. A signal will be output from the NG terminal when the waveform evaluation result is GO.

- (2) When waveform parameter evaluation is used
- 1. Set the upper and lower limit.
- 2. When lower limit < GO range < upper limit, set the evaluation mode to "In". When GO range < lower limit, upper limit < GO range, set the evaluation mode to "Out".

Now start the measurement. A signal will be output from the NG terminal when the waveform parameter evaluation result is GO.

NOTE

If the result of either waveform evaluation or waveform parameter evaluation is NG, NG is output.

#### 21.7 Using the Microphone Input (MIC)

#### **⚠** CAUTION

- To prevent damage to the unit, take care never to exceed the voltage rating of the MIC output.
- Do not connect any other equipment besides a microphone to this jack.
- · This input serves for recording a voice memo when using the recorder function.
- · For details on how to record a voice memo, refer to Section 7.2.8.

Maximum input rating: 0 to 5.0 V DC + AC peak

Connector type: miniature phone jack, 3.5 mm dia.

Input configuration: mono



- · When using a stereo microphone, a stereo-to-mono adapter should be used.
- · For microphones with standard-size phone plugs (6.3 mm dia.) or with other plugs, a suitable plug adapter should be used.
- · The 8845 does not provide a microphone power supply.

#### Microphone types

The following microphone types can be used:

Dynamic microphone

Electret condenser microphone (with internal battery)

The following microphone models have been verified to work with the 8845.

· Dynamic microphones

DM-H110 (Aiwa)

AT-K40 (Audio Technica)

F-V310 (Sony)

MV-K2 (JVC)

RP-VK2 (Matsushita)

· Electret condenser microphones

AT9820 (Audio Technica)

ECM-Z70 (Sony)

ECM-T110 (Sony)

RP-VC3 (Matsushita)


#### 21.8 Using the Key Lock Function

- · This function disables all front-panel controls of the 8845.
- The function serves to prevent unintended changes to settings during a measurement.

#### Method

- 1. Set the KEY LOCK switch to ON.
- 2. To cancel the function, set the KEY LOCK switch to OFF.


  (The key lock function will not be canceled by turning the power off and on.)
- · When the key lock function is active, the indication "Key Lock" is shown on the display.
- · If the backlight saver function is used and the display backlight turns off, it can be turned on again by touching any key. The function assigned to the key will not be activated.



## Chapter 22 Using the D/A Output Unit 9539 (Option)

#### 22.1 Overview

The D/A output unit 9539 can be used to convert the waveform data captured with the recorder function into an analog voltage waveform (step waveform) with a range of +6.4  $\rm V$  to -6.4  $\rm V$ .



#### 22.2 Specifications

Specifications measured at  $23\%\pm5\%$ , relative humidity 35% - 80%, one hour after power-on. Guarantee period is 6 months.

Output voltage	when measured with 8916, 8917, 8919, 8927, 8928 : $\pm 6.4~V~(250~mV/DIV)$ when measured with 8918 : 125 mV/DIV					
	Temperature range (°C/DIV)	Recording range (°C)	Output voltage (V)			
	10 20 50	-90 to 421 -90 to 842 -90 to 1200	-1.1359 (*1), -1.125 to 5.2625 (*2) -1.1359 (*1), -0.5625 to 5.2625 (*2) -1.1359 (*1), -0.225 to 3, 5.2625 (*2)			
	*1: For recorded values lower than -90°C, -1.1359 V is output.  *2: In the following cases +5.2625 V (DC) is output:  · Recorded value exceeds the measurement range of the thermocouple.  · Recorded value exceeds the upper limit of the measurement.  · Recorded value was taken in burnout condition of thermocouple.					
Maximum output voltage	num output voltage ±6.4 V (open-load condition)					
DC amplitude precision						
DC offset precision						
Temperature characteristics		de: ±0.02% f.s./°C(typ.) 0.02% f.s./°C(typ.)				
Output format	unded), output ground directly					
Output impedance	$50 \Omega \pm 10\% (DC)$					
Load impedance	$1~k\Omega$ or more (DC), 10000 pF or less (possible drive range)					
Output waveform	put waveform Step waveform (no smoothing filter)					
Output resolution	12 bit (for output of data measured with 8916, 8917, 8918, 8919, 8928) 14 bit (for output of data measured with 8927)					
Update rate	e rate 20 kS/s(max.) (corresponding to sampling rate of recording functi					
Number of output channels						
Output connector type	BNC					
Dimensions and mass	Dimensions and mass 29.8(W)×106.8(H)×108(D)mm (not including projection), 110g					


#### Output voltage

The relation between the measured voltage (temperature) and the output voltage is shown.




- · The output voltage of  $\pm 6.4$  V (max.) applies to the open-load condition. Use the unit with load impedances of 1 k $\Omega$  or less. (At higher output impedances, the waveform will be distorted.)

#### Using the 8916, 8917, 8919, 8927, 8928



#### Using the 8918



#### NOTE

When magnification/compression is  $\times 1$ , the D/A output voltage per 1 DIV of measured temperature is 125 mV.

#### Example

When  $10^{\circ}$ C was measured using the  $10^{\circ}$ C/DIV range, the D/A output is 125 mV DC.

#### 22.3 Usage Precautions



- The output connector ground of the D/A output unit 9539 is directly connected to the frame ground of the 8845. Therefore it is essential to connect the protective ground terminal of the 8845 to a good ground. Otherwise, a potential may exist between the output connector and exposed metal parts of the 8845.
- Do not apply an external voltage to the output connectors, to prevent the risk of electric shock and damage.



- When power to the 8845 is turned on or off, voltage spikes may be present in the D/A output. Ensure that no equipment is connected to the D/A output unit 9539 when turning the 8845 on or off.
- For reference, the intensity of the voltage spikes is shown below.

Power ON: approx. 6 Vp-p (approx. 100 ms) Power OFF: approx. 4 Vp-p (approx. 100 ms)


**⚠** CAUTION

The D/A output unit 9539 is designed only for use with the 8845 MEMORY HiCORDER. Do not use it for any other purpose.



- · When the D/A output is used, do not connect other equipment or measurement objects to the input of the 8927 unit. Otherwise noise currents flowing in the ground line may cause signal noise.
- · To minimize susceptibility to external noise, use a BNC-BNC cable.


#### 22.4 Replacing Units



- To prevent the risk of electric shock, be sure to turn the power to the 8845 OFF before inserting or removing the unit.
- Fasten the screw securely, to prevent the risk of performance degradation or damage.

This section describes how to install the D/A output unit 9539. To remove the unit, reverse the procedure described below.

- 1. Disconnect all input cables and the thermocouple connection.
- 2. Turn power of the 8845 off and disconnect the power cord.
- 3. Grasp the BNC connectors on the D/A output unit and insert the unit into the expansion slot.
- 4. Secure the unit by fastening the screw with a Phillips screwdriver, as shown in the illustration.




### 22.5 Output of a Waveform Recorded With the Memory Recorder or Recorder Function

A waveform recorded can be output in two ways:

- (1) Outputting data in memory on the unit or data read from tape into the unit, specifying the range for output, using the A/B cursors (vertical or trace).
- (2) Using the "playback" function and supplying the data side to the output. (Recorder function only)


NOTE

- · Waveform data recorded with a sampling frequency of 40 kS/s (2.5 ms/DIV) or above for the time axis are output in intermittent form. (At 2.5 ms/DIV, 1 point is output for every 2 points, and at 2 ms/DIV and 1.25 ms/DIV 1 point for every 4 points.
- · Waveform data gathered with external sampling cannot be output.
- The waveform data recorded with the maximum recording length in memory recorder function can not be replayed. (Section 6.2.3)
- · For the waveform data measured by one channel, recording length of 10000 divisions, and range lower than 5mS/DIV time axis in memory recorder function, it is not replayed when the data between A and B cursors is more than 5000 divisions.
- (1) Specifying output range with A and B cursors



#### Method

Record the waveform in Memory recorder or Recorder function or read data of MEM\_WAVE, R\_WAVE file from a DDS tape,




Status screen in Memory recorder or recorder function

STATUS \*\*\* RECORD (page1) 11:37:28 time/div: (100Hz) time/div zoom: 1s/DIV) 000d00h01m00s recording time: format: dot-line: recording medium: file name: [HIOKI 8845 DAT print mode: smooth print: (1) OFF mic: 7 (execute) A/B cursor playback output channel1: output channel2: mode: 5 SINGLE 6


4

- 1. Record the waveform data in memory recorder or recorder function, or read data from DDS tape (M\_WAVE, R\_WAVE files).


  ( IF Section 13.6).
- 2. The data in the specified function are shown on the display when the data is read.
- 3. Scroll the waveform and use the A/B cursors (vertical or trace) to specify the range for output ( Section 19.2).
- 4. Press the STATUS key to activate the STATUS screen (memory or recorder).
- · When the D/A output unit is installed, the setting item A/B cursor playback appears.
- 5. Move the flashing cursor to the **Output channel** item and specify the channel of the waveform to be output.



6. Move the flashing cursor to the **mode** item and select the output mode.




7. Move the flashing cursor to the **execute** item of "A/B cursor playback".



- 8. Press the F1 [exec] key. The specified waveform range is output.
- 9. If "Output mode" is set to **REPEAT**, press the STOP key when wishing to stop the output.
- (2) Using the "playback" function and supplying the data side to the output. (Recorder function only)

Output of data in real time from D/A output unit

For details on playback, refer to Section 13.6.2.



NOTE

If the STOP key was pressed to force measurement stop while the D/A output (A/B cursors, playback) is active, 0 V is output.

# Chapter 23 Maintenance

## 23.1 Cleaning of the Unit and Parts

#### (1) Main unit

Gently wipe dirt from the surface of the unit with a soft cloth moistened with a small amount of water or mild detergent.

Do not try to clean the unit using cleaners containing organic solvents such as benzine, alcohol, acetone, ether, ketones, thinners, or gasoline. They may cause discoloration or damage.

## (2) Printer head

In normal use, the printer does not require periodic maintenance. However, depending on usage conditions, the thermal head may become contaminated by dust or paper scraps. If the print seems light or if there are dropped sections, clean the head as described below.


#### Method 1

- 1. Press the SYSTEM key to call up the SYSTEM screen.
- 2. Press the [SELF CHECK] function key.
- 3. Move the flashing cursor to the **Printer check** item.
- 4. Press the F5 [CLEANING] key for about 5 seconds. During this interval, the printer prints 100% black section.
- 5. If this method does not alleviate the problem, perform the steps of cleaning method 2 as described below.

#### Method 2

- 1. Moisten printer paper on the rear with dehydrated alcohol, and set the paper in the printer. (If the front side of the paper is moistened, discoloring will occur.)
- 2. Raise the head-up lever and move the printer paper back and forth to clean the head.

Moisten this side with cleaning alcohol




NOTE

- · Do not use organic solvents such as thinners and sandpaper.
- · After using alcohol, be sure that the printer is completely dry.
- · After extended use, paper residue (visible as a white powder-like substance) may accumulate on the roller. While a small amount of residue has no adverse effect, the roller can be cleaned using a air-blow brush (such as sold as a camera accessory).
- · Always use the paper cutter integrated in the printer cover to cut printer paper. If the paper is cut near the thermal head, a large amount of paper residue may accumulate on the roller.

#### (3) DAT drive head

NOTE

- · When the green TAPE indicator on the DAT drive flashes, the drive must be cleaned, using a commercially available cleaning tape for DDS type drives.
- · As a precautionary measure, the drive should be cleaned about every 50 hours of use, also if the TAPE indicator is not flashing.
- · Use the cleaning tape supplied or cleaning tapes expressly designed for DDS (Digital Data Storage) systems. Cleaning tapes designed for audio DAT recorders will not be recognized as cleaning tape.



### Cleaning procedure

- 1. Insert the cleaning tape into the tape slot.
- 2. The drive automatically recognizes the tape as a cleaning tape and runs it for about 10 seconds.
- 3. The tape is automatically ejected.

NOTE

- · Do not rewind the cleaning tape.
- The green TAPE indicator has various operation patterns. ( Section 13.3) When the indicator flashes slowly, the tape is damaged or worn. If the indicator still flashes after cleaning was performed, the DDS tape is worn and should be replaced.



## 23.2 Replacing the DC Power Supply Fuse

- · When the unit is powered from a DC source, and the DC power supply fuse has blown, replace the fuse as described below.
- The fuse for the AC power supply is integrated in the unit and cannot be replaced by the user. When the unit does not operate normally using the AC power supply, contact a HIOKI service representative.




- If the fuse has blown, an internal defect in the power supply section of the 8845 may be cause. Check for defects before replacing the fuse.
- To prevent the risk of electric shock when replacing the fuse, turn power to the 8845 OFF and disconnect the power cord from the AC outlet. Also disconnect any input cables from measurement objects.
- Use only a fuse of exactly the specified rating and type. Never use a different fuse or short-circuit the fuse holder, since this involves a severe risk of electric shock and injury.

Type A melting fuse (NM), 12 A/250 V

Size: 6.4 dia. imes 31.8 mm

#### Replacement procedure

- 1. Set the power switch of the 8845 and the intermediate switch on the DC power supply cable to OFF.
- 2. Disconnect the AC power cord and the DC power cord.
- 3. Remove the old fuse from the fuse holder.
- 4. Insert a new fuse.
- 5. Reconnect the power cord and other cables.



## 23.3 Removing the Battery Before Discarding the 8845


- · The 8845 incorporates a lithium battery for memory backup.
- · Before final disposal of the 8845, remove the battery as described below.




- To avoid the risk of electric shock, be sure that all cables and the power cord are disconnected before removing the battery.
- Dispose of the battery as prescribed in your community.

#### Removing the battery


- 1. Verify that the power is switched OFF.
- 2. Disconnect all input cables and the power cord.
- 3. Remove the 8 screws which fasten the rear panel, using a Phillips screwdriver.



4. Remove the rear panel. The battery is located near the center of the PCB.



- 5. Pull the battery up and cut the positive terminal with a wire cutter.
- 6. Pull the battery further up.
- 7. Cut the negative terminal (under the battery) with a wire cutter.



## 23.4 Troubleshooting

If the unit does not seem to operate normally, check the following points before requesting service.

Problem	Check	Ref. page
LED does not light when the unit is turned on.	Is power cord connected properly?	45, 46
The screen and indicators do not light when using the DC power supply.	Has the fuse for the DC power supply blown?	450
There is absolutely no variation in the recorded waveform.	Is the "Pretrigger stanby" message displayed? (When pretriggering is activated, triggering does not occur until the current waveform is fully captured.)	203
	Has the "Waiting for trigger" message appeared? Check the trigger settings.	201
	Are all of the channels switched off on the display?	181
	Has the timer trigger been set?	216
There is absolutely no variation in the recorded waveform.	Is the measurement range setting appropriate?	184
	Has a low pass filter been set?	191, 193
The printed recording is non-existent.	Is the recording paper back to front?	54, 57
The printed recording is very faint	Are you using the correct (thermal) recording paper?	21, 57
During memory recorder operation, the apparent frequency of the recording is much lower than the expected frequency.	This is likely to be an aliasing error.  Either switch to envelope mode, or make the time axis range setting faster.	84, 107, Appendix 6
Recording lines are dense or blurred.	Input signal contains ripple components.  Make suitable filter settings at input unit.	191
The keys are dead and do not respond.	Has the unit been put into the key lock condition (message "KEY LOCK" appeared?  Press the KEY LOCK key to clear the key lock condition.	438
	Is the unit being remotely controlled ("GP-IB REMOTE" is displayed), if the GP-IB interface is being used?	

If none of the above conditions apply, and the cause of the problem is not understood, try performing a SYSTEM RESET.

All the settings will revert to the factory settings.

Try the following operation, 1 or 2.


## System reset

#### Method 1

- 1. Press the SYSTEM key to call up the SYSTEM screen, and select the **Initialize** item.
- 2. Move the flashing cursor to the (3) Initialize settings item and press the [exec] function key.

For details, refer to Section 11.3.3.

**Method 2** Turn the unit on while holding down the STOP key.



Turn unit on while pressing STOP key.

Chapter 24

Messages

**Error and Warning** 

## 24.

24.1 Overview

### Error messages

- · Error messages are shown at the bottom of the screen.
- Error messages are displayed until the cause of the error is removed or a key is pressed (in some instances, only the STOP key can be used).
- · If the volume setting is ON (High, Medium, Low), an intermittent beep sound is heard along with the error message.

### Warning messages

- · Warning messages are shown at the bottom of the screen.
- · Warning messages are displayed only once when the cause occurs.
- · Warning messages disappear when a key is pressed.
- · If the volume setting is ON (High, Medium, Low), a single beep sound is heard along with the warning message.

## 24.2 Error Messages

Error no.	Message and explanation	Reference
1	Set printer paper Printer paper has run out. Load paper. Then keep the PRINT key depressed for a while.	54
2	Set printer lever Head up/down lever is raised. Lower the lever. Then keep the PRINT key depressed for a while.	54
3	No Waveform data There are no waveform data to be printed.	
41	Bad A/B cursor position Move A/B cursors to appropriate position.	402

## 24.3 Warning Messages

Warning no.	Message and explanation	Reference
201	Set printer paper Printer paper has run out. Load paper. Then keep the PRINT key depressed for a while.	54
202	Set printer lever Head up/down lever is raised. Lower the lever. Then keep the PRINT key depressed for a while.	54
205	Invalid key (measurement in progress) Pressed key is invalid, because measurement is being carried out.	
207	Auto setting failed Automatic range setting was not completed successfully.	100, 123
211	Auto store failed	
212	Bad A/B cursor position Move A/B cursors to appropriate position.	402
213	Invalid key (MEASUREMENT) Pressed key is invalid, because 'measurement' is ON.	
300	Cannot start Cannot start measurement from SYSTEM screen.	
301	Invalid key (SYSTEM screen) Pressed key is invalid, because SYSTEM screen is being displayed.	
302	Invalid key (DAT screen) Pressed key is invalid, because DAT screen is being displayed.	
303	Invalid key (monitor screen) Pressed key is invalid, because monitor screen is being displayed.	
324	Waveform processing not possible (averaging) Waveform processing cannot be carried out, because averaging is being used.	
327	Invalid key (evaluation) Pressed key is invalid, because waveform evaluation is being carried out.	
328	Invalid key (superimpose) Pressed key is invalid, because superimpose function is active.	
329	Invalid key (display format) Waveform evaluation cannot be carried out, because display format is not single screen or X-Y single screen.	
330	Invalid key (recording length) Memory segmentation and waveform processing cannot be carried out, because recording length is too long.	321, 382
331	Invalid key Recording length setting too high for averaging.	393
332	Invalid key (display format) Waveform evaluation cannot be carried out, because display format is not single screen or Nyquist display.	

Warning no.	Message and explanation	Reference
335	Invalid key (sequential save) Waveform processing cannot be carried out, because sequential save is active.	
336	Invalid key (multi-block) Waveform processing cannot be carried out, because multi-block function is active.	
337	Invalid key (roll mode) Superimpose and waveform processing cannot be carried out, because roll mode is active.	
339	Invalid key (STATUS screen) Pressed key is invalid, because STATUS screen is being displayed.	
340	Invalid key Recording length not set.	
341	Invalid key (multi-block) Multi-block function is active. Number of units cannot be changed.	
351	Invalid key (trigger) Pretrigger setting cannot be made, because all trigger sources are OFF (free-run condition).	203
352	Invalid key (CHANNEL screen) Pressed key is invalid, because CHANNEL screen is being displayed.	
353	Invalid key (trigger) Pretrigger cannot be used with external sampling.	
361	Cannot print Choose a shorter logging cycle.	94, 268
380	No data in reference memory block There are no data in the reference memory block for the multi- block function.	
381	Same setting for reference memory block and current block Reference memory block and currently used block are set to the same values.	
382	No waveform data Display screen cannot be used because there are no waveform data.	
383	No memory waveform data Record waveform data with FFT processing using memory function.	
384	Invalid reference memory block recording length The recording length of the reference memory block is different from the recording length of the current block. Record data with same recording length.	
385	Invalid key (FFT) Pressed key is invalid, because FFT function is being used.	
386	Invalid key (recorder) Pressed key is invalid, because recorder function is being used.	
388	No waveform evaluation area Create waveform evaluation area.	362

Warning no.	Message and explanation	Reference
390	Invalid key (upper limit) Setting cannot be higher than upper limit.	
391	Invalid key (lower limit) Setting cannot be lower than lower limit.	
392	Invalid key (2 units use) Recording length cannot be set to higher value because 2 units are being used. Reduce number of units.	85
393	Invalid key (4 units use) Recording length cannot be set to higher value because 4 units are being used. Reduce number of units.	85
394	Invalid key (8units use) Recording length cannot be set to higher value because 8 units are being used. Reduce number of units.	85
396	Out of range Setting range of variable function is exceeded.	85
397	Out of range Setting range of scaling function is exceeded.	243
398	Out of range Setting range of variable function after scaling is exceeded.	244
400	DAT not inserted No DDS tape is inserted.	285
401	Cannot read data (DAT) File does not contain data recorded with 8845.	
402	Format error (DAT) The DDS tape is not formatted for use with the 8845.	
403	Write protect (DAT) DDS tape is write protected. Set write protection to OFF.	284
404	Insufficient capacity (DAT) Store cannot be carried out, because there is not enough remaining capacity on the DDS tape.	300
405	File access error (DAT) File access during store or format operation failed.	
406	DAT is removed Insert a DDS tape.	285
407	Cannot store (DAT) File cannot be stored because maximum number of files (1000) is reached.	284
410	Auto store error (write protect) Auto store cannot be carried out, because DDS tape is write protected. Set to write enable.	
411	Auto store error (insufficient capacity) Auto store cannot be carried out, because there is not enough remaining capacity on the DDS tape.	300
412	Auto store error (no tape) Auto store cannot be carried out, because there is no DDS tape in the drive.	
413	No file (DAT) Read operation failed because there is no file on the DDS tape.	

Warning no.	Message and explanation	Reference
414	No file (DAT) Erase operation failed because there is no file on the DDS tape.	
415	Increased error count (DAT) Read and write error count has exceeded 100.	288
416	No waveform data Store could not be carried out, because there are no waveform data.	
417	No waveform evaluation area Store could not be carried out, because there is no waveform evaluation area.	
418	Cannot playback (external sampling) Playback cannot be carried out, because waveform was recorded with external sampling.	303
419	Cannot playback (not a loaded waveform)	
420	Invalid key (X-Y display) Pressed key is invalid,, because current display format is X-Y display.	
421	Syntax error Equation contains a syntax error. Correct equation.	323, 324
422	Cannot copy equation Copy function cannot be carried out, because the copy source equation contains a Z number higher than the copy target equation.	326
423	Halt the calculation. Pressing the stop key halts calculation.	
424	Octave processing error Octave processing cannot be carried out, because the frequency range uses external sampling.	
430	Invalid key (start time) Start time cannot be later than end time.	
431	Invalid key (end time) End time cannot be earlier than start time.	
440	Invalid key Other unit set to logic input.	
441	Invalid key (playback in progress)	
442	Maximum number of files reached No more files can be stored on this DDS tape.	
443	Tape capacity insufficient No more files can be stored on this DDS tape.	
444	Tape not formatted	
445	Data with faster range than 5 ms/DIV cannot be played back.	
446	A trigger filter could not be set with current time axis range. The filter is invalid.	208
447	Data cannot be loaded In multi-block mode, waveform cannot be loaded into an empty block.	385

Warning no.	Message and explanation	Reference
450	No waveform data Transfer could not be carried out, because there are no waveform data.	
451	Adjustment of auto-balance failed	
452	Cannot transfer. Too long recording length in memory recorder function. The waveform data is measured by time axis range; 1.25 or 2 ms/DIV, using the 8927 1 unit.	120
453	No file (DAT) Cannot change the file name.	
454	Invalid key The time axis cannot be set differently from the original recorder waveform.	
455	Cannot start. "DATtoMEM" has already been executed up to the end.	
456	Cannot load. File cannot be loaded because the ROM version is out of date. Upgrade the ROM version.	
537	Cannot playback. Playback could not be carried out, because there are no waveform data.	
538	Cannot playback Recording length setting too high for playback.	444
539	Cannot start 'DATtoFFT' has already been, executed up to the end.	

## **Appendix**

## Appendix 1 Glossary

- % RH	Relative humidity (relative amount vs. saturation amount of moisture vapor in one cubic meter)
A	
A/D	Conversion of an analog quantity into a digital quantity
A/D converter	Device for analog-to-digital conversion
AC	Abbreviation of "alternating current".
Active Low	An action is performed when the signal voltage state changes from High to Low.
Aliasing	Phantom signal components; a phenomenon that occurs if sampling frequency is low in relation to the frequency of the sampled signal (
Analog	Continuous physical quantity such as voltage or current
ANSI	American National Standards Institute; also used for standards issued by this institute.
Attenuator	Device for reducing the level of a signal
Averaging	Determining the mean of a certain number of data.
В	
Bit	Smallest unit of binary information
Byte	Unit of information. 1 byte is made up of 8 bits.

## C

Channel (CH)	Input signal route
Channel crosstalk	Interference between signals in adjacent channels
Chart	Printout of recorded waveform
Chart speed	Paper feed rate at which the chart was created
Chassis	Metal frame of the unit
Comment	A string input by the user. Also measurement conditions and other information printed for all functions.
Common mode	Voltage between ground and measurement input line
CPU	Abbreviation of "central processing unit", the central component of a computer
Crest factor	Peak value/rms value
Cutoff frequency	Point where the filter output amplitude is $1/\sqrt{2}$ of the input.

## D

D/A	Conversion of a digital quantity into an analog quantity
D/A converter	Device for digital-to-analog conversion
DAT	Abbreviation of "Digital Audio Tape" recorder
dB (decibel)	Unit for expressing the ratio of attenuation or gain, for voltage, current, power etc.
DC	Direct current
DDS	Abbreviation of "Digital Data Storage". A DAT format for storing digital data.
Digital	Discrete physical quantity
DIV (division)	Increment on display or printout
Dot	One display point on the LCD screen. Also, a point on a waveform without interpolation.
Dynamic range	Ratio of maximum vs. minimum amplitude that can be displayed

## E

Envelope	A curve connecting the peaks of successive cycles of a signal

## 

FFT Abbreviation of "Fast Fourier Transform" ( F Appendix	
File	A collection of data on a medium such as tape
Floating	Electrical circuits that are configured separately and kept apart
Full-span voltage	Voltage range that can be expressed by 20 DIV

1	~
Œ	7

Gain	Difference between output and input in decibel
GND	Ground, reference potential
GP-IB	Abbreviation of "general-protocol interface bus", an 8-bit bus standard used mainly for measuring equipment
I	
Interface	Device for allowing data exchange between 8845 and a computer.
Isolation	Separation of electrical circuits from each other
L	
LCD	Abbreviation of "liquid-crystal display"
LED	Abbreviation of "light-emitting diode"
Logging	Numeric expression of sampling data
Logic-level	Waveform expressed as High and Low level
Low-pass filter	Filter that passes through only signals below a certain frequency
M	
Maximum allowable input	Maximum voltage that may be applied to the input terminals of the input unit.
Maximum floating voltage	Maximum voltage that may be applied between ground and an input unit.
Memory	A device for storing digital data
0	
Offset	Amount of shift in relation to 0 V when scaling is used
Option	Non-standard accessory for the unit
P	
Parameter	Signal waveform attributes such as maximum value, rms value, etc.
Peak hold	Retaining the maximum value at a frequency point
Pretrigger	The condition of the signal before triggering occurred
Probe	Signal line for supplying the signal to the input
PT	Abbreviation of (voltage) "potential transformer"
The second secon	

	7

RAM	Abbreviation of "random access memory"
Recording length	Total amount of sampling data expressed as number of increments
Ripple component	AC component of noise
RMS (rms)	Abbreviation of "root mean square" value, also called effective value. For alternating current, the value identical to the direct current work.
ROM	Abbreviation of "read-only memory"

## S

Sampling	Measuring an analog waveform at regular intervals ( ☐ Appendix 2.1)
Sampling data	Data gained by measuring an analog waveform at regular intervals and converting the results into digital data
Sampling rate	Rate at which sampling carried out; sampling frequency
Scaling	Conversion of voltage value into a specified unit
Scroll	Moving data shown on screen up/down or right/left
Slope	Slanted section of a rising or falling voltage
Storage	Storing measurement data in the internal memory

## T

TFT	Abbreviation of "thin film transistor"		
Thermal head	Print head of thermal printer		
Threshold value	When turning an analog signal into a logic signal, the level at which the measured value is divided between High and Low.		
Trigger	An event that causes a certain action (such as starting or stopping a measurement) to happen.		
Trigger source	Signal that serves as trigger		

## U

Unbalanced input	Using a two-pole input in such a way that one pole carries the
·	signal referenced to the other pole

## W

Word	A unit for expressing digital data. The digital data for one input
	signal point after conversion.

## Z


Zero adjust Matching of zero position and actual ground level		
,	Zero adjust	Matching of zero position and actual ground level

## Appendix 2 Reference

## Appendix 2.1 Memory Recorder Function, Recorder Function


## () Sampling

- · The 8845 converts the input signal (analog value) into digital form and performs all internal processing in the digital domain. The analog-to-digital conversion is achieved by sampling, that is measuring the signal level at regular intervals.
- · The interval between the measurement instances is called the sampling cycle (unit: seconds).
- · The number of measurement instances per second is called the sampling rate or sampling frequency. It is the reciprocal value of the sampling cycle (unit: samples per second, or Hz)



### Aliasing

When the frequency of the signal to be measured approaches the sampling frequency, beyond a certain point the measured signal frequency will be lower than the actual signal frequency.



- This phenomenon is called aliasing, and it occurs if sampling is carried out at a frequency lower than the so- called Nyquist frequency determined by Nyquist's sampling theorem.
- · Sampling theorem

Fs = 2 · Fmax (1)


Fmax: Highest frequency component to be measured

Fs: Sampling frequency (Nyquist frequency)

· In order to be able to restore the original waveform from the sampling data, the sampling frequency must be at least twice as high as the signal frequency.

## Measurement limit frequency

- The sampling theorem says that the sampling frequency must be twice as high as the signal frequency in order to be able to restore the original waveform.
- · But in order to reproduce a sine waveform with peaks intact, about 25 sampling points per cycle are required.
- · Because the time axis range setting determines the measurement limit frequency, this setting should be set as high as possible.



TIME/DIV (s/DIV)	Sampling period (s)	Measurement limit frequency (Hz)
500 μ	5 μ	8 k
1 m	10 μ	4 k
1.25 m	12.5 $\mu$	3.2 k
2 m	20 μ	2 k
2.5 m	25 μ	1.6 k
5 m	50 μ	800
10 m	100 $\mu$	400
20 m	200 μ	200
50 m	$500~\mu$	80
100 m	1 m	40
200 m	2 m	20
500 m	5 m	8
1	10 m	4
2	20 m	2
5	50 m	0.8
10	100 m	0.4
20	200 m	0.2
50	500 m	0.08
60 (1min)	600 m	0.067
120 (2min)	1.2	0.033
300 (5min)	3	0.013
600 (10min)	6	0.007
1200 (20min)	12	0.003
3600 (1h)	36	0.001

## **Appendix 2.2 FFT Function**

#### • FFT


FFT stands for Fast Fourier Transformation, which is a calculation method used to decompose a time-domain waveform into frequency components. By performing FFT calculation, various calculations can be performed.

### Concept of time domain and frequency domain

The signals measured by this memory recorder have values which correspond to time, that is the signals are functions of time.

Waveform in the figure below is an example of such a signal. Signals which are expressed as a function of time are called time domain signals.

In reality, a signal consists of a number of sine-waves of different frequencies, called frequency components, which combine to create the final shape of the waveform. Expressing waveform the source signal, as a function of its frequency components yields a frequency domain representation. Often, the characteristics of a signal which cannot be easily analyzed in the time domain, can be clearly revealed by the frequency domain representation.



#### Fourier transformation and the Inverse Fourier transformation

The following equations define the Fourier transformation and the Inverse Fourier transformation.

$$F(\omega) = \Im |f(t)| = \int_{-\infty}^{+\infty} f(t) \cdot \exp(-j\omega t) dt \qquad 2$$

$$f(t) = \Im^{-1} |F(\omega)| = \frac{1}{2\pi} \int_{-\infty}^{+\infty} F(\omega) \cdot \exp(j\omega t) d\omega \quad \Im$$


The function  $F(\omega)$  generally results in a complex number, and can be expressed as follows.

$$F(\omega) = |F(\omega)| \cdot \exp(j\phi(\omega)) = |F(\omega)| \angle \phi(\omega) \cdots \Phi$$

 $|F(\omega)|$ : Absolute value spectrum of f(t)


 $\phi$  ( $\omega$ ): Unit spectrum of the phase of f(t)

When conversion is made from the time domain to the frequency domain, the magnitude information and phase information are clearly expressed as indicated in equation (4). The figure below shows  $F(\omega)$  in vector form.



## Application of Fourier transform (transfer function, unit-impulse response)

As an application of Fourier transform, this section describes a steady-state response in a static linear system.



Stationary Linear System

fin(t): time function of input (source signal)

fout(t): time function of output (response function)

h(t): unit impulse response of linear system

 $t, \tau$ : time

The relationship between the input and output is expressed as follows: This indicates that the response of the linear system can be determined just by knowing the unit impulse response h(t) of the system.

In the frequency domain, Fin(  $\omega$  ), Fout(  $\omega$  ), H(  $\omega$  ), and  $\,\omega\,$  are defined as follows

 $Fin(\omega)$ : Fourier transformation of fin(t)

Fout( $\omega$ ): Fourier transformation of fout(t)

 $H(\omega)$ : Fourier transformation of h(t)

 $\omega$ : Angular frequency

Fout 
$$(\omega) = \text{Fin}(\omega) \cdot H(\omega)$$
 6

Therefore, when fin(t) and fout(t) are measured, the system transfer function H ( $\omega$ ) and the unit impulse response h(t) can be obtained by performing an FFT operation and an inverse FFT operation.

### Aliasing

When the frequency of the signal to be measured approaches the sampling frequency, beyond a certain point the measured signal frequency will be lower than the actual signal frequency. In such a case, frequency components that do not exist will appear in the waveform along the frequency axis. This phenomenon is called aliasing, and it occurs if sampling is carried out at a frequency lower than the so-called Nyquist frequency determined by Nyquist's sampling theorem.


Sampling theorem

Fs = 2 · Fmax ①

Fmax: Highest frequency component to be measured


Fs: Sampling frequency (Nyquist frequency)

- · In order to be able to restore the original waveform from the sampling data, the sampling frequency must be at least twice as high as the signal frequency.
- · If sampling is carried out at a frequency lower than the Nyquist frequency, frequency components above 1/2 of the sampling frequency will be aliased to lower frequencies, and the measured signal will appear to contain frequency components that actually do not exist.




### Anti-aliasing filter

- · In FFT processing, when the frequency bandwidth of the input signal is unlimited, frequency spectrum components that do not exist will appear, due to aliasing. To prevent this, a low-pass filter is required which cuts off the input waveform at 1/2 of the sampling frequency. Such a low-pass filter is called an anti-aliasing filter.
- The 8919 FFT analog unit incorporates an anti- aliasing filter and therefore allows the 8845 to perform FFT analysis without being subject to aliasing.




### **Example 1** When an anti-aliasing filter is not used.



Spectrum where frequency components higher than 1/2 of sampling frequency cause aliasing. Components that do not actually exist are observed.

**Example 2** When an anti-aliasing filter is used.




Aliasing spectrum components are effectively removed.

### Window processing

Fourier transform is defined as the integration from negative infinity to positive infinity, but in actual measurement this calculation is not possible. Therefore only a limited segment of the continuous signal is taken for processing. This is called window processing.


The FFT algorithm assumes that the data of that limited segment are repeated and defines the input signal using a periodic function for determining the frequency spectrum.

Depending on the phase at the start and end of the stored waveform, there may be a difference between the waveform as calculated by FFT processing and the actual input waveform.




## Leakage error

When the signal waveform as assumed by the FFT algorithm and the actual waveform are different, the processing result will contain an error. This error is called the leakage error.



Spectrum having small leakage




Spectrum having large leakage

#### Window function

- · When a limited segment of the input signal is captured, a function can be applied to reduce the leakage error.
- · This function is called the window function.
- To minimize the leakage error, a suitable window should be chosen which matches the type of input signal.
- · Possible window types include rectangular, Hanning, exponential, flat-top, minimum, force, etc. In the 8845, three window functions (rectangular, Hanning, exponential) are available.
- · Generally, the rectangular window function is most useful for single waveforms, the Hanning window function for continuous waveforms, and the exponential window function for attenuated waveforms.

## · Rectangular window




## · Hanning window

Input waveform

Waveform assumed by FFT processing

Hanning window

Waveform after window processing




## · Exponential window

Input waveform

Waveform assumed by FFT processing

Exponential window

Waveform after window processing



## Index

- A -		- B -	
A4 print	272	Backlight saver	236
ABS	333	Block display	421, 426
AND/OR ·····	······ 202, 211, 217	BUSY	286
Absolute value	333		
AC power connector	45	- C -	
AC power supply	44		
AC power switch	44	CCR	143, 164
Accessories	21	CH.SET ·····	179, 418
Aliasing	······· A1, A6, A11	CH.SET key	179, 418
ACOS	337	CHAN key ·····	5, 59
ACR	143, 158	Channel selection ·····	229
All out	359	Clock setting	60, 223
Analog input	····· 7, 23, 178, 181	Coherence function ·····	143, 168
Analog trigger	14, 205	Comment input	247
Analysis channel ·····	141	Common logarithm	333
Anti-aliasing filter	32, 130, 193	COH	143,168
Arc-cosine	337	COPY	5, 271, 272
Arc-sine	337	COPY key	5, 271, 272
Arc-tangent	338	COS	337
Area value	355	Cross power spectrum	143, 162
ASIN	337	Cross-correlation function ····	143, 164
ATAN ·····	338	CSP	143, 162
AUTO	14, 201	CURSOR ·····	5, 62
Auto correlation function	143, 158	CURSOR keys	5, 62
AUTO key ·····	····· 5, 100, 123	Cutoff frequency ··· 25, 27, 29	, 32, 34, 191, A2
Auto range function	100, 123		
Auto save ·····	293		
Auto scroll	412		
AUTO STOP	14, 201		
Average value	353		

Averaging ----- 18, 389

- D -		- F -	
Dark	181, 268	FEED	5, 264, 272
DAT	5, 59, A2	FEED key	5, 264, 272
DAT check	255	FFT	17, 74, 127
DAT drive head clean	449	FFT analysis mode	17, 140
DAT drive indicator		FFT channel mode	17, 129
DAT drive operation	285	File deleting	309
DAT to FFT function		File information	287
DAT to MEM function	316	File key	5, 59
Data restoring	314	File list	287
DC power supply		File name input	292
DC power supply connector		File rename	311
DDS tape		File searching	307
Delete	322	File sorting	308
DIF	324, 334	Filter width	206
DIF2	324, 334	Floating decimal point	324
DISP	5, 59	Four arithmetical operation	
DISP key	5, 59	Fourier transform	A9
Display check	254	Frequency	354
Display format 15-	17, 86, 113, 134	Frequency range	130
Display graph	183	Function keys	62
Display scale	144, 328	Fuse 12, 21,	34, 39, 44, 450
Dynamic range	17, A2	Fuse holder	9, 39, 450
		Fuse replacement	450
- E -			
		- G -	
Editor	•		
EJECT button		General specification	
Equation input		GO 344	
Equation number		GO&NG	
Eraser		Grid setting	
Error	•	Ground terminal	····· 7, 44
Evaluation period			
Event mark		- H -	
EXP			
Exponential		HELP	
Exponential averaging		HELP key	
EXT SMPL	·	Handle	
EXT TRIG	•	Hard copy	
External trigger		Head up/down lever	
eu ·····	240	Histogram	143, 159

-   -		Linear spectrum 143, 152	
		List and gauge function —	235
IMP		List print	19, 273
IN		LOG	333
INT	ŕ	Logic input	23, 178-180
INT2	323, 336	Logic probe ·····	24, 48
Initialization of setting item		Logic probe connection	48
Initialize setting	454	Logic trigger	14, 211
Input cable	39	Low-pass filter 25, 27,	29, 32, 34, 191, A3
Input coupling	187	-	
Input unit slot	7	- M -	
Installation environment ·····	43	- IVI -	
Installation orientation	41	Maximum allowable inpu	t ······ 3, 13, 25-29,
Interface	257	•	32, 34, 58
Intermittent print	239	Maximum floating voltage	e···3, 25-30, 32, 58
Interpolation function 15	-17, 93, 116, 147	Maximum sampling speed	
Inverse trigonometric	338	D.T 1	32, 34
		Maximum value	
		Measurement limit freque	=
		Medium dark	
JOG control	5, 60, 61	MIC	
		Minimum value	
<b>. K</b>		MOV	· · · · · ·
- IV		Moving average	334
Key check	253		
KEY LOCK	9, 438	- N -	
Key lock	9, 438	Natural logarithm	
		New data	
		NG	
Uletzon			
LCD backlight ON/OFF	236	NG evaluation output ······ Normal ······	
LCD backlight saver	19, 236		
LCD screen	5	Normal print	
LED check	251	Nyquist frequency	Ab, A11
LEVEL MON.	5, 416		
LEVEL MON. key	5, 416	- O -	
Leakage error	····· A15	OCM	440 470
Level monitor screen	418	OCT	ŕ
Level trigger	206	Octave analysis	
LIN	143, 152	Octave filter	
Light	181	Option	
Line cursor (horizontal) ·······	402, 405	Optional accessories	
Line cursor (vertical)		Out	344, 358

- P -		Sampling frequency	A5
_		Sampling rate	A4, A5
Paint		Sampling speed	11
Partial print		Scaling	19, 240, A4
Peak hold		Scroll ·····	410, A4
Peak value display	138	Select key	5, 60
Period	354	Self check	249
Playback ·····	302, 444	Sequential save function	380
Position display	······ 421, 422	SHUTTLE control	
Power spectrum	143, 156	SIN	336
Pre-trigger	····· 14, 203, A3	Sine	336
PRINT	······ 5, 13, 264, 430	Single	14, 201, 305
PRINT key	5, 264	SLI	320, 324, 334
Printer	7, 267	Slope	207
Printer check	252	Smooth print	15, 262
Printer head cleaning	······ 447	Source channel	
Printer recording format		SQR	
PSP		Stand	
		Standard deviation	
- R -		Start time	
- 11 -		START	
Read	301	START key	
Real time print	279	STATUS	
Recording a voice memo	118, 437	STATUS key	
Recording length	15, 85	Stop mode	
Recording target	117	Stop operation	
Recording time	112	Stop time	
Reference data ·····	136	Storage waveform	
Reformatting	313	STOP	
Remote terminal	9	STOP key	
Repeat	14, 201, 305	Store area	
Reverse	369	STR	
RMS	143, 154, 187, 353	Superimpose	95
RMS spectrum ·····	143, 154	Symbols	
RMS value	353	SYSTEM	5, 59, 222
Roll mode	94	SYSTEM key	5, 59, 222
ROM/RAM check ······	250	System reset	
Root	333	v	
		- T -	
- S -		- 1 -	
		TAN	337
Safety symbol	·····iii	TAPE ·····	286
Sampling	······ 84, 107, A4, A5	Tape slot	7, 285, 449

Thermocouple connect ————————————————————————————————————	tect 284	
Time axis magnification 98, 120 w1	141	
Time axis range w2 w2	141	
Time interval 216		
Time to maximum value 353	<u> </u>	
Time to minimum value 354	<b>2</b> 4	
Timer trigger 14, 216 X-Y area	342, 356	
Trace cursor 403 X-Y plottin	ng90	
Transferring data 119		
TRF 143, 160	<b>- Z -</b>	
TRIG OUT 9, 13, 433	idemi	
Trigger 14, 199, A4 Zero adjus	stment 190	
Trigger filter 14, 206 Zero positi	ion189, 195	
Trigger level 14, 206		
Trigger mode 14, 201	- Others -	
Trigger slope 206		
Trigger source 14, 202 1st differen	ntial 323, 335	
Trigonometric function 336 1st integra	al 323, 336	
2nd differe	ential 323, 335	
	al	
8916 ANA	LOG UNIT 25	
Undo	RMS UNIT27	
Unit impulse response ————————————————————————————————————	PERATURE UNIT29	
Using the A/B cursor 402 8927 ANA	LOG UNIT 32	
9437 CON	NECTION CABLE 39	
■ <b>V</b> ■ 9574 INPU	UT CABLE 39	
VALUE 5, 61		
Variable display fun 15, 16, 195		
Voltage axis range 184		
Volume setting 238		
W -		
Warning457		
Waveform evaluation		
Waveform parameter calculation 340		
Waveform parameter evaluation 344		
Waveform processing ————————————————————————————————————		
Window		
Window function 132, A16, A17		
Window-in trigger 14, 209		

#### **HIOKI 8845 MEMORY HICORDER**

Instruction Manual

Publication date: November 1998 Revised edition 5

Edited and published by HIOKI E.E. CORPORATION

Technical Sales Support Section

All inquiries to Sales and Marketing International Department

81 Koizumi, Ueda, Nagano, 386-1192, Japan

FAX: +81-268-28-0568 TEL: +81-268-28-0562

E-mail: os-com@hioki.co.jp

Printed in Japan 8845A981-05

- · All reasonable care has been taken in the production of this manual, but if you find any points which are unclear or in error, please contact your supplier or the Sales and Marketing International Department at HIOKI headquarters.
- · In the interests of product development, the contents of this manual are subject to revision without prior notice.
- · Unauthorized reproduction or copying of this manual is prohibited.



HIOKI E.E. CORPORATION

#### **HEAD OFFICE**

81 Koizumi, Ueda, Nagano 386-1192, Japan TEL +81-268-28-0562 / FAX +81-268-28-0568 E-mail: os-com@hioki.co.jp

#### HIOKI USA CORPORATION

6 Corporate Drive, Cranbury, NJ 08512, USA TEL +1-609-409-9109 / FAX +1-609-409-9108

8845A981-05 98-11-0001H

