

IM3523
IM3523A

HIOKI

Communication Instruction Manual

IM3533
IM3533-01
IM3536

LCR METER

IM3570
IM7580

IMPEDANCE ANALYZER

IM3590

CHEMICAL
IMPEDANCE ANALYZER

EN



Contents

Introduction.....	1	■ Connecting the USB Cable	24
Safety Information	1	3.3 GP-IB Connection and Settings (IM3523 only, when connected to the Z3000)	25
<hr/>		■ Connecting the GP-IB Cable	25
Chapter 1 Specifications	3	■ Setting GP-IB	25
1.1 RS-232C Specifications	3	3.4 RS-232C Connection and Settings (IM3523 only, when connected to the Z3001)	27
1.2 GP-IB Specifications	4	■ Connecting the RS-232C Cable	27
1.3 USB Specifications	4	■ Setting RS-232C	28
1.4 LAN Specifications	4	3.5 LAN Settings and Connection (IM3523 needs to be connected to the Z3002)	30
<hr/>		■ LAN Settings	30
Chapter 2 Model IM3570/ IM3536 Connection and Setting	5	■ Connecting a LAN Cable	33
2.1 Overview of Communication	5	3.6 Remote Mode	34
2.2 RS-232C Connection and Settings	7	<hr/>	
■ Connecting the RS-232C Cable	7	Chapter 4 Model IM3533/ IM3533-01/ IM3590 Connection and Setting	35
■ Setting RS-232C	8	4.1 Overview of Communication	35
2.3 GP-IB Connection and Settings	9	4.2 USB Settings and Connection	37
■ Connecting the GP-IB Cable	9	■ Setting USB	37
■ Setting GP-IB	9	■ Connecting the USB Cable	38
2.4 USB Settings and Connection	11	4.3 GP-IB Connection and Settings (when connected to the Z3000)	39
■ Setting USB	11	■ Connecting the GP-IB Cable	39
■ Connecting the USB Cable	12	■ Setting GP-IB	39
2.5 LAN Settings and Connection	13	4.4 RS-232C Connection and Settings (when connected to the Z3001)	41
■ LAN Settings	13	■ Connecting the RS-232C Cable	41
■ Connecting a LAN Cable	18	■ Setting RS-232C	42
2.6 Remote Mode	19	4.5 LAN Settings and Connection (when connected to the Z3002)	43
<hr/>		■ LAN Settings	43
Chapter 3 Model IM3523/ IM3523A Connection and Setting	21	■ Connecting a LAN Cable	48
3.1 Overview of Communication	21	4.6 Remote Mode	49
■ IM3523	21	<hr/>	
■ IM3523A	22		
3.2 USB Settings and Connection	23		
■ Setting USB	23		

Chapter 5 Model IM7580 Connection and Setting 51

5.1 Overview of Communication	51
5.2 USB Settings and Connection	53
■ Setting USB	53
■ Connecting the USB Cable	54
5.3 LAN Settings and Connection	55
■ LAN Settings	55
■ Connecting a LAN Cable	60
5.4 GP-IB Connection and Settings (when connected to the Z3000)	61
■ Connecting the GP-IB Cable	61
■ Setting GP-IB	61
5.5 RS-232C Connection and Settings (when connected to the Z3001)	63
■ Connecting the RS-232C Cable	63
■ Setting RS-232C	64
5.6 Remote Mode	65

Appendix A 1

Appendix 1 Checking the USB Virtual COM Port.....	A 1
--	-----

Introduction

This instruction manual provides details on the communication interfaces of the IM3523, IM3523A, IM3533, IM3533-01, IM3536 LCR Meter, IM3570, IM7580 Impedance Analyzer and IM3590 Chemical Impedance Analyzer.

In this document, the “instrument” means the IM3523, IM3523A, IM3533, IM3533-01, IM3536, IM3570, IM7580 and IM3590.

The latest edition of the instruction manual

The contents of this manual are subject to change, for example as a result of product improvements or changes to specifications.

The latest edition can be downloaded from Hioki’s website.

<https://www.hioki.com/global/support/download/>



Product registration

Register your product in order to receive important product information.

<https://www.hioki.com/global/support/myhioki/registration/>





Safety Information

This manual contains information and warnings essential for safe operation of the instrument and for maintaining it in safe operating condition. Before using it, be sure to carefully read the following safety precautions.


Safety Symbols

The following symbols in this manual indicate the relative importance of cautions and warnings.

 WARNING	Indicates that incorrect operation presents a significant hazard that could result in serious injury or death to the user.
 CAUTION	Indicates that incorrect operation presents a possibility of injury to the user or damage to the product.
NOTE	Advisory items related to performance or correct operation of the product.

Notation

Symbols in this manual

	Indicates the prohibited action.
(p.)	Indicates the location of reference information.
*	Indicates that descriptive information is provided below.
[]	Menus, commands, dialogs, buttons in a dialog, and other names on the screen and the keys are indicated in brackets.
CURSOR (Bold character)	Bold characters within the text indicate operating key labels.
Windows	Unless otherwise specified, “Windows” represents Windows 7, Windows 8, or Windows 10.
Dialogue	Dialogue box represents a Windows dialog box.

Mouse Operation

Click:	Press and quickly release the left button of the mouse.
Right-click:	Press and quickly release the right button of the mouse.
Double click:	Quickly click the left button of the mouse twice.
Drag:	While holding down the left button of the mouse, move the mouse and then release the left button to deposit the chosen item in the desired position.

Specifications

Chapter 1

1.1 RS-232C Specifications

Transmission Method	Communication method: Full duplex Synchronous method: Start-stop synchronization	
Transmission Speed	9600 bps, 19200 bps, 38400 bps, 57600 bps	
Data Bits	8 bits	
Parity	None	
Stop bit	1 bits	
Message terminator (delimiter)	CR+LF, CR	
Flow control	Hardware (RTS/CTS control), software (XON/XOFF control) "Handshake (About Buffer Flow Control)" (p. 3) IM7580: Software (XON/XOFF control only)	
Electrical Specifications	Input voltage level	5 to 15 V ON -15 to -5 V OFF
	Output voltage level	5 to 9 V ON -9 to -5 V OFF

Handshake (About Buffer Flow Control)


Control during Receiving

When using hardware (RTS/CTS control):

- When the data in the receive buffer exceeds 85% of the buffer, CA(RTS) is set to OFF and the controller is notified that there is not much space remaining in the buffer.
- Processing of the data in the buffer continues, and then CA(RTS) is set to ON and the controller is notified that there is sufficient remaining space in the buffer when the amount of data becomes less than 25%.

When using software (XON/XOFF control):

- When the data in the receive buffer exceeds 75% of the buffer, XOFF(13H) is sent and the controller is notified that there is not much space remaining in the buffer.
- Processing of the data in the buffer continues, and then XON(11H) is sent and the controller is notified that there is sufficient remaining space in the buffer when the amount of data becomes less than 25%.



Control during Sending

When using hardware (RTS/CTS control):

- When CB(CTS) is confirmed to be OFF, the sending of data is halted. When it is confirmed to be ON, the sending of data is resumed.

When using software (XON/XOFF control):

- When XOFF is received, the sending of data is halted. When XON is received, the sending of data is resumed.

4

1.2 GP-IB Specifications

1.2 GP-IB Specifications

SH1	Supports all source handshake functions.
AH1	Supports all acceptor handshake functions.
T6	Supports standard talker functions. Supports serial poll functions. Talk only mode is not supported. Supports the talker cancel function by MLA (My Listen Address).
L4	Supports standard listener functions. Listener only mode is not supported. Supports the listener cancel function by MTA (My Talk Address).
SR1	Supports all service request functions.
RL1	Supports all remote/local functions.
PP0	Parallel poll functions are not supported.
DC1	Supports all device clear functions.
DT1	Supports all device trigger functions.
C0	Controller functions are not supported.

Code used: ASCII code

1.3 USB Specifications

Connector	Series B receptacle
Compliance standard	USB2.0 (Full Speed/High Speed) (IM3523A: Full Speed only)
No. of ports	1
Class	Communication class
Supported OS	Windows 7, Windows 8, Windows 10, or Windows 11

1.4 LAN Specifications

Connector	RJ-45 connector × 1
Compliance standard	IEEE 802.3-compliant Ethernet
Transfer system	10BASE-T/ 100BASE-TX Auto detected IM7580: 10BASE-T/ 100BASE-TX/ 1000BASE-T Auto detected
Protocol	TCP/IP
Function	Command control


Model IM3570/ IM3536 Connection and Setting

Chapter 2

2.1 Overview of Communication

You can control the instrument with communication commands from a computer via the GP-IB, RS-232C, USB, and LAN interfaces.

There are the following four communication methods. To enable communication, the communication conditions need to be set on the instrument.



RS-232C communication (p. 7)

Printer can be connected to enable printing measurement values and screens.

GP-IB communication (p. 9)

- Commands common to IEEE-488-2 1987 (requirement) can be used.
- The instrument complies with the following standard. (Compliance standard: IEEE-488.1 1987)
- The instrument has been designed with reference to the following standard. (Reference standard: IEEE-488.2 1987)

USB communication (p. 11)

The instrument is communication class compatible.

LAN communication (p. 13)

Command control using the TCP/IP protocol is possible.

! WARNING

- Always turn both devices OFF when connecting and disconnecting an interface connector. Otherwise, an electric shock accident may occur.
- To avoid damage to the instrument, do not short-circuit the terminal and do not input voltage to the terminal.
- Failure to fasten the connectors properly may result in sub-specification performance or damage to the equipment.

! CAUTION


- To avoid damage, do not disconnect the communications cable while the instrument is sending or receiving data.
- Use a common ground for both the instrument and the computer. Grounding them to different ground points will result in a potential difference between the instrument's ground and the computer's ground. If the communications cable is connected while such a potential difference exists, it may result in equipment malfunction or failure.
- Before connecting or disconnecting any communications cable, always turn off the instrument and the computer. Failure to do so could result in equipment malfunction or damage.
- After connecting the communications cable, tighten the screws on the connector securely. Failure to secure the connector could result in equipment malfunction or damage.

6

2.1 Overview of Communication

Screen Displayed while Setting Interfaces


When you set an interface, the icon for the set interface is displayed on the right side of the screen.



2.2 RS-232C Connection and Settings

Connecting the RS-232C Cable

Connect the RS-232C cable to the RS-232C connector.
(Recommended cable: 9637 RS-232C cable)




To connect the instrument to a controller (DTE), use a **crossover cable** compatible with the connectors on both the instrument and the controller. The I/O connector is a DTE (Data Terminal Equipment) configuration.

Connector (D-sub) Pin No.	Interchange Circuit Name	CCITT Circuit No.	EIA Abbreviation	JIS Abbreviation	Common Abbreviation
1	Unused				
2	Received Data	104	BB	RD	RxD
3	Transmitted Data	103	BA	SD	TxD
4	Unused	108/2	CD	ER	DTR
5	Signal Ground	102	AB	SG	GND
6	Unused				
7	Request to Send	105	CA	RS	RTS
8	Clear to Send	106	CB	CS	CTS
9	Unused				

Example: Connecting to a DOS/V PC

Specification: D-sub 9-pin female and female connector, reverse connection






NOTE Hardware control will not work properly if you use a cable that has CA(RTS) and CB(CTS) short-circuited.

2.2 RS-232C Connection and Settings


Setting RS-232C

Procedure

You can configure the setting from any of **LCR** mode and **ANALYZER** mode (only IM3570).



Press **RS232C**.



Select the baud rate setting.

Select the handshake setting.

- No flow control
- Hardware (RTS/CTS control)
- Software (XON/XOFF control)
- Hardware + software

Select the terminator setting.


- CR+LF
- CR

4 Press **EXIT** to confirm the setting.

2.3 GP-IB Connection and Settings

Connecting the GP-IB Cable



Connect the GP-IB cable to the GP-IB connector.



Recommended cable:
9151-02 GP-IB connection cable (2 m)


Setting GP-IB

Procedure You can configure the setting from any of **LCR** mode and **ANALYZER** mode (only IM3570).




10

2.3 GP-IB Connection and Settings




Press **GPIB**.



Use **▲** or **▼** to set the GP-IB address.

Select the terminator setting.



4 Press **EXIT** to confirm the setting.

2.4 USB Settings and Connection


NOTE To connect the instrument to a computer the first time, a dedicated USB driver must be installed. Before connecting the instrument to the computer, install the USB driver. The USB driver can be downloaded from the bundled CD, or our web site. (<http://www.hioki.com>) The USB driver is compatible with the Windows 7 (32-bit, 64-bit version), Windows 8 (32-bit, 64-bit version), Windows 10 (32-bit, 64-bit version), and Windows 11 (64-bit version) operating systems. Additionally, do not put the computer into the sleep state while the instrument is connected to the computer.

Setting USB

Procedure

You can configure the setting from any of **LCR** mode and **ANALYZER** mode (only IM3570).

1



LCR Measurement Screen

Z 16.1515kΩ

θ -89.992°


Vac 1.026 V
Iac 63.51μA

INFORMATION

FREQ	1.0000kHz	SPEED	MED	OPEN	OFF
V	1.000V	TRIG	INT	SHORT	OFF
LIMIT	OFF	AVG	OFF	LOAD	OFF
RANGE	AUTO 30kΩ	DELAY	0.0000s	CABLE	0m
LOW Z	OFF	DCBIAS	OFF	SCALE	OFF
JUDGE	OFF				

ZOOM ON INFO DC

2



Interface Settings

I/F INFO TEST CLOCK

RS232C GPIB USB LAN PRINT

BAUD RATE 9600 19200 38400 57600

HANDSHAKE OFF HARD XON/OFF BOTH

TERM CR+LF CR

USB Setting

IF INFO TEST CLOCK

RS232C GPIB USB LAN PRINT


TERM CR+LF CR

EXIT


Press **USB**.

12

2.4 USB Settings and Connection




Select the terminator setting.



4 Press **EXIT** to confirm the setting.

Connecting the USB Cable

Connect a USB cable (commercially available USB cable) to the USB port of the instrument.



2.5 LAN Settings and Connection

LAN Settings

You can perform command control using the TCP/IP protocol.
Set the instrument to match your network environment in advance.

- NOTE**
- Make these settings before connecting to a network. Changing settings while connected can duplicate IP addresses of other network devices, and incorrect address information may otherwise be presented to the network.
 - The instrument does not support DHCP (automatic IP address assignment) on a network.

Setting Items

IP address	Identifies each device connected on a network. Each network device must be set to a unique address. The instrument supports IP version 4, with IP addresses indicated as four decimal octets, e.g., "192.168.0.1".
Subnet mask	This setting is for separating the IP address into the network address that indicates the network and the host address that indicates the instrument. On this instrument, the subnet mask is represented as four decimal numbers separated by "." such as "255.255.255.0."
Default Gateway	When the computer and instrument are on different but overlapping networks (subnets), this IP address specifies the device to serve as the gateway between the networks. If the computer and instrument are connected one-to-one, no gateway is used, and the instrument's default setting "0.0.0.0" can be kept as is.

Network Environment Configuration

Example 1. Connecting the instrument to an existing network

When connecting the instrument to an existing network, the network settings need to be confirmed in advance.

An IP address which is not the same as that of another network device needs to be assigned.
Confirm the following items with the network administrator, and write them down.

IP Address	_____ . _____ . _____ . _____
Subnet Mask	_____ . _____ . _____ . _____
Default Gateway	_____ . _____ . _____ . _____

Example 2. Connecting multiple instruments to a single computer using a hub

When building a local network with no outside connection, the following private IP addresses are recommended.

Example of private IP address:

IP Address Computer: 192.168.0.100

Instrument: 192.168.0.1, 192.168.0.2, 192.168.0.3...

(Set an IP address that differs from that of other network devices.)

Subnet Mask 255.255.255.0

Default Gateway OFF(0.0.0.0)

Example 3. Connecting one instrument to a single computer using the 9642 LAN Cable

The 9642 LAN Cable can be used with its supplied connection adapter to connect one instrument to one computer, in which case the IP address is freely settable. Use the recommended private IP addresses.

IP Address Computer: 192.168.0.100

Instrument: 192.168.0.1 (Set to a different IP address than the computer.)




Subnet Mask 255.255.255.0

Default Gateway OFF(0.0.0.0)


2.5 LAN Settings and Connection

Procedure

You can configure the setting from any of **LCR** mode and **ANALYZER** mode (only IM3570).




Press **LAN**.





Select the IP address.

2.5 LAN Settings and Connection




Use  or  to set the IP address.

Press  to confirm the setting.



Select the subnet mask.




Use  or  to set the subnet mask, and press  to confirm the setting.

NOTE Any of the following 30 subnet masks can be set for the instrument.

128.000.000.000	255.128.000.000	255.255.128.000	255.255.255.128
192.000.000.000	255.192.000.000	255.255.192.000	255.255.255.192
224.000.000.000	255.224.000.000	255.255.224.000	255.255.255.224
240.000.000.000	255.240.000.000	255.255.240.000	255.255.255.240
248.000.000.000	255.248.000.000	255.255.248.000	255.255.255.248
252.000.000.000	255.252.000.000	255.255.252.000	255.255.255.252
254.000.000.000	255.254.000.000	255.255.254.000	
255.000.000.000	255.255.000.000	255.255.255.000 (Initial setting)	


16

2.5 LAN Settings and Connection




Select the default gateway.

If the default gateway does not need to be set, for example, when connecting the instrument and computer on a one-to-one basis using a cross cable, leave this set to OFF.




Use ▲ or ▼ to set the default gateway.



Press EXIT to confirm the setting.



Select the port number.


2.5 LAN Settings and Connection




Use  or  to set the port number to use for communication commands.

Settable range : 1024 to 65535

Press  to confirm the setting.



Select the terminator setting.



12 Press  to confirm the setting.

Connecting a LAN Cable

Use a LAN cable to connect the instrument and computer.

CAUTION When connecting the instrument to your LAN using a LAN cable of more than 30 m or with the cable laid outdoors, take appropriate countermeasures that include installing a surge protector for LANs. Such signal wiring is susceptible to induced lighting, which can cause damage to the instrument.


Required items:

When connecting the instrument to an existing network (prepare any of the following):

- Straight-through Cat 5, 100BASE-TX-compliant Ethernet cable (up to 100 m, commercially available). For 10BASE communication, a 10BASE-T-compliant cable may also be used.
- Hioki 9642 LAN Cable (option)
(A cross adapter cannot be used.)

When connecting one instrument to a single computer (prepare one of the following):


- 100BASE-TX-compliant cross-over cable (up to 100 m)
- 100BASE-TX-compliant straight-through cable with cross-over adapter (up to 100 m)
- Hioki 9642 LAN Cable (option)



The MAC address of the LAN is displayed below the serial number.


You can also check it on the instrument screen.

See: "Checking the Version of the Instrument" in the instruction manual.




When connecting the instrument to a single computer (connect the instrument to the computer)

Connecting with the 9642 LAN Cable and crossover adapter (supplied with the 9642)



2.6 Remote Mode


When you connect a device to an interface and start communication, the mode becomes remote mode (remote operation state) and the keys on the LCD are disabled.




All of the keys except **LOCAL** are disabled.

Canceling Remote Mode

Procedure



Press **LOCAL** to return to the normal state (local state).



The measurement screen is redisplayed.

Model IM3523/ IM3523A Connection and Setting

Chapter 3

3.1 Overview of Communication

! WARNING

- Always turn both devices OFF when connecting and disconnecting an interface connector. Otherwise, an electric shock accident may occur.
- To avoid damage to the instrument, do not short-circuit the terminal and do not input voltage to the terminal.
- Failure to fasten the connectors properly may result in sub-specification performance or damage to the equipment.


! CAUTION

- To avoid damage, do not disconnect the communications cable while the instrument is sending or receiving data.
- Use a common ground for both the instrument and the computer. Grounding them to different ground points will result in a potential difference between the instrument's ground and the computer's ground. If the communications cable is connected while such a potential difference exists, it may result in equipment malfunction or failure.
- Before connecting or disconnecting any communications cable, always turn off the instrument and the computer. Failure to do so could result in equipment malfunction or damage.
- After connecting the communications cable, tighten the screws on the connector securely. Failure to secure the connector could result in equipment malfunction or damage.

IM3523

You can control the instrument with communication commands from a computer via the USB, GP-IB, RS-232C and LAN interfaces.

There are the following four communication methods. To enable communication, the communication conditions need to be set on the instrument.



USB communication (p. 23)

The instrument is communication class compatible.

GP-IB communication (when connected to the Z3000) (p. 25)

- Commands common to IEEE-488-2 1987 (requirement) can be used.
- The instrument complies with the following standard. (Compliance standard: IEEE-488.1 1987)
- The instrument has been designed with reference to the following standard. (Reference standard: IEEE-488.2 1987)

3.1 Overview of Communication

RS-232C communication (when connected to the Z3001) (p. 27)

Printer can be connected to enable printing measurement values and screens.


LAN communication (when connected to the Z3002) (p. 30)

Command control using the TCP/IP protocol is possible.

IM3523A

You can control the instrument with communication commands from a computer via the USB and LAN interfaces.

There are the following two communication methods. To enable communication, the communication conditions need to be set on the instrument.



USB communication (p. 23)

The instrument is communication class compatible.

LAN communication (p. 30)

Command control using the TCP/IP protocol is possible.

3.2 USB Settings and Connection

NOTE

IM3523

To connect the instrument to a computer the first time, a dedicated USB driver must be installed. Before connecting the instrument to the computer, install the USB driver. The USB driver can be downloaded from the bundled CD, or our web site. (<http://www.hioki.com>)


IM3523A

When the instrument is connected to a computer, the USB driver is automatically installed. Since the OS standard driver is installed, it is not necessary to install another driver.

The USB driver is compatible with the Windows 7 (32-bit, 64-bit version), Windows 8 (32-bit, 64-bit version), Windows 10 (32-bit, 64-bit version), and Windows 11 (64-bit version) operating systems. Additionally, do not put the computer into the sleep state while the instrument is connected to the computer.


Setting USB

- 1 Open the SYSTEM screen.



F 4 ▶ The SYSTEM screen will be displayed.

- 2 Select USB as the interface.




F 1 ▶ Select USB.

1 Select.

IM3523

The display will vary with the installed options.

Selected interface



When an option is connected

Using the Z3000


Using the Z3001

Using the Z3002




3.2 USB Settings and Connection

3 Select the terminator setting.




4




Connecting the USB Cable

Connect a USB cable (commercially available USB cable) to the USB port of the instrument.

IM3523




IM3523A



3.3 GP-IB Connection and Settings (IM3523 only, when connected to the Z3000)

Connecting the GP-IB Cable


Connect the GP-IB cable to the GP-IB connector.




Recommended cable:
9151-02 GP-IB connection cable (2 m)

Setting GP-IB

- 1 Open the SYSTEM screen.




- 2 Select GP-IB as the interface.




26

3.3 GP-IB Connection and Settings (IM3523 only, when connected to the Z3000)


3 Select the terminator setting.



4 Set the GP-IB address.
Valid setting range: 0 to 30



5




3.4 RS-232C Connection and Settings (IM3523 only, when connected to the Z3001)

3.4 RS-232C Connection and Settings (IM3523 only, when connected to the Z3001)

Connecting the RS-232C Cable

Connect the RS-232C cable to the RS-232C connector.
(Recommended cable: 9637 RS-232C cable)




To connect the instrument to a controller (DTE), use a **crossover cable** compatible with the connectors on both the instrument and the controller. The I/O connector is a DTE (Data Terminal Equipment) configuration.

Connector (D-sub) Pin No.	Interchange Circuit Name	CCITT Circuit No.	EIA Abbreviation	JIS Abbreviation	Common Abbreviation
1	Unused				
2	Received Data	104	BB	RD	RxD
3	Transmitted Data	103	BA	SD	TxD
4	Data Terminal Ready	108/2	CD	ER	DTR
5	Signal Ground	102	AB	SG	GND
6	Unused				
7	Request to Send	105	CA	RS	RTS
8	Clear to Send	106	CB	CS	CTS
9	Unused				

Example: Connecting to a DOS/V PC


Specification: D-sub 9-pin female and female connector, reverse connection




NOTE Hardware control will not work properly if you use a cable that has CA(RTS) and CB(CTS) short-circuited.

Setting RS-232C


1 Open the SYSTEM screen.




2 Select RS-232C as the interface.



3 Select from the following baud rate setting.
9600, 19200, 38400, 57600



4 Select the terminator setting.



3.4 RS-232C Connection and Settings (IM3523 only, when connected to the Z3001)

5 Select the handshake setting.

2

F 1
F 2

Select the handshake setting.

1

Select.

OFF	No flow control
HARD	Hardware (RTS/CTS control)
XON/OFF	Software (XON/XOFF control)
BOTH	Hardware + software

6

EXIT

F 4

You will return to the measurement screen.

3.5 LAN Settings and Connection (IM3523 needs to be connected to the Z3002)

LAN Settings

You can perform command control using the TCP/IP protocol.
Set the instrument to match your network environment in advance.

NOTE

- Make these settings before connecting to a network. Changing settings while connected can duplicate IP addresses of other network devices, and incorrect address information may otherwise be presented to the network.
- The instrument does not support DHCP (automatic IP address assignment) on a network.

Setting Items

IP address	Identifies each device connected on a network. Each network device must be set to a unique address. The instrument supports IP version 4, with IP addresses indicated as four decimal octets, e.g., "192.168.0.1".
Subnet mask	This setting is for separating the IP address into the network address that indicates the network and the host address that indicates the instrument. On this instrument, the subnet mask is represented as four decimal numbers separated by "." such as "255.255.255.0."
Default Gateway	When the computer and instrument are on different but overlapping networks (subnets), this IP address specifies the device to serve as the gateway between the networks. If the computer and instrument are connected one-to-one, no gateway is used, and the instrument's default setting "0.0.0.0" can be kept as is.

Network Environment Configuration

Example 1. Connecting the instrument to an existing network

When connecting the instrument to an existing network, the network settings need to be confirmed in advance.

An IP address which is not the same as that of another network device needs to be assigned.
Confirm the following items with the network administrator, and write them down.

IP Address _____:_____:_____:_____

Subnet Mask _____:_____:_____:_____

Default Gateway _____:_____:_____:_____

Example 2. Connecting multiple instruments to a single computer using a hub

When building a local network with no outside connection, the following private IP addresses are recommended.

Example of private IP address:

IP Address Computer: 192.168.0.100
 Instrument: 192.168.0.1, 192.168.0.2, 192.168.0.3...

(Set an IP address that differs from that of other network devices.)

Subnet Mask 255.255.255.0

Default Gateway OFF(0.0.0.0)

Example 3. Connecting one instrument to a single computer using the 9642 LAN Cable

The 9642 LAN Cable can be used with its supplied connection adapter to connect one instrument to one computer, in which case the IP address is freely settable. Use the recommended private IP addresses.


IP Address Computer: 192.168.0.100
 Instrument: 192.168.0.1 (Set to a different IP address than the computer.)

Subnet Mask 255.255.255.0


Default Gateway OFF(0.0.0.0)

3.5 LAN Settings and Connection (IM3523 needs to be connected to the Z3002)


- 1** Open the SYSTEM screen.




- 2** Select LAN as the interface.



- 3** Select the IP address.



- 4** Select the subnet mask.



NOTE Any of the following 30 subnet masks can be set for the instrument.

128.000.000.000	255.128.000.000	255.255.128.000	255.255.255.128
192.000.000.000	255.192.000.000	255.255.192.000	255.255.255.192
224.000.000.000	255.224.000.000	255.255.224.000	255.255.255.224
240.000.000.000	255.240.000.000	255.255.240.000	255.255.255.240
248.000.000.000	255.248.000.000	255.255.248.000	255.255.255.248
252.000.000.000	255.252.000.000	255.255.252.000	255.255.255.252
254.000.000.000	255.254.000.000	255.255.254.000	
255.000.000.000	255.255.000.000	255.255.255.000 (Initial setting)	

3.5 LAN Settings and Connection (IM3523 needs to be connected to the Z3002)

5 Select the default gateway.

The screenshot shows a menu with the following text: I/F | INFO | TEST | KIND:LAN | IP ADDRESS : 192.168.000.001 | GATEWAY : 000.000.000.000 | EXIT. A blue box highlights the GATEWAY field. To the right, a vertical menu shows 'OFF' selected. Further right are function keys F1, F2, and F3. Below the screen are navigation arrows and the text 'Select.'.

- F 1 Select the default gateway.
- F 2 Set the default gateway to OFF (000.000.000.000).
- F 3

1 Select.

If the default gateway does not need to be set, for example, when connecting the instrument and computer on a one-to-one basis using a cross cable, leave this set to OFF.

6 Select the terminator setting.

The screenshot shows a menu with the following text: I/F | INFO | TEST | KIND:LAN | IP ADDRESS : 192.168.000.001 | SUBNETMASK : 255.255.255.000 | TERM : CR+LF | PORT : 03500 | EXIT. A blue box highlights the TERM field. To the right, a vertical menu shows 'CR+LF' selected. Further right are function keys F1 and F2. Below the screen are navigation arrows and the text 'Select.'.

- F 1 Select the terminator setting.
- F 2

1 Select.

7 Select the port number.
Settable range : 1024 to 65535

The screenshot shows a menu with the following text: I/F | INFO | TEST | KIND:LAN | IP ADDRESS : 192.168.000.001 | SUBNETMASK : 255.255.255.000 | GATEWAY : 000 | TERM : CR+LF | PORT : 03500 | EXIT. A blue box highlights the PORT field. To the right, a vertical menu shows 'CLEAR' selected. Further right are function keys F1, F2, and F3. Below the screen are navigation arrows and the text 'Select.'.

- F 1 Select the port number.
- F 2 Revert the setting to the default value.
- F 3

1 Select.

8

The screenshot shows the same menu as in step 7. A blue box highlights the EXIT button. To the right is function key F4. Below the screen are navigation arrows and the text 'Select.'.

- F 4 You will return to the measurement screen.

1 Select.

3.5 LAN Settings and Connection (IM3523 needs to be connected to the Z3002)

Connecting a LAN Cable

Use a LAN cable to connect the instrument and computer.

Required items:


When connecting the instrument to an existing network (prepare any of the following):

- Straight-through Cat 5, 100BASE-TX-compliant Ethernet cable (up to 100 m, commercially available). For 10BASE communication, a 10BASE-T-compliant cable may also be used.
- Hioki 9642 LAN Cable (option)
(A cross adapter cannot be used.)

When connecting one instrument to a single computer (prepare one of the following):

- 100BASE-TX-compliant cross-over cable (up to 100 m)
- 100BASE-TX-compliant straight-through cable with cross-over adapter (up to 100 m)
- Hioki 9642 LAN Cable (option)


IM3523




The MAC address of the LAN is displayed above the serial number.

You can also check it on the instrument screen.

See: "Checking the Version of the Instrument" in the instruction manual.



IM3523A




The LAN MAC address is shown to the right of the LAN terminal.

You can also check it on the instrument screen.

See: "Checking the Version of the Instrument" in the instruction manual.

When connecting the instrument to a single computer (connect the instrument to the computer)

Connecting with the 9642 LAN Cable and crossover adapter (supplied with the 9642)



3.6 Remote Mode

When you connect a device to an interface and start communication, the mode becomes remote mode (remote operation state) and the keys on the LCD are disabled.

Remote status

NORM		LOCAL	
Z	10.0020kΩ	∅	0.079 °
Vac 988.9mV			
Iac 98.87μA			
: 1.0000kHz : V : 1.000V : R : 100kΩ : MED : EXT :			

F 1 Keys other than [F1] are disabled.

Canceling Remote Mode

1

NORM		LOCAL	
Z	10.0020kΩ	∅	0.079 °
Vac 988.9mV			
Iac 98.87μA			
: 1.0000kHz : V : 1.000V : R : 100kΩ : MED : EXT :			

F 4 ▶ You will return to the measurement screen.

2

NORM		BASIC	
Z	10.0020kΩ	∅	0.079 °
Vac 988.9mV		Rdc	
Iac 98.87μA		ADVNC	
		SYS	
: 1.0000kHz : V : 1.000V : R : 100kΩ : MED : EXT :			

You will return to the measurement screen.


Model IM3533/ IM3533-01/ IM3590 Connection and Setting

Chapter 4

4.1 Overview of Communication

You can control the instrument with communication commands from a computer via the USB, GP-IB, RS-232C and LAN interfaces.

There are the following four communication methods. To enable communication, the communication conditions need to be set on the instrument.



USB communication (p. 37)

The instrument is communication class compatible.

GP-IB communication (when connected to the Z3000) (p. 39)

- Commands common to IEEE-488-2 1987 (requirement) can be used.
- The instrument complies with the following standard. (Compliance standard: IEEE-488.1 1987)
- The instrument has been designed with reference to the following standard. (Reference standard: IEEE-488.2 1987)

RS-232C communication (when connected to the Z3001) (p. 41)

Printer can be connected to enable printing measurement values and screens.

LAN communication (when connected to the Z3002) (p. 43)

Command control using the TCP/IP protocol is possible.

! WARNING

- Always turn both devices OFF when connecting and disconnecting an interface connector. Otherwise, an electric shock accident may occur.
- To avoid damage to the instrument, do not short-circuit the terminal and do not input voltage to the terminal.
- Failure to fasten the connectors properly may result in sub-specification performance or damage to the equipment.

! CAUTION

- To avoid damage, do not disconnect the communications cable while the instrument is sending or receiving data.
- Use a common ground for both the instrument and the computer. Grounding them to different ground points will result in a potential difference between the instrument's ground and the computer's ground. If the communications cable is connected while such a potential difference exists, it may result in equipment malfunction or failure.
- Before connecting or disconnecting any communications cable, always turn off the instrument and the computer. Failure to do so could result in equipment malfunction or damage.
- After connecting the communications cable, tighten the screws on the connector securely. Failure to secure the connector could result in equipment malfunction or damage.

4.1 Overview of Communication

Screen Displayed while Setting Interfaces

When you set an interface, the icon for the set interface is displayed on the right side of the screen.

The screenshot shows the LCR meter's main display with the following data:

- Measurement: $4.99105k\Omega$
- Phase angle: 0.014°
- Vac: 978.4mV
- Iac: 196.0 μ A

The 'INFORMATION' section displays the following settings:

FREQ	1.0000kHz	JUDGE	OFF	OPEN	OFF
V	1.000V	SPEED	MED	SHORT	OFF
LIMIT	OFF	AVG	OFF	LOAD	OFF
RANGE	AUTO 10k Ω	DELAY	0.0000s	CABLE	0m
LOW Z	OFF	SYNC	OFF	SCALE	OFF
J SYNC	OFF	DCBIAS	OFF		

The right-side menu includes: MODE, SET, ADJ, SYS, FILE, ZOOM ON, INFO DC, and TRIG.

The callout box lists the following interface options:

- USB**: When USB is set
- GPIB**: When GP-IB is set
- RS232C**: When RS-232C is set
- LAN**: When LAN is set
- PRINT**: When printer is set



4.2 USB Settings and Connection

NOTE To connect the instrument to a computer the first time, a dedicated USB driver must be installed. Before connecting the instrument to the computer, install the USB driver. The USB driver can be downloaded from the bundled CD, or our web site. (<http://www.hioki.com>) The USB driver is compatible with the Windows 7 (32-bit, 64-bit version), Windows 8 (32-bit, 64-bit version), Windows 10 (32-bit, 64-bit version), and Windows 11 (64-bit version) operating systems. Additionally, do not put the computer into the sleep state while the instrument is connected to the computer.

Setting USB

The display will vary with the installed options.

Procedure You can configure the setting from any of **LCR** mode, **ANALYZER** mode, and **TRANSFORMER** mode.



Press **USB**.


When an option is connected

Using the Z3000


Using the Z3001

Using the Z3002

4.2 USB Settings and Connection




Select the terminator setting.



4 Press **EXIT** to confirm the setting.

Connecting the USB Cable


Connect a USB cable (commercially available USB cable) to the USB port of the instrument.



4.3 GP-IB Connection and Settings (when connected to the Z3000)

Connecting the GP-IB Cable

Connect the GP-IB cable to the GP-IB connector.



Recommended cable:
9151-02 GP-IB connection cable (2 m)

Setting GP-IB

Procedure

You can configure the setting from any of **LCR** mode, **ANALYZER** mode, and **TRANSFORMER** mode.

1

LCR Measurement Screen

LCR

Z **4.99105k Ω**

OFF

θ **0.014 $^{\circ}$**

OFF

Vac 978.4mV
Iac 196.0 μ A

INFORMATION

FREQ	1.0000kHz	JUDGE	OFF	OPEN	OFF
V	1.000V	SPEED	MED	SHORT	OFF
LIMIT	OFF	AVG	OFF	LOAD	OFF
RANGE	AUTO 10k Ω	DELAY	0.0000s	CABLE	0m
LOW Z	OFF	SYNC	OFF	SCALE	OFF
J SYNC	OFF	DCBIAS	OFF		

ZOOM ON INFO DC TRIG

▶▶

Interface Settings

SYS

I/F INFO TEST CLOCK


GP IB USB LAN PRINT

ADDRESS ▲ 01 ▼


TERM LF CR+LF

40

4.3 GP-IB Connection and Settings (when connected to the Z3000)




Press  .



Use  or  to set the GP-IB address.

Select the terminator setting.




4 Press  to confirm the setting.

4.4 RS-232C Connection and Settings (when connected to the Z3001)

Connecting the RS-232C Cable

Connect the RS-232C cable to the RS-232C connector.
(Recommended cable: 9637 RS-232C cable)




To connect the instrument to a controller (DTE), use a **crossover cable** compatible with the connectors on both the instrument and the controller. The I/O connector is a DTE (Data Terminal Equipment) configuration.

Connector (D-sub) Pin No.	Interchange Circuit Name	CCITT Circuit No.	EIA Abbreviation	JIS Abbreviation	Common Abbreviation
1	Unused				
2	Received Data	104	BB	RD	RxD
3	Transmitted Data	103	BA	SD	TxD
4	Data Terminal Ready	108/2	CD	ER	DTR
5	Signal Ground	102	AB	SG	GND
6	Unused				
7	Request to Send	105	CA	RS	RTS
8	Clear to Send	106	CB	CS	CTS
9	Unused				

Example: Connecting to a DOS/V PC

Specification: D-sub 9-pin female and female connector, reverse connection






NOTE Hardware control will not work properly if you use a cable that has CA(RTS) and CB(CTS) short-circuited.

4.4 RS-232C Connection and Settings (when connected to the Z3001)


Setting RS-232C

Procedure

You can configure the setting from any of **LCR** mode, **ANALYZER** mode, and **TRANSFORMER** mode.



Press **RS232C**.



Select the baud rate setting.

Select the handshake setting.

- OFF** No flow control
- HARD** Hardware (RTS/CTS control)
- XON/OFF** Software (XON/XOFF control)
- BOTH** Hardware + software

Select the terminator setting.

- CR+LF** CR+LF
- CR** CR

4 Press **EXIT** to confirm the setting.

4.5 LAN Settings and Connection (when connected to the Z3002)

LAN Settings

You can perform command control using the TCP/IP protocol.
Set the instrument to match your network environment in advance.

- NOTE**
- Make these settings before connecting to a network. Changing settings while connected can duplicate IP addresses of other network devices, and incorrect address information may otherwise be presented to the network.
 - The instrument does not support DHCP (automatic IP address assignment) on a network.

Setting Items

IP address	Identifies each device connected on a network. Each network device must be set to a unique address. The instrument supports IP version 4, with IP addresses indicated as four decimal octets, e.g., "192.168.0.1".
Subnet mask	This setting is for separating the IP address into the network address that indicates the network and the host address that indicates the instrument. On this instrument, the subnet mask is represented as four decimal numbers separated by "." such as "255.255.255.0."
Default Gateway	When the computer and instrument are on different but overlapping networks (subnets), this IP address specifies the device to serve as the gateway between the networks. If the computer and instrument are connected one-to-one, no gateway is used, and the instrument's default setting "0.0.0.0" can be kept as is.

Network Environment Configuration

Example 1. Connecting the instrument to an existing network

When connecting the instrument to an existing network, the network settings need to be confirmed in advance.

An IP address which is not the same as that of another network device needs to be assigned.
Confirm the following items with the network administrator, and write them down.

IP Address	_____ : _____ : _____ : _____
Subnet Mask	_____ : _____ : _____ : _____
Default Gateway	_____ : _____ : _____ : _____

Example 2. Connecting multiple instruments to a single computer using a hub

When building a local network with no outside connection, the following private IP addresses are recommended.

Example of private IP address:

IP Address Computer: 192.168.0.100

Instrument: 192.168.0.1, 192.168.0.2, 192.168.0.3...

(Set an IP address that differs from that of other network devices.)

Subnet Mask 255.255.255.0

Default Gateway OFF(0.0.0.0)

Example 3. Connecting one instrument to a single computer using the 9642 LAN Cable

The 9642 LAN Cable can be used with its supplied connection adapter to connect one instrument to one computer, in which case the IP address is freely settable. Use the recommended private IP addresses.

IP Address Computer: 192.168.0.100

Instrument: 192.168.0.1 (Set to a different IP address than the computer.)




Subnet Mask 255.255.255.0

Default Gateway OFF(0.0.0.0)


4.5 LAN Settings and Connection (when connected to the Z3002)

Procedure

You can configure the setting from any of **LCR** mode, **ANALYZER** mode, and **TRANSFORMER** mode.




Press **LAN**.





Select the IP address.

4.5 LAN Settings and Connection (when connected to the Z3002)




Use  or  to set the IP address.

Press  to confirm the setting.



Select the subnet mask.




Use  or  to set the subnet mask, and press  to confirm the setting.

NOTE Any of the following 30 subnet masks can be set for the instrument.


128.000.000.000	255.128.000.000	255.255.128.000	255.255.255.128
192.000.000.000	255.192.000.000	255.255.192.000	255.255.255.192
224.000.000.000	255.224.000.000	255.255.224.000	255.255.255.224
240.000.000.000	255.240.000.000	255.255.240.000	255.255.255.240
248.000.000.000	255.248.000.000	255.255.248.000	255.255.255.248
252.000.000.000	255.252.000.000	255.255.252.000	255.255.255.252
254.000.000.000	255.254.000.000	255.255.254.000	
255.000.000.000	255.255.000.000	255.255.255.000 (Initial setting)	

4.5 LAN Settings and Connection (when connected to the Z3002)




Select the default gateway.

If the default gateway does not need to be set, for example, when connecting the instrument and computer on a one-to-one basis using a cross cable, leave this set to OFF.




Use ▲ or ▼ to set the default gateway.

Press EXIT to confirm the setting.



Select the port number.


4.5 LAN Settings and Connection (when connected to the Z3002)




Use or to set the port number to use for communication commands.

Settable range : 1024 to 65535

Press to confirm the setting.



Select the terminator setting.



12 Press to confirm the setting.

4.5 LAN Settings and Connection (when connected to the Z3002)

Connecting a LAN Cable

Use a LAN cable to connect the instrument and computer.



Required items:

When connecting the instrument to an existing network (prepare any of the following):

- Straight-through Cat 5, 100BASE-TX-compliant Ethernet cable (up to 100 m, commercially available).
For 10BASE communication, a 10BASE-T-compliant cable may also be used.
- Hioki 9642 LAN Cable (option)
(A cross adapter cannot be used.)

When connecting one instrument to a single computer (prepare one of the following):

- 100BASE-TX-compliant cross-over cable (up to 100 m)
- 100BASE-TX-compliant straight-through cable with cross-over adapter (up to 100 m)
- Hioki 9642 LAN Cable (option)




The MAC address of the LAN is displayed above the serial number.

You can also check it on the instrument screen.

See: "Checking the Version of the Instrument" in the instruction manual.


When connecting the instrument to a single computer (connect the instrument to the computer)

Connecting with the 9642 LAN Cable and crossover adapter (supplied with the 9642)



4.6 Remote Mode


When you connect a device to an interface and start communication, the mode becomes remote mode (remote operation state) and the keys on the LCD are disabled.




All of the keys except **LOCAL** are disabled.

Canceling Remote Mode

Procedure



Press **LOCAL** to return to the normal state (local state).



The measurement screen is redisplayed.


Model IM7580 Connection and Setting

Chapter 5

5.1 Overview of Communication

You can control the instrument with communication commands from a computer via the USB, GP-IB, RS-232C and LAN interfaces.

There are the following four communication methods. To enable communication, the communication conditions need to be set on the instrument.



USB communication (p. 53)

The instrument is communication class compatible.

LAN communication (p. 55)

Command control using the TCP/IP protocol is possible.

GP-IB communication (when connected to the Z3000) (p. 61)

- Commands common to IEEE-488-2 1987 (requirement) can be used.
- The instrument complies with the following standard. (Compliance standard: IEEE-488.1 1987)
- The instrument has been designed with reference to the following standard. (Reference standard: IEEE-488.2 1987)

RS-232C communication (when connected to the Z3001) (p. 63)



- WARNING**
- Always turn both devices OFF when connecting and disconnecting an interface connector. Otherwise, an electric shock accident may occur.
 - To avoid damage to the instrument, do not short-circuit the terminal and do not input voltage to the terminal.
 - Failure to fasten the connectors properly may result in sub-specification performance or damage to the equipment.



- CAUTION**
- To avoid damage, do not disconnect the communications cable while the instrument is sending or receiving data.
 - Use a common ground for both the instrument and the computer. Grounding them to different ground points will result in a potential difference between the instrument's ground and the computer's ground. If the communications cable is connected while such a potential difference exists, it may result in equipment malfunction or failure.
 - Before connecting or disconnecting any communications cable, always turn off the instrument and the computer. Failure to do so could result in equipment malfunction or damage.
 - After connecting the communications cable, tighten the screws on the connector securely. Failure to secure the connector could result in equipment malfunction or damage.

5.1 Overview of Communication

Screen Displayed while Setting Interfaces

When you set an interface, the icon for the set interface is displayed on the right side of the screen.



USB

When USB is set

GPIB

When GP-IB is set

RS232C

When RS-232C is set

LAN

When LAN is set

5.2 USB Settings and Connection

NOTE To connect the instrument to a computer the first time, a dedicated USB driver must be installed. Before connecting the instrument to the computer, install the USB driver. The USB driver can be downloaded from the bundled CD, or our web site. (<http://www.hioki.com>) The USB driver is compatible with the Windows 7 (32-bit, 64-bit version), Windows 8 (32-bit, 64-bit version), Windows 10 (32-bit, 64-bit version), and Windows 11 (64-bit version) operating systems. Additionally, do not put the computer into the sleep state while the instrument is connected to the computer.


Setting USB

The display will vary with the installed options.


Procedure

You can configure the setting from any of **LCR** mode and **ANALYZER** mode.

1



Interface Settings



2




Press **USB**.

5.2 USB Settings and Connection




Select the terminator setting.



4 Press **EXIT** to confirm the setting.

Connecting the USB Cable

Connect a USB cable (commercially available USB cable) to the USB port of the instrument.



5.3 LAN Settings and Connection

LAN Settings

You can perform command control using the TCP/IP protocol.
Set the instrument to match your network environment in advance.

- NOTE**
- Make these settings before connecting to a network. Changing settings while connected can duplicate IP addresses of other network devices, and incorrect address information may otherwise be presented to the network.
 - The instrument does not support DHCP (automatic IP address assignment) on a network.

Setting Items

IP address	Identifies each device connected on a network. Each network device must be set to a unique address. The instrument supports IP version 4, with IP addresses indicated as four decimal octets, e.g., "192.168.0.1".
Subnet mask	This setting is for separating the IP address into the network address that indicates the network and the host address that indicates the instrument. On this instrument, the subnet mask is represented as four decimal numbers separated by "." such as "255.255.255.0."
Default Gateway	When the computer and instrument are on different but overlapping networks (subnets), this IP address specifies the device to serve as the gateway between the networks. If the computer and instrument are connected one-to-one, no gateway is used, and the instrument's default setting "0.0.0.0" can be kept as is.

Network Environment Configuration

Example 1. Connecting the instrument to an existing network

When connecting the instrument to an existing network, the network settings need to be confirmed in advance.

An IP address which is not the same as that of another network device needs to be assigned.
Confirm the following items with the network administrator, and write them down.

IP Address	_____ . _____ . _____ . _____
Subnet Mask	_____ . _____ . _____ . _____
Default Gateway	_____ . _____ . _____ . _____

Example 2. Connecting multiple instruments to a single computer using a hub

When building a local network with no outside connection, the following private IP addresses are recommended.

Example of private IP address:

IP Address Computer: 192.168.0.100

Instrument: 192.168.0.1, 192.168.0.2, 192.168.0.3...

(Set an IP address that differs from that of other network devices.)

Subnet Mask 255.255.255.0

Default Gateway OFF(0.0.0.0)

Example 3. Connecting one instrument to a single computer using the 9642 LAN Cable

The 9642 LAN Cable can be used with its supplied connection adapter to connect one instrument to one computer, in which case the IP address is freely settable. Use the recommended private IP addresses.

IP Address Computer: 192.168.0.100

Instrument: 192.168.0.1 (Set to a different IP address than the computer.)



Subnet Mask 255.255.255.0

Default Gateway OFF(0.0.0.0)


5.3 LAN Settings and Connection

Procedure

You can configure the setting from any of **LCR** mode and **ANALYZER** mode.





Press **LAN**.



Select the IP address.


5.3 LAN Settings and Connection



NOTE Any of the following 30 subnet masks can be set for the instrument.


128.000.000.000	255.128.000.000	255.255.128.000	255.255.255.128
192.000.000.000	255.192.000.000	255.255.192.000	255.255.255.192
224.000.000.000	255.224.000.000	255.255.224.000	255.255.255.224
240.000.000.000	255.240.000.000	255.255.240.000	255.255.255.240
248.000.000.000	255.248.000.000	255.255.248.000	255.255.255.248
252.000.000.000	255.252.000.000	255.255.252.000	255.255.255.252
254.000.000.000	255.254.000.000	255.255.254.000	
255.000.000.000	255.255.000.000	255.255.255.000 (Initial setting)	

5.3 LAN Settings and Connection




Select the default gateway.

If the default gateway does not need to be set, for example, when connecting the instrument and computer on a one-to-one basis using a cross cable, leave this set to OFF.




Use ▲ or ▼ to set the default gateway.

Press **EXIT** to confirm the setting.



Select the port number.

5.3 LAN Settings and Connection




Use or to set the port number to use for communication commands.

Settable range : 1024 to 65535

Press to confirm the setting.



Select the terminator setting.



12 Press to confirm the setting.

5.3 LAN Settings and Connection

Connecting a LAN Cable

Use a LAN cable to connect the instrument and computer.


Required items:

When connecting the instrument to an existing network (prepare any of the following):

- Straight-through Cat 5, 100BASE-T-compliant Ethernet cable (up to 100 m, commercially available).
For 100BASE/10BASE communication, a 100BASE-TX/10BASE-T-compliant cable may also be used.
- Hioki 9642 LAN Cable (option)
(A cross adapter cannot be used.)

When connecting one instrument to a single computer (prepare one of the following):

- 1000BASE-T-compliant cross-over cable (up to 100 m)
- 1000BASE-T-compliant straight-through cable with cross-over adapter (up to 100 m)
- Hioki 9642 LAN Cable (option)




The MAC address of the LAN is displayed below the serial number.
You can also check it on the instrument screen.

See: "Checking the Version of the Instrument" in the instruction manual.

When connecting the instrument to a single computer (connect the instrument to the computer)


Connecting with the 9642 LAN Cable and crossover adapter (supplied with the 9642)



5.4 GP-IB Connection and Settings (when connected to the Z3000)

Connecting the GP-IB Cable


Connect the GP-IB cable to the GP-IB connector.




Setting GP-IB

Procedure


You can configure the setting from any of **LCR** mode and **ANALYZER** mode.



5.4 GP-IB Connection and Settings (when connected to the Z3000)






Press  .



Use  or  to set the GP-IB address.

Select the terminator setting.


-  LF with EOI
-  LF with CR+EOI

4 Press  to confirm the setting.

5.5 RS-232C Connection and Settings (when connected to the Z3001)

Connecting the RS-232C Cable

Connect the RS-232C cable to the RS-232C connector.
(Recommended cable: 9637 RS-232C cable)




To connect the instrument to a controller (DTE), use a **crossover cable** compatible with the connectors on both the instrument and the controller. The I/O connector is a DTE (Data Terminal Equipment) configuration.

Connector (D-sub) Pin No.	Interchange Circuit Name	CCITT Circuit No.	EIA Abbreviation	JIS Abbreviation	Common Abbreviation
1	Unused				
2	Received Data	104	BB	RD	RxD
3	Transmitted Data	103	BA	SD	TxD
4	Data Terminal Ready	108/2	CD	ER	DTR
5	Signal Ground	102	AB	SG	GND
6	Unused				
7	Unused				
8	Unused				
9	Unused				

Example: Connecting to a DOS/V PC



Specification: D-sub 9-pin female and female connector, reverse connection



5.5 RS-232C Connection and Settings (when connected to the Z3001)

Setting RS-232C

Procedure You can configure the setting from any of **LCR** mode and **ANALYZER** mode.



Press **RS232C**.




- Select the baud rate setting.
- Select the handshake setting.
 - OFF** No flow control
 - XON/OFF** Software (XON/XOFF control)
- Select the terminator setting.
 - CR+LF** CR+LF
 - CR** CR

4 Press **EXIT** to confirm the setting.

5.6 Remote Mode


When you connect a device to an interface and start communication, the mode becomes remote mode (remote operation state) and the keys on the LCD are disabled.




All of the keys except **LOCAL** are disabled.

Canceling Remote Mode

Procedure



Press **LOCAL** to return to the normal state (local state).




The measurement screen is redisplayed.

Appendix

Appendix 1 Checking the USB Virtual COM Port

The instrument's USB interface supports communications-class performance, allowing control operations on par with RS-232C to be performed from a computer. When you connect the instrument to a computer and set its interface to USB, it will be recognized as a virtual COM port on the computer.

Device Manager starts.



Check the COM number on the right of “HIOKI IM3570 Impedance Analyzer” port in the **[Ports (COM & LPT)]** list.

- When the IM3523, IM3523A, IM3533, IM3533-01, IM3590 and IM7580 : Check the COM number to the right of “HIOKI USB Device” in the **[Ports (COM & LPT)]** list.
- When the IM3570 : Check the COM number to the right of “HIOKI IM3570 Impedance Analyzer” in the **[Ports (COM & LPT)]** list.

NOTE

The procedure to start Device Manager differs depending on the version of the Windows operating system.

For details, refer to Help of the operating system.

A2

Appendix 1 Checking the USB Virtual COM Port

HIOKI
www.hioki.com/



**All regional
contact
information**

HEADQUARTERS

81 Koizumi
Ueda, Nagano 386-1192 Japan

HIOKI EUROPE GmbH

Helfmann-Park 2
65760 Eschborn, Germany
hioki@hioki.eu

2111 EN

Edited and published by HIOKI E.E. CORPORATION

Printed in Japan

- CE declarations of conformity can be downloaded from our website.
- Contents subject to change without notice.
- This document contains copyrighted content.
- It is prohibited to copy, reproduce, or modify the content of this document without permission.
- Company names, product names, etc. mentioned in this document are trademarks or registered trademarks of their respective companies.