HIOKI HIOKI E. E. CORPORATION

Headquarters 81 Koizumi, Ueda, Nagano 386-1192, Japan TEL +81-268-28-0562 FAX +81-268-28-0568 E-mail: os-com@hioki.co.jp URL http://www.hioki.com/ (International Sales and Marketing Department) 1307

For regional contact information, please go to our website at http://www.hioki.com

The Declaration of Conformity for instruments that comply to CE mark requirements may be downloaded from the HIOKI website.

Warranty

Warranty malfunctions occurring under conditions of normal use in conformity with the Instruction Manual and Product Precautionary Markings will be repaired free of charge. This warranty is valid for a period of one (1) year from the date of purchase. Please contact the distributor from which you purchased the product for further information on warranty provisions.

©User Memo

•	Write the follows when you purchase this product. This memo will be surely helpful to send the product to service.				
	The Production Number				
	The date of purchase				
	Shop Name				

З

TEL

DO NOT keep the product with other metals or batteries.

DOOd. IT MAY VIOIATE THE HOOD DO NOT expose the magnet directly

Sanitation Law.

November 2013 Revised edition 5 1FC6P110006705

. Snødden øses e

service personnel.

Instructions for Use

I

Contact a doctor immediately if such to avoid accidental swallowing.

DO NOT put the product in the mouth. Keep it away from children

fire disaster. Reter to the qualitied

The Umark within a black circle denotes the required procedure.

may cause abnormal overheat or DO NOT attempt to disassemble or service the products. Such an act

()	Buttor	n-type	d)			
			3	6	5	0

The Temperature Logger

Instruction Manual

Thank you for the purchase of our product. Before using this system, read this User's Manual for the proper operation This manual should be retained along with the Operation Manual. Those documents will be surely helpful for the future use

ABCD

3650



Instruction Manual

Before Use -----

Features

The management of

Safety Instructions ----- 2

Part Names and Functions --- 3

Operation Instruction ----- $5{\sim}8$

Precautions for Use ------ 9

Maintenance ----- 10

Specifications ------ 11 Declaration of Conformity ---- 12

HIOKI E.E. CORPORATION

the solid wastes ---- 10

Part Names and Functions

(Main body)

HIOKI •000000 00000 ABCDEF ⊁ The ID number ABCDEF The product-specific number (12 digits) The product number



Operation Instruction 1

1. Before use

Set the 3650 in preparation for the start of measurements (3650 Initial Settings) The 3920-01 Data Reader (not included in this system) and a personal computer are used for the 3650 to start measuring temperature. Refer to the 3920-01 Instruction Manual and the Software Operation Manual in details

•	Basic Information The ID number of the 3650 is unique throughout all the 3650s.
	The number will be used when the analysis software reads the data. Write down the number in advance before the setting.
•	Items to set
	Set the Date and Time
	The 3650 internal clock is displayed. Mark off the checkbox next to "Adjust to PC Time to adjust to the clock of computer.
•	Set the Date to Start Measuring
	Set the date and time to start measuring temperature.
•	Set the Measuring Interval
	Set the time interval between the consecutive measurements of temperature.
•	Set the Recording Mode
	The 3650 can record two thousand and forty eight (2048) data at maximum. There are two possible modes to choose from in the recording. Enable memory overwriting
	"Yes" :Record the newest data until now (max, 2048)
	"No" : Record the oldest data from start of measuring (max, 2048)
	Set the Temperature Alarm Warning
	Set the warning temperature when measuring temperature.
	Data outside of this range will be recorded as the alarm temperature time.

d, contact with the	nuot si tosteful examination. If any defect is foun	dealer or the user support.
5	(friemuoob zirtt) IsunsM noitourtenl 0235	
5	Screws for fixing holders 4×12	Â
L	faneM	
L	(llsm2) TobloH	
L	Holder (Large)	
L	3650 Temperature Logger	

Take out the user's manual and make sure that the following items are included in your package. Check the Packaging

situation which, if not avoided, could result in serious consequences in some cases. if not avoided, could result in death or serious in jury. CAUTION also indicates such a hazardous WARNING and CRUTION. WRRNING indicates a potentially hazardous situation which, prevent the risk of harming or damaging people. Safety instructions are divided into two sections;

@Marning

Atter reading this manual, keep it in a place where anyone can have access at any time.

Caution "Anoteces in some cases when the product is not handled properly.

indicates a potentially hazardous situation which could result in death or serious in Jury when the product is not handled properly.

indicates a potentially hazardous situation which could result in serious

Satety Instructions written in this manual are intended for the proper use of our product to Before using, read this 'Safety Instructions' thoroughly for the proper operation.

Satety Instructions

Betore Use



Features

Measuring temperature: Measures the temperature of the environment where the 3650 is placed.

Measuring temperature range: The measuring temperature range is as follows. 3650 ∶ -40°C to +85°C

Recording Duration

The following table shows the number of data that can be recorded in the memory when the temperature is continuously measured.

Measuring Time Interval	Data Counts
1 minute	1.4 day
3 minutes	5.2 days
5 minutes	7 days
10 minutes	14 days
30 minutes	42 days
1 hour	85 days

Possible recording counts: Over 500 thousand times

(4 years when measured in 5 minutes interval)

The usage in a place where the ambient temperature is over 50 may reduce the defined recording counts.

% For example, the battery will be exhausted if the 3650 is left at more than 80 $^\circ\!\!\mathrm{C}$ for approximately half a year



Characteristics of relationship between battery life and operating temperature (example)

The data recorded in the 3650 can be retrieved with the 3920-01 Data Reader (Refer to the 3920-013920-01 Instruction Manual and the Software Operation Manual in details), * Recorded date cannot be read out when the battery power is close to nil. 4

Operation Instruction 2

3. Initial settings 2 to start measuring temperature

(Example) The setting screen to start measuring temperature using the analysis software for Windows (3920-01)

Adjust the date and time to the computer

- Set the starting date and time to 19 minutes later than the current time.
- Set the Measuring Time Interval to 1 minute.
- et the High Temperature alarm at 40.0 and the Low Temperature at -10.0

<mark>-)</mark> Initial Setting	×
Date/Time: 🔽 Adjust	to PC Time
	3650-Time 2001/02/05 15:34:37
	PC-Time 2001/02/05 15:36:37
Start Date : 2001	/ 02 - / 05 - 15 - : 56 -
	Wait Time 19 Min
Measuring Interval 1	Min Memory Size 1.4days
Enable Overwrite 🔽 (Po	Total Counts 63346 ssible recording counts: Over 500 thousand times)
Alarm : High-Temp Low-Temp	
Memo	CoolBox No.22 Beef
<com1></com1>	
	OK Exit



The included magnet or screws are used depending on the place to fix the holder. • Attaching the magnet • Fixing with screws

Use the scotch tape at the back of the magnet to attach to the frame at the back side of the holder (Large) firmly.

e Screw the holder (Large) as illustrated below.



Precautions for Use

7

Precautions for Use		
Avoid using the 3650 in any place where it will be subject to vibration. Otherwise, it may cause failure.	Avoid exposing the 3650 directly to the sun or using it near fire. Otherwise, it may cause failure.	
Avoid using the 3650 in water. Otherwise, it may cause failure.	Avoid using or storing the 3650 in any place exposed to rain. Otherwise, it may cause failure.	

% When installing the 3650 in water or in an environment where water always splashes, please use the 3650 well sealed in a plastic bag.

• Before Use

Before you use the 3650 for a long time, be sure to check the total counts. If the count is close to five hundred thousand, the battery may wear out before the measurements are complete. Before you use the 3650, it is also recommended that it be tested in a normal

temperature for several times to confirm its proper operation.

 $\% \mbox{The usage in an environment where the ambient temperature is over <math display="inline">50^\circ \mbox{C}$ may shorten battery life.

*Recorded date cannot be read out when the battery power is close to nil.

Operation Instruction 4

Remove the 3650 out of the holder when used without the holder. \bullet Removing the 3650



Connect to the 3920-01 Data Reader • Used with the holder Connect to the 3920-01 Data Reader with the 3650 in the holder (Small) • Used without the holder Remove the 3650 from the holder and connect to the 3920-01 Data Reader



- Connect to the 3920-01 Data Reader Connect the 3920-01 Data Reader (Large)

8

Specifications

Product Name	Temperature Logger (button-typed)	
Model Name	3650	
Measuring Temperature Count	1	
Measuring Temperature Range	- 40°C to 85°C	
Operating Temperature Range	- 40°C to 85°C	
Storage Temperature Range	- 40°C to 85°C	
Resolution	0.5℃	
Maximum Measuring Counts	Over 500,000 (The usage in a place where the ambient temperature is over 50°C may reduce the specified count. Battery life is approximately half a year when operating continuously or storing for a long time at more than 80°C.)	
Accuracy of measurements	- 40.0°C to -10.5°C ±2°C - 10.0°C to 30.0°C ±1.5°C 30.5°C to 85.0°C ±2°C	
Accuracy of clock	$0^{\circ} C \sim 45^{\circ} C$ ± 1 minute per month other - 8 minutes per month max.	
Resistance to water	Ordinary water resistance	
Conformity	EN61326	
Dimension	17,35 mm across and 5,89 mm thick	

 Dimension
 17.35 mm across and 5.89 mm thick

 Weight
 3.3g

The Declaration of Conformity for instruments that comply to CE mark requirements may be downloaded from the HIOKI website.

11

• Regular cleaning is recommended to keep the 3650 clean all the time.

Don't wipe with polish, powder soap, benzene, oil or hot water.



Holder, the 3650

Stop the operation of the 3650 and wipe with a dry cloth.

2 Check after the maintenance

- After finishing the maintenance, check the following items for a proper operation.
- There is no fissure in the holder.
- No equipment is abnormally heated.

If anything seems to be wrong, feel free to ask to the store where you purchased this product or the service center.

The management of the solid wastes

Instructions for disposal

Attention Dispose the wastes as noncombustible. However, under various state and local laws, it may be illegal to dispose of the wastes that way. Check with your local solid waste officials for details in your area for proper disposal.

9