

## MEMORY HICORDER MR8740T





Perfect for multi-point measurements on high-performance boards

108 Channels of Simultaneous Testing

••• Delivering triple-digit multichannel measurement

Analog 108ch


Analog (96ch) + Logic (48ch) 144ch

 $\begin{array}{c} {\rm Signal\ generation} \\ {\rm Max.} \end{array} \\ {216} ch$ 










## Compact, measures up to 108 channels

## Multi-channel, reduced footprint

The MR8740T achieves testing of up to 108 channels, double that of conventional models, while maintaining the same unit size. Test high-performance ECU boards, with their ever-increasing number of test points, with a single measurement system. Make the most of your limited space for testing systems.



## Isolated design for fault prevention

### All channels isolated

Isolation of all channels prevents noise from connected devices, with no negative effect due to different ground potential. Eliminate faults and other trouble caused by mistaken wirings and over-voltages / over-currents due to shorted boards.



Between input channels

Between main unit and input channel

\* Only the 8971 and 8973 units are



## **MEMORY HICORDER MR8740T**

Analog Max. 108ch Test data transfer time

As artificial intelligence advances in automobiles and other advanced industries the need for technology to simultaneously process large volumes of data, as well as safety and security, has arrived. The MR 8740T supports your testing needs with simultaneously sampled measurements across multiple channels.







Simultaneous sampling on all channels




\*1: When using 8966 \*2: When using MR8990, U8991

## Transfer time for test data reduced to almost zero

### Minimize dead time while testing

Previously, calculations and saving/transferring data after measurements were slow processes, and much of the testing time was taken up by dead time while waiting to perform the next test. The MR8740T dramatically reduces the time both for calculations and saving data, almost completely eliminating dead time while performing tests.



## Save recorded data 100 times faster

#### Minimize the time required to save on devices and media

The MR8740T features a brand new interface and faster internal processing, reducing the time required to save measurement data to media. For example, saving that required 10 minutes previously can now be completed in as little as 6 seconds. This saves you the trouble of waiting for data to be saved and improves work efficiency.

Legacy models	USB 2.0	
	036 2.0	1/20 of conventional models
MR8740T	USB 3.0	1/30 of conventional models
	Internal SSD	1/100 of conventional models

#### Save data in real time NEW




#### Save data while measurement is ongoing

The MR8740T saves data in real-time to recording media while measurement is ongoing thanks to a combination of high-speed data transfer performance and high-speed data saving performance. For example, if saving data to the internal SSD, the instrument can save 64 channels of data in real time at a sampling rate of 1 MS/s.



# **Applications**



## **Control simulation**

Generating and measuring signals with a single device eliminates the need to prepare separate measurement and generator devices.

Simulated output of various sensor signals and control pulse signals allows you to simulate the test waveforms (DC output, sine wave output) of engine controls for automobiles, high speed trains, and airplanes, and control boards for airbags, brake systems, power steering, and active suspension.







Airbag control test

Brake system control test

Engine control test


## Tests using distortion measurements

Input the analog signal from a strain gauge or extensometer and the analog signal from a stress sensor.

Use the scaling function to convert those values to tensile strain, and to convert the stress sensor value to tensile stress.

Measure analog and logic at the same time, to simultaneously record a variety of signals with a single test.







Measure stress in moving parts of industrial robots



Multi-point measurement of propellers on wind power generators, etc.

# **ECU Testing**

ECUs are connected to a large number and wide variety of sensors. Add a signal generation unit to simulate these sensors. By measuring the simulation results with a measurement unit at the same time, you can perform all steps from signal generation to measurement with a single MR8740T.

The U8794 also offers resistance output to enable thermistor circuit testing.



## Replace multiple DMMs with a single unit


Replace multiple desktop DMM units with a single MEMORY HiCORDER for measuring multi-channel sensors. Select from the MR8990 2-channel unit with a wide range, or the U8991 4-channel unit to measure multiple channels. In addition to reducing the number of units required, system simplification makes maintenance and management easier.

Expandable to a maximum of 108 channels using multiple 4-channel

# 108 Benchtop DMMs







### Comparison of DIGITAL VOLTMETER UNIT MR8990 and U8991

External appearance	HOOK! OF SHEET OF SHE	Service Office O		
Model No.	MR8990	U8991		
Measurement functions	No. of channels: 2, for DC voltage measurement	No. of channels: 4, for DC voltage measurement		
Input terminals	Banana input terminal Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)	isolated from the unit, the maximum voltage that can		
Measurement range	100, 1000 mV f.s. 10, 100, 1000 V f.s., 5 ranges	1, 10, 100 V f.s., 3 ranges		
Measurement resolution	ent 1/1,000,000 of measurement range (using 24-bit ΔΣ modulation A/D)			
Integration time	20 ms × NPLC (during 50 Hz),	16.67 ms × NPLC (during 60 Hz)		
Basic measurement accuracy	±0.01% rdg. ±0.0025% f.s. (at range of 1000 mV f.s.)	±0.02% rdg. ±0.0025% f.s.		
Maximum input voltage	500 V DC (the maximum voltage that can be applied across input pins without damage)	100 V DC (the maximum voltage that can be applied across input pins without damage)		


## Specifications for DC voltage measurements

Measure minute fluctuations in sensor output for automobiles or voltage fluctuations in batteries with high precision and at high resolution. The maximum voltage input is 500 V DC for the MR8990 and 100 V DC for the U8991. Both units also feature high input resistance.

## Real-time Save

# Save data while measurement is ongoing, even with extended recording, high-speed sampling, and numerous channels

The MR8740T offers real-time save functionality that saves data to recording media while measurement is ongoing. Hioki recommends using the instrument's large internal SSD unit when you need to record data for extended periods of time. If you wish to save data after measurement has completed, you can specify a USB drive as the save destination. Additionally, you can use the real-time save function to control how long the instrument can continue measuring without being dependent on the amount of built-in storage memory. Files are saved as 512 MB segments when using the real-time save function.



### Real-time save capabilities when measuring 108 channels

Save destination	Number of channels	Sampling speed	Supported measurement time	Maximum sampling speed at which real-time saving is supported*1
Internal SSD (480 GB)	108 ch	500 kS/s	About 1 hr.	5 MS/s (12 channels)
USB Drive Z4006 (16 GB)	108 ch	100 kS/s	About 10 min.	1 MS/S (12 channels)*2
PC	108 ch	20 kS/s	Depends on PC capacity	200 kS/s (12 ch)

<sup>\*1:</sup> For 2 channels (no settings for channel 1) \*2 When connected via a USB 3.0 connector only.

### Maximum sampling speeds at which real-time saving is supported

Save destination	Number of channels used						
Save desimation	Up to 12	12 to 32	33 to 64	65 or more			
Internal SSD	5 MS/s	2 MS/s	1 MS/s	500 kS/s			
USB Drive Z4006	1 MS/s *2	500 kS/s *2	200 kS/s *2	100 kS/s *2			
PC	200 kS/s	100 kS/s	50 kS/s	20 kS/s			

<sup>\*1:</sup> Double channel counts if U8991 is installed. \*2: When connected via a USB 3.0 connector only.


# Amount of time for which data can be saved in real time to internal SSD (reference values)

d: Days h: Hours min: Minutes s: Seconds

0	Number of channels used							
Sampling speed	Up to 12 13 to 32		33 to 64	65 or more				
5 MS/s	50 min	-	-	-				
2 MS/s	2 h 05 min	1 h 02 min 30 s	-	_				
1 MS/s	4 h 10 min	2 h 05 min	1 h 02 min 30 s	-				
500 kS/s	8 h 20 min	4 h 10 min	2 h 05 min	1 h 02 min 30 s				
200 kS/s	20 h 50 min	10 h 25 min	5 h 12 min 30 s	2 h 36 min 15 s				
100 kS/s	1 d 17 h 40 min	20 h 50 min	10 h 25 min	5 h 12 min 30 s				
50 kS/s	3 d 11 h 20 min	1 d 17 h 40 min	20 h 50 min	10 h 25 min				
20 kS/s	8 d 16 h 20 min	4 d 08 h 10 min	2 d 04 h 05 min	1 d 2 h 02 min 30 s				
10 kS/s	17 d 08 h 40 min	8 d 16 h 20 min	4 d 08 h 10 min	2 d 04 h 05 min				
5 kS/s	34 d 17 h 20 min	17 d 08 h 40 min	8 d 16 h 20 min	4 d 08 h 10 min				
2 kS/s	86 d 19 h 20 min	43 d 09 h 40 min	21 d 16 h 50 min	10 d 20 h 25 min				
1 kS/s	173 d 14 h 40 min	86 d 19 h 20 min	43 d 09 h 40 min	21 d 16 h 50 min				
500 S/s	347 d 05 h 20 min	173 d 14 h 40 min	86 d 19 h 20 min	43 d 09 h 40 min				
200 S/s	1	ł	217 d 00 h 20 min	108 d 12 h 10 min				
100 S/s			ł	217 d 00 h 20 min				


### Saving data directly to your PC

Transfer measurement data directly to your PC by using the FTP sending function together with the real-time save function. This makes it easier to observe data after the measuring process.



# Long-term measurements for more efficient testing

The real-time save function boasts high-speed sampling and multi-channel measurements. Perform an approximately 1-hour measurement at 5 MS/s in 2 channels or 1 MS/s in 64 channels.



# Complete Product Lineup



Install up to 27 modules

## **Build Your Ideal Inspection System**

Choose from a diverse array of modules to build your perfect test system.

To test a ECU that requires multi-point, high-precision measurements, combine the U8975, U8978 and U8991 4-channel units to build a measurement system that delivers a maximum of 108 channels. In addition, create an integrated testing system that can simulate engine behaviors and sensors by utilizing the waveform generators, pulse generators, and VIR generators available on select units.

Use ANALOG UNIT 8966 and DIGITAL VOLTMETER UNIT MR8990 to supplement waveforms of high-speed and high-voltage signals, such as for inverter boards, in the same way as when measuring with a DMM. Combine high-precision units that perform simultaneous sampling for safe and reliable operation in a variety of measurement scenarios.

Unit interchangeability

Use any of the 18 types listed in the unit selection guide below.

The MR8740T is compatible with the same units used for the HIOKI MEMORY HICORDER MR8740, MR8741, MR6000, MR8827, and MR8847A.

## Unit selection guide (18 types available)

	Measured signal	Model No.	Description	No. of channels	Fastest sampling	Bandwidth	A/D resolution	DC accuracy	Max. input voltage	Min. resolution (*1)	Max. sensitivity range	Isolated/ Non- isolated	Notes
	Voltage	8966	ANALOG UNIT	2 ch	20 MS/s	DC to 5 MHz	12 bits	±0.5% f.s.	400 V DC	0.05 mV	100 mV f.s.	Yes	n/a
	Voltage (multi-channel)	U8975	4ch ANALOG UNIT	4 ch	5 MS/s	DC to 2 MHz	16 bits	±0.1% f.s.	200 V DC	0.125 mV	4 V f.s.	Yes	n/a
NEW	Voltage (multi-channel, high resolution)	U8978	4CH ANALOG UNIT	4 ch	5 MS/s	DC to 2 MHz	16 bits	±0.3% f.s.	40 V DC	3.125 uV	100 mV f.s.	Yes	n/a
	Voltage (high resolution)	8968	HIGH RESOLUTION UNIT	2 ch	1 MS/s	DC to 100 kHz	16 bits	±0.3% f.s.	400 V DC	3.125 uV	100 mV f.s.	Yes	with AAF
	Voltage (DC, RMS)	8972	DC/RMS UNIT	2 ch	1 MS/s	DC to 400 kHz	12 bits	±0.5% f.s.	400 V DC	0.05 mV	100 mV f.s.	Yes	with RMS
	Voltage (high voltage)	U8974	HIGH VOLTAGE UNIT	2 ch	1 MS/s	DC to 100 kHz	16 bits	±0.25% f.s.	1000 V DC 700 V AC	0.125 mV	4 V f.s.	Yes	Maximum rated voltage to ground 600 V AC/DC CAT IV
	Voltage (high resolution)	MR8990	DIGITAL VOLTMETER UNIT	2 ch	2 ms	n/a	24 bits	±0.01% rdg. ±0.0025% f.s.	500 V DC	0.1 uV	100 mV f.s.	Yes	Maximum rated voltage to ground 300 V AC/DC CAT II
	Voltage (high resolution)	U8991	DIGITAL VOLTMETER UNIT	4 ch	20 ms	n/a	24 bits	±0.02% rdg. ±0.0025% f.s.	100 V DC	1 uV	1 V f.s.	Yes	Maximum rated voltage to ground 100 V AC/DC
	Current	8971	CURRENT UNIT	2 ch	1 MS/s	DC to 100 kHz	12 bits	±0.65% f.s.	Current sensor only		on current nsor	No	with RMS Max. 4 units
NEW	Current	U8977	3CH CURRENT UNIT	3 ch	5 MS/s	DC to 2 MHz	16 bits	±0.3% f.s.	Current sensor only		on current nsor	No	Max. 3 units
	Temperature	8967	TEMPERATURE UNIT	2 ch	1.2 ms	DC	16 bits	Detailed reference	Thermocouples only	0.01°C	200°C (392°F) f.s.	Yes	n/a
	Strain	U8969	STRAIN UNIT	2 ch	200 kS/s	DC to 20 kHz	16 bits	±0.5% f.s. ±4 με	Strain only	0.016 με	400 μ <b>ε</b> f.s.	Yes	n/a
	Frequency	8970	FREQ UNIT	2 ch	200 kS/s	DC to 100 kHz (*3)	16 bits	n/a	400 V DC	0.002 Hz	Depends on mode	Yes	n/a
NEW	Acceleration	U8979	Charge Unit	2 ch	200 kS/s	DC to 50 kHz (DC) 1 Hz to 50 kHz (AC)	16 bits	±0.5% f.s. (Voltage) ±2.0% f.s. (Acceleration)	40 V DC		nds on ion sensor	Yes	Supports TEDS
	Logic	8973	LOGIC UNIT	4 probes	n/a	n/a	n/a	n/a	n/a	n/a	n/a	No	9320-01,9327, Requires 9320-01, 9327 or MR9321-01

(\*1) Minimum resolution shows the highest sensitivity resolution. (\*2) When using the 9665 (\*3) Minimum pulse width 2 µs

Target	Model No.	Description	Channels	Output	Frequency	Output range
Voltage	MR8791	PULSE GENERATOR UNIT	8 ch	Pulse, pattern	0.1 Hz to 20 kHz (pulse) 10 Hz to 120 kHz (pattern clock)	Logic output (Amplitude: 0 to 5 V), Open collector output
Voltage	MR8790	WAVEFORM GENERATOR UNIT	4 ch	DC, sine wave	DC, 1 Hz to 20 kHz	Output: -10 V to 10 V (Amplitude setting range: 0 to 20 Vpp)
Voltage / Current / Resistance	U8794	VIR GENERATOR UNIT	8 ch	DC voltage, DC current, resistance (simulated output)	n/a	Voltage: -0.1 V to 5.3 V, Current: $\pm 5$ mA, Resistance: 10 $\Omega$ to 1 M $\Omega$

# Unit Advantages

Ideal for simulation testing that involves signal generation and measurement







U8794 for generating voltage, current, and resistance

MR8790 for generating waveform signals


MR8791 for generating pulse signals

## Generate voltage/current signals, pulses and simulated resistance

Use generator units in place of the sensor output for simulation testing or board testing lines using generated signals. Combine a generator unit and measurement unit to perform generation and measurement with a single test system.

## **VIR GENERATOR UNIT U8794**

Output DC voltage, DC current, and resistance.





Electronic circuitry built with compact resistors



Traditional switching resistors are large and take up space.

8 channels with 1 unit

# Easily configure output settings and monitor measured values

You can easily set the constant voltage, constant current, or resistance value to output for each channel. Internal voltage, current, and resistance values can be displayed on the same screen.

## Ideal for testing that requires simulated signals

When used as an ECU testing device, generate simulated signals from various sensors, which is indispensable for testing electronic parts and maintaining equipment.

## Generator units can simulate a variety of sensor signals

ECU type	Sensor function	Sensor type	Generator unit
	Air flow sensor	Voltage	U8794
	Throttle sensor	Voltage	U8794
	O2 sensor	Voltage	U8794
Engine	Knock sensor	Voltage	MR 8790
management	Crank angle sensor	Voltage	MR 8791
system	Camshaft sensor	Voltage	MR 8791
	Water temperature sensor	Resistance	U8794
	Intake air temperature sensor	Resistance	U8794
Driving management system	Torque sensor G sensor Steering angle sensor Speed sensor	Voltage	MR 8790 MR 8791 U 8794
Safety & comfort management system	Ultrasonic/radar sensor Vibration sensor Refrigerant pressure sensor Humidity sensor	Voltage Resistance	MR8790 MR8791 U8794



#### **Testing electronic parts**

Use the recorder's internal voltage monitor and current monitor to test electronic parts. Or, check resistance values and diode direction characteristics based on the output current and measured voltage.

### Testing and maintaining equipment

Easily maintain and test equipment involved in voltage and current measurements thanks to high accuracy output.

Simultaneous sampling on all channels across all units




Measure up to 200 V U8975 Measure at 24-bit resolution U8991

Measure with high sensitivity at 100 mV f.s.: U8978

## Ideal for measurements that require simultaneity

All channels are equipped with an A/D converter and measurement timings are synchronized, eliminating sampling time difference between units and channels. This delivers accurate time measurement for cursor readout and time difference measurements.




## Record briefly at high speed, record for a long time at low speed

Use high-speed sampling to capture inverter waveforms, and low-speed sampling to measure RMS values on multiple channels.

## Maximum recording time to internal memory

	When using a	When using a	4-channel unit
Sampling rate	2-channel unit	When using U8975, U8978	When using U8991
Sampling rate	Recording length:	Recording length:	Recording length:
	10 M points	5 M points	2 M points
20 MS/s	0.5s	0.25 s	0.1
10 MS/s	1 s	0.5s	0.2
5 MS/s	2 s	1 s	0.4
2 MS/s	5 s	2 s	1
1 MS/s	10 s	5 s	2
500 kS/s	20 s	10 s	4
200 kS/s	50 s	25 s	10
100 kS/s	1 m 40 s	50 s	20
50 kS/s	3 m 20 s	1 m 40 s	40
20 kS/s	8 m 20 s	4 m 10 s	1 m 40
10 kS/s	16 m 40 s	8 m 20 s	3 m 20
5 kS/s	33 m 20 s	16 m 40 s	6 m 40
2 kS/s	1 h 23 m 20 s	41 m 40 s	16 m 40
1 kS/s	2 h 46 m 40 s	1 h 23 m 20 s	33 m 20
500 S/s	5 h 33 m 20 s	2 h 46 m 40 s	1 h 6 m 40
200 S/s	13 h 53 m 20 s	6 h 56 m 40 s	2 h 46 m 40
100 S/s	1 d 3 h 46 m 40 s	13 h 53 m 20 s	5 h 33 m 20
50 S/s	2 d 7 h 33 m 20 s	1 d 3 h 46 m 40 s	11 h 6 m 40
20 S/s	5 d 18 h 53 m 20 s	2 d 21 h 26 m 40 s	1 d 3 h 46 m 40
10 S/s	11 d 13 h 46 m 40 s	5 d 18 h 53 m 20 s	2 d 7 h 33 m 20
5 S/s	23 d 3 h 33 m 20 s	11 d 13 h 46 m 40 s	4 d 15 h 6 m 40
2 S/s	57 d 20 h 53 m 20 s	28 d 22 h 26 m 40 s	11 d 13 h 46 m 40
1 S/s	115 d 17 h 46 m 40 s	57 d 20 h 53 m 20 s	23 d 3 h 33 m 20



# Instantaneous measurement of various inverter waveforms

Simultaneously measure and record multiple phenomena, such as the voltage, current, torque, and rotation signal on the primary and secondary sides of an inverter, from high voltage to minute voltage.


# Highly accurate measurement of RMS values over long periods of time

Use the high-resolution CURRENT UNIT 8971 for highly accurate measurements of RMS values over long periods of time.

# Measurement and Analysis Functions

## Triggers that detect targeted events

Set triggers on any channel to record data whenever an event occurs. This setting can be configured for all channels.




### Setting multiple triggers for a single channel


Set up to 4 triggers for a single channel.

Sometimes the cause of issues are unclear, preventing you from setting up the proper trigger to capture the necessary waveforms and conduct further analysis. By being able to set glitch, level, windowin, and window-out triggers for the same input waveform, for instance, you can broaden the scope of your investigation and increase your chances of catching the signal anomalies.





Setting Screen with Easy-to-Understand Trigger System Chart



## Warning function using trigger settings

Trigger settings are used to issue a warning if the setting range is exceeded.

For example, during an immunity test, this function can be used to notify the user when the variable limit value of the measured voltage is exceeded. In such cases, a window out trigger is used.


## **Output warning**

- (1) When a waveform exceeds the upper and/or lower limits of the setting range, an event mark is displayed on the screen and an alarm sounds. When the waveform is once again within the upper and/or lower limits of the setting range, the alarm stops and an event mark is displayed on the screen.
- (2) In each case, the time, channel, type of trigger, and voltage measurement value are displayed on the top right side of the screen. \* Effective for sampling at 100 KS/s or less.

### When unsure about trigger level

## Setting trigger level automatically

Take a preliminary measurement of a specified number of samples before the actual measurement, and use the average of those values to set the trigger level. This function is useful both for the warning function and for normal triggers.



Warning function settings are the same as for triggers, and easy to use.




Warning displayed at the top of the screen when the alarm sounds

## Calculation function with high analytical performance

#### **Waveform processing**

In addition to calculating numerical values such as average values and RMS values, up to 16 types of simultaneous processing are available by combining calculations in the waveform dimension with differential arithmetic, including the four arithmetic operations, between channels.



# Simultaneously make up to 16 waveform calculations by combining the four arithmetic operations and 11 types of calculations

Four arithmetic operations (addition, subtraction, multiplication, and division)	Parallel displacement along time axis (SLI)
Absolute value (ABS)	Differentiation (primary (DIF), secondary (DIF2))
Exponentiation (EXP)	Integration (primary (INT), secondary (INT2))
Common logarithm (LOG)	Trigonometric functions (SIN, COS, TAN)
Square root (SQR), cube root (CBR)	Reverse trigonometric functions (ASIN, ACOS, ATAN, ATAN2)
Moving average (MOV)	MR8990 DIGITAL VOLTMETER UNIT time shift for PLC delay (PLCS)

#### **Numerical calculations**

The measured waveforms are analyzed with numerical parameters.

The MR8740T features several new numerical calculations including overshoot and undershoot calculations.

In addition to analog and logic channels, the recorder performs calculations on waveform processing results. It also features a numerical judgment function.

## Simultaneous numerical calculations of up to 108 out of a total of 33 computations

Average value	Duty ratio		
RMS value	Pulse count		
Peak to peak value	Four arithmetic operations		
Maximum value	Time difference		
Time to maximum value	Phase difference		
Minimum value	High-level		
Time to minimum value	Low-level		
Period	Median value		
Frequency	Amplitude		
Rise time	Overshoot		
Fall time	Undershoot		
Standard deviation	+Width		
Area value	-Width		
X-Y area value	Burst width		
Specified level time	Integration values		
Specified time level	XY waveform angle		
Pulse width			

# Find a specific waveform within large amounts of measurement data

Set the peak values or trigger conditions you want to search for to have the relevant data retrieved and displayed automatically.


Our new Memory HiCorder HiConcierge function automatically calculates the characteristics of the reference waveform you have set and searches all of the measured data to detect any waveforms with low similarity as anomalous waveforms.

This drastically reduces the amount of time required to search for anomalies by eliminating the need to scroll through measured waveforms and checking them visually.

# Auto search of anomalous waveforms with Concierge

#### **Memory HiCorder Concierge**

A new waveform search function that finds anomalous waveforms in all of the measured data. This function is ideal for situations where it is difficult to set the right triggers before measuring because the nature of potential anomalies cannot be predicted.



Memory HiCorder Concierge Waveform Search Screen



## Rich set of search methods

#### Peak search

Search for the maximum value, minimum value, local maxima, or local minima in all of the measured data, and mark the search point in the waveform.

#### Trigger search

Set trigger conditions for all of the measured data again to search for points where the conditions are fulfilled, even if no triggers were set during the measuring process.

#### Jump

Jump to an event mark you made while measuring, to the cursor position on the display, or to the location measured at a specified time.


# Smart Links with Monitors and PCs



## Easily check measured waveforms and the settings of communication commands


During the design of an inspection system, a monitor and PC is needed to set communication commands and confirm that the measurement waveform is correct. You can check whether the setting information of the communication commands are accurately transmitted with the CMD ERR lamp on the main body. It is easy to further verify whether the measurement range (time axis and voltage axis), measurement time, triggers, and calculations are operating according to your settings. In this way, it's easy to build your ideal system.

\* A display with a resolution of 1920 x 1080 or better is recommended




## Display system for efficient work

Configure various settings while viewing a variety of information on a single screen. Improve work efficiency by reducing the need to switch or scroll through screens in order to check the settings for each channel.



### Waveform analysis with 8 cursors

When building a system or analyzing faulty parts, perform a detailed check of waveforms in order to verify proper operation. Use multiple cursors on the MR8740T to smoothly analyze and evaluate actual waveforms.



### LabView compatibility

NEW

The MR8740T can be controlled with LabVIEW. Search for "MR8740-50" under "Download Software" in the "Support" section of Hioki's website and download the LabVIEW driver.



# Control the MR8740T with a single computer

Connect the MR8740T to a computer via LAN in order to control it with communication commands. This allows you to configure, generate, measure, and acquire data with only a single computer. After the testing system is built, remove the monitor for a more compact system.



# Standard recorder when control via PC is not required

If the unit will be used only as a basic recorder and there is no need to use a computer for control, use only the MR8740T together with a monitor to take and record measurements. Display the channel waveforms that are measured with the MR8740T on the monitor in order to quickly analyze and calculate results.

# High-speed communication function

A 1000 BASE-TX LAN terminal is equipped as standard.


# FTP server function


The content of the MR8740T's memory (USB memory and internal SSD) can be copied to the computer.

## FTP transfer function

Measurement data can be transferred directly to the computer.

## Interface





## LEDs indicate unit status

The POWER STANDBY lamp and DIAG lamp indicate the basic status. The CMD ERR lamp lights when an error or warning occurs.

LED name	Color/ flashing	Meaning when on	How to turn off
	Orange	Power standby	Main power switch OFF
POWER STANDBY	Green	Power ON	Activate switch OFF *
OTANDBT	Green/ flashing	Power ON (warming up)	Activate switch OFF *
DIAG	See below		-
CMD ERR	Red	Syntax error in command received, or warning occurred	*Goes off with CLS

\* If the POWER STANDBY lamp is steady or flashing green, do not turn the main power switch OFF.

#### **DIAG LED Mode Table**

Display order of priority	Color/ flashing	Status	Supplement
1	Red	Ambient temperature too high (environmental temperature > 35°C/95°F)	
2	Purple	Ambient temperature too low (environmental temperature < 10 °C/50 °F)	
3	O Yellow	CPU load factor 80% or more	The average load factor is updated every 0.5 seconds.
	Blue	The instrument is in the trigger standby state.	
4	Green	Recording in progress	
	Pink	Recording finished	New command received, switches to normal display.
5	O White	Normal operation in progress (stopped)	

## Internal battery

The MR8740T is equipped with a battery (sealed lead acid battery) for shutting down the Windows operating system when the power supply is cut off. This allows the unit to be shut down normally even when there is an unexpected power failure or a breaker trips.

Using the battery to shut down normally if there is a power failure



- Breaker OFF - Power outage (for 150 ms or longer)

- Power cord disconnected



000 0000 0000

\* If the main power switch is switched off while the recorder is in operation, the internal battery will not turn on, preventing the recorder from shutting down normally. Before turning the main power off, be sure to first put the recorder in standby



<sup>\*</sup> The internal battery should be replaced regularly, according to the estimated service life indicated in the table above. If the service life is exceeded and a power outage occurs, Windows might not shut down normally, and if so Windows might not start up again normally. Therefore, it is important to replace the battery on a regular basis. At the recommend replacement time, please contact your authorized Hioki distributor or reseller for a replacement battery.

## 1 Space for units

Max. 27 units can be installed Model 8973 can only be installed in slots 25 to 27

#### 2 USB 2.0 connector x2

For connecting a USB memory stick, USB mouse, or USB keyboard

### 3 Activate button

ctivates the unit, or places it in standby

#### 4 POWER lamp Indicates the unit is activated or in standby

## 5 DIAG light

### 6 Command error lamp

## 7 Air vents

For reducing the internal temperature

## 8 PS2 connector

Not operational with this system

## 9 USB 2.0 connector x2

For connecting a USB memory stick, USB mouse, or USB keyboard

#### 10 COM terminal

Not operational with this system

#### 11 HDMI terminal

For connecting to monitors using an HDMI cable Max. resolution: 3840 x 1260

#### 12 VGA terminal

For connecting to monitors using an RGB cable Max. resolution: 2560 x 1600

### 13 Display Port terminal

For connecting to monitors using a Display Port cable Max. resolution: 4096 x 2160

#### 14 1000 BASE-T connector

For connecting to the network via a LAN cable

#### 15 USB 3.0 connector x4

For connecting a USB memory stick, USB mouse, or USB keyboard

#### 16 Audio terminals

Not operational with this syster

### 17 External control terminals

For inputting various external signals to control the device

### 18 Model No., Serial No.

Numbers for identifying the unit

#### 19 Main power switch

For turning the power ON or OFF
\* Place the unit in standby before turning the power OFF

#### 20 Power inlet

onnect the included power cord.

### **External control terminals**


Connect an external device to the external control terminal in order to use that external device to start and stop the measurements made by the unit.


No.	Terminal name	Operation
1	GND	-
2	IN1	Start/stop measurements, save,
3	IN2	forced termination, event input
4	GND	-
5	OUT1	Judgment output, occurrence of errors,
6	OUT2	busy, trigger standby
7	GND	-
8	EXT.TRIG	Inputs signal as an external trigger source
9	TRIG.OUT	Outputs a signal when triggering occurs
10	GND	-
11	EXT.SMPL	Inputs external sampling signals

## **Analysis software**

Wave Viewer Wv (Bundled software) Download free updates from the HIOKI website.

The MR8740T ships standard with Wave Viewer Wv, an application for displaying and converting waveforms. The application allows you to review waveforms stored in binary data captured with the MR8740T on a PC and convert files to CSV format so that they can be loaded by Excel.





Sample Wy Screen

Sample Excel Screen

### • Wave Viewer (Wv) Brief Specifications

Operating environment	Windows 10 / 8 / 7 (32 / 64-bit)
Functions	Simple display of waveform files     Convert binary data files to text format, CSV, etc.     Scroll function, enlarge/reduce display, jump to cursor/trigger position, etc.

## WAVE PROCESSOR 9335 (Software sold separately)

Waveform display, calculation, and printing functionality

• 9335 Brief Specifications

Operating environment	Windows 10 / 8 / 7 (32 / 64-bit)	
Functions	<ul> <li>Display functions: Waveform display, X-Y display, Cursor fur- File loading: Readable data formats (MEM, REC, RMS, .P able file size: Maximum file size that can be saved by a give be limited depending on the computer configuration)</li> <li>Data conversion: Conversion to CSV format, Batch convers</li> </ul>	OW) / Maximum load- en device (file size may
Printing	- Print function: Printing image file output (expanded META t - Print formatting: 1 up, 2-to-16 up, 2-to-16 rows, X-Y 1-to-4 u	

## **Product Specifications**

corder  OG UNIT 8966 installed: Up to 54 analog channels  IC UNIT 8973 inserted: Up to 48 analog channels + 48 logic channels  OG UNIT 9875 / U8978 / U8991 installed: Up to 108 analog channels  OG UNIT 9875 inserted: Up to 96 analog channels + 48 logic channels  or are limited to slots 25 to 27 only.  ith ANALOG UNIT 8966, all channels at the same time)  impling 10 MS/s  erecording length per channel by limiting the number of modules in use  sic Using all modules; 16 modules: using modules 1 through 16; 8  sing modules 1 through 8; 4 modules: using modules 1 through 4  5 modules  8 modules  8 modules  4 modules  6MW/ch  32MW/ch  64MW/ch  nent will be disabled for modules other than those shown above.  collution Degree 2, altitude up to 2000 m (6562, 20 ft)  CC (32°F to 104°F), less than 80 % RH (no condensation)  O°C (14°F to 122°F), 80 % RH or less (no condensation)  61010  1326 Class A  1 minute (sensed current: 10 mA) between main unit and power supply livy voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations for rated ge)  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V or supply frequency: 50 Hz/60 Hz, Expected f
IC UNIT 8975 inserted: Up to 48 analog channels + 48 logic channels OG UNIT 9975 / U8975 / U8991 installed: Up to 108 analog channel IC UNIT 8975 inserted: Up to 96 analog channels + 48 logic channels are limited to slots 25 to 27 only. With ANALOG UNIT 8966, all channels at the same time) ampling 10 MS/s  erecording length per channel by limiting the number of modules in use. Using all modules; 16 modules: using modules 1 through 16; 8 sing modules 1 through 8; 4 modules: using modules 1 through 4 modules in use. 8 modules 1 through 8; 4 modules: using modules 1 through 4 modules 1 through 8; 4 modules: using modules 1 through 4 modules 1 through 4 modules 1 through 8; 4 modules: using modules 1 through 4 modules 1 through 16; 8 modules 1 thro
ith ANALOG UNIT 8966, all channels at the same time) impling 10 MS/s  er recording length per channel by limiting the number of modules in uses: Using all modules; 16 modules: using modules 1 through 16; 8 sing modules 1 through 8; 4 modules: using modules 1 through 4 modules 3 modules 1 through 4; 8 modules 4 modules 4 modules 6 modules 6 modules 6 modules 1 through 4; 9 modules 1 throu
er recording length per channel by limiting the number of modules in use is: Using all modules; 16 modules: using modules 1 through 16; 8 sing modules 1 through 8; 4 modules: using modules 1 through 4 6 modules 1 through 8; 4 modules: using modules 1 through 4 6 modules 8 modules 4 modules 4 modules 6 modules 1 through 4 6 modules 4 modules 4 modules 6 modules 6 modules 4 modules 6 m
Existing all modules: 16 modules: using modules 1 through 16; 8 sing modules 1 through 8; 4 modules: using modules 1 through 4 6 modules 8 modules 4 modules 4 modules 4 modules 4 modules 4 modules 4 modules 5 modules 4 modules 6 modules 7 modules
Existing all modules: 16 modules: using modules 1 through 16; 8 sing modules 1 through 8; 4 modules: using modules 1 through 4 6 modules 8 modules 4 modules 4 modules 4 modules 4 modules 4 modules 4 modules 5 modules 4 modules 6 modules 7 modules
8 modules 4 modules 6 MW/ch 32 MW/ch 64 MW/ch nent will be disabled for modules other than those shown above.  5 July 10 July
6MW/ch 32MW/ch 64MW/ch nent will be disabled for modules other than those shown above.  Dilution Degree 2, altitude up to 2000 m (6562.20 ft)  C (32°F to 104°F), less than 80 % RH (no condensation)  0°C (14°F to 122°F), 80 % RH or less (no condensation)  61010 61326 Class A  1 minute (sensed current: 10 mA) between main unit and power supplity voltage: 100 V to 240 V AC (consider ±10% voltage fluctuations for rated ge)  are supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V experts (discharged once/day, 23°C (73°F)) "Reference: Approx. 4 years (at 23°C (73°F)) for clock and settings  years (discharged once/day, 23°C (73°F)) "Reference: Approx. 4 years (argued 5 times/year  2 mm (16.77 in ±0.08 in) W x 177 mm ±2 mm (6.97 in ±0.08 in) H x  n (19.88 in ±0.08 in) D (excluding protrusions)  1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)  Quick Start Manual (booklet), instruction Manual (detailed edition) (CD-on disk (CD-R), blank panel (blank slot only), rack installation hardware  re and humidity range: 23°C ±5°C (73°F ±9°F), 80 % RH or less  5, or a product with similar specifications  B  0  3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
6MW/ch 32MW/ch 64MW/ch nent will be disabled for modules other than those shown above.  collution Degree 2, altitude up to 2000 m (6562.20 ft)  C (32°F to 104°F), less than 80 % RH (no condensation)  0°C (14°F to 122°F), 80 % RH or less (no condensation)  61010  611326 Class A  1 minute (sensed current: 10 mA) between main unit and power supply voltage: 100 V to 240 V AC (consider ± 10 % voltage fluctuations for rated ge)  are supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  61047, leap-year correcting 24 -hour clock  1 years (at 23°C (73°F)) for clock and settings  1 years (discharged once/day, 23°C (73°F)) "Reference: Approx. 4 years harged 5 times/year  2 mm (16.77 in ± 0.08 in) W x 177 mm ± 2 mm (6.97 in ± 0.08 in) H x  1 (19.88 in ± 0.08 in) D (excluding protrusions)  1.0 kg (733.7 oz ± 35.3 oz) (with ANALOG UNIT 8966 installed)  1.0 kg (733.7 oz ± 35.3 oz) (with ANALOG UNIT 8966 installed)  1.0 units (CD-R), blank panel (blank slot only), rack installation hardware  free and humidity range: 23°C ± 5°C (73°F ± 9°F), 80 % RH or less  5, or a product with similar specifications  8  3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
nent will be disabled for modules other than those shown above.  Dilution Degree 2, altitude up to 2000 m (6562.20 ft)  C (32°F to 104°F), less than 80% RH (no condensation)  0°C (14°F to 122°F), 80% RH or less (no condensation)  61010  1326 Class A  1 minute (sensed current: 10 mA) between main unit and power suppl ly voltage: 100 V to 240 V AC (consider ± 10% voltage fluctuations for rated ge)  er supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  10dar, leap-year correcting 24-hour clock  10 years (at 23°C (73°F)) for clock and settings  10 years (discharged once/day, 23°C (73°F)) *Reference: Approx. 4 years rarged 5 times/year  12 mm (16.77 in ±0.08 in) W x 177 mm ±2 mm (6.97 in ±0.08 in) H x  11 (19.88 in ±0.08 in) D (excluding protrusions)  13.5 kg (493.8 oz ±17.6 oz) (main unit only)  14.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)  15. Quick Start Manual (booklet), Instruction Manual (detailed edition) (CD-lon disk (CD-R), blank panel (blank slot only), rack installation hardware  15. or a product with similar specifications  16. B  18. B  19. Cash of the start of the similar specifications  19. Cash of the
C (32°F to 104°F), less than 80 % RH (no condensation)  O°C (14°F to 122°F), 80 % RH or less (no condensation)  0°C (14°F to 122°F), 80 % RH or less (no condensation)  61010  61010  61326 Class A  1 minute (sensed current: 10 mA) between main unit and power suppl ly voltage: 100 V to 240 V AC (consider ±10 % voltage fluctuations for rated ge)  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V
C (32°F to 104°F), less than 80% RH (no condensation)  0°C (14°F to 122°F), 80% RH or less (no condensation)  61010  61010  1326 Class A  1 minute (sensed current: 10 mA) between main unit and power supply obtained by voltage: 100 V to 240 V AC (consider ± 10% voltage fluctuations for rated ge)  9° supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V obtained by ears (discharged once/day, 23°C (73°F)) "Reference: Approx. 4 years (at 23°C (73°F)) for clock and settings  9° years (discharged once/day, 23°C (73°F))" Reference: Approx. 4 years (16.77 in ± 0.08 in) W x 177 mm ± 2 mm (6.97 in ± 0.08 in) H x (19.88 in ± 0.08 in) D (excluding protrusions)  1.0 kg (473.7 oz ± 35.3 oz) (with ANALOG UNIT 8966 installed)  1.0 kg (733.7 oz ± 35.3 oz) (with ANALOG UNIT 8966 installed)  1.0 cuick Start Manual (booklet), instruction Manual (detailed edition) (CD-ion disk (CD-R), blank panel (blank slot only), rack installation hardware and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less  5. or a product with similar specifications  8  10  13 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
0°C (14°F to 122°F), 80 % RH or less (no condensation) 61010 61010 61326 Class A  1 minute (sensed current: 10 mA) between main unit and power suppl lify voltage: 100 V to 240 V AC (consider ± 10% voltage fluctuations for rated ge) or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V lodar, leap-year correcting 24 -hour clock of logars (at 23°C (73°F)) for clock and settings years (discharged once/day, 23°C (73°F)) "Reference: Approx. 4 years larged 5 times/year 2 mm (16.77 in ± 0.08 in) W x 177 mm ± 2 mm (6.97 in ± 0.08 in) H x in (19.88 in ± 0.08 in) D (excluding protrusions) 0.5 kg (493.8 oz ±17.6 oz) (main unit only) 1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed) 0. Quick Start Manual (booklet), Instruction Manual (detailed edition) (CD-ion disk (CD-R), blank panel (blank slot only), rack installation hardware re and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 5, or a product with similar specifications B 0 3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
61010 11326 Class A  1 minute (sensed current: 10 mA) between main unit and power supplicitly voltage: 100 V to 240 V AC (consider ± 10 % voltage fluctuations for rated ge) or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V (dar, leap-year correcting 24-hour clock by ears (at 23 °C (73 °F)) for clock and settings years (discharged once/day, 23 °C (73 °F)) "Reference: Approx. 4 years (at 23 °C (73 °F)) for book and settings years (discharged once/day, 23 °C (73 °F)) "Reference: Approx. 4 years (arged 5 times/year arged 5 times/year arged 5 times/year arged 5 times/year by 10 × 177 mm ± 2 mm (6.97 in ± 0.08 in) H x by 10 × 177 mm ± 2 mm (6.97 in ± 0.08 in) H x by 10 × 177 mm ± 2 mm (6.97 in ± 0.08 in) H x by 11 × 177 mm ± 2 mm (6.97 in ± 0.08 in) H x by 12 mm (16.77 in ± 0.08 in) W x 177 mm ± 2 mm (6.97 in ± 0.08 in) H x by 13 × 17 m ± 0.08 in) M x 177 mm ± 2 mm (6.97 in ± 0.08 in) H x by 14 × 17 m ± 0.08 in) M x 177 mm ± 2 mm (6.97 in ± 0.08 in) H x by 15 × 17 m ± 0.08 in) M x 177 mm ± 2 mm (6.97 in ± 0.08 in) H x by 16 × 17 m ± 0.08 in) M x 177 mm ± 2 mm (6.97 in ± 0.08 in) H x by 17 m ± 0.08 in) M x 177 mm ± 2 mm (6.97 in ± 0.08 in) H x by 18 in ± 0.08 in) M x 177 mm ± 2 mm (6.97 in ± 0.08 in) H x by 18 in ± 0.08 in) M x 177 mm ± 2 mm (6.97 in ± 0.08 in) H x by 19 × 10 × 10 × 10 × 10 × 10 × 10 × 10 ×
1 minute (sensed current: 10 mA) between main unit and power supply voltage: 100 V to 240 V AC (consider ± 10 % voltage fluctuations for rated ge) er supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V dar, leap-year correcting 24-hour clock  1 years (at 23°C (73°F)) for clock and settings  1 years (discharged once/day, 23°C (73°F)) "Reference: Approx. 4 years ararged 5 times/year  2 mm (16.77 in ± 0.08 in) W x 177 mm ± 2 mm (6.97 in ± 0.08 in) H x  1 (19.88 in ± 0.08 in) D (excluding protrusions)  1.0 kg (733.7 oz ± 35.3 oz) (with ANALOG UNIT 8966 installed)  2. Quick Start Manual (booklet), Instruction Manual (detailed edition) (CD-ion disk (CD-R), blank panel (blank slot only), rack installation hardware  re and humidity range: 23°C ± 5°C (73°F ± 9°F), 80 % RH or less  5, or a product with similar specifications  8  0  3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
1 minute (sensed current: 10 mA) between main unit and power supply voltage: 100 V to 240 V AC (consider ± 10 % voltage fluctuations for rated ge) er supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V (dar, leap-year correcting 24 -hour clock of years (at 23 °C (73 °F)) for clock and settings years (discharged once/day, 23 °C (73 °F)) "Reference: Approx. 4 years (arged 5 times/year 2 mm (16.77 in ± 0.08 in) W x 177 mm ± 2 mm (6.97 in ± 0.08 in) H x in (19.88 in ± 0.08 in) D (excluding protrusions) 0.5 kg (493.8 oz ±17.6 oz) (main unit only) 1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed) (OLO-ion disk (CD-R), blank panel (blank slot only), rack installation hardware and humidity range: 23 °C ± 5 °C (73 °F ± 9 °F), 80 % RH or less the result of the similar specifications at the similar specification at the similar specification at the similar specification at the similar specification at the
ly voltage: 100 V to 240 V AC (consider ±10 % voltage fluctuations for rated ge)  er supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 V  idar, leap-year correcting 24 -hour clock  by years (at 23 °C (73 °F)) for clock and settings  years (discharged once/day, 23 °C (73 °F)) "Reference: Approx. 4 years  larged 5 times/year  2 mm (16.77 in ±0.08 in) W x 177 mm ±2 mm (6.97 in ±0.08 in) H x  in (19.88 in ±0.08 in) D (excluding protrusions)  1.5 kg (493.8 oz ±17.6 oz) (main unit only)  1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)  1.0 uck Start Manual (booklet), Instruction Manual (detailed edition) (CD-  ion disk (CD-R), blank panel (blank slot only), rack installation hardware  re and humidity range: 23 °C ±5 °C (73 °F ±9 °F), 80 % RH or less  5, or a product with similar specifications  B  0  3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
ge)  r supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 \ Indianal leap-year correcting 24-hour clock  lyears (at 23 °C (73 °F)) for clock and settings  years (discharged once/day, 23 °C (73 °F)) "Reference: Approx. 4 years  larged 5 times/year  2 mm (16.77 in ±0.08 in) W x 177 mm ±2 mm (6.97 in ±0.08 in) H x  Indianal leap-year (19.88 in ±0.08 in) D (excluding protrusions)  1.5 kg (493.8 oz ±17.6 oz) (main unit only)  1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)  1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)  1.0 kg (703.7 oz ±35.3 oz) (with analytic leap in the stalled)  2.0 kick Start Manual (booklet), Instruction Manual (detailed edition) (CD-  1.0 in disk (CD-R), blank panel (blank slot only), rack installation hardware  1.0 re and humidity range: 23 °C ±5 °C (73 °F ±9 °F), 80 % RH or less  5. or a product with similar specifications  8.  1.0 stall leap in the similar specifications
or supply frequency: 50 Hz/60 Hz, Expected transient overvoltage: 2500 \ \text{value} at the context of the con
ndar, leap-year correcting 24-hour clock Dyears (at 23°C (73°F)) for clock and settings years (discharged once/day, 23°C (73°F)) *Reference: Approx. 4 years narged 5 times/year 2 mm (16.77 in ±0.08 in) W x 177 mm ±2 mm (6.97 in ±0.08 in) H x n (19.88 in ±0.08 in) D (excluding protrusions) 0.5 kg (493.8 oz ±17.6 oz) (main unit only) 1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)  Quick Start Manual (booklet), Instruction Manual (detailed edition) (CD- ion disk (CD-R), blank panel (blank slot only), rack installation hardware re and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less 5, or a product with similar specifications B 0 13 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
Upears (at 23 °C (73 °F)) for clock and settings years (discharged once/day, 23 °C (73 °F)) *Reference: Approx. 4 years anged 5 times/year 2 mm (16.77 in ±0.08 in) W x 177 mm ±2 mm (6.97 in ±0.08 in) H x in (19.88 in ±0.08 in) D (excluding protrusions) 5.5 kg (493.8 oz ±17.6 oz) (main unit only) 1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)  Quick Start Manual (booklet), Instruction Manual (detailed edition) (CD- ion disk (CD-R), blank panel (blank slot only), rack installation hardware re and humidity range: 23 °C ±5 °C (73 °F ±9 °F), 80 % RH or less 5, or a product with similar specifications B 0 3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
Upears (at 23 °C (73 °F)) for clock and settings years (discharged once/day, 23 °C (73 °F)) *Reference: Approx. 4 years anged 5 times/year 2 mm (16.77 in ±0.08 in) W x 177 mm ±2 mm (6.97 in ±0.08 in) H x in (19.88 in ±0.08 in) D (excluding protrusions) 5.5 kg (493.8 oz ±17.6 oz) (main unit only) 1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)  Quick Start Manual (booklet), Instruction Manual (detailed edition) (CD- ion disk (CD-R), blank panel (blank slot only), rack installation hardware re and humidity range: 23 °C ±5 °C (73 °F ±9 °F), 80 % RH or less 5, or a product with similar specifications B 0 3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
arged 5 times/year  2 mm (16.77 in ±0.08 in) W x 177 mm ±2 mm (6.97 in ±0.08 in) H x n (19.88 in ±0.08 in) D (excluding protrusions)  0.5 kg (493.8 oz ±17.6 oz) (main unit only)  1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)  Quick Start Manual (booklet), Instruction Manual (detailed edition) (CD-ion disk (CD-R), blank panel (blank slot only), rack installation hardware and humidity range: 23°C ±5°C (73°F±9°F), 80% RH or less  5, or a product with similar specifications  B  0  35 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
2 mm (16.77 in ±0.08 in) W x 177 mm ±2 mm (6.97 in ±0.08 in) H x n (19.88 in ±0.08 in) D (excluding protrusions) D 5 kg (493.8 oz ±17.6 oz) (main unit only) 1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)  Quick Start Manual (booklet), Instruction Manual (detailed edition) (CD-lon disk (CD-R), blank panel (blank slot only), rack installation hardware and humidity range: 23 °C ±5 °C (73 °F ±9 °F), 80 % RH or less 5, or a product with similar specifications B 0 38 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
in (19.88 in ±0.08 in) D (excluding protrusions)  0.5 kg (493.8 oz ±17.6 oz) (main unit only)  1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)  Quick Start Manual (booklet), Instruction Manual (detailed edition) (CD-ion disk (CD-R), blank panel (blank slot only), rack installation hardware and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less  5, or a product with similar specifications  8  0  38 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
1.0 kg (733.7 oz ±35.3 oz) (with ANALOG UNIT 8966 installed)  Quick Start Manual (booklet), Instruction Manual (detailed edition) (CD- ion disk (CD-R), blank panel (blank slot only), rack installation hardware  re and humidity range: 23 °C ±5 °C (73 °F ±9 °F), 80 % RH or less  5, or a product with similar specifications  B  0  38 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
, Quick Start Manual (booklet), Instruction Manual (detailed edition) (CD-ion disk (CD-R), blank panel (blank slot only), rack installation hardware re and humidity range: 23°C±5°C (73°F±9°F), 80% RH or less 5, or a product with similar specifications B 0 as B 3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
ion disk (CD-R), blank panel (blank slot only), rack installation hardware re and humidity range: 23°C ±5°C (73°F ±9°F), 80 % RH or less  5, or a product with similar specifications  B  0  3B  3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
re and humidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less  5, or a product with similar specifications  B  0  BB  3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
5, or a product with similar specifications B 0 8B 3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
5, or a product with similar specifications B 0 8B 3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
5, or a product with similar specifications  B  0  BB  3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
5, or a product with similar specifications  B  0  BB  3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
B 0 IB 3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
0 BB 3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
3 Ethernet 1000 BASE-T, 100 BASE-TX, 10 BASE-T
O STRUITE
C CTR LITTE
S, FTP, HTTP
ompliant x 4, USB 2.0 compliant x 4
mouse, USB memory stick
ceptacle
Resolution: 2560 x 1600 dots (Max.)
Resolution: 3840 x 2160 dots (Max.)
rt Resolution: 4096 x 2304 dots (Max.) nded resolution: 1920 x 1080 dots or better
on type
+10 V DC
ge 2.5 V to 10 V for high level, 0 V to 0.8 V for low level
50 ms or more during high periods, 50 ms or more during low
val 200 ms or greater
2
START, STOP, START/STOP, SAVE, ABORT, event
e Open drain output (active low, with 5 V voltage output)
tage 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level
50 V DC, 50 MA, 200 MW
2
Judgment (PASS), judgment (FAIL), occurrence of errors,
busy, trigger standby
input +10 V DC
innut
99er ON/OFF
input +10 V DC  gger ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods Trigger filter ON : 2.5 ms or more during high periods
input +10 V DC  gger ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods Trigger filter ON : 2.5 ms or more during low periods 2.5 ms or more during low periods Rising/falling selection possible
input +10 V DC  gger ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods Trigger filter ON : 2.5 ms or more during low periods 2.5 ms or more during low periods Rising/falling selection possible Rising: Triggering occurs when the voltage rises from low
input +10 V D C  gger  ON / OFF  External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods Trigger filter ON : 2.5 ms or more during high period 2.5 ms or more during low periods Rising/falling selection possible
n g g ta

	Output type	Open drain output (active low, with 5 V voltage output)
	Output voltage	4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level
Trigger output	Maximum input voltage	50 V DC, 50 mA, 200 mW
	Output pulse	Level or pulse selection possible
	width	Level: Sampling period x data number after trigger Pulse: 2 ms ±1 ms
	Maximum input	+10 V DC
	voltage	
	Input voltage	2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ns or more during high periods, 50 ns or more during low
External sampling	Response pulse width	periods
	Maximum input	10 MHz
	frequency Functions	External sampling clock input, rising/falling selection possible
Trigger	T directions	External sampling clock input, namphaling selection possible
Trigger type	Digital comparis	son type
Trigger conditions		dition for trigger sources and interval trigger
	Analog, logic Max. 108 chann	ele
Trigger source	Up to 4 analog t	riggers can be set for each analog channel.
mgger source		ggers can be set for each logic probe. ction is activated if all trigger sources are turned off.
	External trigger	calon is activated if all trigger sources are turned on.
	Level trigger	Triggering occurs when the set level rises (falls).
	Voltage drop	Triggering occurs when peak voltage drops below the set level (For a 50 Hz / 60 Hz commercial power supply only).
	trigger	*Not available with MR 8990, U 8991, or 8970
	Window trigger	Triggering occurs when leaving (OUT) or entering (IN) the
		trigger level upper limit and lower limit setting areas.  Sets the period reference value and cycle range.
	David III	Triggering occurs when the rising (falling) reference value
Analog triggers	Period trigger	period is measured and determined to be outside or within the cycle range.
Analog triggers		* Not available with MR 8990, U 8991, or 8970
		Sets the reference value and pulse width (glitch width).
	Glitch trigger	Triggering occurs if the value is below the set pulse width from rising or falling of the reference value.
		* Not available with MR 8990 or U 8991
	0	Specifying events (1 to 4000)  Counts the number of times conditions were fulfilled for each
	Specifying events	trigger source. Triggering occurs when the set number of
		times is reached.  * Not available when the trigger conditions are set to AND
Logic trigger	Pattern trigger u	
Forcible trigger		le triggering can be prioritized over all trigger sources.)
Interval trigger		ible at specified measuring intervals (hours, minutes, or seconds) ditions are fulfilled when the measuring process starts.
	Afterwards, the	trigger conditions are met at the set measuring intervals.
Trigger filter	OFF, 10, 20, 50	, 100, 150, 200, 250, 500, 1000, 2000, 5000, 10,000 samples
Level setting resolution	1 LSB (12/16-bi	t unit)
	0.0/ +- 400.0/ /	
Pre-triager		y value set in 1% steps available),
Pre-trigger Trigger timing	displaying the re	y value set in 1% steps available), ecording time for pre-trigger
Pre-trigger Trigger timing	displaying the re	scording time for pre-trigger
	displaying the re	cording time for pre-trigger  th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values
	displaying the re START Incompatible wi If trigger condition	cording time for pre-trigger  th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds.
Trigger timing	displaying the re START Incompatible wi If trigger condition	th trigger function (Only analog trigger function can be enabled.)  ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values
Trigger timing	displaying the re START Incompatible wi If trigger condition	cording time for pre-trigger  th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds.
Trigger timing	displaying the re START Incompatible wi If trigger condition If trigger condition	th trigger function (Only analog trigger function can be enabled.)  ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops.  r function, warning function)
Trigger timing	displaying the re START Incompatible wi If trigger condition If trigger condition	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops. r function, warning function) mples are taken, and the average value is set as the criteria for
Trigger timing  Warning function  Auto trigger level	displaying the re START Incompatible wi if trigger condition.  If trigger condition.  ON/OFF (trigger Several data san the window out I Number of samp	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops. r function, warning function) nples are taken, and the average value is set as the criteria for
Trigger timing  Warning function	displaying the re START Incompatible wi If trigger condition If trigger condition ON/OFF (trigger Several data sar the window out it Number of samp	th trigger function (Only analog trigger function can be enabled.)  ons are met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds.  ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops.  'function, warning function)  nples are taken, and the average value is set as the criteria for rigger.
Trigger timing  Warning function  Auto trigger level  Waveform screen	displaying the re START Incompatible wi If trigger condition If trigger condition ON/OFF (trigger Several data san the window out Number of samp	th trigger function (Only analog trigger function can be enabled.)  ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds.  ons are no longer met : Channel numbers and measured values are displayed, and the alarm stops.  Indiction, warning function)  mples are taken, and the average value is set as the criteria for trigger.  less: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens
Trigger timing  Warning function  Auto trigger level	displaying the re START Incompatible wi If trigger condition If trigger condition ON/OFF (trigger Several data san the window out in Number of samp Waveform display in chronological	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops.  If function, warning function) mples are taken, and the average value is set as the criteria for rigger, oles: Select from 100, 200, 300, 400, and 500
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format	displaying the re START Incompatible wi If trigger condition If trigger condition ON/OFF (trigger Several data san the window out Number of samp	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed/saved, an event mark is displayed/saved, an event mark is displayed, and the alarm stops.  If function, warning function) mples are taken, and the average value is set as the criteria for rigger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet.
Trigger timing  Warning function  Auto trigger level  Waveform screen	displaying the re START Incompatible wi If trigger condition on the state of the state of the ON/OFF (trigger Several data sare the window out to Number of samp Waveform display in chronological order Max. 16 sheets "The display form	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed/saved, an event mark is displayed/saved, an event mark is displayed, and the alarm stops.  If function, warning function) mples are taken, and the average value is set as the criteria for rigger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function	displaying the re START Incompatible wi If trigger condition If trigger condition ON/OFF (trigger Several data sai the window out Number of samp Waveform display in chronological order Max. 16 sheets "The display form ON/OFF	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed/saved, an event mark is displayed, and the alarm stops. rfunction, warning function) mples are taken, and the average value is set as the criteria for rigger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel.  at can be selected for each sheet.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format	displaying the re START Incompatible wi If trigger condition If trigger condition ON/OFF (trigger Several data sar the window out U Number of samp Waveform Max. 16 sheets "The display form ON/OFF Waveforms are screen, whereas	th trigger function (Only analog trigger function can be enabled.)  ons are met : Channel numbers and measured values are displayed,saved, an event mark is displayed, and an alarm sounds.  ons are no longer met : Channel numbers and measured values are displayed, and an alarm sounds.  ons are no longer met : Channel numbers and measured values are displayed, saved, an event mark is displayed, and the alarm stops.  Incotion, warning function)  mples are taken, and the average value is set as the criteria for trigger.  Jes: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens  Displays up to 64 channels per sheet.  Multiple sheets can be set for the same channel.  Lat can be selected for each sheet.  displayed in chronological order in the top part of the waveform is the zoomed waveforms are displayed in the bottom part.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function	displaying the re START Incompatible wi If trigger condition of trigger condition of trigger condition of trigger condition of trigger condition of trigger condition of trigger condition was a condition of trigger condition of trigger condi	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops. or function, warning function) mples are taken, and the average value is set as the criteria for rigger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens * Displays up to 64 channels per sheet. * Multiple sheets can be set for the same channel.  sat can be selected for each sheet.  displayed in chronological order in the top part of the waveform
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display	displaying the re START Incompatible wi If trigger condition If trigger condition ON/OFF (trigger Several data sar the window out U Number of samp Waveform Max. 16 sheets "The display form ON/OFF Waveforms are screen, whereas	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed,saved, an event mark is displayed, and the alarm stops.  Inction, warning function) mples are taken, and the average value is set as the criteria for rigger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  at can be selected for each sheet. displayed in chronological order in the top part of the waveform is the zoomed waveforms are displayed in the bottom part.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display	displaying the re START Incompatible will If trigger condition. If trigger condition. ON/OFF (trigger Several data sar the window out Number of samp Waveform display in chronological order Max. 16 sheets "The display form ON /OFF Waveforms are a screen, whereas Displays wavefor Waveform	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops. r function, warning function) mples are taken, and the average value is set as the criteria for rigger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet. Multiple sheets can be set for the same channel. lat can be selected for each sheet. displayed in chronological order in the top part of the waveforms is the zoomed waveforms are displayed in the bottom part.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display	displaying the re START Incompatible wi If trigger condition of trigger condition of trigger condition of trigger condition of trigger condition of trigger condition of trigger condition waveform of trigger condition of	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops. on sare no longer met : Channel numbers and measured values are displayed, and the alarm stops. on function, warning function) on plea are taken, and the average value is set as the criteria for rigger, oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens 2 bisplays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  at can be selected for each sheet. displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part. In screen (32 colors)
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display	displaying the re START Incompatible wi If trigger condition of trigger condition of trigger condition of trigger condition of trigger condition of trigger condition of trigger condition waveform of samp waveform are of trigger condition of	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and the alarm stops.  If function, warning function) mples are taken, and the average value is set as the criteria for rigger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. It is comed waveforms are displayed in the bottom part. It is colors (32 colors) Linear Always ON
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display	displaying the re START Incompatible wi If trigger condition If trigger condition ON/OFF (trigger Several data san the window out Incompany of the Max. 16 sheets "The display form ON/OFF Waveforms are used to screen, whereas Displays wavefor Waveform color Interpolation Variable display	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed, saved, an event mark is displayed, and the alarm stops.  Induction, warning function) mples are taken, and the average value is set as the criteria for origger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  Induction the selected for each sheet.  displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part. In sover the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display	displaying the re START  Incompatible wi If trigger condition  ON/OFF (trigger condition  ON/OFF (trigger condition  ON/OFF (trigger condition  ON/OFF (trigger condition  Number of samp  Waveform  display in  chronological  order  Max. 16 sheets  "The display form  ON / OFF  Waveforms are  screen, whereas  Displays waveform  color  Uniterpolation  Variable  display  Vernier  Grid	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and the alarm stops.  If function, warning function) mples are taken, and the average value is set as the criteria for trigger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  Lat can be selected for each sheet. displayed in chronological order in the top part of the waveform is the zoomed waveforms are displayed in the bottom part. Imms over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display	displaying the re START Incompatible wi If trigger condition If trigger condition ON/OFF (trigger Several data san the window out Incompany of the Max. 16 sheets "The display form ON/OFF Waveforms are used to screen, whereas Displays wavefor Waveform color Interpolation Variable display	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed, saved, an event mark is displayed, and the alarm stops.  Induction, warning function) mples are taken, and the average value is set as the criteria for origger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  Induction the selected for each sheet.  displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part. In sover the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display	displaying the re START Incompatible wi If trigger conditie ON/OFF (trigger Several data sar the window out Number of samp Waveform display in chronological order Max. 16 sheets "The display form ON/OFF Waveforms are screen, whereas Displays wavefor Waveform color Interpolation Variable display Vernier Grid Logic display width Waveform	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops.  Induction, warning function) mples are taken, and the average value is set as the criteria for trigger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens bisplays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  Induction the selected for each sheet.  displayed in chronological order in the top part of the waveform are displayed in the bottom part. In sover the entire waveforms are displayed in the bottom part. In sover the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF/ON  Wide, Standard, Narrow  Displays waveforms upside down.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display  Waveform display	displaying the re START Incompatible wi If trigger conditive If trigger	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and the alarm stops. ons are no longer met : Channel numbers and measured values are displayed, and the alarm stops. ons are taken, and the average value is set as the criteria for rigger, oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens bisplays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  at can be selected for each sheet. displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part. orms over the entire waveform screen. Fixed colors (32 colors) Linear  Always ON  Adjustable input waveform (Adjustment range: 50 % to 200 % of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down. * Not available with 8967, 8970, or 8973
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display  Waveform display	displaying the re START Incompatible will frigger condition of the second of the secon	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops.  Induction, warning function) mples are taken, and the average value is set as the criteria for trigger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens bisplays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  Induction the selected for each sheet.  displayed in chronological order in the top part of the waveform are displayed in the bottom part. In sover the entire waveforms are displayed in the bottom part. In sover the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF/ON  Wide, Standard, Narrow  Displays waveforms upside down.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling	displaying the reSTART Incompatible will frigger condition of the region	th trigger function (Only analog trigger function can be enabled.)  ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops.  ons are no longer met : Channel numbers and measured values are displayed, and the alarm stops.  of function, warning function)  mples are taken, and the average value is set as the criteria for rigger.  oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens  * Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part.  smrs over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform  (Adjustment range: 50% to 200% of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  be adjusted as necessary.  tb ywith mouse clicks and scroll back while measuring.  the latest data by following the measuring process.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display  Waveform display	displaying the re START Incompatible wi If trigger conditive Several data san Waveform display in chronological order Max. 16 sheets 'The display form ON / OFF Waveforms are screen, whereas Displays wavefor Waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can I Scroll left or righ Always displays The drawing sta	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops. of function, warning function) mples are taken, and the average value is set as the criteria for trigger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens oles: Select from 100, 200 and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens oles: Select from 100, 200 and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens oles: Select from 100, 200 and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens oles: Select from 100, 200 and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens oles: Select from 100, 200 and 500  I screen, 2 screens, 4 screens, 8 screens, 16 screens oles: Select from 100, 200 and 500  I screen, 2 screens, 4 screens, 8 screens, 16 screens  oles: Select from 100, 200, 300, 400, and 500  I screen, 2 screens, 4 screens, 8 screens, 16 screens  oles: Select from 100, 200, 300, 400, and 500  I screen, 2 screens, 4 screens, 8 screens, 16 screens  oles: Select from 100, 200, 300, 400, and 500  I screen, 2 screens, 4 screens, 8 screens, 16 screens  oles: Select from 100, 200, 300, 400, and 500  I screen, 2 screens, 4 screens, 8 screens, 16 screens  oles: Select from 100, 200, 300, 400, and 500  I screen, 2 screens, 4 screens, 8 screens, 16 screens  oles: Select from 100, 200, 300, 400, and 500  oles: Select from 100, 200, 300, 400, and 500  oles: Select from 100, 200, 300, 400, and 500  oles: Select from 100, 200, 300, 400, and 500  oles: Select from 100, 200, 300, 400, and 500  oles
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling	displaying the re START Incompatible wi If trigger conditive Several data san Waveform display in chronological order Max. 16 sheets 'The display form ON / OFF Waveforms are screen, whereas Displays wavefor Waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can I Scroll left or righ Always displays The drawing sta	th trigger function (Only analog trigger function can be enabled.)  ons are met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops.  ons are no longer met : Channel numbers and measured values are displayed, and the alarm stops.  of function, warning function)  mples are taken, and the average value is set as the criteria for rigger.  oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens  * Displays up to 64 channels per sheet.  * Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveform the zoomed waveforms are displayed in the bottom part.  smrs over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform  (Adjustment range: 50% to 200% of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down.  * Not available with 8967, 8970, or 8973  be adjusted as necessary.  tb ywith mouse clicks and scroll back while measuring.  the latest data by following the measuring process.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display	displaying the re START Incompatible wi If trigger conditive Several data san Waveform display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are screen, whereas Displays wavefor Waveform color Interpolation Variable display Vernier Interpolation Variable Color Interpolation Variable Interpolation Variabl	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and the alarm stops. ons are no longer met : Channel numbers and measured values are displayed, and the alarm stops. ons are taken, and the average value is set as the criteria for rigger, oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens bisplays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. One of the entire waveform screen.  Fixed colors (32 colors) Linear  Always ON  Adjustable input waveform (Adjustment range: 50 % to 200 % of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down. Not available with 8967, 8970, or 8973 oe adjusted as necessary. by with mouse clicks and scroll back while measuring. the latest data by following the measuring process. rt position (left or right edge) can be selected.  be displayed when the overlay function is turned on.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display  Level monitor	displaying the re START Incompatible wi If trigger conditive ON/OFF (trigger Several data san the window out Number of samp Waveform display in chronological order Max. 16 sheets "The display form ON / OFF Waveforms are screen, whereas Displays wavefor Waveform color Interpolation Variable display Vernier Grid Logic display width Waveform inversion Zoom ratio can I Scroll left or righ Always displays The drawing sat The roll cannot b Numerical display	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed/saved, an event mark is displayed, and the alarm stops.  If function, warning function) mples are taken, and the average value is set as the criteria for trigger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. Tims over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustable input waveform (Adjustment range: 50% to 200% of the input)  OFF / ON  Wide, Standard, Narrrow  Displays waveforms upside down. Not available with 8967, 8970, or 8973  De adjusted as necessary.  It by with mouse clicks and scroll back while measuring. The latest data by following the measuring process. It position (fet or right edge) can be selected. De displayed when the overlay function is turned on.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display  Level monitor	displaying the re START Incompatible wi If trigger conditive If the waveform Interpolation Interpolation Variable Interpolation Variable Interpolation Variable Interpolation Variable Interpolation Interpolation Interpolation Variable Interpolation Interpolat	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and the alarm stops. ons are no longer met : Channel numbers and measured values are displayed, and the alarm stops. ons are taken, and the average value is set as the criteria for rigger, oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens bisplays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. One of the entire waveform screen.  Fixed colors (32 colors) Linear  Always ON  Adjustable input waveform (Adjustment range: 50 % to 200 % of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down. Not available with 8967, 8970, or 8973 oe adjusted as necessary. by with mouse clicks and scroll back while measuring. the latest data by following the measuring process. rt position (left or right edge) can be selected.  be displayed when the overlay function is turned on.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display  Level monitor	displaying the re START  Incompatible will frigger condition of the second of the seco	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed, and the alarm stops. on are taken, and the average value is set as the criteria for origger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. orms over the entire waveform screen. Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustable input waveform (Adjustment range: 50 % to 200 % of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down. Not available with 8967, 8970, or 8973 one adjusted as necessary. It by with mouse clicks and scroll back while measuring. Ithe latest data by following the measuring process. It position (left or right edge) can be selected. One displayed when the overlay function is turned on.  Up to 8 cursors can be displayed. Displays potential, time from trigger, time difference between cursors, and potential difference.  Up to 8 cursors can be displayed.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display  Level monitor function	displaying the re START Incompatible wi If trigger conditive If trigger	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed, saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed, and the alarm stops. of function, warning function) mples are taken, and the average value is set as the criteria for rigger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveforms at the zoomed waveforms are displayed in the bottom part.  rms over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustable input waveform (Adjustable input waveform (Adjustable with 8967, 8970, or 8973  De adjusted as necessary. The waveforms upside down. Not available with 8967, 8970, or 8973  De adjusted as necessary. The with mouse clicks and scroll back while measuring. The latest data by following the measuring process. The position (left or right edge) can be selected. De displayed when the overlay function is turned on.  Up to 8 cursors can be displayed. Displays potential, time from trigger, time difference between cursors, and potential difference. Up to 8 cursors can be displayed. Displays potential and potential difference.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display  Level monitor function	displaying the re START  Incompatible will frigger condition of the second of the seco	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed, and the alarm stops. on are taken, and the average value is set as the criteria for origger. oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  at can be selected for each sheet. displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. orms over the entire waveform screen. Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustable input waveform (Adjustment range: 50 % to 200 % of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down. Not available with 8967, 8970, or 8973 one adjusted as necessary. It by with mouse clicks and scroll back while measuring. Ithe latest data by following the measuring process. It position (left or right edge) can be selected. One displayed when the overlay function is turned on.  Up to 8 cursors can be displayed. Displays potential, time from trigger, time difference between cursors, and potential difference.  Up to 8 cursors can be displayed.
Trigger timing  Warning function  Auto trigger level  Waveform screen  Display format  Sheet function  Zoom display  Full screen display  Waveform display  Enlarge / Reduce Waveform scrolling  Roll display  Level monitor function	displaying the re START Incompatible wi If trigger conditive Several data san Inchronological Order Inchronological Orde	th trigger function (Only analog trigger function can be enabled.) ons are met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and an alarm sounds. ons are no longer met : Channel numbers and measured values are displayed,/saved, an event mark is displayed, and the alarm stops. ons are no longer met : Channel numbers and measured values are displayed, and the alarm stops. on are taken, and the average value is set as the criteria for rigger, oles: Select from 100, 200, 300, 400, and 500  1 screen, 2 screens, 4 screens, 8 screens, 16 screens Displays up to 64 channels per sheet. Multiple sheets can be set for the same channel.  at can be selected for each sheet.  displayed in chronological order in the top part of the waveforms the zoomed waveforms are displayed in the bottom part. orms over the entire waveform screen.  Fixed colors (32 colors)  Linear  Always ON  Adjustable input waveform (Adjustment range: 50 % to 200 % of the input)  OFF / ON  Wide, Standard, Narrow  Displays waveforms upside down. Not available with 8967, 8970, or 8973 oe adjusted as necessary. tby with mouse clicks and scroll back while measuring. the latest data by following the measuring process. or position (left or right edge) can be selected. Oe displayed when the overlay function is turned on.  Up to 8 cursors can be displayed. "Displays potential, time from trigger, time difference between cursors, and potential difference. Up to 8 gauges can be displayed. "Displays potential and potential difference. Up to 8 gauges can be displayed.

	Real-time	20 M, 10 M, 5 M, 2 M, 1 M, 500 k, 200 k, 100 k, 50 k, 20 k, 10 k, 5 k, 2 k, 1 k, 500, 200, 100, 50, 20, 10, 5, 2, 1 [S/s]
	sampling	External sampling: Max. 10 MHz depending on external sampling
		terminal input signal Maximum configurable sampling speed
		[Using internal SSD as save destination] 5 MS/s (up to 12 channels), 2 MS/s (13 to 32 channels), 1 MS/s (33 to
Sampling speed	With real-time	64 channels), 500 kS/s (65 or more channels) [Using USB Drive Z4006 as save destination]
	saving enabled *: Values in	1 MS/s (up to 12 channels), 500 kS/s (13 to 24 channels), 200 kS/S (25 to 64 channels), 100 kS/s (65 or more channels)
	parentheses indicate	[Using FTP transmission as save destination]
	number of channels	200 kS/s (up to 12 channels), 100 kS/s (13 to 24 channels), 50 kS/s (25 to 64 channels), 20 kS/s (65 or more channels)
		*USB memory stick performance is guaranteed only when connected via USB 3.0 connector.
		*Double all channel counts if the U 8991 is installed.  [Fixed recording lengths]
		When using 27 modules: 2 M (with U8991), 5 M (with U8975, MR 8990), 10 M (54 channels) [points]
		When using 16 modules: 5 M (with U8991), 10 M (with U8975,
		MR 8990), 20 M (32 channels) [points] When using 8 modules: 10 M (with U8991), 20 M (with U8975,
		MR 8990), 50 M (16 channels) [points] When using 4 modules: 20 M (with U8991), 50 M (with U8975,
	Real-time	MR 8990), 100 M (8 channels) [points] [User-specified recording lengths]
Maximum recording length	sampling	When using 27 modules: 4194300 (with U8991), 8388600 (with U8975, MR 8990), 16777200 (54 channels) [points]
		When using 16 modules: 8388600 (with U8991), 16777200 (with U8975, MR8990), 33554400 (32 channels) [points]
		When using 8 modules: 16777200 (with U8991), 33554400 (with
		U8975, MR8990), 67108800 (16 channels) [points] When using 4 modules: 33554400 (with U8991), 67108800 (with
		U8975, MR8990), 134217600 (8 channels) [points] *User-configurable in units of 100 points.
	With real-time saving enabled	Determined by space available on save destination, file system, and number of measurement channels
Repeat	Single measurem	nent, repeat measurement, user-specified count
measurement	is enabled.	user-specified count settings are not available when real-time saving
Scaling	* Model: Select a	o and offset, 2-point input, Model, Output rate, dB, Rating amodel to configure the scaling settings automatically.
<u> </u>	* Automatic detec	ction and automatic scaling are available when a current unit is used. , channel comments
Comments	Channel numbe	ers and channel comments are added on the setting screen and
Help	waveform scree Displays the inst	-
Saving	000	1000 (1000)
	USB MEMORY	Internal SSD (480 GB)  74006 (16 GR)
Save destination	STICK Sending to FTP	Z4006 (16 GB)  PC with a LAN connection
	Sending by	Send file to specified email address
File format	email FAT, FAT32, NT	
Filename	-	and Japanese input
Processing identical filenames	the file when trans	number at the beginning before saving (Date and time added after sferred by FTP)
	ON / OFF  * Automatically sa	aves the data obtained for the recording length at the end of a
Auto saving	measuring proc	cess.
	* If a memory divi	e not supported. ision is set, it is possible for measurement of the next block to start
		s with the oldest creation dates and saves data when there is no
Deleting and saving	Deletes the files free space left o	with the oldest creation dates and saves data when there is no on the specified media at the save destination.
Deleting and saving	Deletes the files free space left o * Enabled for auto Settings data	with the oldest creation dates and saves data when there is no on the specified media at the save destination.
Deleting and saving	Deletes the files free space left o * Enabled for auto Settings data Measurement data	with the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving .SET Binary format (.MEM), text format (.CSV)
	Deletes the files free space left o * Enabled for auto Settings data Measurement data Index	with the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving .SET Binary format (.MEM), text format (.CSV) Divided saving (.IDX)
Deleting and saving  Types of saved data	Deletes the files free space left o *Enabled for auto Settings data Measurement data Index Displayed images	with the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving .SET Binary format (.MEM), text format (.CSV)
	Deletes the files free space left o * Enabled for auto Settings data Measurement data Index Displayed	s with the oldest creation dates and saves data when there is no on the specified media at the save destination.  o saving  SET  Binary format (.MEM), text format (.CSV)  Divided saving (.IDX)  .BMP, .PNG, .JPG  .CSV
Types of saved data	Deletes the files free space left o * Enabled for auto Settings data Measurement data Index Displayed images Numerical calculation results Startup	with the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving
	Deletes the files free space left or the space left of the space l	with the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving .SET Binary format (.MEM), text format (.CSV) Divided saving (.IDX) .BMP, .PNG, .JPG .CSV .STARTUP.SET
Types of saved data	Deletes the files free space left or the space left of the space l	s with the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving SET  Binary format (MEM), text format (CSV)  Divided saving (IDX)  BMP, .PNG, .JPG  CSV  STARTUP.SET  If from all the channels available or from the displayed channels easurement data.  lata (text format) is culled according to the specified culling value
Types of saved data  Saving channels	Deletes the files free space left or aut Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement differs 2 to 1000) to Types of saved	s with the oldest creation dates and saves data when there is no on the specified media at the save destination.  o saving .SET  Binary format (.MEM), text format (.CSV)  Divided saving (.IDX) .BMP, .PNG, .JPG  .CSV  STARTUP.SET el from all the channels available or from the displayed channels easurement data. lata (text format) is culled according to the specified culling value before saving.
Types of saved data  Saving channels	Deletes the files free space left or aut Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement d (from 2 to 1000) te	with the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving
Types of saved data  Saving channels	Deletes the files free space left or aut Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement differs 2 to 1000) to Types of saved	s with the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving .SET Binary format (.MEM), text format (.CSV) Divided saving (.IDX) .BMP, .PNG, .JPG .CSV .STARTUP.SET el from all the channels available or from the displayed channels seasurement data. tata (text format is culled according to the specified culling value before saving. d data .Division method .OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data .OFF, Every 60,000 points of data,
Types of saved data  Saving channels  Culled data saving	Deletes the files free space left or aut Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement diffrom 2 to 1000) t Types of savec Binary format	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving .SET Binary format (.MEM), text format (.CSV) Divided saving (.IDX) .BMP, .PNG, .JPG .CSV .STARTUP.SET If from all the channels available or from the displayed channels easurement data. lata (text format) is culled according to the specified culling value before saving. d data Division method OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 60,000 points of data, Every 1,000,000 points of data,
Types of saved data  Saving channels  Culled data saving	Deletes the files free space left to  *Enabled for auts Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement d (from 2 to 1000) t Types of savec Binary format  Numerical calculation Text format  Numerical calculations  Numerical calcula	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving
Types of saved data  Saving channels  Culled data saving  File division	Deletes the files free space left to  **Enabled for auts* Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement differed 2 to 1000) till Types of saved Binary format  Text format  Numerical calculation results  New files or exis	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving
Types of saved data  Saving channels  Culled data saving	Deletes the files free space left to  *Enabled for aut  Settings data  Measurement  data  Index  Displayed  images  Numerical  calculation results  Startup  Select a channe  when saving me  Measurement  dfrom 2 to 1000) to  Types of savec  Binary format   Text format   Numerical calculation   Text format   Numerical calculation   *Example of the saving me  Select whether  Select	s with the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving .SET  Binary format (.MEM), text format (.CSV)  Divided saving (.IDX) .BMP, .PNG, .JPG  .CSV  STARTUP.SET el from all the channels available or from the displayed channels seasurement data. lata (text format) is culled according to the specified culling value before saving. d data  Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data Every 1,000,000 points of data  Culation  OFF, By the calculation number
Types of saved data  Saving channels  Culled data saving  File division	Deletes the files free space left to  *Enabled for auts Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement d(from 2 to 1000) t Types of savec Binary format  Text format  Numerical calculation results  *Enabled when results  *Enabled when results  *Select whether t measure.	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving SET  Binary format (MEM), text format (CSV)  Divided saving (IDX)  BMP, .PNG, .JPG  CSV  STARTUP.SET  If from all the channels available or from the displayed channels easurement data.  lata (text format) is culled according to the specified culling value before saving.  d data
Types of saved data  Saving channels  Culled data saving  File division  Specifying files	Deletes the files free space left to  Enabled for aut  Settings data  Measurement  data  Index  Displayed  images  Numerical  calculation results  Startup  Select a channe  when saving me  Measurement di  (from 2 to 1000) t  Types of savec  Binary format   Text format   Numerical calcresults  New files or exis  Select whether t  measure.  Instant saving	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving .SET  Binary format (.MEM), text format (.CSV)  Divided saving (.IDX) .BMP, .PNG, .JPG  .CSV  STARTUP.SET .el from all the channels available or from the displayed channels sasurement data. lata (text format) is culled according to the specified culling value before saving. d data Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 60,000 points of data, Every 1,000,000 points of data OFF, By the calculation number  sting files numerical calculation results are saved. to create a new file or add data to an existing file when starting to
Types of saved data  Saving channels  Culled data saving  File division  Specifying files  SAVE operation	Deletes the files free space left to  *Enabled for auts Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement d(from 2 to 1000) t Types of savec Binary format  Text format  Numerical calculation results  *Enabled when results  *Enabled when results  *Select whether t measure.	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving
Types of saved data  Saving channels  Culled data saving  File division  Specifying files  SAVE operation	Deletes the files free space left to  Enabled for aut  Settings data  Measurement  data  Index  Displayed  images  Numerical  calculation results  Startup  Select a channe  when saving me  Measurement di  (from 2 to 1000) t  Types of savec  Binary format   Text format   Numerical calcresults  New files or exis  Select whether t  measure.  Instant saving	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving .SET  Binary format (.MEM), text format (.CSV)  Divided saving (.IDX) .BMP, .PNG, .JPG  .CSV  STARTUP.SET  el from all the channels available or from the displayed channels sasurement data. lata (text format) is culled according to the specified culling value before saving. d data Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data OFF, Every 60,000 points of data, Every 1,000,000 points of data OFF, By the calculation number  sting files numerical calculation results are saved. to create a new file or add data to an existing file when starting to  Use the SAVE operation to save data to a save destination, under a filename, and with saving settings that have been pre-set. Select the full range or a specific segment.
Types of saved data  Saving channels  Culled data saving  File division  Specifying files  SAVE operation	Deletes the files free space left to "Enabled for aut Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement difford 2 to 1000) to Types of savec Binary format Text format Numerical calcresults New files or exis "Senabled when results" New files or exis "Senabled when results Instant saving Saving range SSD USB MEMORY	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving
Types of saved data  Saving channels  Culled data saving  File division  Specifying files  SAVE operation  Loading data	Deletes the files free space left to  **Enabled for auts* Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement d (from 2 to 1000) it Types of saved Binary format Text format  Numerical calculation results New files or exis **Enabled when r **Select whether t measure.  Instant saving Saving range  SSD USB MEMORY STICK Settings data	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving
Types of saved data  Saving channels  Culled data saving  File division  Specifying files  SAVE operation  Loading data  Loading source  Types of loaded	Deletes the files free space left to "Enabled for aut Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement difform 2 to 1000) to Types of savec Binary format Text format Numerical calcresults New files or exis "Enabled when results "Startup Select whether timessure. Instant saving Saving range SSD USB MEMORY STICK Settings data Measurement data Measurement data free substantial saving SSD USB MEMORY STICK Settings data Measurement	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving
Types of saved data  Saving channels  Culled data saving  File division  Specifying files  SAVE operation  Loading data  Loading source	Deletes the files free space left to "Enabled for aut Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement d (from 2 to 1000) to 1000 for	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving  SET  Binary format (MEM), text format (CSV)  Divided saving (IDX)   BMP, .PNG, .JPG   CSV  STARTUP.SET  el from all the channels available or from the displayed channels easurement data.  talta (text format) is culled according to the specified culling value before saving.  d data Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number  sting files  numerical calculation results are saved.  to create a new file or add data to an existing file when starting to  Use the SAVE operation to save data to a save destination, under a filename, and with saving settings that have been pre-set.  Select the full range or a specific segment.  *Enabled only when data is saved with the SAVE operation.  Internal SSD (480 GB)  Z4006 (16 GB)  .SET  Binary format (MEM), text format (CSV)  Divided saving (IDX)
Types of saved data  Saving channels  Culled data saving  File division  Specifying files  SAVE operation  Loading data  Loading source  Types of loaded data	Deletes the files free space left to  Enabled for aut  Settings data  Measurement  data  Measurement  data  Measurement  data  Displayed  images  Numerical  calculation results  Startup  Select a channe  when saving me  Measurement d.  (from 2 to 1000) t  Types of savec  Binary format   Text format  Numerical calcresults  New files or exis  * Enabled when r  * Select whether t  measure.  Instant saving  Saving range   SSD  USB MEMORY  STICK  Settings data  Measurement  data  Startup	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving  SET  Binary format (MEM), text format (CSV)  Divided saving (IDX)   BMP, .PNG, .JPG  .CSV  STARTUP.SET  el from all the channels available or from the displayed channels beasurement data.  atta (text format) is culled according to the specified culling value before saving.  d data Division method  OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data  OFF, Every 60,000 points of data, Every 1,000,000 points of data  OFF, By the calculation number  string files  numerical calculation results are saved.  to create a new file or add data to an existing file when starting to  Use the SAVE operation to save data to a save destination, under a filename, and with saving settings that have been pre-set.  Select the full range or a specific segment.  * Enabled only when data is saved with the SAVE operation.  Internal SSD (480 GB)  Z4006 (16 GB)  .SET  Binary format (.MEM), text format (.CSV)
Types of saved data  Saving channels  Culled data saving  File division  Specifying files  SAVE operation  Loading data  Loading source  Types of loaded data  Numerical calcula  Maximum number of	Deletes the files free space left o *Enabled for aut Settings data Measurement data Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement d (from 2 to 1000) the Types of saved Binary format Text format Numerical calculation results Select a channe when saving me Measurement d (from 2 to 1000) the Types of saved Binary format Numerical calculations of the Select whether the measure. Instant saving Saving range SSD USB MEMORY STICK Settings data Measurement data Index Startup titons	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving .SET Binary format (.MEM), text format (.CSV) Divided saving (.IDX) .BMP, .PNG, .JPG .CSV .STARTUP.SET .Set from all the channels available or from the displayed channels assurement data. tata (text format) is culled according to the specified culling value before saving.  d data Division method .OFF, Every 16 MB of data, Every 32 MB of data, Every 64 MB of data .OFF, Every 16 MB of data, Every 32 MB of data, Every 1,000,000 points of data .OFF, Every 40,000 points of data .OFF, By the calculation number .Sting files .numerical calculation results are saved. to create a new file or add data to an existing file when starting to .Use the SAVE operation to save data to a save destination, under a filename, and with saving settings that have been pre-setSelect the full range or a specific segmentEnabled only when data is saved with the SAVE operationInternal SSD (480 GB) .SET .Binary format (.MEM), text format (.CSV) .Divided saving (.IDX) .STARTUP.SET
Types of saved data  Saving channels  Culled data saving  File division  Specifying files  SAVE operation  Loading data  Loading source  Types of loaded data  Numerical calcula	Deletes the files free space left to  **Enabled for auts* Settings data* Measurement data* Index Displayed images Numerical calculation results Startup Select a channe when saving me Measurement d (from 2 to 1000) t  Types of savec Binary format  Text format  Numerical calculation results New files or exis **Enabled when r **Select whether t measure.  Instant saving  Saving range  SSD USB MEMORY STICK Settings data Measurement data Index Startup  tions  108 items x Mea	swith the oldest creation dates and saves data when there is no on the specified media at the save destination. o saving separation of the specified media at the save destination. o saving SET  Binary format (.MEM), text format (.CSV)  Divided saving (.IDX)  BMP, .PNG, JPG  CSV  STARTUP.SET  If from all the channels available or from the displayed channels seasurement data.  talat (text format) is culled according to the specified culling value before saving.  d. data

	1	
Calculation items	average value, F frequency (*), pe value, time differ minimum value, arithmetic opera XY waveform an	ue, maximum value, minimum value, high level, low level, MMS value, standard deviation, rise time (*), fall time (*), eriod (*), pulse duty ratio (*), pulse count, area value, X-Y area ence (*), phase difference (*), time to maximum value, time to specified level time, specified time level, pulse width (*), four titions, median value, amplitude, integration value burst width (*), gle, overshoot, undershoot, + Width (*), - Width (*) statistical function
	Targeted	Analog channels, logic channels, waveform processing
	waveforms Judgment	channels
Numerical judgment	settings Stop	ON/OFF
	conditions	PASS, FAIL, PASS&FAIL
Waveform proces	sing	
Maximum number of calculations	16 formulas	
Calculation range	Full range or Sp	ecified segments
Maximum recording	2,000,000 poir	nts
length Standard operator	+,-,×,÷	
		square root, logarithm, exponentiation, SIN, ASIN, COS, ACOS, erentiation, secondary differentiation, integration, secondary
Calculation items		ing average, slide, PLCS
Memory segment		
Max. divisions	1024 blocks	
Block search		data that is saved in divided memory block.  measured waveform data into the desired block area and
Past waveform comparison		creen to the current waveform.
Bulk save	Saves a huge ra	nge of data in all blocks
Display	Specify a block	to display.
Waveform search	l	Laval via day, in via day, a. A
	Trigger	Level, window-in, window-out  If a logic channel is chosen as the target channel, searches can
	Peak	be made using logic triggers.  Maximum, minimum, local maximum, local minimum
Search methods		Histogram or standard deviation
	Concierge	*Choose to compare to corresponding fundamental waves or immediately prior waveforms.
	Jump	Event mark, cursor, time (specified as absolute time, relative time,
	Full range	or number of points), trigger point, search mark  All data stored in internal memory
Search range	Specified	·
0	interval	Choose a range specified by A/B or C/D.
Search count	Up to 10,000 poi	cified number of search targets remain in the search range after
Continuous search		rch, you can continue to search waveform data after the last search
Display method		n location to display the data.
Other		
	Available	anling rate and magaziroment range for the input waveform are
Auto range	automatically se	
Beep sound		th external sampling , Alarm and operation
Beep sound	Sending e-mails	
0 11 11 -	Sending	Automatic saving, saving with the SAVE operation
Sending e-mails	timing	Attach data specified in the main text or files specified by a
	Sent data	type of saved data.
Initialization Self-check		nitialization, setting initialization, complete initialization  LAN check, media check
Language	Japanese, Engli	
Error and warning		ails of errors and warnings when they occur.
display		
Time value display Zero position		mal time, date, data values
display	ON/OFF	
Waveform screen background color	Black or white	
baonground color	Permitted or Not	
Restart permission	* Permitted: If sett restarted.	tings are changed during the measuring process, the unit is
		settings cannot be changed during the measuring process.
Time settings	Set the date and	I time.
Number of current sensor connections	Up to 9 with cor	mbinations of Current Unit 8971, 3ch Current Unit 8977
	8971 Current Unit	Max. 4
Module limitations	U8977 3 ch	Max. 3
Woddie III III ations	Current Unit 8973 Logic	Max. 3
	Unit	Supported locations (slots 25 to 27)
	Green Green	POWER ON .
POWER LED display	(flashing)	Aging in progress (for 30 minutes after the power is turned on)
diopidy	Orange Not on	STANDBY (the power switch on the rear is on)  Main power supply is off (the power switch on the rear is off)
	INOLOIT	Syntax error in command received
CMD ERR LED display	Red	* Goes off with a CLS command. Or when a warning occurs
uispiay	Not on	No error or warning
	Red	Ambient temperature is too high (> 35°C / 95°F)
	Purple	Ambient temperature is too low (< 10 °C / 50 °F)  CPU load factor 80 % or more
DIACLED "	Yellow	* The average load factor is updated every 0.5 seconds.
DIAG LED display	Blue Green	The instrument is in the trigger standby state.  Recording in progress
	Pink	Recording finished. New command received, switches to
		normal display.
	White	Normal operation in progress (stopped)

## **Option Specifications (sold separately)**

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



ANALOG UNIT 89	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2, for voltage measurement
Input terminals	Isolated BNC connector (input impedance $1\mathrm{M}\Omega$ , input capacitance $30\mathrm{pF}$ ) Max. rated voltage to ground: $300\mathrm{V}$ AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/50 k/500 kHz
Measurement resolution	1/2000 of measurement range (using 12-bit A/D conversion)
Maximum sampling rate	20 MS/s (simultaneous sampling in 2 channels)
Measurement accuracy	±0.5% f.s. (with filter 5 Hz, zero position accuracy included)
Frequency characteristics	DC to 5 MHz -3 dB (with AC coupling: 7 Hz to 5 MHz -3 dB)
Input coupling	AC/DC/GND
Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without damage)

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



4ch ANALOG UNI	T U8975 (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 4, for voltage measurement
Input terminals	Isolated BNC connector (input impedance 1 $M\Omega$ , input capacitance 30 pF) Max. ratled voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)
Measurement range	4, 10, 20, 40, 100, 200 V f.s., 6 ranges AC voltage for possible measurement/display: 140 V rms Low-pass filter: 5/500/5 k/200 kHz
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)
Maximum sampling rate	5 MS/s (simultaneous sampling in 4 channels)
Measurement accuracy	±0.1% f.s. (with filter 5 Hz, zero position accuracy included)
Frequency characteristics	DC to 2 MHz -3 dB
Input coupling	DC/GND
Maximum input voltage	200 V DC (the maximum voltage that can be applied across input pins without damage)

Dimensions/mass: approx. 106~mm (4.17 in) W  $\times$  19.8~mm (0.78 in) H  $\times$  196.5~mm (7.74 in) D, approx. 250~g (8.8 oz) Accessories: None



4CH ANALOG UN	IT U8978 (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 4, for voltage measurement
Input terminals	Isolated BNC connector (input impedance 1 M $\Omega$ , input capacitance 30 pF), Max. rated voltage to ground: 30 V AC or 60 V DC for direct input, 300 V AC, DC (CAT II) when combined with the 9665 (Between each input channel and the main unit, and between the input channels)
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40 V f.s., 9 ranges Low-pass filter: 5/500/5 k/200 kHz
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)
Maximum sampling rate	5 MS/s (simultaneous sampling in 4 channels)
Measurement accuracy	±0.3% f.s. (with filter 5 Hz, zero position accuracy included)
Frequency characteristics	DC to 2 MHz -3 dB
Input coupling	DC/GND
Maximum input voltage	40 V DC (with direct input), 400 V DC (with 9665)

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 260 g (9.2 oz) Accessories: None



DIGITAL VOLTM MR8990	ETER UNIT (Accuracy at 23 ±5°C/73 ±6°F, 80% RH after 30 minutes of warm- up time and calibration, Accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2, for DC voltage measurement
	Banana input connectors (Input impedance: 100 M $\Omega$ or higher with 100 mV f.s. to 10 V f.s. range, otherwise 10 M $\Omega$ )
Input terminals	$Max.\ rated\ voltage\ to\ ground:\ 300\ V\ AC,\ DC\ (with\ input\ isolated\ from\ the\ unit,\ the\ maximum\ voltage\ that\ can\ be\ applied\ between\ input\ channel\ and\ chassis\ and\ between\ input\ channels\ without$
	damage)
Measurement range	100, 1000 mV f.s.
Weasurement range	10, 100, 1000 V f.s., 5 ranges
Measurement resolution	1/1,000,000 of measurement range (using 24-bit ΔΣ modulation A/D)
Integration time	20 ms × NPLC (during 50 Hz), 16.67 ms × NPLC (during 60 Hz)
Response time	2 ms +2 x integration time or less (rise - f.s. $\rightarrow$ + f.s., fall + f.s. $\rightarrow$ - f.s.)
Basic measurement accuracy	±0.01% rdg, ±0.0025% f.s. (at range of 1000 mV f.s.)
Maximum input voltage	500 V DC (the maximum voltage that can be applied across input pins without damage)

Dimensions/mass: approx. 106~mm (4.17 in) W imes 19.8 mm (0.78 in) H imes 196.5 mm (7.74 in) D, approx. 250~g (8.8 oz) Accessories: None



DIGITAL VOLTME	TER UNIT U8991 (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80 % RH after 30 minutes of warm-up time; Accuracy guaranteed for 1 year)	
Measurement functions	No. of channels: 4, for DC voltage measurement	
	Isolated BNC connectors (Input impedance: 100 M $\Omega$ or higher with 1 V f.s. to 10 V f.s. range, otherwise 10 M $\Omega$ )	
Input terminals	Max, rated voltage to ground: 100 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)	
Measurement range	1, 10, 100 V f.s., 3 ranges	
Measurement resolution	1/1,000,000 of measurement range (using 24-bit ΔΣ modulation A/D)	
Integration time	20 ms × NPLC (during 50 Hz), 16.67 ms × NPLC (during 60 Hz)	
Basic measurement accuracy	±0.02% rdg. ±0.0025% f.s.	
Maximum input voltage	100 V DC (the maximum voltage that can be applied across input pins without damage)	

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



DC/RMS UNIT 897	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)	
Measurement functions	No. of channels: 2, for voltage measurement, DC/RMS selectable	
Input terminals	Isolated BNC connector (input impedance 1 $M\Omega$ , input capacitance 30 pF) Max, ratled voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)	
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/100 kHz	
Measurement resolution	1/2000 of measurement range (using 12-bit A/D conversion)	
Maximum sampling rate	1 MS/s (simultaneous sampling in 2 channels)	
Measurement accuracy	±0.5% f.s. (with filter 5 Hz, zero position accuracy included)	
RMS measurement	$RMS\ accuracy; \pm 1\%\ f.s.\ (DC, 30\ Hz\ to\ 1\ kHz) \pm 3\%\ f.s.\ (1\ kHz\ to\ 100\ kHz)$ Response time: SLOW 5 s (rise time from 0 to 90% of full scale), MID 800 ms (rise time from 0 to 90% of full scale), MID 800 ms (rise time from 0 to 90% of full scale) Crest factor: 2	
Frequency characteristics	DC to 400 kHz -3 dB (with AC coupling: 7 Hz to 400 kHz -3 dB)	
Input coupling	AC/DC/GND	
Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without damage)	

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



HIGH RESOLUTI 8968	ON UNIT (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)	
Measurement functions	No. of channels: 2, for voltage measurement	
Input terminals	Isolated BNC connector (input impedance 1 $M\Omega$ , input capacitance 30 pF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)	
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/50 KHz	
Anti-aliasing filter	Integrated filter for suppressing aliasing distortion caused by FFT processing (automatic cutoff frequency setting/OFF)	
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)	
Maximum sampling rate	1 MS/s (simultaneous sampling in 2 channels)	
Measurement accuracy	±0.3% f.s. (with filter 5 Hz, zero position accuracy included)	
Frequency characteristics	DC to 100 kHz -3 dB (with AC coupling: 7 Hz to 100 kHz -3 dB)	
Input coupling	AC/DC/GND	
Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without damage)	

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



3CH CURRENT UN U8977	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 3, Current measurement with optional current sensor		
Input terminals	Dedicated connector terminal (ME15W) (input impedance 1 MΩ, common GND with recorder)		
Compatible current sensors	9272-05, CT6841-05, CT6843-05, CT6844-05, CT6845-05, CT6846-05, CT6862-05, CT6863-05, 9709-05, CT6904, CT6865-05, CT6875, CT6876 (Direct connection) CT7631, CT7636, CT7642, CT7731, CT7736, CT7742, CT7044, CT7045, CT7046 (Connection using optional CONVERSION CABLE CT9920)		
Measurement range	- Directly connected current sensor: Automatically identify rating of compatible current sensors Using 9272-05 (20 A), CT6841-05: 2 A to 100 A f.s., 6 ranges Using 272-05 (200 A), CT6843-05; CT6863-05: 20 A to 1000 A f.s., 6 ranges Using 9272-05 (200 A), CT6843-05; CT6863-05: 20 A to 1000 A f.s., 6 ranges Using 272-05 (200 A), CT6843-05; CT6865-05; CT6904, CT6875: 40 A to 2000 A f.s., 6 ranges Using CT6846-05; CT6865-05; CT6876: 80 A to 4000 A f.s., 6 ranges Using CT6846-05, CT6865-05; CT6876: 80 A to 4000 A f.s., 6 ranges - Current sensors connected using CT9920: Select conversion rate or model Using CT7631, CT7731: 200 A, 1 range Using CT7643, CT7746: 200 A to 1000 A, 3 ranges Using CT7642, CT7742: 2000 A t/4000 A, 2 ranges Using CT7644, CT7045, CT7046: 2000 A to 10,000 A, 3 ranges		
Measurement accuracy (with 5 Hz filter ON) Note: Add the accuracy and attributes of the current sensor being used.	±0.3% f.s. Frequency characteristics: DC to 2 MHz ±3 dB		
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)		
Maximum sampling rate	5 MS/s (simultaneous sampling in 3 channels)		
Other functions	Input coupling: DC/GND, Low-pass filter: 5/500/5 k/200 kHz		
	·		

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: CONVERSION CABLE 9318  $\times$  2 (To connect the current sensor to the 8971)



	,		
CURRENT UNIT 8	971 (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, Current measurement with optional current sensor		
Input terminals	Sensor connector (input impedance 1 M $\Omega$ , exclusive connector for current sensor via the CONVERSION CABLE 9318, common GND with recorder)		
Compatible current sensors	CT6862, CT6863, 9709, CT6865, CT6841, CT6843, CT6844, CT6845, CT6846, 9272-10 (To connect to the 8971 via the CONVERSION CABLE 9318)		
Measurement range	Using 9272-10 (20 A), CT6841: 2 A to 100 A f.s., 6 ranges Using CT6862: 4 A to 200 A f.s., 6 ranges Using 9272-10 (200 A), CT6843, CT6863: 20 A to 1000 A f.s., 6 ranges Using CT6844, CT6845, 9709, CT6846*1, CT6865*1: 40 A to 2000 A f.s., 6 ranges *1: The conversion ratio needs to be set to 2 for scaling.		
Measurement accuracy (with 5 Hz filter ON) * Note: Add the accuracy and attributes of the current sensor being used.	±0.65% f.s.  RMS accuracy: ±1% f.s. (DC, 30 Hz to 1 kHz), ±3% f.s. (1 kHz to 10 kHz)  RMS response time: 100 ms (rise time from 0 to 90% of full scale)  Crest factor: 2  Frequency characteristics: DC to 100 kHz ±3 dB (with AC coupling: 7 Hz to 100 kHz)		
Measurement resolution	1/2000 of measurement range (using 12-bit A/D conversion)		
Maximum sampling rate	1 MS/s (simultaneous sampling in 2 channels)		
Other functions	Input coupling: AC/DC/GND, Low-pass filter: 5/50/500/5 k/50 kHz		

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 230 g (8.1 oz) Accessories: None



HIGH-VOLTAGE L	JNIT U8974	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)	
Measurement functions	No. of channels: 2, for voltage measurement, DC/RMS selectable Max. rated voltage to ground: 1000 V AC, DC for measurement category III, 600 V AC, DC for measurement category IV		
Input terminals	Banana input terminal (Input impedance: 4 MΩ, Input capacitance: 5 pF)		
Measurement range	4, 10, 20, 40, 100, 200, 400, 1000 V f.s. (DC mode), 8 ranges 10, 20, 40, 100, 200, 400, 1000 V f.s. (RMS mode), 7 ranges Low-pass filter: 5/50/500/5 k/50 kHz		
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)		
Maximum sampling rate	1 MS/s		
Measurement accuracy	±0.25% f.s. (with filter 5 Hz, zero position accuracy included)		
RMS measurement	RMS accuracy: ±1.5% f.s. (DC, 30 Hz to 1 kHz), ±3% f.s. (1 kHz to 100 kHz) Response time: High speed 150 ms, medium speed 500 ms, low speed 2.5 s		
Frequency characteristics	DC to 100 kHz-3 dB		
Input coupling	DC/GND		
Maximum input voltage	1000 V DC, 700 V AC		

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 245 g (8.6 oz) Accessories: CONVERSION CABLE L9769  $\times$ 2 (Cable length: 60 cm)



Added to the second of the sec		
STRAIN UNIT U89	(Accuracy at 23 ±5°C/73 ±9°F, 80% RH or less after 30 minutes of warm-up time and auto-balance; Accuracy guaranteed for 1 year)	
Measurement functions	No. of channels: 2, for distortion measurement (electronic auto-balancing, balance adjustment range within ±10,000 με or less)	
Input terminals	NDIS connector EPRC07-R9FNDIS (via CONVERSION CABLE L9769; NDIS connector PRC03-12A10-7M10.5)  Max. rated voltage to ground: 30 V AC rms or 60 V DC (with input isolated from the main unit, the maximum voltage that can be applied between input channel and chassis; and between input channels without damage)	
Suitable transducer	Strain gauge converter, Bridge impedance: 120 $\Omega$ to 1 k $\Omega$ , Bridge voltage: 2 V $\pm 0.05$ V, Gauge rate: 2.0	
Measurement range	400, 1000, 2000, 4000, 10,000, 20,000 με f.s., 6 ranges Low-pass filter: 5/10/100/1 kHz	
Measurement resolution	1/25,000 of measurement range (using 16-bit A/D conversion)	
Maximum sampling rate	200 kS/s (simultaneous sampling in 2 channels)	
Measurement accuracy After auto-balancing	$\pm 0.5\%$ f.s. $\pm 4$ $\mu\epsilon$ (5 Hz filter ON)	
Frequency characteristics	DC to 20 kHz +1/-3 dB	

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  204.5 mm (8.05 in) D, approx. 240 g (8.5 oz) Accessories: Ferrite clamp  $\times$  2



TEMP UNIT 8967	(Accuracy at 23 $\pm$ 5°C/73 $\pm$ 9°F, 20 to 80% RH after 30 minutes of warmup time and zero adjustment, Accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for temperature measurement with thermocouple (voltage measurement not available)		
Input terminals	Thermocouple input: Push-button terminal block, Recommended wire diameter: single-wire 0.14 to 1.5 mm², braided wire 0.14 to 1.0 mm² (conductor wire diameter 90.18 mm or more), AWG 26 to 16 Input impedance: min. 5 MΩ (with line fault detection ON/OFF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)		
Temperature measurement range Note: Upper and lower limit values depend on the thermocouple	200°C (392°F) f.s. (-100°C to 200°C (-148°F to 392°F)), 1000°C (1832°F) f.s. (-200°C to 1000°C (-328°F to 1832°F)), 2000°C (3632°F) f.s. (-200°C to 2000°C (-328°F to 3632°F)), 3 ranges Measurement resolution: 1/20,000 of measurement range (using 16-bit A/D conversion)		
Thermocouple range (JIS C 1602-1995) (ASTM E-988-96)	K: -200°C to 1350°C (-328°F to 2462°F), R: 0°C to 1700°C (32°F to 3092°F), F: -200°C to 1100°C (-328°F to 2012°F), S: 0°C to 1700°C (32°F to 3092°F), E: -200°C to 800°C (-328°F to 1472°F), B: 400°C to 1800°C (752°F to 3272°F), W (WRe5-26): 0°C to 2000°C (32°F to 3632°F) N: -200°C to 1300°C (-328°F to 2372°F), The second of		
	Reference junction compensation: internal/external (switchable), line fault detection ON/OFF possible		
Data refresh rate	3 methods, Fast: 1.2 ms (digital filter OFF), Normal: 100 ms (digital filter 50/60 Hz), Slow: 500 ms (digital filter 10 Hz)		
Measurement accuracy	Thermocouple K, J, E, T, N: $\pm 0.1\%$ f.s. $\pm 1^{\circ}$ C ( $\pm 1.8^{\circ}$ F), ( $\pm 0.1\%$ f.s. $\pm 2^{\circ}$ C ( $\pm 3.6^{\circ}$ F) at $-200^{\circ}$ C to $0^{\circ}$ C ( $\pm 3.2^{\circ}$ F) to $3.2^{\circ}$ F) of $\pm 0.2^{\circ}$ F). Thermocouple R, S, B, W: $\pm 0.1\%$ f.s. $\pm 3.5^{\circ}$ C ( $\pm 6.3^{\circ}$ F) (at $0^{\circ}$ C ( $\pm 3.2^{\circ}$ F) to less than $400^{\circ}$ C ( $\pm 3.2^{\circ}$ F) (at $400^{\circ}$ C ( $\pm 3.2^{\circ}$ F) or more). Reference junction compensation [RJC] accuracy: $\pm 1.5^{\circ}$ C ( $\pm 2.7^{\circ}$ F) (added to measurement accuracy with internal reference junction compensation).		

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 250 g (8.8 oz) Accessories: None



FREQ UNIT 8970	(Accuracy at 23 $\pm$ 5°C/73 $\pm$ 9°F, 20 to 80 % RH after 30 minutes of warm-up time; Accuracy guaranteed for 1 year)	
Measurement functions	No. of channels: 2, for voltage input based frequency measurement, rotation, power frequency, integration, pulse duty ratio, pulse width	
Input terminals	Isolated BNC connector (input impedance 1 $M\Omega$ , input capacitance 30 pF), Max. rated voltage to ground: 300 V.AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)	
Frequency mode	Measurement range: Between DC to 100 kHz (minimum pulse width 2 μs), 20 Hz to 100 kHz fs., 8 ranges Accuracy: ±0.1% fs. (exclude 100 kHz range), ±0.7% f.s. (100 kHz range)	
Rotation mode	Measurement range: Between 0 to 2 million rotations/minute (minimum pulse width 2µs), 2 kr/min to 2 Mr/min f.s, 7 ranges Accuracy: ±0.1% f.s. (exclude 2 Mr/min range), ±0.7% f.s. (2 Mr/min range)	
Power frequency mode	Measurement range: 50 Hz (40 to 60 Hz), 60 Hz (50 to 70 Hz), 400 Hz (390 to 410 Hz), 3 ranges Accuracy: ±0.03 Hz (50, 60 Hz), ±0.1 Hz (400 Hz range)	
Integration mode	Measurement range: 40 k-counts f.s. to 20 M-counts f.s. 6 ranges Accuracy: ±0.0025% f.s.	
Duty ratio mode	Measurement range: Between 10 Hz to 100 kHz (minimum pulse width 2 µs), 100% f.s. Accuracy: ±1% (10 Hz to 10 kHz), ±4% (10 kHz to 100 kHz)	
Pulse width mode	Measurement range: Between 2 μs to 2 s, 10 ms to 2 s f.s. Accuracy: ±0.1% f.s.	
Measurement resolution	0.0025% f.s. (integration mode), 0.01% f.s. (exclude integration, power frequency mode), 0.01 Hz (power frequency mode)	
Input voltage range and threshold level	$\pm 10V$ to $\pm 400V, 6$ ranges, selectable threshold level at each range	
Other functions	Slope, Level, Hold, Smoothing, Low-pass filter, Switchable DC/AC input coupling, Frequency dividing, Integration over-range keep/return	

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 190 g (6.7 oz) Accessories: None



LOGIC UNIT 8973	
Measurement functions	No. of channels: 16 channels (4 ch/1 probe connector × 4 connectors)
	Mini DIN connector (for HIOKI logic probes only) Compatible logic probes: 9320-01, 9327, MR9321-01

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 230 g (8.1 oz) Accessories: None



CHARGE UNIT U897	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for acceleration measurement		
Input terminals	Voltage input / pre-amp embedded input: Metal BNC connector (Under voltage input: input impedance $1~\rm M\Omega$ , input capacitance $200~\rm pF$ or less)		
	Charge input: Miniature connector (#10-32UNF) Max. rated voltage to ground: 30 V AC or 60 V DC (with input isolated from the main unit, the maximum voltage that can be applied between input channel and chassis, and between input channels without damage)  *Voltage input terminal GND and charge input terminal GND for the same channel are shared.		
Suitable transducer	Charge output type acceleration detector Pre-amp embedded acceleration detector		
Measurement range Charge input (Miriature connector) Pre-amp embedded input (BNC connector)	1 (m/s²) to 200 k (m/s²) f.s., 12 ranges x 6 types Charge input sensitivity: 0.1 to 10 pC /(m/s²) Pre-amp embedded sensor input sensitivity: 0.1 to 10 mV /(m/s²) Amplitude accuracy: ±2% f.s. Frequency characteristics: (1.5) to 50 kHz -3 dB (charge input) Low-pass filter: 500/5 kHz Pre-amp supply power: 3.5 mA ±20%. 22 V ±5% Maximum input charge: ±500 pC (6 ranges on high sensitivity side), 50.000 pC (6 ranges on low sensitivity side)		
Measurement range Voltage input (BNC connector)	10 mV to 40 V f.s., 12 ranges, DC amplitude accuracy: ±0.5% f.s. Frequency characteristics: DC to 50 kHz -3 dB (with DC coupling), 1 Hz to 50 kHz -3 dB (with AC coupling) Low-pass filter: 5/500/5 kHz, input coupling: AC/DC/GND Maximum input voltage: 40 V DC		
Measurement resolution	1/25,000 of measurement range (using 16-bit A/D conversion)		
Maximum sampling rate	200 kS/s		
Anti-aliasing filter	Integrated filter for suppressing aliasing distortion caused by FFT processing (automatic cutoff frequency setting/OFF)		
TEDS	IEEE 1451.1.4 class I support (Support for sensor information reading and automatic sensitivity setting)		

Dimensions/mass: approx. 106~mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 230 g (8.1 oz) Accessories: None



WAVEFORM GEN MR8790	ERATOR UNIT	(Accuracy at 23 ±5°C/73 ±9°F, 80% RH after 30 minutes of warm-up time; Accuracy guaranteed for 1 year)
Output terminal	No. of channels: 4, SMB terminal (Output impedance: 1 $\Omega$ or less) Max. rated voltage to ground: 30 V rms AC or 60 V DC	
Output voltage range	-10 V to 10 V (Amplitude setting range: 0 V to 20 V p-p, Setting resolution: 1 mV)	
Max. output current	5 mA	
Output function	DC, Sine wave (Output frequency range: 0 Hz to 20 kHz)	
Accuracy	Amplitude accuracy: ±0.25% of setting ±2 mV p-p (1 Hz to 10 kHz) Offset accuracy: ±3 mV DC output accuracy: ±0 mV	
Other	Self-test function (Voltage, Current)	

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 230 g (8.1 oz) Accessories: None




PULSE GENERAT	FOR UNIT MR8791	(Accuracy at 23 ±5°C/73 ±9°F, 80% RH or less with no condensation; accuracy guaranteed for 1 year)
Output terminal	No. of channels: 8, Connector: 9 Max. rated voltage to ground: 3 Logic output/Open collector ou	0 V rms AC or 60 V DC (between unit and output channels)
Output mode 1	Pattern output: Read frequency	: 0 Hz to 120 kHz, 2048 logic patterns
	Pulse output: Frequency 0 Hz to	20 kHz, Duty 0.1% to 99.9%
Output mode 2	Logic output: Output voltage le (H level: 3.8 V or more, L level: 0.8	
	Open collector output: Absolute Overcurrent protection: 100 mA	e maximum rated voltage for collector/emitter 50 V
Other	Self-test function	

Dimensions/mass: approx. 106 mm (4.17 in) W  $\times$  19.8 mm (0.78 in) H  $\times$  196.5 mm (7.74 in) D, approx. 280 g (9.9 oz) Accessories: None



VIR GENERATOR	UNIT U8794	(Accuracy at 23 $\pm5^{\circ}\text{C/73}~\pm9^{\circ}\text{F},~80\%$ RH or less with no condensation; accuracy guaranteed for 1 year)
Output terminal	No. of channels: 8 (each channel is isolated), Connector: 25-pin D-sub Max. rated voltage to ground: 25 V	
Output items	DC voltage, DC current, resistance (simulated output)	
	DC voltage: -0.100 0 V to +5.	300 0 V (setting resolution: 0.1 mV)
Output range	1 mA range: -1.000 00 mA to 250 μA range: -250. 00 μA to	-5.000 0 mA, Setting resolution: 0.1 μA +1.000 00 mA, Setting resolution: 0.01 μA +250.00 μA, Setting resolution: 0.01 μA -50.000 μA, Setting resolution: 0.001 μA tting resolution: 6 digits
Output accuracy	DC voltage: 5 V range, ±0.035% of setting ± 800 μV  DC current: 5 mA range: ±0.050% of setting ± 4.0 μA 1 mA range: ±0.050% of setting ± 800 nA 250 μA range: ±0.050% of setting ± 200 nA 50 μA range: ±0.050% of setting ± 40 nA	
Other	Self diagnostic, switch output	terminals, estimate target connection, cancel offset

## **System Chart of Options**



#### Storage media

\*Use only the storage media sold by HIOKI. Compatibility and performance are not guaranteed for storage media made by other manufacturers. You may be read from or save data to such media



USB DRIVE Z4006

16 GB Using highly durable and reliable SLC flash memory

### PC Software (free)



Waveform Viewer Wv

Software for checking waveforms with binary data on a PC, saving data in CSV format, and transferring to spreadsheet programs

Operating environment Windows 10/8/7 (32/64-bit) Functions:

- Simple display of waveform files
   Convert binary data files to text format, CSV, etc.
- Scroll function, enlarge/reduce display, jump to cursor/trigger position, etc.



WAVE PROCESSOR 9335

PC display for massive amounts of waveform data and more

#### Logic signal measurement



LOGIC PROBE 9327
4-channel type, for voltage/contact signal ON/
OFF detection (response pulse width 100 ns or more, miniature terminal type)



LOGIC PROBE MR9321-01 4 isolated channels, ON/OFF detection of AC/ DC voltage (miniature terminal type)



LOGIC PROBE 9320-01 4-channel type, for voltage/contact signal ON/ OFF detection (response pulse width 500 ns or more, miniature terminal type)



CONNECTION CABLE L9795-01

Max. rated voltage to ground: 30 V AC rms or 60 V DC SMB terminal - alligator clip Cable length: 1.5 m (4.92 ft)



CONNECTION CABLE L9795-02

Max. rated voltage to ground 30 V AC rms or 60 V DC SMB terminal - BNC terminal Cable length: 1.5 m (4.92 ft)

Input modules

Input cords not included. Please purchase them separately. When using the 9709 with CURRENT UNIT 8971, up to a total of



ANALOG UNIT 8966 2 ch, voltage input, 20 MS/s, (DC to 5 MHz)



4ch ANALOG UNIT U8975

4 ch, voltage input, 5 MS/s, (DC to 2 MHz)  $\,$ 



4CH ANALOG UNIT U8978

4 ch, voltage input, 5 MS/s, (DC to 2 MHz), highest sensitivity range 100 mV f.s.



HIGH RESOLUTION UNIT 8968 2 ch, voltage input, 1 MS/s (DC to 100 kHz)



DC/RMS UNIT 8972

2 ch, voltage/1 MS/s, (DC to 400 kHz) RMS rectifier (DC, 30 to 100 kHz)



HIGH-VOLTAGE UNIT U8974

2 ch, voltage input, max. 1000 V DC and 700 V AC



DIGITAL VOLTMETER UNIT MR8990

2 ch, high-precision DC voltage, 0.1 μV resolution, maximum sampling rate 500 times/s



DIGITAL VOLTMETER UNIT U8991

4 ch, high-precision DC voltage, 1 µV resolution, maximum sampling rate 50 times/s



**CURRENT UNIT 8971** 

2 ch, for measuring current using dedicated current sensors, 2 CONVERSION CABLES 9318 included, for use with up to 4 units



3CH CURRENT UNIT U8977

3 ch, for measuring current using dedicated current sensors, can be directly connected to ME15W (12-pin) connector-type sensors, for use with up to 3 units



TEMP UNIT 8967 2 ch, thermocouple temperature input

STRAIN UNIT U8969



2 ch, strain gauge type converter amp

CONVERSION CABLE L9769 (for STRAIN UNIT U8969 only, included)



FREQ UNIT 8970

2 ch. for measurement of frequency, RPM, pulse, etc.



CHARGE UNIT U8979

2 ch, for acceleration measurement, supports charge output, pre-amp output, and voltage output



LOGIC UNIT 8973

4 terminals, 16 ch, up to 3 units (slots 25 to 27 only)

Output modules

\* Output cords not included. Please purchase them separately \* Configure settings with communication commands.



WAVEFORM GENERATOR UNIT MR8790 4ch, DC output ±10 V, Sine wave output 1 Hz to 20 kHz





PULSE GENERATOR UNIT MR8791 8ch, Pulse output 0.1 Hz to 20 kHz, Pattern output



VIR GENERATOR UNIT U8794

8ch, DC voltage output, DC current output, resistance output (simulated resistance)

## SCI Monitor 4.0

HSCI-4.0-CAN FD



HSCI-4.0-SENT

HSCI-4.0-LIN

CAN monitors. LIN monitors, and SENT monitors that are the same size as the MR8740 T unit can be purchased from Nihon System Eight Co., Ltd. Power is supplied to a monitor when it is installed on the MR8740 T. Note that it will not be possible to record or analyze the data with the MR 8740 T or HIOKI software. Please contact Nihon System Eight for additional information http://nse-inc.co.jp/

Sor details, see product information on Hioki's website.

**INPUT CORD (A)** 

\* Voltage is limited to the specifications of the

CONNECTION CORD L9790 Flexible φ 4.1 mm (0.16 in) thin cable allowing for up to 600 V ir 1.8 m (5.91 ft) length \* The end clip is sold separately.

ALLIGATOR CLIP L9790-01 Red/black set attaches to the ends of the cables L9790

GRABBER CLIP 9790-02

\* When this clip is attached to the end of the L9790, input is limited to CAT II 300 V. Red/black set.

CONTACT PIN 9790-03

Red/black set attaches to the ends of the cables L9790

INPUT CORD (B)

Voltage is limited to the specifications of the input modules in use.

CONNECTION CORD L9198

 $\phi$  5.0 mm (0.20 in) dia., cable allowing for up to 300 V input, 1.7 m (5.58 ft) length, small alligator clip

CONNECTION CORD L9197

 $\phi$  5.0 mm (0.20 in) dia., cable allowing for up to 600 V input, 1.8 m (5.91 ft) length, detachable large alligator clips are bundled

GRABBER CLIP 9243

Attaches to the tip of the L9197, red/black set, full length: 196 mm (7.72 in)

INPUT CORD (C)

Voltage is limited to the specifications of th



10:1 PROBE 9665

Max. rated voltage to ground is same as for input module, max. input voltage 1 kV rms (up to 500 kHz), 1.5 m (4.92 ft) length

100:1 PROBE 9666

Max. rated voltage to ground is same as for input module, max. input voltage 5 kV peak (up to 1 MHz), 1.5 m (4.92 ft) length

INPUT CORD (D)

Voltage to ground is within this product's specifications. \*Separate power source is also



DIFFERENTIAL PROBE P9000-01 (Wave Only) For Memory HiCorder, 1 kV AC, DC, Frequency band: 100 kHz

DIFFERENTIAL PROBE P9000-02 (Switch between Wave/RMS) For Memory HiCorder, 1 kV AC, DC, Frequency band: 100 kHz

AC ADAPTER Z1008 100 to 240 V AC

INPUT CORD (E)

Voltage to ground is within this product's specifications. \*Separate power source is also



**DIFFERENTIAL PROBE 9322** AC, 2 kV DC, Frequency bands

AC ADAPTER 9418-15

INPUT CORD (F)

CONNECTION CABLE L4940 Banana plug - banana plug, Cord length 1.5 m (4.92 ft)

EXTENSION CABLE L4931 Extend the length of banana plug cables, Cable length: 1.5 m (4.92 ft)

ALLIGATOR CLIP L4935 Attach to the tip of banana plug cables, CAT IV 600 V, CAT III 1000 V

BUS BAR CLIP L4936

Attach to the tip of banana plug cables, CAT III 600 V

MAGNETIC ADAPTER L4937 Attach to the tip of banana plug cables, CAT III 1000 V

GRABBER CLIP 9243

Attach to the tip of banana plug cables, red/black set, full length: 196 mm (7.72 in), CAT III 1000 V

INPUT CORD (G)

\* For the MR8990 \*Voltage is limited to the specifications of the input modules in use.



TEST LEAD L2200 Cable length: 70 cm, tips interchangeable with a pin test lead or alligator clip, maximum input voltage: CAT IV 600 V, CAT III 1000 V

BNC - clip, Cord length: 1.5m (4.92 ft)

High-precision current measurement \*ME15W (12-pin) terminal type \*Directly connect to U8977



High-precision pull-through current sensors, observe waveforms from DC to distorted AC AC/DC CURRENT SENSOR CT6862-05, 1 MHz, 50 A AC/DC CURRENT SENSOR CT6863-05, 500 kHz, 200 A Observe waveforms from DC to distorted AC

AC/DC CURRENT PROBE CT6841-05, 1 MHz, 20 A AC/DC CURRENT PROBE CT6843-05, 500 kHz, 200 A

CI AMP ON SENSOR 9272-05, 100 kHz, 200 A

High-precision pull-through current sensors, observe waveforms from DC to distorted AC AC/DC CURRENT SENSOR CT6875, 2 MHz, 500 A

AC/DC CURRENT SENSOR CT6876, 1.5 MHz, 1000 A
Observe waveforms from DC to distorted AC AC/DC CURRENT PROBE CT6844-05, 200 kHz, 500 A AC/DC CURRENT PROBE CT6845-05, 100 kHz, 500 A

AC/DC CURRENT PROBE CT6846-05, 20 kHz, 1000 A

Precautions when connecting the CURRENT UNIT 8971 with a high-precision current sensor

 High-precision current sensor (ME15W) + CT9901 + 9318 → CURRENT UNIT 8971 High-precision current sensor (ME15W) + CT955x + BNC cable ightarrow exc CURRENT UNIT 8971

CURRENT UNIT 99/1 High-precision current sensor (PL23) + 9318 → CURRENT UNIT 8971 High-precision current sensor (PL23) + CT9900 + CT955x + BNC cable → except CURRENT UNIT 8971

The 9318 is bundled with the CURRENT UNIT 8971.

oine the high-precision current sensor and the power supply 55) to perform current measurements with a voltage input unit. ensors with ME15W (12-pin) terminals (-05 type) can be connec

The separately available CONVERSION CABLE CT9900 is required in orde to use a sensor with a PL23 (10-pin) terminal.

POWER SUPPLY for Sensors SENSOR UNIT CT9555 1 ch, with waveform output CONNECTION CORD L9217

PL23 (10-pin) - ME15W (12-pin) conversion



CONVERSION CABLE CT9900 Convert PL23 (10-pin) terminal to ME15W (12-pin) terminal

Both cord ends are isolated BNC, 1.6 m (5.25 ft)

vavailable CONVERSION CABLE CT9901 is required in high-precision current sensor equipped with a ME15W all (-05 ppe) with the CURRENT UNIT 8971. Sock is not required in order to use a sensor equipped with b) terminal with the 8971, the CONVERSION CABLE 9318 with the 8971) is required for that setup.

ME15W (12-pin) - PL23 (10-pin) conversion

CONVERSION CABLE CT9901

Convert ME15W (12-pin) tem nal to PL23 (10-pin) terminal

Other current sensor types

General-purpose current measurement \*PL14 terminal type

AC/DC AUTO ZERO CURRENT SENSOR CT7731

AC/DC AUTO ZERO CURRENT SENSOR CT7736

AC/DC AUTO ZERO CURRENT SENSOR CT7742 DC, 1 Hz to 5 kHz, 2000 A

AC/DC CURRENT SENSOR CT7631

AC/DC CURRENT SENSOR CT7636

AC/DC CURRENT SENSOR CT7642 DC, 1 Hz to 10 kHz, 2000 A

AC FLEXIBLE CURRENT SENSOR CT7044

AC FLEXIBLE CURRENT SENSOR CT7045

AC FLEXIBLE CURRENT SENSOR CT7046 ф254 mm (10.00 in), 6000 A

eparately available CONVERSION CABLE CT9920 is ed in order to connect a PL14 terminal general-purpose nt sensor to the CURRENT UNIT U8977.

CONVERSION CABLE CT9920 Convert PL14 terminal to ME15W (12-pin)

PL14 - ME15W (12-pin) conversion

The MEMORY HICORDER can be used with various types of current sensors and probes

DC, 1 Hz to 5 kHz, 100 A

DC, 1 Hz to 5 kHz, 600 A

DC, 1 Hz to 10 kHz, 100 A

DC. 1 Hz to 10 kHz, 600 A

ф100 mm (3.94 in), 6000 A

ф180 mm (7.09 in), 6000 A

U8977 only

#### 10 mA class to 500 A (High speed)



CLAMP ON PROBE 3273-50 Frequency characteristics: DC to 50 MHz wideband response, 10 mA-class up to 30 A rms

CLAMP ON PROBE 3276

Frequency characteristics: DC to 100 MHz wideband response, 10 mA-class up to 30 A rms



CLAMP ON PROBE 3274 Frequency characteristics: DC to 10 MHz wideband response, up to 150 A rms

CLAMP ON PROBE 3275

Frequency characteristics: DC to 2 MHz wideband response, up to 500 A rms

Custom cable For P9000. Inquire with your local Hioki distributor.

(1) Bus powered USB cable (2) USB(A)- Micro B cable

(3) 3-prong cable



Non-contact voltage measuring NON-CONTACT AC VOLTAGE PROBE SP3000-01 5 V rms rated, 10 Hz to 100 kHz band width



NON-CONTACT AC VOLTAGE PROBE SP3000 Sold individually

AC VOLTAGE PROBE SP9001 Sold individually

### Other options for input



CONNECTION CORD L9217 Cord has insulated BNC connectors at both ends, signal output use, 1.6 m (5.25 ft) length

CONVERSION ADAPTER 9199
Receiving side banana terminal, output BNC terminal

Temperature sensor THERMOCOUPLE



For reference only. Please purchase locally.

## **OUTPUT CORD L9095**

Leak Current \*For commercial power lines, 50/60 Hz



CLAMP ON LEAK HITESTER 3283 10 mA range / 10 µA resolution to 200 A range, with monitor / analog output 1 V f.s.

Connect to BNC terminal, 1.5 m (4.92 ft) length AC ADAPTER 9445-02 100 to 240 V AC, 9 V/ 1 A

Precautions for connecting current sensors and current probes

\*Depending on the combination of current sensors and current probes, physical and space limitations may prevent simultaneous connection. Hioki can assist with special order conversion cables please inquire with your local distributor.

\*A total of 9 current sensors and current probes can be connected simultaneously to the Memory HiCorder. (Total with the CURRENT UNIT U8977, CURRENT UNIT 8971, and PROBE POWER UNIT Z5021 connected)

\*Three U8977 current units and four 8971 current units can be simultaneously connected to the Memory

\*Only the U8977 can use the CT9920 to convert a PL14 connector sensor. The 8971 does not support this combination.

INPUT CORD (H)



CONNECTION CORD 9166

## The MR8740T supports your testing technologies with simultaneously sampled measurements across multiple channels.







## Set examples

## Multi-channel measurement for ECU development

In addition to the measurement of 68 analog channels + 24 logic channels, the MR8740T can also generate waveforms on 4 channels, generate pulses on 8 channels, and output DC voltage/DC current/ simulated resistance on 40 channels. This allows the simultaneous testing of multiple points, such as for high-performance boards, with a single unit.

MEMORY HICORDER	MR8740-50	1 unit
4ch ANALOG UNIT	U8975	17
CONNECTION CORD	L9790	68
ALLIGATOR CLIP	L9790-01	68
WAVEFORM GENERATOR UNIT	MR8790	1
CONNECTION CABLE	L9795-01	4
PULSE GENERATOR UNIT	MR8791	1
VIR GENERATOR UNIT	U8794	5
LOGIC UNIT	8973	3
LOGIC PROBE	9327	3

## Support for a wide range of multi-channel measurements

High speed, isolation, and high precision are achieved even with multi-channel measurement.

High-speed isolated recording across 108 channels at 5 MS/s

MEMORY HICORDER	MR8740-50	1 unit
4ch ANALOG UNIT	U8975	27
CONNECTION CORD	L9790	108
ALLIGATOR CLIP	L9790-01	108

High-precision voltage measurements across 108 channels at a sampling rate of 50 times/s

MEMORY HICORDER	MR8740-50	1 unit
DIGITAL VOLTMETER UNIT	U8991	27
CONNECTION CORD	L9790	108
ALLIGATOR CLIP	L9790-01	108

Multi-channel strain measurements across 54 channels with a strain gauge converter

MEMORY HICORDER	MR8740-50	1 unit
STRAIN UNIT	U8969	27
CONVERSION CABLE	L9769	54

Note: Company names and product names appearing in this brochure are trademarks or registered trademarks of various companies.

DISTRIBUTED BY



**HEADQUARTERS** 

81 Koizumi. Ueda, Nagano 386-1192 Japan https://www.hioki.com/

